




# CLI Reference Guide

Managed Switches

1910013605 REV6.0.0

January 2024

## COPYRIGHT & TRADEMARKS

Specifications are subject to change without notice.  tp-link is a registered trademark of TP-Link Corporation Limited. Other brands and product names are trademarks or registered trademarks of their respective holders.

No part of the specifications may be reproduced in any form or by any means or used to make any derivative such as translation, transformation, or adaptation without permission from TP-Link Corporation Limited. Copyright © 2024 TP-Link Corporation Limited. All rights reserved.

<https://www.tp-link.com>

# CONTENTS

<b>Preface</b>	<b>1</b>
<b>Chapter 1 Using the CLI</b>	<b>7</b>
1.1 Accessing the CLI	7
1.1.1 Logon by a console port	7
1.1.2 Logon by Telnet	10
1.1.3 Logon by SSH	11
1.2 CLI Command Modes	19
1.3 Privilege Restrictions	23
1.4 Conventions	23
1.4.1 PoE Disclaimer	23
1.4.2 Format Conventions	23
1.4.3 Special Characters	23
1.4.4 Parameter Format	24
<b>Chapter 2 Line Commands (Only for Certain Devices)</b>	<b>25</b>
2.1 line	25
2.2 media-type rj45	26
<b>Chapter 3 User Interface</b>	<b>27</b>
3.1 enable	27
3.2 service password-encryption	27
3.3 enable password	28
3.4 enable secret	29
3.5 configure	30
3.6 exit	31
3.7 end	31
3.8 clipaging	32
3.9 history	32
3.10 history clear	33
<b>Chapter 4 User Management Commands</b>	<b>34</b>
4.1 user name (password)	34
4.2 user name (secret)	35
4.3 service password-recovery	36
4.4 show user account-list	37
4.5 show user configuration	38

<b>Chapter 5</b>	<b>System Configuration Commands</b>	<b>39</b>
5.1	system-time manual	39
5.2	system-time ntp	39
5.3	system-time dst predefined	41
5.4	system-time dst date	42
5.5	system-time dst recurring	43
5.6	hostname	44
5.7	location	45
5.8	contact-info	45
5.9	led	46
5.10	ip address	46
5.11	ip address-alloc	47
5.12	controller cloud-based (Only for Certain Devices)	48
5.13	controller inform-url (Only for Certain Devices)	49
5.14	reset	50
5.15	service reset-disable	50
5.16	reboot	51
5.17	reboot-schedule	51
5.18	copy running-config startup-config	52
5.19	copy startup-config tftp	53
5.20	copy tftp startup-config	53
5.21	copy backup-config tftp	54
5.22	copy backup-config startup-config	55
5.23	copy running-config backup-config	55
5.24	copy tftp backup-config	56
5.25	boot application	56
5.26	boot config	57
5.27	remove backup-image	58
5.28	firmware upgrade	58
5.29	mcu-firmware unit upgrade (Only for Certain Devices)	59
5.30	mcu-firmware type (Only for Certain Devices)	60
5.31	boot autoinstall start	60
5.32	boot autoinstall persistent-mode	61
5.33	boot autoinstall auto-save	61
5.34	boot autoinstall auto-reboot	62
5.35	boot autoinstall retry-count	63
5.36	show boot autoinstall	63

5.37	show boot autoinstall downloaded-config.....	64
5.38	ping.....	64
5.39	tracert .....	65
5.40	show system-info.....	66
5.41	show image-info.....	67
5.42	show boot.....	67
5.43	show running-config .....	68
5.44	show startup-config .....	69
5.45	show system-time .....	69
5.46	show system-time dst.....	70
5.47	show system-time ntp.....	70
5.48	show cable-diagnostics interface.....	71
5.49	show cpu-utilization.....	71
5.50	show memory-utilization .....	72
5.51	show controller.....	72
5.52	show temperature.....	73
5.53	show voltage.....	73
5.54	clear config interace.....	74
5.55	power backup unit (Only for Certain Devices) .....	74
5.56	show power (Only for Certain Devices).....	75
<b>Chapter 6 File System Configuration Commands (Only for Certain Devices)</b>		<b>76</b>
6.1	copy.....	76
6.2	cd .....	76
6.3	dir .....	77
6.4	pwd .....	77
6.5	rename.....	78
6.6	delete .....	78
6.7	ftp.....	79
6.8	open .....	80
6.9	put.....	80
6.10	get.....	81
6.11	close.....	81
<b>Chapter 7 Management Port Configuration Commands (Only for Certain Devices)</b>		<b>83</b>
7.1	management-port protocol .....	83
7.2	management-port ip.....	83

7.3	management-port ipv6 enable .....	84
7.4	management-port ipv6 address .....	85
7.5	show management-port .....	85
<b>Chapter 8</b>	<b>EEE Configuration Commands .....</b>	<b>87</b>
8.1	eee .....	87
8.2	show interface eee .....	87
<b>Chapter 9</b>	<b>SDM Template Commands .....</b>	<b>89</b>
9.1	sdm prefer .....	89
9.2	show sdm prefer .....	90
<b>Chapter 10</b>	<b>Time Range Commands .....</b>	<b>92</b>
10.1	time-range .....	92
10.2	absolute .....	92
10.3	periodic .....	93
10.4	holiday (time-range mode) .....	94
10.5	holiday .....	95
10.6	show holiday .....	95
10.7	show time-range .....	96
<b>Chapter 11</b>	<b>Port Configuration Commands .....</b>	<b>97</b>
11.1	interface .....	97
11.2	interface range .....	98
11.3	description .....	99
11.4	shutdown .....	99
11.5	flow-control .....	100
11.6	duplex .....	101
11.7	jumbo-size .....	101
11.8	speed .....	102
11.9	clear counters .....	103
11.10	show fiber-ports .....	103
11.11	show interface status .....	104
11.12	show interface counters .....	104
11.13	show interface configuration .....	105
<b>Chapter 12</b>	<b>Port Isolation Commands .....</b>	<b>107</b>
12.1	port isolation .....	107
12.2	show port isolation interface .....	108

<b>Chapter 13 Loopback Detection Commands</b> .....	<b>109</b>
13.1 loopback-detection (global).....	109
13.2 loopback-detection interval.....	109
13.3 loopback-detection recovery-time .....	110
13.4 loopback-detection (interface).....	111
13.5 loopback-detection config process-mode.....	111
13.6 loopback-detection recover .....	112
13.7 show loopback-detection global .....	113
13.8 show loopback-detection interface .....	114
<b>Chapter 14 Stack Commands (Only for Certain Devices)</b> .....	<b>115</b>
14.1 switch stack-name.....	115
14.2 switch stack-group.....	116
14.3 group-info.....	116
14.4 interface port .....	117
14.5 switch priority .....	117
14.6 switch renumber .....	118
14.7 switch provision .....	119
14.8 show switch stack-ports .....	119
14.9 show switch.....	120
14.10 show switch unitid.....	120
14.11 show switch neighbors .....	121
<b>Chapter 15 DDM Commands (Only for Certain Devices)</b> .....	<b>122</b>
15.1 ddm state enable .....	122
15.2 ddm shutdown.....	123
15.3 ddm temperature_threshold.....	123
15.4 ddm voltage_threshold.....	124
15.5 ddm bias_current_threshold.....	125
15.6 ddm tx_power_threshold.....	126
15.7 ddm rx_power_threshold.....	127
15.8 show ddm configuration.....	128
15.9 show ddm status .....	129
15.10 show fiber-ports.....	129
<b>Chapter 16 Etherchannel Commands</b> .....	<b>131</b>
16.1 channel-group .....	131
16.2 port-channel load-balance.....	132

16.3	lacp system-priority .....	133
16.4	lacp port-priority .....	134
16.5	show etherchannel .....	134
16.6	show etherchannel load-balance.....	135
16.7	show lacp.....	136
16.8	show lacp sys-id.....	136
<b>Chapter 17 MAC Address Commands.....</b>		<b>138</b>
17.1	mac address-table static.....	138
17.2	no mac address-table dynamic.....	139
17.3	mac address-table aging-time .....	139
17.4	mac address-table filtering .....	140
17.5	mac address-table notification .....	141
17.6	mac address-table max-mac-count.....	142
17.7	mac address-table notification (interface) .....	143
17.8	mac address-table security .....	144
17.9	mac address-table vlan-security .....	145
17.10	show mac address-table .....	146
17.11	clear mac address-table.....	147
17.12	show mac address-table aging-time.....	147
17.13	show mac address-table max-mac-count .....	148
17.14	show mac address-table interface .....	149
17.15	show mac address-table count.....	149
17.16	show mac address-table address.....	150
17.17	show mac address-table vlan.....	151
17.18	show mac address-table notification.....	151
17.19	show mac address-table security.....	152
<b>Chapter 18 IEEE 802.1Q VLAN Commands .....</b>		<b>153</b>
18.1	vlan .....	153
18.2	name.....	154
18.3	vlan_trunk (globally).....	154
18.4	vlan_trunk (interface).....	155
18.5	switchport general allowed vlan.....	156
18.6	switchport pvid.....	156
18.7	switchport check ingress .....	157
18.8	switchport acceptable frame.....	158
18.9	show vlan summary .....	159



18.10	show vlan brief.....	159
18.11	show vlan.....	160
18.12	show interface switchport.....	160
<b>Chapter 19 MAC-based VLAN Commands.....</b>		<b>162</b>
19.1	mac-vlan mac-address .....	162
19.2	mac-vlan.....	163
19.3	show mac-vlan.....	163
19.4	show mac-vlan interface .....	164
<b>Chapter 20 Protocol-based VLAN Commands .....</b>		<b>165</b>
20.1	protocol-vlan template .....	165
20.2	protocol-vlan vlan .....	166
20.3	protocol-vlan group.....	167
20.4	show protocol-vlan template.....	168
20.5	show protocol-vlan vlan.....	169
<b>Chapter 21 Private VLAN Commands (Only for Certain Devices) .....</b>		<b>170</b>
21.1	private-vlan primary.....	170
21.2	private-vlan community.....	170
21.3	private-vlan isolated.....	171
21.4	private-vlan association.....	172
21.5	switchport private-vlan .....	172
21.6	switchport private-vlan host-association.....	173
21.7	switchport private-vlan mapping .....	174
21.8	show vlan private-vlan .....	175
21.9	show vlan private-vlan interface .....	175
<b>Chapter 22 VLAN-VPN Commands (Only for Certain Devices) .....</b>		<b>177</b>
22.1	dot1q-tunnel.....	177
22.2	switchport dot1q-tunnel tpid.....	178
22.3	dot1q-tunnel mapping .....	178
22.4	switchport dot1q-tunnel mode .....	179
22.5	switchport dot1q-tunnel missdrop (only for certain devices).....	180
22.6	switchport dot1q-tunnel use_inner_priority .....	181
22.7	switchport dot1q-tunnel mapping .....	181
22.8	switchport dot1q-tunnel replace .....	182
22.9	switchport dot1q-tunnel replace-out.....	183
22.10	show dot1q-tunnel.....	184

22.11	show dot1q-tunnel mapping.....	185
22.12	show dot1q-tunnel interface .....	185
<b>Chapter 23 ERPS Commands.....</b>		<b>187</b>
23.1	erps ring.....	187
23.2	control-vlan.....	187
23.3	description .....	188
23.4	guard-timer .....	189
23.5	wtr-timer .....	189
23.6	holdoff-timer .....	190
23.7	protected-instance.....	191
23.8	raps-mel.....	191
23.9	revertive.....	192
23.10	sub-ring.....	193
23.11	tc-notify erps .....	193
23.12	tc-protection interval .....	194
23.13	tc-protection threshold .....	194
23.14	version .....	195
23.15	virtual-channel.....	196
23.16	erps ring rpl .....	196
23.17	erps ring protect-switch.....	197
23.18	show erps ring .....	198
<b>Chapter 24 GVRP Commands.....</b>		<b>199</b>
24.1	gvrp.....	199
24.2	gvrp (interface) .....	199
24.3	gvrp registration.....	200
24.4	gvrp timer .....	201
24.5	show gvrp interface.....	202
24.6	show gvrp global .....	203
<b>Chapter 25 IGMP Snooping Commands.....</b>		<b>204</b>
25.1	ip igmp snooping (global).....	204
25.2	ip igmp snooping version .....	204
25.3	ip igmp snooping drop-unknown .....	205
25.4	ip igmp snooping header-validation .....	206
25.5	ip igmp snooping vlan-config .....	206
25.6	ip igmp snooping vlan-config (immediate-leave) .....	208
25.7	ip igmp snooping vlan-config (report-suppression) .....	209

25.8	ip igmp snooping vlan-config (router-ports-forbidden).....	210
25.9	ip igmp snooping vlan-config (rport interface) .....	211
25.10	ip igmp snooping vlan-config (static) .....	211
25.11	ip igmp snooping vlan-config (querier) .....	212
25.12	ip igmp snooping (interface) .....	214
25.13	ip igmp snooping max-groups.....	214
25.14	ip igmp snooping immediate-leave.....	216
25.15	ip igmp snooping authentication.....	216
25.16	ip igmp snooping accounting .....	217
25.17	ip igmp profile .....	218
25.18	deny.....	218
25.19	permit.....	219
25.20	range .....	219
25.21	ip igmp filter .....	220
25.22	clear ip igmp snooping statistics .....	221
25.23	show ip igmp snooping .....	221
25.24	show ip igmp snooping interface.....	222
25.25	show ip igmp snooping vlan.....	223
25.26	show ip igmp snooping groups .....	223
25.27	show ip igmp profile.....	224

**Chapter 26 Layer 3 IGMP Commands (Only for Certain Devices)..... 226**

26.1	ip igmp (global).....	226
26.2	ip igmp (on specific ports) .....	226
26.3	ip igmp header-validation.....	227
26.4	ip igmp version .....	227
26.5	ip igmp last-member-query-count .....	228
26.6	ip igmp last-member-query-interval.....	229
26.7	ip igmp query-interval .....	230
26.8	ip igmp query-max-response-time.....	230
26.9	ip igmp robustness .....	231
26.10	ip igmp startup-query-interval.....	232
26.11	ip igmp last-member-query-count .....	232
26.12	show ip igmp .....	233
26.13	show ip igmp groups .....	234
26.14	show ip igmp groups interface .....	234
26.15	show ip igmp groups interface vlan.....	235

26.16	show ip igmp groups interface vlan.....	236
26.17	show ip igmp interface vlan.....	236
<b>Chapter 27 PIM Commands (Only for Certain Devices).....</b>		<b>238</b>
27.1	ip multicast-routing .....	238
27.2	ip pim (globally).....	238
27.3	ip pim (on specific ports).....	239
27.4	ip pim hello-interval .....	239
27.5	show ip multicast .....	240
27.6	show ip mroute.....	241
27.7	show ip pim interface .....	241
27.8	show ip pim neighbor .....	242
27.9	show ip pim statistic.....	243
<b>Chapter 28 Static Multicast Routing Commands (Only for Certain Devices) ..</b>		<b>244</b>
28.1	ip mroute .....	244
28.2	show ip mroute static.....	245
<b>Chapter 29 MLD Snooping Commands.....</b>		<b>246</b>
29.1	ipv6 mld snooping (global).....	246
29.2	ipv6 mld snooping drop-unknown .....	246
29.3	ipv6 mld snooping vlan-config .....	247
29.4	ipv6 mld snooping vlan-config (immediate-leave) .....	248
29.5	ipv6 mld snooping vlan-config (report-suppression) .....	249
29.6	ipv6 mld snooping vlan-config (router-ports-forbidden).....	250
29.7	ipv6 mld snooping vlan-config (rport interface) .....	251
29.8	ipv6 mld snooping vlan-config (static) .....	251
29.9	ipv6 mld snooping vlan-config (querier) .....	252
29.10	ipv6 mld snooping (interface) .....	254
29.11	ipv6 mld snooping max-groups.....	254
29.12	ipv6 mld snooping immediate-leave .....	256
29.13	ipv6 mld profile .....	256
29.14	deny.....	257
29.15	permit.....	257
29.16	range .....	258
29.17	ipv6 mld filter .....	259
29.18	clear ipv6 mld snooping statistics .....	259
29.19	show ipv6 mld snooping.....	260
29.20	show ipv6 mld snooping interface.....	260

29.21	show ipv6 mld snooping vlan.....	261
29.22	show ipv6 mld snooping groups .....	262
29.23	show ipv6 mld profile .....	262
<b>Chapter 30 MVR Commands.....</b>		<b>264</b>
30.1	mvr (global).....	264
30.2	mvr group .....	264
30.3	mvr mode.....	265
30.4	mvr querytime.....	266
30.5	mvr vlan.....	267
30.6	mvr (interface).....	267
30.7	mvr type.....	268
30.8	mvr immediate .....	269
30.9	mvr vlan (group).....	269
30.10	mvr vlan (rule).....	270
30.11	mvr mode dynamic auto-enable .....	271
30.12	show mvr .....	271
30.13	show mvr interface .....	272
30.14	show mvr members .....	272
<b>Chapter 31 MSTP Commands.....</b>		<b>274</b>
31.1	debug spanning-tree.....	274
31.2	spanning-tree (global) .....	275
31.3	spanning-tree (interface) .....	275
31.4	spanning-tree common-config .....	276
31.5	spanning-tree mode.....	277
31.6	spanning-tree mst configuration .....	278
31.7	instance .....	279
31.8	name.....	279
31.9	revision .....	280
31.10	spanning-tree mst instance .....	281
31.11	spanning-tree mst .....	281
31.12	spanning-tree priority .....	282
31.13	spanning-tree timer .....	283
31.14	spanning-tree hold-count .....	284
31.15	spanning-tree max-hops .....	284
31.16	spanning-tree bpdudfilter.....	285
31.17	spanning-tree bpdudflood.....	286

31.18	spanning-tree bpduguard .....	286
31.19	spanning-tree guard loop.....	287
31.20	spanning-tree guard root .....	288
31.21	spanning-tree guard tc .....	288
31.22	spanning-tree mcheck.....	289
31.23	show spanning-tree active.....	289
31.24	show spanning-tree bridge .....	290
31.25	show spanning-tree interface.....	290
31.26	show spanning-tree interface-security .....	291
31.27	show spanning-tree mst.....	292
<b>Chapter 32 Debug Commands .....</b>		<b>295</b>
32.1	debug tppacket packet-print (only for certain devices).....	295
32.2	debug spanning-tree.....	295
<b>Chapter 33 LLDP Commands.....</b>		<b>297</b>
33.1	lldp .....	297
33.2	lldp forward_message.....	297
33.3	lldp hold-multiplier .....	298
33.4	lldp timer.....	299
33.5	lldp receive.....	300
33.6	lldp transmit .....	300
33.7	lldp snmp-trap .....	301
33.8	lldp tlv-select .....	302
33.9	lldp management-address .....	302
33.10	lldp med-fast-count.....	303
33.11	lldp med-status .....	304
33.12	lldp med-tlv-select.....	304
33.13	lldp med-location .....	305
33.14	show lldp.....	306
33.15	show lldp interface.....	306
33.16	show lldp local-information interface.....	307
33.17	show lldp neighbor-information interface .....	308
33.18	show lldp traffic interface.....	308
<b>Chapter 34 L2PT Commands (Only for Certain Devices) .....</b>		<b>310</b>
<b>34.1</b>	<b>l2protocol-tunnel.....</b>	<b>310</b>
<b>34.2</b>	<b>l2protocol-tunnel type .....</b>	<b>311</b>
<b>34.3</b>	<b>show l2protocol-tunnel global.....</b>	<b>312</b>

34.4	<b>show l2protocol-tunnel interface</b> .....	313
34.5	l2protocol-tunnel dst-mac .....	313
34.6	Switch(config)#l2protocol-tunnel dst-mac 192.168.0.100show l2protocol-tunnel dst-mac 314	
<b>Chapter 35 PPPoE ID-Insertion Commands (Only for Certain Devices).....</b>		<b>315</b>
35.1	<b>pppoe id-insertion (global)</b> .....	315
35.2	<b>pppoe circuit-id (interface)</b> .....	316
35.3	<b>pppoe circuit-id type</b> .....	316
35.4	<b>pppoe remote-id</b> .....	317
35.5	<b>show pppoe id-insertion global</b> .....	318
35.6	<b>show pppoe id-insertion interface</b> .....	319
<b>Chapter 36 Static Routes Commands .....</b>		<b>320</b>
36.1	ip routing.....	320
36.2	interface vlan .....	320
36.3	interface loopback.....	321
36.4	switchport .....	321
36.5	interface range port-channel.....	322
36.6	description .....	323
36.7	shutdown.....	323
36.8	interface port-channel .....	324
36.9	ip route .....	325
36.10	ipv6 routing .....	326
36.11	ipv6 route .....	326
36.12	show interface vlan.....	327
36.13	show ip interface .....	327
36.14	show ip interface brief.....	328
36.15	show ip route .....	329
36.16	show ip route specify .....	329
36.17	show ip route summary.....	330
36.18	show ipv6 interface .....	331
36.19	show ipv6 route .....	331
36.20	show ipv6 route summary .....	332
<b>Chapter 37 RIP Configuration Commands (Only for Certain Devices) .....</b>		<b>333</b>
37.1	router rip.....	333
37.2	network.....	333
37.3	version .....	334

37.4	timer basic .....	335
37.5	distance .....	336
37.6	auto-summary .....	336
37.7	default-metric .....	337
37.8	redistribute .....	337
37.9	allow-ecmp .....	338
37.10	default-information originate .....	339
37.11	neighbor .....	339
37.12	passive-interface .....	340
37.13	ip rip authentication mode .....	340
37.14	ip rip authentication string .....	341
37.15	ip rip authentication key-chain .....	342
37.16	ip rip receive version .....	343
37.17	ip rip send version .....	343
37.18	ip rip split-horizon .....	344
37.19	ip rip v2-broadcast .....	345
37.20	show ip rip .....	345
37.21	show ip rip status .....	346
37.22	clear ip rip .....	346
<b>Chapter 38 RIPng Configuration Commands (Only for Certain Devices) .....</b>		<b>347</b>
38.1	router ripng .....	347
38.2	ipv6 rip enable .....	347
38.3	timer basic .....	348
38.4	default-metric .....	349
38.5	redistribute .....	349
38.6	allow-ecmp .....	350
38.7	default-information originate .....	351
38.8	passive-interface .....	351
38.9	ip rip split-horizon .....	352
38.10	show ipv6 rip .....	353
38.11	show ipv6 rip status .....	353
38.12	clear ipv6 rip .....	353
<b>Chapter 39 OSPF Configuration Commands (Only for Certain Devices) .....</b>		<b>355</b>
39.1	router ospf .....	355
39.2	router-id .....	356
39.3	network .....	356



39.4	maximum-paths .....	357
39.5	redistribute.....	358
39.6	default-metric.....	359
39.7	default-metric.....	359
39.8	auto-cost.....	360
39.9	distance.....	361
39.10	timers throttle spf.....	362
39.11	compatible rfc 1583.....	362
39.12	area stub.....	363
39.13	area nssa.....	364
39.14	area default-cost.....	365
39.15	area range.....	365
39.16	area authentication.....	367
39.17	area virtual-link.....	367
39.18	area virtual-link authentication.....	368
39.19	area virtual-link authentication-key.....	369
39.20	area virtual-link message-digest-key.....	370
39.21	ip ospf cost.....	371
39.22	ip ospf retransmit-interval.....	372
39.23	ip ospf transmit-delay.....	373
39.24	ip ospf priority.....	373
39.25	ip ospf hello-interval.....	374
39.26	ip ospf dead-interval.....	375
39.27	ip ospf authentication.....	375
39.28	ip ospf authentication-key.....	376
39.29	ip ospf message-digest-key.....	377
39.30	ip ospf network.....	377
39.31	ip ospf mtu-ignore.....	378
39.32	ip ospf passive.....	379
39.33	clear ip ospf.....	379
39.34	show ip ospf.....	380
39.35	show ip ospf database.....	380
39.36	show ip ospf interface.....	381
39.37	show ip ospf neighbor.....	381
39.38	show ip ospf border-routers.....	382
39.39	show ip ospf route.....	383

**Chapter 40 OSPFv3 Configuration Commands (Only for Certain Devices) ..... 384**

40.1	ipv6 router ospf .....	384
40.2	router-id.....	384
40.3	maximum-paths .....	385
40.4	redistribute.....	386
40.5	default-information originate.....	386
40.6	auto-cost .....	387
40.7	distance .....	388
40.8	distance ospf .....	389
40.9	timers throttle spf .....	389
40.10	timers lsa arrival .....	390
40.11	area stub.....	391
40.12	area nssa .....	392
40.13	area range .....	392
40.14	ipv6 ospf area .....	393
40.15	ipv6 ospf cost.....	394
40.16	ipv6 ospf retransmit-interval.....	395
40.17	ipv6 ospf transmit-delay.....	395
40.18	ipv6 ospf priority .....	396
40.19	ipv6 ospf hello-interval.....	397
40.20	ipv6 ospf dead-interval .....	397
40.21	ipv6 ospf network .....	398
40.22	ipv6 ospf mtu-ignore.....	399
40.23	ipv6 ospf passive .....	399
40.24	clear ipv6 ospf .....	400
40.25	show ipv6 ospf.....	400
40.26	show ipv6 ospf database.....	401
40.27	show ipv6 ospf interface .....	401
40.28	show ipv6 ospf neighbor .....	402
40.29	show ipv6 ospf border-routers .....	402
40.30	show ipv6 ospf rib.....	403

**Chapter 41 IPv6 Address Configuration Commands ..... 404**

41.1	ipv6 enable .....	404
41.2	ipv6 address autoconfig.....	404
41.3	ipv6 address link-local .....	405
41.4	ipv6 address dhcp .....	406
41.5	ipv6 address ra.....	406

41.6	ipv6 address eui-64 .....	407
41.7	ipv6 address .....	408
41.8	show ipv6 interface .....	409
<b>Chapter 42 ARP Commands.....</b>		<b>410</b>
42.1	arp .....	410
42.2	clear arp-cache .....	411
42.3	arp dynamicrenew .....	411
42.4	arp timeout .....	412
42.5	gratuitous-arp intf-status-up enable .....	412
42.6	gratuitous-arp dup-ip-detected enable .....	413
42.7	gratuitous-arp learning enable .....	414
42.8	gratuitous-arp send-interval .....	414
42.9	ip proxy-arp .....	415
42.10	ip local-proxy-arp .....	416
42.11	show arp .....	416
42.12	show ip arp (interface) .....	417
42.13	show ip arp summary .....	418
42.14	show gratuitous-arp .....	418
42.15	show ip proxy-arp .....	419
<b>Chapter 43 VRRP Commands (Only for Certain Devices) .....</b>		<b>420</b>
43.1	ip vrrp vrid.....	420
43.2	ipv6 vrrp vrid .....	421
43.3	ip vrrp vrid authentication-mode.....	421
43.4	ip vrrp vrid description .....	422
43.5	ip vrrp vrid preempt-mode .....	423
43.6	ip vrrp vrid priority.....	424
43.7	ip vrrp vrid timer-advertise .....	425
43.8	ip vrrp vrid track .....	425
43.9	ip vrrp vrid version .....	426
43.10	ip vrrp vrid virtual-ip.....	427
43.11	ip vrrp vrid virtual-ip secondary.....	428
43.12	ipv6 vrrp vrid address link-local .....	429
43.13	ipv6 vrrp vrid address.....	430
43.14	show ip vrrp.....	430
43.15	show ip vrrp statistics .....	431
43.16	clear ip vrrp statistics .....	432

**Chapter 44 DHCP Server Commands..... 433**

44.1	service dhcp server .....	433
44.2	ip dhcp server extend-option capwap-ac-ip .....	433
44.3	ip dhcp server extend-option vendor-class-id.....	434
44.4	ip dhcp server excluded-address .....	435
44.5	ip dhcp server pool.....	436
44.6	ip dhcp server ping timeout .....	436
44.7	ip dhcp server ping packets.....	437
44.8	network.....	438
44.9	lease .....	438
44.10	address hardware-address.....	439
44.11	address client-identifier.....	440
44.12	default-gateway .....	440
44.13	dns-server .....	441
44.14	netbios-name-server .....	442
44.15	netbios-node-type.....	442
44.16	next-server.....	443
44.17	domain-name.....	444
44.18	bootfile .....	444
44.19	option .....	445
44.20	show ip dhcp server status .....	446
44.21	show ip dhcp server statistics.....	446
44.22	show ip dhcp server extend-option.....	447
44.23	show ip dhcp server pool .....	447
44.24	show ip dhcp server excluded-address.....	448
44.25	show ip dhcp server manual-binding .....	448
44.26	show ip dhcp server binding .....	449
44.27	clear ip dhcp server statistics.....	449
44.28	clear ip dhcp server binding.....	450

**Chapter 45 DHCP Relay Commands..... 451**

45.1	service dhcp relay.....	451
45.2	ip dhcp relay hops.....	451
45.3	ip dhcp relay time.....	452
45.4	ip helper-address.....	453
45.5	ip dhcp relay information option .....	453
45.6	ip dhcp relay information strategy .....	454
45.7	ip dhcp relay information format.....	455

45.8	ip dhcp relay information circuit-id .....	456
45.9	ip dhcp relay information remote-id .....	457
45.10	ip dhcp relay default-interface .....	457
45.11	ip dhcp relay vlan .....	458
45.12	show ip dhcp relay .....	459
<b>Chapter 46 DHCPV6 Relay Commands .....</b>		<b>460</b>
46.1	ipv6 dhcp relay .....	460
46.2	ipv6 dhcp relay vlan 1 helper-address .....	460
46.3	ipv6 dhcp relay information option 18 .....	461
<b>46.1</b>	<b>Switch(config-if)# ipv6 dhcp relay information option18 .....</b>	<b>462</b>
<b>46.2</b>	<b>.....</b>	<b>462</b>
<b>46.3</b>	<b>.....</b>	<b>462</b>
46.4	ipv6 dhcp relay information option37 .....	462
46.5	ipv6 dhcp relay information remote-id.....	462
46.6	show ipv6 dhcp relay.....	463
46.7	show ipv6 dhcp relay counters.....	464
<b>Chapter 47 DHCP L2 Relay Commands .....</b>		<b>465</b>
47.1	ip dhcp l2relay .....	465
47.2	ip dhcp l2relay vlan .....	465
47.3	ip dhcp l2relay information option .....	466
47.4	ip dhcp l2relay information strategy.....	467
47.5	ip dhcp l2relay information format.....	468
47.6	ip dhcp l2relay information circuit-id.....	469
47.7	ip dhcp l2relay information remote-id.....	469
47.8	show ip dhcp l2relay.....	470
47.9	show ip dhcp l2relay interface.....	471
<b>Chapter 48 DHCPV6 L2 Relay Commands .....</b>		<b>472</b>
48.1	ipv6 dhcp l2relay .....	472
48.2	ipv6 dhcp l2relay vlan.....	472
48.3	ipv6 dhcp l2relay information option18.....	473
<b>48.4</b>	<b>.....</b>	<b>474</b>
<b>48.5</b>	<b>.....</b>	<b>474</b>
<b>48.6</b>	<b>.....</b>	<b>474</b>
48.4	ipv6 dhcp l2relay information option37 .....	474
48.5	ipv6 dhcp l2relay information remote-id .....	474
48.6	show ipv6 dhcp l2relay interface .....	475

<b>Chapter 49 QoS Commands</b> .....	<b>476</b>
49.1    qos trust mode .....	476
49.2    qos port-priority .....	477
49.3    qos cos-map .....	477
49.4    qos dot1p-remap .....	478
49.5    qos dscp-map.....	479
49.6    qos dscp-remap.....	480
49.7    qos queue bandwidth.....	481
49.8    qos queue mode .....	482
49.9    show qos cos-map .....	483
49.10   show qos dot1p-remap interface .....	484
49.11   show qos dot1p-remap .....	484
49.12   show qos dscp-map interface .....	485
49.13   show qos dscp-map .....	486
49.14   show qos dscp-remap interface .....	486
49.15   show qos dscp-remap .....	487
49.16   show qos port-priority interface .....	487
49.17   show qos trust interface.....	488
49.18   show qos queue interface .....	489
<b>Chapter 50 Bandwidth Control Commands</b> .....	<b>490</b>
50.1    storm-control rate-mode .....	490
50.2    storm-control.....	491
50.3    storm-control exceed .....	492
50.4    storm-control recover .....	493
50.5    bandwidth.....	493
50.6    show storm-control.....	494
50.7    show bandwidth .....	495
<b>Chapter 51 Voice VLAN Commands</b> .....	<b>496</b>
51.1    voice vlan.....	496
51.2    voice vlan (interface) .....	496
51.3    voice vlan priority .....	497
51.4    voice vlan oui .....	498
51.5    show voice vlan .....	498
51.6    show voice vlan oui-table .....	499
51.7    show voice vlan interface .....	499

<b>Chapter 52</b>	<b>Auto VoIP Commands</b>	<b>501</b>
52.1	auto-voip	501
52.2	auto-voip (interface)	501
52.3	auto-voip dot1p	502
52.4	auto-voip untagged	503
52.5	auto-voip none	503
52.6	no auto-voip (interface)	504
52.7	auto-voip dscp	504
52.8	auto-voip data priority	505
52.9	show auto-voip	505
<b>Chapter 53</b>	<b>Access Control Commands</b>	<b>507</b>
53.1	user access-control ip-based enable	507
53.2	user access-control ip-based	507
53.3	user access-control mac-based enable	508
53.4	user access-control mac-based	509
53.5	user access-control port-based enable	510
53.6	user access-control port-based	510
53.7	user access-control ipv6-based enable	511
53.8	user access-control ipv6-based	512
<b>Chapter 54</b>	<b>HTTP and HTTPS Commands</b>	<b>513</b>
54.1	ip http server	513
54.2	ip http port	514
54.3	ip http max-users	514
54.4	ip http session timeout	515
54.5	ip http secure-server	516
54.6	ip http secure-port	516
54.7	ip http secure-protocol	517
54.8	ip http secure-ciphersuite	518
54.9	ip http secure-max-users	519
54.10	ip http secure-session timeout	520
54.11	ip http secure-server download certificate	520
54.12	ip http secure-server download key	521
54.13	show ip http configuration	522
54.14	show ip http secure-server	523

<b>Chapter 55 SSH Commands</b> .....	<b>524</b>
55.1 ip ssh server.....	524
55.2 ip ssh port.....	524
55.3 ip ssh algorithm.....	525
55.4 ip ssh algorithm compatibility.....	526
55.5 ip ssh timeout.....	526
55.6 ip ssh max-client.....	527
55.7 ip ssh download.....	528
55.8 remove public-key.....	528
55.9 show ip ssh.....	529
<b>Chapter 56 Telnet Commands</b> .....	<b>530</b>
56.1 telnet.....	530
56.2 telnet enable.....	530
56.3 telnet port.....	531
56.4 show telnet-status.....	531
<b>Chapter 57 Serial Port Commands</b> .....	<b>533</b>
57.1 serial_port baud-rate.....	533
<b>Chapter 58 AAA Commands</b> .....	<b>534</b>
58.1 tacacs-server host.....	534
58.2 show tacacs-server.....	535
58.3 radius-server host.....	536
58.4 show radius-server.....	537
58.5 aaa group.....	538
58.6 server.....	538
58.7 show aaa group.....	539
58.8 aaa authentication login.....	540
58.9 aaa authentication enable.....	541
58.10 aaa authentication dot1x default.....	542
58.11 aaa accounting dot1x default.....	542
58.12 show aaa authentication.....	543
58.13 show aaa accounting.....	544
58.14 line telnet.....	544
58.15 login authentication (telnet).....	545
58.16 line ssh.....	545
58.17 login authentication (ssh).....	546



58.18	line console .....	547
58.19	login authentication (console) .....	547
58.20	enable authentication (telnet) .....	548
58.21	enable authentication (ssh) .....	549
58.22	enable authentication (console) .....	550
58.23	ip http login authentication .....	550
58.24	ip http enable authentication .....	551
58.25	show aaa global .....	552
58.26	enable admin password .....	552
58.27	enable admin secret .....	554
58.28	enable-admin .....	555
<b>Chapter 59 IEEE 802.1x Commands .....</b>		<b>556</b>
59.1	dot1x system-auth-control .....	556
59.2	dot1x handshake .....	557
59.3	dot1x auth-protocol .....	557
59.4	dot1x vlan-assignment .....	558
59.5	dot1x accounting .....	559
59.6	dot1x mab .....	560
59.7	dot1x guest-vlan .....	560
59.8	dot1x timeout quiet-period .....	561
59.9	dot1x timeout supp-timeout .....	562
59.10	dot1x max- req .....	563
59.11	dot1x .....	563
59.12	dot1x port-control .....	564
59.13	dot1x port-method .....	565
59.14	dot1x auth-init .....	566
59.15	dot1x auth-reauth .....	566
59.16	show dot1x global .....	567
59.17	show dot1x interface .....	568
59.18	show dot1x auth-state interface .....	568
<b>Chapter 60 Port Security Commands .....</b>		<b>570</b>
60.1	mac address-table max-mac count .....	570
60.2	show mac address-table max-mac-count .....	571
<b>Chapter 61 Port Mirroring Commands .....</b>		<b>572</b>
61.1	monitor session destination interface .....	572
61.2	monitor session source .....	573

61.3	monitor session 1 destination remote vlan .....	574
61.4	monitor session 1 source remote vlan.....	575
61.5	show monitor session .....	576
<b>Chapter 62 ACL Commands.....</b>		<b>577</b>
62.1	access-list create .....	577
62.2	access-list packet-content profile .....	577
62.3	access-list resequence .....	578
62.4	access-list mac .....	579
62.5	access-list ip.....	580
62.6	access-list combined.....	582
62.7	access-list ipv6 .....	584
62.8	access-list packet-content config.....	586
62.9	access-list action.....	587
62.10	redirect .....	588
62.11	s-condition .....	589
62.12	s-mirror .....	590
62.13	qos-remark.....	590
62.14	access bind .....	591
62.15	show access-list .....	592
62.16	show access-list bind.....	592
62.17	show access-list status .....	593
62.18	show access-list counter .....	593
62.19	clear access-list.....	594
<b>Chapter 63 IPv4 IMPB Commands.....</b>		<b>595</b>
63.1	ip source binding.....	595
63.2	ip dhcp snooping .....	596
63.3	ip dhcp snooping vlan .....	597
63.4	ip dhcp snooping max-entries.....	597
63.5	ip dhcp snooping trust .....	598
63.6	show ip source binding .....	599
63.7	show ip dhcp snooping .....	599
63.8	show ip dhcp snooping interface.....	600
<b>Chapter 64 IPv6 IMPB Commands.....</b>		<b>601</b>
64.1	ipv6 source binding .....	601
64.2	ipv6 dhcp snooping .....	602
64.3	ipv6 dhcp snooping vlan.....	603

64.4	ipv6 dhcp snooping max-entries .....	603
64.5	ipv6 nd snooping.....	604
64.6	ipv6 nd snooping vlan .....	605
64.7	ipv6 nd snooping max-entries .....	605
64.8	show ipv6 source binding.....	606
64.9	show ipv6 dhcp snooping.....	607
64.10	show ipv6 dhcp snooping interface .....	607
64.11	show ipv6 nd snooping .....	608
64.12	show ipv6 nd snooping interface .....	608
<b>Chapter 65 IP Verify Source Commands .....</b>		<b>610</b>
65.1	ip verify source .....	610
65.2	ip verify source logging.....	611
65.3	show ip verify source .....	611
65.4	show ip verify source interface .....	612
<b>Chapter 66 IPv6 Verify Source Commands .....</b>		<b>613</b>
66.1	ipv6 verify source.....	613
66.2	show ipv6 verify source .....	614
66.3	show ipv6 verify source interface.....	614
<b>Chapter 67 DHCPv4 Filter Commands .....</b>		<b>616</b>
67.1	ip dhcp filter .....	616
67.2	ip dhcp filter (interface) .....	616
67.3	ip dhcp filter mac-verify .....	617
67.4	ip dhcp filter limit rate.....	618
67.5	ip dhcp filter decline rate .....	619
67.6	ip dhcp filter server permit-entry .....	620
67.7	show ip dhcp filter .....	621
67.8	show ip dhcp filter interface.....	621
67.9	show ip dhcp filter server permit-entry.....	622
<b>Chapter 68 DHCPv6 Filter Commands .....</b>		<b>623</b>
68.1	ipv6 dhcp filter .....	623
68.2	ipv6 dhcp filter (interface).....	623
68.3	ipv6 dhcp filter limit rate .....	624
68.4	ipv6 dhcp filter decline rate.....	625
68.5	ipv6 dhcp filter server permit-entry.....	626
68.6	show ipv6 dhcp filter .....	627

68.7	show ipv6 dhcp filter interface .....	627
68.8	show ip dhcp filter server permit-entry.....	628
<b>Chapter 69 DoS Defend Commands .....</b>		<b>629</b>
69.1	ip dos-prevent .....	629
69.2	ip dos-prevent type .....	629
69.3	show ip dos-prevent.....	631
<b>Chapter 70 sFlow Commands (Only for Certain Devices).....</b>		<b>633</b>
70.1	sflow address.....	633
70.2	sflow enable .....	634
70.3	sflow collector collector-ID .....	634
70.4	sflow sampler.....	635
70.5	show sflow global.....	636
70.6	show sflow collector.....	637
70.7	show sflow sampler .....	637
<b>Chapter 71 Ethernet OAM Commands (Only for Certain Devices) .....</b>		<b>638</b>
71.1	ethernet-oam.....	638
71.2	ethernet-oam mode .....	639
71.3	ethernet-oam link-monitor symbol-period.....	639
71.4	ethernet-oam link-monitor frame .....	640
71.5	ethernet-oam link-monitor frame-period .....	641
71.6	ethernet-oam link-monitor frame-seconds .....	643
71.7	ethernet-oam remote-failure .....	644
71.8	ethernet-oam remote-loopback received-remote- loopback.....	645
71.9	ethernet-oam remote-loopback .....	646
71.10	clear ethernet-oam statistics .....	646
71.11	clear ethernet-oam event-log.....	647
71.12	show ethernet-oam configuration .....	648
71.13	show ethernet-oam event-log.....	649
71.14	show ethernet-oam statistics.....	649
71.15	show ethernet-oam status .....	650
<b>Chapter 72 DLDAP Commands (Only for Certain Devices) .....</b>		<b>651</b>
72.1	dldap (global).....	651
72.2	dldap interval.....	651
72.3	dldap shut-mode .....	652
72.4	dldap reset (global) .....	653

72.5	dldp(interface) .....	653
72.6	dldp reset (interface) .....	654
72.7	show dldp .....	654
72.8	show dldp interface .....	655
<b>Chapter 73 SNMP Commands .....</b>		<b>656</b>
73.1	snmp-server.....	656
73.2	snmp-server view .....	656
73.3	snmp-server group.....	657
73.4	snmp-server user.....	659
73.5	snmp-server community .....	661
73.6	snmp-server host.....	661
73.7	snmp-server engineID .....	663
73.8	snmp-server traps snmp .....	664
73.9	snmp-server traps .....	665
73.10	snmp-server traps ddm .....	667
73.11	snmp-server traps vlan.....	668
73.12	snmp-server traps security.....	669
73.13	snmp-server traps security dhcp6-filter .....	669
73.14	snmp-server traps acl .....	670
73.15	snmp-server traps ip.....	670
73.16	snmp-server traps power (Only for Certain Devices).....	671
73.17	snmp-server traps link-status .....	672
73.18	rmon history .....	673
73.19	rmon event .....	674
73.20	rmon alarm .....	675
73.21	rmon statistics.....	677
73.22	show snmp-server .....	677
73.23	show snmp-server view.....	678
73.24	show snmp-server group .....	678
73.25	show snmp-server user .....	679
73.26	show snmp-server community.....	679
73.27	show snmp-server host.....	680
73.28	show snmp-server engineID.....	680
73.29	show rmon history .....	680
73.30	show rmon event.....	681
73.31	show rmon alarm.....	682
73.32	show rmon statistics .....	682

<b>Chapter 74 PoE Commands (Only for Certain Devices)</b> .....	<b>684</b>
74.1 power inline consumption (global) .....	684
74.2 power profile .....	684
74.3 power inline consumption (interface) .....	686
74.4 power inline consumption (unit) .....	686
74.5 power inline priority .....	687
74.6 power inline supply .....	688
74.7 power inline profile .....	688
74.8 power inline time-range .....	689
74.9 show power inline .....	690
74.10 show power inline configuration interface .....	690
74.11 show power inline information interface .....	691
74.12 show power profile .....	691
74.13 power recovery ststus enable .....	692
74.14 power recovery status .....	692
74.15 show power recovery .....	693
74.16 show power recovery interface .....	694
<b>Chapter 75 ARP Inspection Commands</b> .....	<b>695</b>
75.1 ip arp inspection .....	695
75.2 ip arp inspection validate .....	695
75.3 ip arp inspection vlan .....	696
75.4 ip arp inspection vlan logging .....	697
75.5 ip arp inspection trust .....	698
75.6 ip arp inspection limit-rate .....	698
75.7 ip arp inspection burst-interval .....	699
75.8 ip arp inspection recover .....	700
75.9 ip arp inspection exceed .....	701
75.10 show ip arp inspection .....	701
75.11 show ip arp inspection interface .....	702
75.12 show ip arp inspection vlan .....	703
75.13 show ip arp inspection statistics .....	703
75.14 clear ip arp inspection statistics .....	704
<b>Chapter 76 ND Detection Commands</b> .....	<b>705</b>
76.1 ipv6 nd detection .....	705
76.2 ipv6 nd detection vlan .....	705
76.3 ipv6 nd detection vlan logging .....	706

76.4	ipv6 nd detection trust.....	706
76.5	show ipv6 nd detection.....	707
76.6	show ipv6 nd detection interface.....	708
76.7	show ipv6 nd detection statistics .....	708
76.8	show ipv6 nd detection vlan .....	709
<b>Chapter 77 System Log Commands .....</b>		<b>710</b>
77.1	logging buffer .....	710
77.2	logging buffer level.....	710
77.3	logging file flash .....	711
77.4	logging file flash frequency .....	712
77.5	logging file flash level .....	713
77.6	logging host index.....	713
77.7	logging console.....	714
77.8	logging console level.....	715
77.9	logging monitor .....	716
77.10	logging monitor level.....	716
77.11	clear logging .....	717
77.12	show logging local-config .....	718
77.13	show logging loghost.....	718
77.14	show logging buffer.....	719
77.15	show logging flash .....	719

# Preface

This Guide is intended for network administrator to provide referenced information about CLI (Command Line Interface). The device mentioned in this Guide stands for Managed Switch without any explanation. Some models featured in this guide may be unavailable in your country or region. For local sales information, visit <https://www.tp-link.com>.

## Overview of this Guide

### Chapter 1: Using the CLI

Provide information about how to use the CLI, CLI Command Modes, Security Levels and some Conventions.

### Chapter 2: Line Commands (Only for Certain Devices)

Provide information about the commands used to make related configurations for the desired users and set the priority of the console media type.

### Chapter 3: User Interface

Provide information about the commands used to switch between five CLI Command Modes.

### Chapter 4: User Management Commands

Provide information about the commands used for user management.

### Chapter 5: System Configuration Commands

Provide information about the commands used for configuring the System information and System IP, reboot and reset the switch, upgrade the switch system and commands used for cable test.

### Chapter 6: File System Configuration Commands

Provide information about the commands used for configuring the File System.

### Chapter 7: Management Port Configuration Commands

Provide information about the commands used for configuring the Management Port.

### Chapter 8: EEE Configuration Commands

Provide information about the commands used for configuring EEE.

### Chapter 9: SDM Template Commands

Provide information about the commands used for configuring the SDM templates.

### Chapter 10: Time Range Commands

Provide information about the commands used for configuring the time range.

### Chapter 11: Port Configuration Commands

Provide information about the commands used for configuring the Speed, Negotiation Mode, and Flow Control for Ethernet ports.



## **Chapter 12: Port Isolation Commands**

Provide information about the commands used for configuring Port Isolation function.

## **Chapter 13: Loopback Detection Commands**

Provide information about the commands used for configuring the Loopback Detection function.

## **Chapter 14: Stack Commands**

Provide information about the commands used for configuring the Stack function.

## **Chapter 15: DDM Commands (Only for Certain Devices)**

Provide information about the commands used for DDM (Digital Diagnostic Monitoring) function.

## **Chapter 16: Etherchannel Commands**

Provide information about the commands used for configuring LAG (Link Aggregation Group) and LACP (Link Aggregation Control Protocol).

## **Chapter 17: MAC Address Commands**

Provide information about the commands used for Address configuration.

## **Chapter 18: IEEE 802.1Q VLAN Commands**

Provide information about the commands used for configuring IEEE 802.1Q VLAN.

## **Chapter 19: MAC-based VLAN Commands**

Provide information about the commands used for configuring MAC-based VLAN.

## **Chapter 20: Protocol-based VLAN Commands**

Provide information about the commands used for configuring Protocol VLAN.

## **Chapter 21: Private VLAN Commands (Only for Certain Devices)**

Provide information about the commands used for configuring Private VLAN.

## **Chapter 22: VLAN-VPN Commands (Only for Certain Devices)**

Provide information about the commands used for configuring VLAN-VPN (Virtual Private Network) function.

## **Chapter 23: ERPS Commands**

Provide information about the commands used for configuring ERPS (Ethernet Ring Protection Switching) function.

## **Chapter 24: GVRP Commands**

Provide information about the commands used for configuring GVRP (GARP VLAN registration protocol).

## **Chapter 25: IGMP Snooping Commands**

Provide information about the commands used for configuring the IGMP Snooping (Internet Group Management Protocol Snooping).

### **Chapter 26: Layer 3 IGMP Commands (Only for Certain Devices)**

Provide information about the commands used for configuring the layer 3 IGMP Snooping (Internet Group Management Protocol Snooping).

### **Chapter 27: PIM Commands (Only for Certain Devices)**

Provide information about the commands used for configuring the PIM (Protocol Independent Multicast) function.

### **Chapter 28: Static Multicast Routing Commands (Only for Certain Devices)**

Provide information about the commands used for configuring the Static Multicast Routing function.

### **Chapter 29: MLD Snooping Commands**

Provide information about the commands used for configuring the MLD Snooping (Multicast Listener Discovery Snooping).

### **Chapter 30: MVR Commands**

Provide information about the commands used for configuring the MVR.

### **Chapter 31: MSTP Commands**

Provide information about the commands used for configuring the MSTP (Multiple Spanning Tree Protocol).

### **Chapter 32: Debug Commands**

Provide information about the commands used for configuring the debug function.

### **Chapter 33: LLDP Commands**

Provide information about the commands used for configuring LLDP function.

### **Chapter 34: L2PT Commands (Only for Certain Devices)**

Provide information about the commands used for configuring L2PT (Layer 2 Protocol Tunneling).

### **Chapter 35: PPPoE ID-Insertion Commands (Only for Certain Devices)**

Provide information about the commands used for configuring PPPoE ID-Insertion.

### **Chapter 36: Static Routes Commands**

Provide information about the commands used for configuring the Static Route function.

### **Chapter 37: RIP Configuration Commands**

Provide information about the commands used for configuring the RIP (Routing Information Protocol).

### **Chapter 38: RIPng Configuration Commands**

Provide information about the commands used for configuring the RIP (RIP next generation).

### **Chapter 39: OSPF Configuration Commands**

Provide information about the commands used for configuring the OSPF (Open Shortest Path First).

### **Chapter 40: OSPFv3 Configuration Commands**

Provide information about the commands used for configuring the OSPFv3 (Open Shortest Path First version 3).

### **Chapter 41: IPv6 Address Configuration Commands**

Provide information about the commands used for configuring the System IPv6 addresses.

### **Chapter 42: ARP Commands**

Provide information about the commands used for configuring the ARP (Address Resolution Protocol) functions.

### **Chapter 43: VRRP Commands (Only for Certain Devices)**

Provide information about the commands used for configuring VRRP (Virtual Router Redundancy Protocol).

### **Chapter 44: DHCP Server Commands**

Provide information about the commands used for configuring the DHCP Server function.

### **Chapter 45: DHCP Relay Commands**

Provide information about the commands used for configuring the DHCP Relay function.

### **Chapter 46: DHCPV6 Relay Commands**

Provide information about the commands used for configuring the DHCPV6 Relay function.

### **Chapter 47: DHCP L2 Relay Commands**

Provide information about the commands used for configuring the DHCP L2 Relay function.

### **Chapter 48: DHCPV6 L2 Relay Commands**

Provide information about the commands used for configuring the DHCPV6 L2 Relay function.

### **Chapter 49: QoS Commands**

Provide information about the commands used for configuring the QoS function.

### **Chapter 50: Bandwidth Control Commands**

Provide information about the commands used for configuring the Bandwidth Control.

### **Chapter 51: Voice VLAN Commands**

Provide information about the commands used for configuring Voice VLAN.

### **Chapter 52 Auto VoIP Commands**

Provide information about the commands used for configuring Auto VoIP.

### **Chapter 53: Access Control Commands**

Provide information about the commands used for configuring Access Control.

#### **Chapter 54: HTTP and HTTPS Commands**

Provide information about the commands used for configuring the HTTP and HTTPS logon.

#### **Chapter 55: SSH Commands**

Provide information about the commands used for configuring and managing SSH (Security Shell).

#### **Chapter 56: Telnet Commands**

Provide information about the commands used for configuring and managing SSH (Security Shell).

#### **Chapter 57: Serial Port Commands (Only for Certain Devices)**

Provide information about the commands used for configuring and managing SSH (Security Shell).

#### **Chapter 58: AAA Commands**

Provide information about the commands used for configuring AAA (authentication, authorization and accounting).

#### **Chapter 59: IEEE 802.1X Commands**

Provide information about the commands used for configuring IEEE 802.1X function.

#### **Chapter 60: Port Security Commands**

Provide information about the commands used for configuring Port Security.

#### **Chapter 61: Port Mirroring Commands**

Provide information about the commands used for configuring the Port Mirror function.

#### **Chapter 62: ACL Commands**

Provide information about the commands used for configuring the ACL (Access Control List).

#### **Chapter 63: IPv4 IMPB Commands**

Provide information about the commands used for binding the IP address, MAC address, VLAN and the connected Port number of the Host together.

#### **Chapter 64: IPv6 IMPB Commands**

Provide information about the commands used for binding the IPv6 address, MAC address, VLAN and the connected Port number of the Host together.

#### **Chapter 65: IP Verify Source Commands**

Provide information about the commands used for guarding the IP Source by filtering the IP packets based on the IP-MAC Binding entries.

#### **Chapter 66: IPv6 Verify Source Commands**

Provide information about the commands used for guarding the IPv6 Source by filtering the IP packets based on the IP-MAC Binding entries.

**Chapter 67: DHCPv4 Filter Commands**

Provide information about the commands used for configuring the DHCPv4 Filter.

**Chapter 68: DHCPv6 Filter Commands**

Provide information about the commands used for configuring the DHCPv6 Filter.

**Chapter 69: DoS Defend Command**

Provide information about the commands used for DoS defend and detecting the DoS attack.

**Chapter 70: sFlow Commands (Only for Certain Devices)**

Provide information about the commands used for configuring the Sampled Flow function.

**Chapter 71: Ethernet OAM Commands (Only for Certain Devices)**

Provide information about the commands used for configuring the Ethernet OAM (Operation, Administration, and Maintenance) function.

**Chapter 72: DLDP Commands (Only for Certain Devices)**

Provide information about the commands used for configuring the DLDP (Device Link Detection Protocol).

**Chapter 73: SNMP Commands**

Provide information about the commands used for configuring the SNMP (Simple Network Management Protocol) functions.

**Chapter 74: PoE Commands (Only for Certain Devices)**

Provide information about the commands used for configuring PoE function.

**Chapter 75: ARP Inspection Commands**

Provide information about the commands used for protecting the switch from the ARP cheating or ARP Attack.

**Chapter 76: ND Detection Commands**

Provide information about the commands used for configuring ND detection.

**Chapter 77: System Log Commands**

Provide information about the commands used for configuring system log.

# Chapter 1 Using the CLI

## 1.1 Accessing the CLI

You can log on to the switch and access the CLI by the following three methods:

1. Log on to the switch by the console port on the switch.
2. Log on to the switch remotely by a Telnet connection through an Ethernet port.
3. Log on to the switch remotely by an SSH connection through an Ethernet port.

### 1.1.1 Logon by a console port



**Note:** Console port is only available on certain devices.

#### ■ Console Port

The switch has two console ports: an RJ-45 console port and a Micro-USB console port. Console output is active on devices connected to both console ports, but console input is only active on one console port at a time.

The Micro-USB connector takes precedence over the RJ-45 connector. When the switch detects a valid connection on the Micro-USB console port, input from the RJ-45 console port is immediately disabled, and input from the Micro-USB console port is enabled. Removing the Micro-USB connection immediately reenables input from the RJ-45 console connection.

#### ■ USB Console Driver

If you are using the USB port on the MAC OS X or Linux OS for console connection, there is no need to run a USB driver.

If you are using the switch's Micro-USB console port with the USB port of a Windows PC, a driver for the USB port is required. The USB driver is provided on the resource CD. Follow the InstallShield Wizard to accomplish the installation.

The TP-Link USB Console Driver supports the following Windows operating systems:

- 32-bit Windows XP SP3
- 64-bit Windows XP
- 32-bit Windows Vista
- 64-bit Windows Vista
- 32-bit Windows 7

- 64-bit Windows 7
- 32-bit Windows 8
- 64-bit Windows 8
- 32-bit Windows 8.1
- 64-bit Windows 8.1
- 32-bit Windows 10
- 64-bit Windows 10

After the TP-Link USB Console Driver is installed, the PC's USB port will act as RS-232 serial port when the PC's USB port is connected to the switch's Micro-USB console port. And the PC's USB port will act as standard USB port when the PC's USB port is unplugged from the switch.


- Logon

Take the following steps to log on to the switch by the console port.

1. Connect the PCs or Terminals to the console port on the switch by the provided cable.
2. Start the terminal emulation program (such as the HyperTerminal, PuTTY, Tera Term) on the PC.
3. Specify the connection COM port in the terminal emulation program. If the Micro-USB Console port is used, you can view which port is assigned to the USB serial port in the following path:

Control Panel -> Hardware and Sound -> Device Manager -> Ports ->USB Serial Port.

Figure 1-1 USB Serial Port Number




4. Configure the terminal emulation program or the terminal to use the following settings:


- Baud rate: 38400 bps
- Data bits: 8
- Parity: none
- Stop bits: 1
- Flow control: none



5. Type the Username and Password in the Hyper Terminal window. The default value for both of them are **admin**. Press **Enter** in the main window and "Switch>" will appear indicating that you have successfully logged in to the switch and you can use the CLI now.

Figure 1-2 Log in to the Switch



 **Note:** The first time you log in, change the password to better protect your network and devices.

### 1.1.2 Logon by Telnet

To log on to the switch by a Telnet connection, please take the following steps:

1. Click **Start** and type in **cmd** in the Search programs and files window and press the **Enter** button.




Figure 1-1 Run Window

2. Type in telnet 192.168.0.1 in the cmd window and press **Enter**.

```
C:\Windows\system32\cmd.exe
Microsoft Windows [Version 10.0.19045.2965]
(c) Microsoft Corporation. All rights reserved.

C:\Users\admin>telnet 192.168.0.1
```


Figure 1-2 Type in the telnet command

3. Type in the login username and password (both **admin** by default). Press **Enter** and you will enter User EXEC Mode.

```
Telnet 192.168.0.1
***** User Access Login *****
User:admin
Password:

SG6654XHP>
```

Figure 1-2 Log in the Switch

 **Note:** The first time you log in, change the password to better protect your network and devices.

4. Type in **enable** command and you will enter Privileged EXEC Mode. By default, no password is needed. Later you can set a password for users who want to access the Privileged EXEC Mode.

```
Telnet 192.168.0.1
***** User Access Login *****
User:admin
Password:

SG6654XHP>enable
SG6654XHP#
```

Figure 1-3 Enter into Privileged EXEC Mode

### 1.1.3 Logon by SSH

To log on by SSH, a Putty client software is recommended. There are two authentication modes to set up an SSH connection:

**Password Authentication Mode:** It requires username and password, which are both **admin** by default.

**Key Authentication Mode:** It requires a public key for the switch and a private key for the SSH client software. You can generate the public key and the private key through Putty Key Generator.



**Note:**

1. Before SSH login, please follow the steps shown in Figure 1-4 to enable the SSH function through Telnet connection, which is enabled by default for some models.
2. The first time you log in, change the password to better protect your network and devices.

```
Telnet 192.168.0.1
***** User Access Login *****
User:admin
Password:

SG6654XHP>enable
SG6654XHP#config
SG6654XHP(config)#ip ssh server
SG6654XHP(config)#_
```

Figure 1-4 Enable SSH function

■ **Password Authentication Mode**

1. Open the software to log on to the interface of PuTTY. Enter the IP address of the switch into **Host Name** field; keep the default value 22 in the **Port** field; select **SSH** as the Connection type.





Figure 1-5 SSH Connection Config

2. Click the **Open** button in the above figure to log on to the switch. Enter the login user name and password to log on the switch, and then enter enable to enter Privileged EXEC Mode, so you can continue to configure the switch.



```
192.168.0.1 - PuTTY
login as: admin
admin@192.168.0.1's password:
SG6654XHP>enable
SG6654XHP#
```

Figure 1-6 Log on the Switch

■ **Key Authentication Mode**

2. Select the key type and key length, and generate SSH key.




Figure 1-7 Generate SSH Key

 **Note:**

1. The key length is in the range of 512 to 3072 bits.
2. During the key generation, randomly moving the mouse quickly can accelerate the key generation.

3. After the key is successfully generated, please save the public key and private key to a TFTP server.





Figure 1-8 Save the Generated Key

4. Log on to the switch by Telnet and download the public key file from the TFTP server to the switch, as the following figure shows:



```
Telnet 192.168.0.1
***** User Access Login *****
User:admin
Password:
SG6654XHP>enable
SG6654XHP#config
SG6654XHP(config)#ip ssh download v2 public ip-address 192.168.0.100
Start to download SSH key file.....
```

The screenshot shows a Telnet session on a switch. The user logs in as 'admin' and enters 'enable' to reach the privileged EXEC mode. Then, the user enters 'config' to enter the configuration mode. The command 'ip ssh download v2 public ip-address 192.168.0.100' is entered. The output shows 'Start to download SSH key file.....'. Two red arrows point to 'public' and '192.168.0.100' in the command, with labels 'The filename of the public key' and 'The IP address of the TFTP server' respectively.

Figure 1-9 Download the Public Key

 **Note:**

1. The key type should accord with the type of the key file.
2. The SSH key downloading cannot be interrupted.



5. After the public key is downloaded, please log on to the interface of PuTTY and enter the IP address for login.




Figure 1-10 SSH Connection Config

6. Click **Browse** to download the private key file to SSH client software and click **Open**.




Figure 1-11 Download the Private Key

7. After successful authentication, please enter the login user name. If you log on to the switch without entering password, it indicates that the key has been successfully downloaded.




Figure 1-12 Log on the Switch

## 1.2 CLI Command Modes

The CLI is divided into different command modes: User EXEC Mode, Privileged EXEC Mode, Global Configuration Mode, Interface Configuration Mode and VLAN Configuration Mode.

Interface Configuration Mode can also be divided into Interface Ethernet, Interface link-aggregation and some other modes, which is shown as the following diagram.

The following table gives detailed information about the Accessing path, Prompt of each mode and how to exit the current mode and access the next mode.

Mode	Accessing Path	Prompt	Logout or Access the next mode
User EXEC Mode	Primary mode once it is connected with the switch.	<b>Switch&gt;</b>	Use the <b>exit</b> command to disconnect the switch. Use the <b>enable</b> command to access Privileged EXEC mode.
Privileged EXEC Mode	Use the <b>enable</b> command to enter this mode from User EXEC mode.	<b>Switch#</b>	Enter the <b>disable</b> or the <b>exit</b> command to return to User EXEC mode. Enter <b>configure</b> command to access Global Configuration mode.
Global Configuration Mode	Use the <b>configure</b> command to enter this mode from Privileged EXEC mode.	<b>Switch(config)#</b>	Use the <b>exit</b> or the <b>end</b> command or press <b>Ctrl+Z</b> to return to Privileged EXEC mode. Use the <b>interface gigabitEthernet port</b> or <b>interface range gigabitEthernet port-list</b> command to access interface Configuration mode. Use the <b>vlan vlan-list</b> to access VLAN Configuration mode.
Interface Configuration Mode	Layer 2 Interface: Use the <b>interface gigabitEthernet port</b> , <b>interface port-channel port-channel-id</b> or <b>interface range gigabitEthernet port-list</b> command to enter this mode from Global Configuration mode.	<b>Switch(config-if)#</b>  or <b>Switch(config-if-range)#</b>	Use the <b>end</b> command or press <b>Ctrl+Z</b> to return to Privileged EXEC mode. Enter the <b>exit</b> or the <b>#</b> command to return to Global Configuration mode. A port number must be specified in the <b>interface</b> command.

Mode	Accessing Path	Prompt	Logout or Access the next mode
Interface Configuration Mode	<p>Layer 3 Interface: Use the <b>no switchport</b> command to enter Routed Port mode from Interface Configuration mode.</p> <p>Use the <b>interface vlan <i>vlan-id</i></b> command to enter VLAN Interface mode from Global Configuration mode.</p> <p>Use the <b>interface loopback <i>id</i></b> command to enter Loopback Interface mode from Global Configuration mode.</p>	<p><b>Switch (config-if)#</b></p> <p>or</p> <p><b>Switch(config-if-range)#</b></p>	<p>Use the <b>switchport</b> command to switch to the Layer 2 interface mode.</p> <p>Use the <b>end</b> command or press <b>Ctrl+Z</b> to return to Privileged EXEC mode.</p> <p>Enter the <b>exit</b> or the <b>#</b> command to return to Global Configuration mode.</p>
Router Configuration Mode	<p>Layer 3 Interface: Use the <b>router rip</b> or <b>router ripng</b> command to enter this mode from Global Configuration mode.</p>	<p><b>Switch (config-router)</b></p>	<p>Use the <b>end</b> command or press <b>Ctrl+Z</b> to return to Privileged EXEC mode.</p> <p>Enter the <b>exit</b> command or the <b>#</b> command to return to Global configuration mode.</p>
VLAN Configuration Mode	<p>Use the <b>vlan <i>vlan-list</i></b> command to enter this mode from Global Configuration mode.</p>	<p><b>Switch (config-vlan)#</b></p>	<p>Use the <b>end</b> command or press <b>Ctrl+Z</b> to return to Privileged EXEC mode.</p> <p>Enter the <b>exit</b> command or the <b>#</b> command to return to Global configuration mode.</p>



**Note:**

1. The user is automatically in User EXEC Mode after the connection between the PC and the switch is established by a Telnet/SSH connection.
2. Global Configuration Mode/Interface Configuration Mode/VLAN Configuration Mode is only available in standalone mode.
3. Each command mode has its own set of specific commands. To configure some

commands, you should access the corresponding command mode firstly.

- **Global Configuration Mode:** In this mode, global commands are provided, such as the Spanning Tree, Schedule Mode and so on.
  - **Interface Configuration Mode:** In this mode, users can configure one or several ports, different ports corresponds to different commands
    - a). Interface fastEthernet/gigabitEthernet/two-gigabitEthernet/ten-gigabitEthernet: Configure parameters for a fastEthernet/gigabitEthernet/two-gigabitEthernet/ten-gigabitEthernet port, such as Duplex-mode, flow control status.
    - b). Interface range fastEthernet/gigabitEthernet/two-gigabitEthernet/ten-gigabitEthernet: Configure parameters for several fastEthernet/gigabitEthernet/two-gigabitEthernet/ten-gigabitEthernet ports.
    - c). Interface link-aggregation: Configure parameters for a link-aggregation, such as broadcast storm.
    - d). Interface range link-aggregation: Configure parameters for multi-trunks.
    - e). Interface vlan: Configure parameters for the vlan-port.
  - **VLAN Configuration Mode:** In this mode, users can create a VLAN and add a specified port to the VLAN.
4. Some commands are global, that means they can be performed in all modes:
- **show:** Display all information of switch, for example: statistic information, port information, VLAN information.
  - **history:** Display the commands history.

## 1.3 Privilege Restrictions

This switch's security is divided into four privilege levels: User level, Power User level, Operator level and Admin level. You can define username and password pairs, and assign a specific privilege level to each pair. Different privilege levels have access to specified commands, which is illustrated in the **Privilege Requirement** in each command. For details about how to configure username and password pairs, please refer to [user name \(password\)](#) and [user name \(secret\)](#).

Users can enter Privileged EXEC mode from User EXEC mode by using the **enable** command. In default case, no password is needed. In Global Configuration Mode, you can configure password for Admin level by **enable password** command. Once password is configured, you are required to enter it to access Privileged EXEC mode.

## 1.4 Conventions

### 1.4.1 PoE Disclaimer

PoE budget calculations are based on laboratory testing. Actual PoE power budget is not guaranteed and will vary as a result of client limitations and environmental factors.

### 1.4.2 Format Conventions

The following conventions are used in this Guide:

- Items in square brackets [] are optional
- Items in braces {} are required
- Alternative items are grouped in braces and separated by vertical bars. For example: **speed** {10 | 100 | 1000 }
- Bold indicates an unalterable keyword. For example: **show logging**
- Normal Font indicates a constant (several options are enumerated and only one can be selected). For example: **mode** {dynamic | static | permanent}
- Italic Font indicates a variable (an actual value must be assigned). For example: **bridge aging-time** *aging-time*

### 1.4.3 Special Characters

You should pay attentions to the description below if the variable is a character string:

- These six characters " < > , \ & cannot be input.

- If a blank is contained in a character string, single or double quotation marks should be used, for example 'hello world', "hello world", and the words in the quotation marks will be identified as a string. Otherwise, the words will be identified as several strings.

#### **1.4.4 Parameter Format**

Some parameters must be entered in special formats which are shown as follows:

- MAC address must be enter in the format of xx:xx:xx:xx:xx:xx.
- One or several values can be typed for a port-list or a vlan-list using comma to separate. Use a hyphen to designate a range of values, for instance, 1/0/1, 1/0/3-5, 1/0/7 indicates choosing port 1/0/1, 1/0/3, 1/0/4, 1/0/5, 1/0/7.

# Chapter 2 Line Commands (Only for Certain Devices)



Note: Line Commands are only available on certain devices.

## 2.1 line

### Description

The line command is used to enter the Line Configuration Mode and make related configurations for the desired user(s).

### Syntax

```
line { console linenum | vty startlinenum endlinenum }
```

### Parameter

linenum — The number of users allowed to login through console port. Its value is 0 in general, for the reason that console input is only active on one console port at a time.

startlinenum — The start serial number of the login user selected to configure the login mode and password, ranging from 0 to 15. 0 means the first login user number, 1 means the second, and the rest can be done on the same manner.

endlinenum — The end serial number of the login user selected to configure the login mode and password, ranging from 0 to 15. 0 means the first login user number, 1 means the second, and the rest can be done on the same manner.

### Command Mode

Global Configuration Mode

### Privilege Requirement

Only Admin level users have access to these commands.

### Example

Enter the Console port configuration mode and configure the console port 0:

```
Switch(config)#line console 0
```



Enter the Virtual Terminal configuration mode so as to prepare further configurations such as password and login mode for virtual terminal 0 to 5:

```
Switch(config)#line vty 0 5
```

## 2.2 media-type rj45

### Description

The `media-type rj45` command is used to configure the console media type as RJ-45 for input. The switch has two console ports available — an RJ-45 console port and a micro-USB console port. Console input is active on only one console port at a time. By default, the micro-USB connector takes precedence over the RJ-45 connector, which means that, when both the RJ-45 console connection and micro-USB console connection are valid, input from the RJ-45 console is disabled, and input from the micro-USB console is enabled. To return to the default configuration, please use `no media-type rj45` command.

### Syntax

```
media-type rj45
```

```
no media-type rj45
```

### Command Mode

```
Line Configuration Mode
```

### Privilege Requirement

Only Admin level users have access to these commands.

### Example

Enable the RJ-45 console input:

```
Switch(config)# line console 0
```

```
Switch(config-line)# media-type rj45
```

Receive the micro-USB console input prior to the RJ-45 console input:

```
Switch(config)# line console 0
```

```
Switch(config-line)# no media-type rj45
```

## Chapter 3 User Interface

### 3.1 enable

#### Description

The **enable** command is used to access Privileged EXEC Mode from User EXEC Mode.

#### Syntax

```
enable
```

#### Command Mode

User EXEC Mode

#### Privilege Requirement

None.

#### Example

If you have set the password to access Privileged EXEC Mode from User EXEC Mode:

```
Switch>enable
Enter password:
Switch#
```

### 3.2 service password-encryption

#### Description

The **service password-encryption** command is used to encrypt the password when the password is defined or when the configuration is written, using the symmetric encryption algorithm. Encryption prevents the password from being readable in the configuration file. To disable the global encryption function, please use **no service password-encryption** command.

#### Syntax

```
service password-encryption
no service password-encryption
```

## Command Mode

Global Configuration Mode

## Privilege Requirement

Only Admin level users have access to these commands.

## Example

Enable the global encryption function:

```
Switch(config)# service password-encryption
```

# 3.3 enable password

## Description

The **enable password** command is used to set or change the password for users to access Privileged EXEC Mode from User EXEC Mode. To remove the password, please use **no enable password** command. This command uses the symmetric encryption.

## Syntax

```
enable password {[ 0] password | 7 encrypted-password }  
no enable password
```

## Parameter

0 — Specify the encryption type. 0 indicates that an unencrypted password will follow. By default, the encryption type is 0.

*password* — A string with 31 characters at most, which can contain only English letters (case-sensitive), digits and 17 kinds of special characters. The special characters are **!\$%()'\*,.-/[]\_{}.** By default, it is empty.

7 — Indicates a symmetric encrypted password with fixed length will follow.

*encrypted-password* — A symmetric encrypted password with fixed length, which you can copy from another switch's configuration file. After the encrypted password is configured, you should use the corresponding unencrypted password if you re-enter this mode.

## Command Mode

Global Configuration Mode

## Privilege Requirement

Only Admin level users have access to these commands.

## User Guidelines

If the password you configured here is unencrypted and the global encryption function is enabled in [service password-encryption](#), the password in the configuration file will be displayed in the symmetric encrypted form.

If both the **enable password** and **enable secret** are defined, only the latest configured password will take effect.

## Example

Set the super password as "admin" and unencrypted to access Privileged EXEC Mode from User EXEC Mode:

```
Switch(config)#enable password 0 admin
```

## 3.4 enable secret

### Description

The **enable secret** command is used to set a secret password, which is using an MD5 encryption algorithm, for users to access Privileged EXEC Mode from User EXEC Mode. To return to the default configuration, please use **no enable secret** command. This command uses the MD5 encryption.

### Syntax

```
enable secret {[ 0 ] password | 5 encrypted-password}
```

```
no enable secret
```

### Parameter

0 — Specify the encryption type. 0 indicates that an unencrypted password will follow. By default, the encryption type is 0.

*password* — A string with 31 characters at most, which can contain only English letters (case-sensitive), digits and 17 kinds of special characters. The special characters are **!\$%()'\*,.-/[]\_{}.** By default, it is empty. The password in the configuration file will be displayed in the MD5 encrypted form.

5 — Indicates an MD5 encrypted password with fixed length will follow.

*encrypted-password* — An MD5 encrypted password with fixed length, which you can copy from another switch's configuration file. After the encrypted password is configured, you should use the corresponding unencrypted password if you re-enter this mode.

## Command Mode

Global Configuration Mode

## Privilege Requirement

Only Admin level users have access to these commands.

## User Guidelines

If both the **enable password** and **enable secret** are defined, only the latest configured password will take effect.

## Example

Set the secret password as "admin" and unencrypted to access Privileged EXEC Mode from User EXEC Mode. The password will be displayed in the encrypted form.

```
Switch(config)#enable secret 0 admin
```

# 3.5 configure

## Description

The **configure** command is used to access Global Configuration Mode from Privileged EXEC Mode.

## Syntax

```
configure
```

## Command Mode

Privileged EXEC Mode

## Privilege Requirement

Only Admin, Operator and Power User level users have access to these commands.

## Example

Access Global Configuration Mode from Privileged EXEC Mode:

```
Switch# configure  
Switch (config)#
```

## 3.6 exit

### Description

The **exit** command is used to return to the previous Mode from the current Mode.

### Syntax

**exit**

### Command Mode

Privileged EXEC Mode and Any Configuration Mode

### Privilege Requirement

None.

### Example

Return to Global Configuration Mode from Interface Configuration Mode, and then return to Privileged EXEC Mode:

```
Switch (config-if)# exit
Switch (config)#exit
Switch#
```

## 3.7 end

### Description

The **end** command is used to return to Privileged EXEC Mode.

### Syntax

**end**

### Command Mode

Privileged EXEC Mode and Any Configuration Mode

### Privilege Requirement

Only Admin level users have access to these commands.

### Example

Return to Privileged EXEC Mode from Interface Configuration Mode:

```
Switch (config-if)#end
Switch #
```

## 3.8 clipaging

### Description

The **clipaging** command is used to enable the pause function for the screen display. If you want to display all the related information of the switch at once when using the show command, please use **no clipaging** command.

### Syntax

```
clipaging
no clipaging
```

### Command Mode

Privileged EXEC Mode and Any Configuration Mode

### Privilege Requirement

None.

### Example

Disable the pause function for the screen display:

```
Switch (config)#no clipaging
```

## 3.9 history

### Description

The **history** command is used to show the latest 20 commands you entered in the current mode since the switch is powered.

### Syntax

```
history
```

### Command Mode

Privileged EXEC Mode and any Configuration Mode

### Privilege Requirement

None.

### Example

Show the commands you have entered in the current mode:

```
Switch (config)# history
1 history
```

## 3.10 history clear

### Description

The **history clear** command is used to clear the commands you have entered in the current mode; therefore, these commands will not be shown next time you use the **history** command.

### Syntax

```
history clear
```

### Command Mode

Privileged EXEC Mode and any Configuration Mode

### Privilege Requirement

Only Admin, Operator and Power User level users have access to these commands.

### Example

Clear the commands you have entered in the current mode:

```
Switch (config)#history clear
```



## Chapter 4 User Management Commands

User Management commands are used to manage the user's logging information by Web, Telnet or SSH, so as to protect the settings of the switch from being randomly changed.

### 4.1 user name (password)

#### Description

The **user name** command is used to add a new user or modify the existed users' information. To delete the existed users, please use **no user name** command. This command uses the symmetric encryption.

#### Syntax

```
user name name [ privilege admin | operator | power_user | user ] password
{ [ 0 ] password | 7 encrypted-password }

no user name name
```

#### Parameter

*name* —— Type a name for users' login. It contains 16 characters at most, composed of digits, English letters and symbols. No spaces, question marks and double quotation marks are allowed.

admin | operator | power\_user | user —— Access level. "admin" means that you can edit, modify and view all the settings of different functions. "operator" means that you can edit, modify and view most of the settings of different functions. "power-user" means that you can edit, modify and view some of the settings of different functions. "user" means that you can only view some of the settings of different functions without the right to edit or modify. It is "admin" by default. For more details about privilege restrictions, please refer to the **Privilege Requirement** part in each command.

0 —— Specify the encryption type. 0 indicates that an unencrypted password will follow. By default, the encryption type is 0.

*password* —— Users' login password, a string with 6–31 alphanumeric characters (case-sensitive) and symbols. No spaces are allowed.

7 —— Indicates a symmetric encrypted password with fixed length will follow.

*encrypted-password* —— A symmetric encrypted password with fixed length, which you can copy from another switch's configuration file. After the

encrypted password is configured, you should use the corresponding unencrypted password if you re-enter this mode.

## Command Mode

Global Configuration Mode

## Privilege Requirement

Only Admin level users have access to these commands.

## User Guidelines

If the password you configured here is unencrypted and the global encryption function is enabled in [service password-encryption](#), the password in the configuration file will be displayed in the symmetric encrypted form.

If both the **user name (password)** and **user name (secret)** are defined, only the latest configured password will take effect.

## Example

Add and enable a new admin user named "tplink", of which the password is "admin" and unencrypted:

```
Switch(config)#user name tplink privilege admin password 0 admin
```

## 4.2 user name (secret)

### Description

The **user name** command is used to add a new user or modify the existed users' information. To delete the existed users, please use **no user name** command. This command uses the MD5 encryption.

### Syntax

```
user name name [ privilege admin | operator | power_user | user ] secret { [ 0 ]  
password | 5 encrypted-password }
```

```
no user name name
```

### Parameter

*name* —— Type a name for users' login. It contains 16 characters at most, composed of digits, English letters and symbols. No spaces, question marks and double quotation marks are allowed.

admin | operator | power\_user | user —— Access level. "admin" means that you can edit, modify and view all the settings of different functions. "operator"

means that you can edit, modify and view most of the settings of different functions. "power-user" means that you can edit, modify and view some of the settings of different functions. "user" means that you can only view some of the settings of different functions without the right to edit or modify. It is "admin" by default.

0 — Specify the encryption type. 0 indicates that an unencrypted password will follow. By default, the encryption type is 0.

*password* —Users' login password, a string with 6–31 alphanumeric characters (case-sensitive) and symbols. No spaces are allowed.

5 — Indicates an MD5 encrypted password with fixed length will follow.

*encrypted-password* — An MD5 encrypted password with fixed length, which you can copy from another switch's configuration file.

## Command Mode

Global Configuration Mode

## Privilege Requirement

Only Admin level users have access to these commands.

## User Guidelines

If both the **user name (password)** and **user name (secret)** are defined, only the latest configured password will take effect.

## Example

Add and enable a new admin user named "tplink", of which the password is "admin". The password will be displayed in the encrypted form.

```
Switch (config)#user name tplink privilege admin secret 0 admin
```

## 4.3 service password-recovery



Note: This command is only available on certain devices.

### Description

The **service password-recovery** command is used to enable the password-recovery feature. To disable the password-recovery feature, please use **no service password-recovery** command.

With password-recovery enabled, you can connect to the switch's console port and delete all your previous set accounts. You can use the default

username and password (which are both admin) to login the switch after its startup.

### Syntax

**service password-recovery**  
**no service password-recovery**

### Command Mode

Global Configuration Mode

### Privilege Requirement

Only Admin level users have access to these commands.

### Example

Enable the switch's password-recovery feature:

```
Switch(config)# service password-recovery
```

## 4.4 show user account-list

### Description

The **show user account-list** command is used to display the information of the current users.

### Syntax

**show user account-list**

### Command Mode

Privileged EXEC Mode and Any Configuration Mode

### Privilege Requirement

Only Admin level users have access to these commands.

### Example

Display the information of the current users:

```
Switch (config)# show user account-list
```

## 4.5 show user configuration

### Description

The **show user configuration** command is used to display the security configuration information of the users, including access-control, max-number and the idle-timeout, etc.

### Syntax

```
show user configuration
```

### Command Mode

Privileged EXEC Mode and Any Configuration Mode

### Privilege Requirement

None.

### Example

Display the security configuration information of the users:

```
Switch (config)# show user configuration
```

## Chapter 5 System Configuration Commands

System Commands can be used to configure the System information and System IP, reboot and reset the switch, upgrade the switch system and other operations.

### 5.1 system-time manual

#### Description

The **system-time manual** command is used to configure the system time manually.

#### Syntax

```
system-time manual time
```

#### Parameter

*time* — Set the date and time manually, MM/DD/YYYY-HH:MM:SS. The valid value of the year ranges from 2000 to 2037.

#### Command Mode

Global Configuration Mode

#### Privilege Requirement

Only Admin and Operator level users have access to these commands.

#### Example

Configure the system mode as manual, and the time is 12/20/2010 17:30:35

```
Switch (config)# system-time manual 12/20/2010-17:30:35
```

### 5.2 system-time ntp

#### Description

The **system-time ntp** command is used to configure the time zone and the IP address for the NTP Server. The switch will get UTC automatically if it has connected to an NTP Server.

#### Syntax

```
system-time ntp { timezone } { ntp-server } { backup-ntp-server }  
{ fetching-rate }
```

#### Parameter

*timezone* — Your local time-zone, and it ranges from UTC-12:00 to UTC+13:00.

The detailed information that each time-zone means are displayed as follow:

UTC-12:00 — TimeZone for International Date Line West.

UTC-11:00 — TimeZone for Coordinated Universal Time-11.

UTC-10:00 — TimeZone for Hawaii.

UTC-09:00 — TimeZone for Alaska.

UTC-08:00 — TimeZone for Pacific Time(US Canada).

UTC-07:00 — TimeZone for Mountain Time(US Canada).

UTC-06:00 — TimeZone for Central Time(US Canada).

UTC-05:00 — TimeZone for Eastern Time(US Canada).

UTC-04:30 — TimeZone for Caracas.

UTC-04:00 — TimeZone for Atlantic Time(Canada).

UTC-03:30 — TimeZone for Newfoundland.

UTC-03:00 — TimeZone for Buenos Aires, Salvador, Brasilia.

UTC-02:00 — TimeZone for Mid-Atlantic.

UTC-01:00 — TimeZone for Azores, Cape Verde Is.

UTC — TimeZone for Dublin, Edinburgh, Lisbon, London.

UTC+01:00 — TimeZone for Amsterdam, Berlin, Bern, Rome, Stockholm, Vienna.

UTC+02:00 — TimeZone for Cairo, Athens, Bucharest, Amman, Beirut, Jerusalem.

UTC+03:00 — TimeZone for Kuwait, Riyadh, Baghdad.

UTC+03:30 — TimeZone for Tehran.

UTC+04:00 — TimeZone for Moscow, St.Petersburg, Volgograd, Tbilisi, Port Louis.

UTC+04:30 — TimeZone for Kabul.

UTC+05:00 — TimeZone for Islamabad, Karachi, Tashkent.

UTC+05:30 — TimeZone for Chennai, Kolkata, Mumbai, New Delhi.

UTC+05:45 — TimeZone for Kathmandu.

UTC+06:00 — TimeZone for Dhaka, Astana, Ekaterinburg.

UTC+06:30 — TimeZone for Yangon (Rangoon).

UTC+07:00 — TimeZone for Novosibirsk, Bangkok, Hanoi, Jakarta.

UTC+08:00 — TimeZone for Beijing, Chongqing, Hong Kong, Urumqi, Singapore.

UTC+09:00 — TimeZone for Seoul, Irkutsk, Osaka, Sapporo, Tokyo.

UTC+09:30 — TimeZone for Darwin, Adelaide.

UTC+10:00 — TimeZone for Canberra, Melbourne, Sydney, Brisbane.

UTC+11:00 — TimeZone for Solomon Is., New Caledonia, Vladivostok.

UTC+12:00 — TimeZone for Fiji, Magadan, Auckland, Wellington.

UTC+13:00 — TimeZone for Nuku'alofa, Samoa.

*ntp-server* — The IP address for the Primary NTP Server.

*backup-ntp-server*—— The IP address for the Secondary NTP Server.

*fetching-rate*—— Specify the rate fetching time from NTP server.

## Command Mode

Global Configuration Mode

## Privilege Requirement

Only Admin and Operator level users have access to these commands.

## Example

Configure the system time mode as NTP, the time zone is UTC-12:00, the primary NTP server is 133.100.9.2 and the secondary NTP server is 139.78.100.163, the fetching-rate is 11 hours:

```
Switch(config)# system-time ntp UTC-12:00 133.100.9.2 139.79.100.163 11
```

## 5.3 system-time dst predefined

### Description

The **system-time dst predefined** command is used to select a daylight saving time configuration from the predefined mode. The configuration can be used recurrently. To disable DST function, please use **no system-time dst** command.

### Syntax

```
system-time dst predefined [ USA /Australia | Europe | New-Zealand ]
```

```
no system-time dst
```

### Parameter

USA /Australia | Europe | New-Zealand —— The mode of daylight saving time. There are 4 options which are USA, Australia, Europe and New-Zealand respectively. The default value is Europe.

Following are the time ranges of each option:

USA —— Second Sunday in March, 02:00 – First Sunday in November, 02:00.

Australia —— First Sunday in October, 02:00 – First Sunday in April, 03:00.

Europe —— Last Sunday in March, 01:00 – Last Sunday in October, 01:00.

New Zealand —— Last Sunday in September, 02:00 – First Sunday in April, 03:00.

## Command Mode

Global Configuration Mode



## Privilege Requirement

Only Admin and Operator level users have access to these commands.

## Example

Configure the daylight saving time as USA standard:

```
Switch(config)#system-time dst predefined USA
```

# 5.4 system-time dst date

## Description

The **system-time dst date** command is used to configure the one-off daylight saving time. The start date is in the current year by default. The time range of the daylight saving time must shorter than one year, but you can configure it spanning years. To disable DST function, please use **no system-time dst** command.

## Syntax

```
system-time dst date {smonth } {sday } {stime } {syear } {emonth } {eday }  
{etime } {eyear } [offset]
```

```
no system-time dst
```

## Parameter

*smonth* — The start month of the daylight saving time. There are 12 values showing as follows: Jan, Feb, Mar, Apr, May, Jun, Jul, Aug, Sep, Oct, Nov, Dec.

*sday* — The start day of the daylight saving time, ranging from 1 to 31. Here you should show special attention to February and the differences between a solar month and a lunar month.

*stime* — The start moment of the daylight saving time, HH:MM.

*syear* — The start year of the daylight saving time.

*emonth* — The end month of the daylight saving time. There are 12 values showing as follows: Jan, Feb, Mar, Apr, May, Jun, Jul, Aug, Sep, Oct, Nov, Dec.

*eday* — The end day of the daylight saving time, ranging from q to 31. Here you should show special attention to February and the differences between a solar month and a lunar month.

*etime* — The end moment of the daylight saving time, HH:MM.

*eyear* — The end year of the daylight saving time.

*offset* — The number of minutes to add during the daylight saving time. It is 60 minutes by default.

## Command Mode

Global Configuration Mode

## Privilege Requirement

Only Admin and Operator level users have access to these commands.

## Example

Configure the daylight saving time from zero clock, Apr 1st to zero clock Oct 1st and the offset is 30 minutes in 2015:

```
Switch(config)# system-time dst date Apr 1 00:00 2015 Oct 1 00:00 2015
30
```

# 5.5 system-time dst recurring

## Description

The **system-time dst recurring** command is used to configure the recurring daylight saving time. It can be configured spanning years. To disable DST function, please use **no system-time dst** command.

## Syntax

```
system-time dst recurring {sweek} {sday} {smonth} {stime} {eweeek} {eday}
{emonth} {etime} [offset]
```

```
no system-time dst
```

## Parameter

*sweek*—The start week of the daylight saving time. There are 5 values showing as follows: first, second, third, fourth, last.

*sday* — The start day of the daylight saving time. There are 7 values showing as follows: Sun, Mon, Tue, Wed, Thu, Fri, Sat.

*smonth*— The start month of the daylight saving time. There are 12 values showing as follows: Jan, Feb, Mar, Apr, May, Jun, Jul, Aug, Sep, Oct, Nov, Dec.

*stime*— The start moment of the daylight saving time, HH:MM.

*eweeek* —The end week of the daylight saving time. There are 5 values showing as follows: first, second, third, fourth, last.

*eday* — The end day of the daylight saving time. There are 5 values showing as follows: Sun, Mon, Tue, Wed, Thu, Fri, Sat.

*emonth*— The end month of the daylight saving time. There are 12 values showing as following: Jan, Feb, Mar, Apr, May, Jun, Jul, Aug, Sep, Oct, Nov, Dec.

*etime*—— The end moment of the daylight saving time, HH:MM.

*offset*—— The number of minutes to add during the daylight saving time. It is 60 minutes by default.

### Command Mode

Global Configuration Mode

### Privilege Requirement

Only Admin and Operator level users have access to these commands.

### Example

Configure the daylight saving time from 2:00am, the first Sunday of May to 2:00am, the last Sunday of Oct and the offset is 45 minutes:

```
Switch(config)# system-time dst recurring first Sun May 02:00 last Sun Oct  
02:00 45
```

## 5.6 hostname

### Description

The **hostname** command is used to configure the system name. To clear the system name information, please use **no hostname** command.

### Syntax

```
hostname [ hostname ]
```

```
no hostname
```

### Parameter

*hostname* —— System Name. The length of the name ranges from 1 to 32 characters. By default, it is the device name, for example "SG6654XHP".

### Command Mode

Global Configuration Mode

### Privilege Requirement

Only Admin and Operator level users have access to these commands.

### Example

Configure the system name as [TP-Link](#)

```
Switch(config)# hostname TP-Link
```

## 5.7 location

### Description

The **location** command is used to configure the system location. To clear the system location information, please use **no location** command.

### Syntax

**location** [ *location* ]

**no location**

### Parameter

*location* — Device Location. It consists of 32 characters at most. It is "Hong Kong" by default.

### Command Mode

Global Configuration Mode

### Privilege Requirement

Only Admin and Operator level users have access to these commands.

### Example

Configure the system location as Hong Kong:

```
Switch(config)# location Hong Kong
```

## 5.8 contact-info

### Description

The **contact-info** command is used to configure the system contact information. To clear the system contact information, please use **no contact-info** command.

### Syntax

**contact-info** [ *contact\_info* ]

**no contact-info**

### Parameter

*contact\_info* — Contact Information. It consists of 32 characters at most. It is "www.tp-link.com" by default.

### Command Mode

Global Configuration Mode

## Privilege Requirement

Only Admin and Operator level users have access to these commands.

## Example

Configure the system contact information as [www.tp-link.com](http://www.tp-link.com):

```
Switch(config)# contact-info www.tp-link.com
```

## 5.9 led



**Note:** This command is only available on certain devices.

### Description

The **led** command is used to control the LEDs.

### Syntax

```
led {on | off}
```

### Parameter

on | off— The LEDs are configured as on or off. By default, they are on.

### Command Mode

Global Configuration Mode

## Privilege Requirement

Only Admin, Operator and Power User level users have access to these commands.

## Example

Configure the LED as off:

```
Switch(config)# led off
```

## 5.10 ip address

### Description

This **ip address** command is used to configure the IP address and IP subnet mask for the specified interface manually. The interface type includes: routed port, port-channel interface, loopback interface and VLAN interface.

### Syntax

```
ip address { ip-addr } { mask } [ secondary ]
```

```
no ip address [ ip-addr ] [ mask ]
```

## Parameter

*ip-addr* — The IP address of the Layer 3 interface.

*mask* — The subnet mask of the Layer 3 interface.

**secondary** — Specify the interface's secondary IP address. If this parameter is omitted here, the configured IP address is the interface's primary address.

## Command Mode

Interface Configuration Mode

## Privilege Requirement

Only Admin, Operator and Power User level users have access to these commands.

## Example

Create the VLAN interface 2 with the primary IP address as 192.168.1.1/24 and secondary IP address as 192.168.2.1/24:

```
Switch (config)# interface vlan 2
Switch (config-if)# ip address 192.168.1.1 255.255.255.0
Switch (config-if)# ip address 192.168.2.1 255.255.255.0 secondary
```

# 5.11 ip address-alloc

## Description

The **IP address-alloc** command is used to enable the DHCP Client function or the BOOTP Protocol. When this function is enabled, the specified interface will obtain IP from DHCP Server or BOOTP server. To disable the IP obtaining function on the specified interface, please use the **no ip address** command. This command applies to the routed port, the port-channel interface and the VLAN interface.

## Syntax

```
ip address-alloc { dhcp | bootp }
```

```
no ip address
```

## Parameter

**dhcp** — Specify the Layer 3 interface to obtain IP address from the DHCP Server.

bootp — Specify the Layer 3 interface to obtain IP address from the BOOTP Server.

## Command Mode

Interface Configuration Mode

## Privilege Requirement

Only Admin, Operator and Power User level users have access to these commands.

## Example


Enable the DHCP Client function on the Lay 3 routed port 1/0/1:

```
Switch (config)# interface gigabitEthernet 1/0/1
Switch (config-if)# no switchport
Switch (config-if)# ip address-alloc dhcp
```

Disable the IP address obtaining function on the VLAN interface 2:

```
Switch (config)# interface vlan 2
Switch (config-if)# no ip address
```

## 5.12 controller cloud-based (Only for Certain Devices)

 **Note:** This command is only available on certain devices

## Description

The **controller cloud-based** command is used to enable Cloud-Based Controller management. When this feature is enabled, you can further add your devices to your Omada Cloud-Based Controller. To disable the feature, use the **no controller cloud-based** command.

## Syntax

```
controller cloud-based
no controller cloud-based
```

## Command Mode

Global Configuration Mode

## Privilege Requirement

Only Admin, Operator and Power User level users have access to these commands.

## 5.13 controller inform-url (Only for

Certain Devices)



**Note:** This command is only available on certain devices

### Description

If your switch and Omada SDN Controller are not located on the same subnet, the **controller inform-url** command is used to inform the switch of the controller's URL/IP address. To disable the feature, use the **no controller inform-url** command.

### Syntax

**controller inform-url** { controller-url | controller-ip }

**no controller inform-url**

### Parameter

controller-url — Specify the URL of Omada SDN Controller.

controller-ip — Specify the IP address of Omada SDN Controller.

### Command Mode

Global Configuration Mode

### Privilege Requirement

Only Admin, Operator and Power User level users have access to these commands.

### Example

Inform the switch of the controller whose IP address is 192.168.1.1:

```
Switch (config)# controller inform-url 192.168.1.1
```



## 5.14 reset

### Description

The **reset** command is used to reset the switch's software. After resetting, all configuration of the switch will restore to the factory defaults and your current settings will be lost.

### Syntax

```
reset [ except-ip ]
```

### Parameter

**except-ip** — Maintain the IP address when resetting the switch.

### Command Mode

Privileged EXEC Mode

### Privilege Requirement

Only Admin level users have access to these commands.

### Example

Reset all settings of the switch except its IP address:

```
Switch # reset except-ip
```

## 5.15 service reset-disable

### Description

The **service reset-disable** command is used to disable the reset function of the console port or reset button. To enable the reset function, use **no service reset-disable** command. By default, the reset function is enabled.

### Syntax

```
service reset-disable  
no service reset-disable
```

### Command Mode

Global Configuration Mode

### Privilege Requirement

Only Admin level users have access to these commands.

### Example

Disable the reset function of console port or reset button:

```
Switch (config)# service reset-disable
```

## 5.16 reboot

### Description

The **reboot** command is used to reboot the Switch. To avoid damage, please don't turn off the device while rebooting.

### Syntax

```
reboot
```

### Command Mode

Privileged EXEC Mode

### Privilege Requirement

Only Admin level users have access to these commands.

### Example

Reboot the switch:

```
Switch # reboot
```

## 5.17 reboot-schedule

### Description

This **reboot-schedule** command is used to configure the switch to reboot at a certain time point. To delete the reboot schedule settings, please use the **reboot-schedule cancel** command.

### Syntax

```
reboot-schedule at time [date] [save_before_reboot]
```

```
reboot-schedule in interval [save_before_reboot]
```

```
reboot-schedule cancel
```

### Parameter

*time* — Specify the time point for the switch to reboot, in the format of hh:mm.

*date* — Specify the date for the switch to reboot, in the format of DD:MM:YYYY. The date should be within 30 days.

**save\_before\_reboot** — Save the configuration file before the switch reboots.

*interval* — Specify a time period after which the switch reboots. It ranges from 1 to 43200 minutes.

**cancel** — Delete the reboot schedule settings.

## Command Mode

Global Configuration Mode

## Privilege Requirement

Only Admin level users have access to these commands.

## User Guidelines

In the command **reboot-schedule at** *time* [ *date* ] [ **save\_before\_reboot** ], if no date is specified and the time you set here is later than the time that this command is executed, the switch will reboot later that day; otherwise the switch will reboot at the time point the next day.

## Example

Specify the switch to save the configuration files and reboot in 200 minutes:

```
Switch (config)# reboot-schedule in 200 save_before_reboot
```

# 5.18 copy running-config startup-config

## Description

The **copy running-config startup-config** command is used to save the current settings.

## Syntax

```
copy running-config startup-config
```

## Command Mode

Privileged EXEC Mode

## Privilege Requirement

Only Admin and Operator level users have access to these commands.

## Example

Save current settings:

```
Switch # copy running-config startup-config
```

## 5.19 copy startup-config tftp

### Description

The **copy startup-config tftp** command is used to backup the configuration file to TFTP server.

### Syntax

```
copy startup-config tftp ip-address ip-addr filename name
```

### Parameter

*ip-addr*—— IP Address of the TFTP server. Both IPv4 and IPv6 addresses are supported, for example 192.168.0.1 or fe80::1234.

*name*—— Specify the name for the configuration file which would be backup.

### Command Mode

Privileged EXEC Mode

### Privilege Requirement

Only Admin and Operator level users have access to these commands.

### Example

Backup the configuration files to TFTP server with the IP 192.168.0.148 and name this file config.cfg:

```
Switch # copy startup-config tftp ip-address 192.168.0.148 filename config
```

Backup the configuration files to TFTP server with the IP fe80::1234 and name this file config.cfg:

```
Switch # copy startup-config tftp ip-address fe80::1234 filename config
```

## 5.20 copy tftp startup-config

### Description

The **copy tftp startup-config** command is used to download the configuration file to the switch from TFTP server.

### Syntax

```
copy tftp startup-config ip-address ip-addr filename name
```

### Parameter

*ip-addr*—— IP Address of the TFTP server. Both IPv4 and IPv6 addresses are supported, for example 192.168.0.1 or fe80::1234.

*name*—— Specify the name for the configuration file which would be downloaded.

### Command Mode

Privileged EXEC Mode

### Privilege Requirement

Only Admin level users have access to these commands.

### Example

Download the configuration file named as config.cfg to the switch from TFTP server with the IP 192.168.0.148:

```
Switch # copy tftp startup-config ip-address 192.168.0.148 filename config
```

Download the configuration file named as config.cfg to the switch from TFTP server with the IP fe80::1234

```
Switch # copy tftp startup-config ip-address fe80::1234 filename config
```

## 5.21 copy backup-config tftp

### Description

The **copy backup-config tftp** command is used to export the backup configuration file of the switch to TFTP server.

### Syntax

```
copy backup-config tftp ip-address ip-addr filename name
```

### Parameter

*ip-addr*—— IP Address of the TFTP server. Both IPv4 and IPv6 addresses are supported, for example 192.168.0.1 or fe80::1234.

*name*—— Specify the name for the configuration file which would be exported.

### Command Mode

Privileged EXEC Mode

### Privilege Requirement

Only Admin level users have access to these commands.

### Example

Export the backup configuration file of the switch to the TFTP server with the IP 192.168.0.148 and name the file config.cfg:

```
Switch # copy backup-config tftp ip-address 192.168.0.148 filename config
```

## 5.22 copy backup-config startup-config

### Description

The **copy backup-config startup-config** command is used to replace the startup configuration file using the backup configuration file.

### Syntax

```
copy backup-config startup-config
```

### Command Mode

Privileged EXEC Mode

### Privilege Requirement

Only Admin level users have access to these commands.

### Example

Replace the startup configuration file using the backup configuration file.:

```
Switch # copy backup-config startup-config
```

## 5.23 copy running-config backup-config

### Description

The **copy running-config backup-config tftp** command is used to save the current running configuration as the backup configuration file.

### Syntax

```
copy running-config backup-config
```

### Command Mode

Privileged EXEC Mode

### Privilege Requirement

Only Admin level users have access to these commands.

### Example

Save the current running configuration as the backup configuration file.

```
Switch # copy running-config backup-config
```

## 5.24 copy tftp backup-config

### Description

The **copy tftp backup-config** command is used to download the backup configuration file from a TFTP server.

### Syntax

**Copy tftp backup-config ip-address *ip-addr* filename *name***

### Parameter

*ip-addr*—— IP Address of the TFTP server. Both IPv4 and IPv6 addresses are supported, for example 192.168.0.1 or fe80::1234.

*name*—— Specify the name for the configuration file which would be downloaded.

### Command Mode

Privileged EXEC Mode

### Privilege Requirement

Only Admin level users have access to these commands.

### Example

Download the configuration file named config.cfg from the TFTP server with the IP 192.168.0.148:

```
Switch # copy tftp backup-config ip-address 192.168.0.148 filename config
```

## 5.25 boot application

### Description

The **boot application** command is used to configure the image file as startup image or backup image.

### Syntax

**boot application filename { image1 | image 2 } { startup | backup }**

**no boot application**

### Parameter

image1 | image2 —— Specify the image file to be configured. By default, the image1.bin is the startup image and the image2.bin is the backup image.

startup | backup — Specify the property of the image, either startup image or backup image.

### Command Mode

Global Configuration Mode

### Privilege Requirement

Only Admin level users have access to these commands.

### Example

Configure the image2.bin as the startup image:

```
Switch (config)# boot application filename image2 startup
```

## 5.26 boot config

### Description

The **boot config** command is used to configure the configuration file as startup configuration or backup configuration.

### Syntax

```
boot config filename { config1 | config 2 } { startup | backup }  
no boot application
```

### Parameter

config1 | config2 — Specify the configuration file to be configured. By default, the config1.cfg is the startup image and the config2.cfg is the backup image.

startup | backup — Specify the property of the configuration.

### Command Mode

Global Configuration Mode

### Privilege Requirement

Only Admin level users have access to these commands.

### Example

Configure the config2.cfg as the startup image:

```
Switch (config)# boot config filename config2 startup
```



## 5.27 remove backup-image

### Description

The **remove backup-image** command is used to delete the backup-image.

### Syntax

```
remove backup-image
```

### Command Mode

Privileged EXEC Mode

### Privilege Requirement

Only Admin level users have access to these commands.

### Example

Delete the backup image file:

```
Switch # remove backup-image
```

## 5.28 firmware upgrade

### Description

The **firmware upgrade** command is used to upgrade the switch's backup image file via the TFTP server. The uploaded firmware file will take place of the Backup Image, and user can choose whether to reboot the switch with the Backup Image.

### Syntax

```
firmware upgrade tftp ip-address ip-addr filename name
```

### Parameter

*ip-addr* — IP Address of the TFTP server. Both IPv4 and IPv6 addresses are supported, for example 192.168.0.1 or fe80::1234.

*name* — Specify the name of the desired firmware file.

### Command Mode

Privileged EXEC Mode

### Privilege Requirement

Only Admin level users have access to these commands.

## Example

Upgrade the switch's backup image file with the file `firmware.bin` in the TFTP server with the IP address `192.168.0.148`, and reboot the switch with this firmware:

```
Switch # firmware upgrade tftp ip-address 192.168.0.148 filename
firmware.bin

It will only upgrade the backup image. Continue? (Y/N):y

Operation OK!

Reboot with the backup image? (Y/N): y
```

Upgrade the switch's backup image file with the file `firmware.bin` in the TFTP server with the IP address `fe80::1234`, but do not reboot the switch:

```
Switch # firmware upgrade tftp ip-address fe80::1234 filename
firmware.bin

It will only upgrade the backup image. Continue? (Y/N):y

Operation OK!

Reboot with the backup image? (Y/N): n
```

## 5.29 mcu-firmware unit upgrade

(Only for Certain Devices)

### Description

The **mcu-firmware unit upgrade** command is used to upgrade the switch's MCU-firmware online.

### Syntax

```
mcu-firmware unit {unit id} type {mcu-type} upgrade
```

### Parameter

*unit id*— Stack unit ID, ranging from 1 to 4.

*mcu-type*— MCU device type, which can be `pse`, `crps`, `fan`, `monitor`.

### Command Mode

None

### Privilege Requirement

Only Admin, Operator and Power User level users have access to these commands.

## Example

Upgrade the switch's MCU-firmware online:

```
Switch#mcu-firmware unit 1 type pse upgrade
```

## 5.30 mcu-firmware type (Only for Certain Devices)

### Description

The **mcu-firmware type** command is used to display the MCU version information.

### Syntax

```
mcu-firmware type {mcu-type} version
```

### Parameter

*mcu-type*— MCU device type, which can be pse, crps, fan, monitor.

### Command Mode

None

### Privilege Requirement

Only Admin, Operator and Power User level users have access to these commands.

### Example

Upgrade the switch's MCU-firmware online:

```
Switch#mcu-firmware unit 1 type pse upgrade
```

## 5.31 boot autoinstall start



**Note:** This command is only available on certain devices.

### Description

The **boot autoinstall start** command is used to start Auto Install function. To stop the Auto Install function, use **no boot autoinstall start**.

### Syntax

```
boot autoinstall start
```

```
no boot autoinstall start
```

### Command Mode

Global Configuration Mode

## Privilege Requirement


Only Admin level users have access to these commands.

## Example

Start Auto Install function:

```
Switch(config)# boot autoinstall start
```

## 5.32 boot autoinstall persistent-mode

 **Note:** This command is only available on certain devices.

### Description

The **boot autoinstall persistent-mode** command is used to start Auto Install function to next reboot cycle. To disable persistent mode, use **no boot autoinstall persistent-mode**.

### Syntax

```
boot autoinstall persistent-mode
```

```
no boot autoinstall persistent-mode
```

### Command Mode

Global Configuration Mode

## Privilege Requirement


Only Admin level users have access to these commands.

## Example

Start Auto Install function:

```
Switch(config)# boot autoinstall persistent-mode
```

## 5.33 boot autoinstall auto-save

 **Note:** This command is only available on certain devices.

### Description

The **boot autoinstall auto-save** command is used to automatically save the new configuration file that was downloaded by Auto Install function to start-up configuration file Auto Install. To disable auto-save configuration feature use **no boot autoinstall auto-save**.

## Syntax

**boot autoinstall auto-save**

**no boot autoinstall auto-save**

## Command Mode

Global Configuration Mode

## Privilege Requirement

Only Admin level users have access to these commands.

## Example

Configure Auto Install function to auto-save new configuration file to start-up configuration file:

```
Switch(config)# boot autoinstall auto-save
```

# 5.34 boot autoinstall auto-reboot



**Note:** This command is only available on certain devices.

## Description

The **boot autoinstall auto-reboot** command is used to automatically reboot the switch after Auto Install function is completed successfully. To disable auto-reboot feature use **no boot autoinstall auto-reboot**.

## Syntax

**boot autoinstall auto-reboot**

**no boot autoinstall auto-reboot**

## Command Mode

Global Configuration Mode

## Privilege Requirement

Only Admin level users have access to these commands.

## Example

Configure the switch to auto reboot after Auto Install function completed successfully:

```
Switch(config)# boot autoinstall auto-reboot
```

## 5.35 boot autoinstall retry-count



**Note:** This command is only available on certain devices.

### Description

The **boot autoinstall retry-count** command is used to configure retry count when Auto Install function uses TFTP to download configuration files in a cycle of Auto Install process. To set retry count to default value use **no boot autoinstall retry-count**.

### Syntax

```
boot autoinstall retry-count count  
no boot autoinstall retry-count
```

### Parameter

*count*— The count of retrying auto install. The value ranges from 1 to 3.

### Command Mode

Global Configuration Mode

### Privilege Requirement

Only Admin level users have access to these commands.

### Example

Configure TFTP retry 2 times when download files failed:

```
Switch(config)# boot autoinstall retry-count 2
```

## 5.36 show boot autoinstall



**Note:** This command is only available on certain devices.

### Description

The **show boot autoinstall** command is used to display the configuration of Auto Install function.

### Syntax

```
show boot autoinstall
```

### Command Mode

Privileged EXEC Mode and Any Configuration Mode

### Privilege Requirement

None.

## Example

Display the configuration of Auto Install function:

```
Switch# show boot autoinstall
```

## 5.37 show boot autoinstall downloaded-config



**Note:** This command is only available on certain devices.

### Description

The **show boot autoinstall downloaded-config** command is used to display the configuration file which downloaded by Auto Install.

### Syntax

```
show boot autoinstall downloaded-config
```

### Command Mode

Privileged EXEC Mode and Any Configuration Mode

### Privilege Requirement

None.

### Example

Display the configuration file which downloaded by Auto Install:

```
Switch# show boot autoinstall downloaded-config
```

## 5.38 ping

### Description

The **ping** command is used to test the connectivity between the switch and one node of the network.

### Syntax

```
ping [ip | ipv6] { ip_addr } [-n count] [-l size] [-i interval]
```

### Parameter

*ip* — The type of the IP address for ping test should be IPv4.

*ipv6* — The type of the IP address for ping test should be IPv6.

*ip\_addr* — The IP address of the destination node for ping test. If the parameter *ip/ipv6* is not selected, both IPv4 and IPv6 addresses are supported, for example 192.168.0.100 or fe80::1234.

**-n count** — The amount of times to send test data during Ping testing. It ranges from 1 to 10. By default, this value is 4.

**-l size** — The size of the sending data during ping testing. It ranges from 1 to 1500 bytes. By default, this value is 64.

**-i interval** — The interval to send ICMP request packets. It ranges from 100 to 1000 milliseconds. By default, this value is 1000.

## Command Mode

Privileged EXEC Mode

## Privilege Requirement

None.

## Example

To test the connectivity between the switch and the network device with the IP 192.168.0.131, please specify the *count* (-l) as 512 bytes and *count* (-i) as 1000 milliseconds. If there is not any response after 8 times' Ping test, the connection between the switch and the network device is failed to establish:

```
Switch # ping 192.168.0.131 -n 8 -l 512
```

To test the connectivity between the switch and the network device with the IP fe80::1234, please specify the *count* (-l) as 512 bytes and *count* (-i) as 1000 milliseconds. If there is not any response after 8 times' Ping test, the connection between the switch and the network device is failed to establish:

```
Switch # ping fe80::1234 -n 8 -l 512
```

## 5.39 tracert

### Description

The **tracert** command is used to test the connectivity of the gateways during its journey from the source to destination of the test data.

### Syntax

```
tracert [ ip | ipv6 ] ip_addr [ maxHops ]
```

### Parameter

*ip* — The type of the IP address for tracert test should be IPv4.

*ipv6* — The type of the IP address for tracert test should be IPv6.



*ip\_addr*— The IP address of the destination device. If the parameter *ip/ipv6* is not selected, both IPv4 and IPv6 addresses are supported, for example 192.168.0.100 or fe80::1234.

*maxHops*— The maximum number of the route hops the test data can pass through. It ranges from 1 to 30. By default, this value is 4.

## Command Mode

Privileged EXEC Mode

## Privilege Requirement

Only Admin, Operator and Power User level users have access to these commands.

## Example

Test the connectivity between the switch and the network device with the IP 192.168.0.131. If the destination device has not been found after 20 *maxHops*, the connection between the switch and the destination device is failed to establish:

```
Switch # tracert 192.168.0.131 20
```

Test the connectivity between the switch and the network device with the IP fe80::1234. If the destination device has not been found after 20 *maxHops*, the connection between the switch and the destination device is failed to establish:

```
Switch # tracert fe80::1234 20
```

## 5.40 show system-info

### Description

The **show system-info** command is used to display System Description, Device Name, Device Location, System Contact, Hardware Version, Firmware Version, System Time, Run Time and so on.

### Syntax

```
show system-info
```

### Command Mode

Privileged EXEC Mode and Any Configuration Mode

### Privilege Requirement

None.

## Example

Display the system information:

```
Switch # show system-info
```

## 5.41 show image-info

### Description

The **show image-info** command is used to display the information of image files in the system.

### Syntax

```
show image-info
```

### Command Mode

Privileged EXEC Mode and Any Configuration Mode

### Privilege Requirement

Only Admin level users have access to these commands.

## Example

Display the system image files' information:

```
Switch# show image-info
```

## 5.42 show boot

### Description

The **show boot** command is used to display the boot configuration of the system.

### Syntax

```
show boot
```

### Command Mode

Privileged EXEC Mode and Any Configuration Mode

### Privilege Requirement

Only Admin level users have access to these commands.

## Example

Display the system boot configuration information:

```
Switch# show boot
```

## 5.43 show running-config

### Description

The **show running-config** command is used to display the current operating configurations of the whole system, a specified unit, or a specified port.

### Syntax

```
show running-config [unit {all | | [exclude keyword] [include keyword] |  
interface {fastEthernet |gigabitEthernet | ten-gigabitEthernet} port}]  
show running-config [all | | [exclude keyword] [include keyword] | interface  
{fastEthernet |gigabitEthernet | ten-gigabitEthernet} port]
```

### Parameter

*unit*— Specify the unit number of a switch to show the unit's operating configurations. By default, it is 1.

**all**— Display all the operating configurations of the whole system or a specified unit.

|— Enable filter to filtrate the configurations. You can use **exclude** and **include** to set the filter rule.

*keyword*— The filter conditions, such as interface, vlan, and user.

*port* — Specify the number of the port to show the port's operating configurations.

### Command Mode

Privileged EXEC Mode and Any Configuration Mode

### Privilege Requirement

Only Admin level users have access to these commands.

### Example

Display the current operating configurations only related to the user:

```
Switch# show running-config | include user
```

## 5.44 show startup-config

### Description

The **show startup-config** command is used to display the current configuration saved in the switch. These configuration settings will not be lost the next time you reboot the switch.

### Syntax

```
show startup-config
```

### Command Mode

Privileged EXEC Mode and Any Configuration Mode

### Privilege Requirement

Only Admin level users have access to these commands.

### Example

Display the saved configuration:

```
Switch# show startup-config
```

## 5.45 show system-time

### Description

The **show system-time** command is used to display the time information of the switch.

### Syntax

```
show system-time
```

### Command Mode

Privileged EXEC Mode and Any Configuration Mode

### Privilege Requirement

None.

### Example

Display the time information of the switch

```
Switch# show system-time
```

## 5.46 show system-time dst

### Description

The **show system-time dst** command is used to display the DST information of the switch.

### Syntax

```
show system-time dst
```

### Command Mode

Privileged EXEC Mode and Any Configuration Mode

### Privilege Requirement

None.

### Example

Display the DST information of the switch

```
Switch# show system-time dst
```

## 5.47 show system-time ntp

### Description

The **show system-time ntp** command is used to display the NTP mode configuration information.

### Syntax

```
show system-time ntp
```

### Command Mode

Privileged EXEC Mode and Any Configuration Mode

### Privilege Requirement

None.

### Example

Display the NTP mode configuration information of the switch:

```
Switch# show system-time ntp
```

## 5.48 show cable-diagnostics interface

### Description

The **show cable-diagnostics interface** command is used to display the cable diagnostics of the connected Ethernet Port., which facilitates you to check the connection status of the cable connected to the switch, locate and diagnose the trouble spot of the network.

### Syntax

```
show cable-diagnostics interface { fastEthernet port | gigabitEthernet port | ten-gigabitEthernet port }
```

### Parameter

*port*—— The number of the port which is selected for Cable test.

### Command Mode

Privileged EXEC Mode and Any Configuration Mode

### Privilege Requirement

None.

### Example

Show the cable-diagnostics of port 3:

```
Switch# show cable-diagnostics interface gigabitEthernet 1/0/3
```

## 5.49 show cpu-utilization

### Description

The **show cpu-utilization** command is used to display the system's CPU utilization in the last 5 seconds/1minute/5minutes.

### Syntax

```
show cpu-utilization
```

### Command Mode

Privileged EXEC Mode and Any Configuration Mode

### Privilege Requirement

None.

## Example

Display the CPU utilization information of the switch:

```
Switch# show cpu-utilization
```

## 5.50 show memory-utilization

### Description

The **show memory-utilization** command is used to display the current system's memory utilization in the last 5 seconds/1minute/5minutes.

### Syntax

```
show memory-utilization
```

### Command Mode

Privileged EXEC Mode and Any Configuration Mode

### Privilege Requirement

None.

## Example

Display the memory utilization information of the switch:

```
Switch# show memory-utilization
```

## 5.51 show controller



**Note:** This command is only available on certain devices.

### Description

The **show controller** command is used to display the current controller settings and status.

### Syntax

```
show controller
```

### Command Mode

Privileged EXEC Mode and Any Configuration Mode

### Privilege Requirement

None.

## Example

Display the current controller settings and status:

```
Switch# show controller
```

## 5.52 show temperature



**Note:** This command is only available on certain devices.

### Description

The **show temperature** command is used to display the temperature of switch.

### Syntax

```
show temperature
```

### Command Mode

Privileged EXEC Mode and Any Configuration Mode

### Privilege Requirement

None.

## Example

Display the temperature information of the switch:

```
Switch-DC# show temperature
```

## 5.53 show voltage



**Note:** This command is only available on certain devices.

### Description

The **show voltage** command is used to display the voltage of DC power board.

### Syntax

```
show voltage
```

### Command Mode

Privileged EXEC Mode and Any Configuration Mode



## Privilege Requirement

None.

## Example

Display the voltage information of the switch:

```
Switch # show voltage
```

## 5.54 clear config interface

### Description

The **clear config interface** command is used to clear all configurations of a specified port.

### Syntax

```
clear config interface [fastEthernet | gigabitEthernet | two-gigabitEthernet  
| ten-gigabitEthernet | port-channel] port
```

### Parameter

*port*—— The port number.

### Command Mode

Privileged EXEC Mode and Any Configuration Mode

### Privilege Requirement

Only Admin level users have access to these commands.

### Example

Clear all configurations of gigabitEthernet port 1/0/3:

```
Switch(config)# clear config interface gigabitEthernet 1/0/3
```

## 5.55 power backup unit (Only for Certain Devices)

### Description

The **power backup unit** command is used to configure the power backup mode.

### Syntax

```
power backup unit {unit id} {power} mode {mode}
```

### Parameter

*unit id*—— Stack unit ID, ranging from 1-4.

*power*— power supply module number.

*mode*— Power backup mode

### Command Mode

Global Configuration Mode

### Privilege Requirement

Only Admin and Operator level users have access to these commands.

### Example

Configure the power backup mode of stack unit 1:

```
Switch(config)#power backup unit 1 pwr1 mode enable
```

## 5.56 show power (Only for Certain Devices)

### Description

The **show power** command is used to display the power details.

### Syntax

```
show power [detail]
```

### Command Mode

Privileged EXEC Mode and Any Configuration Mode

### Privilege Requirement

None.

### Example

Display the power details:

```
Switch#show power
```

# Chapter 6 File System Configuration Commands

(Only for Certain Devices)

File System Commands can be used to configure the File System.

## 6.1 copy

### Description

The **copy** command is used to copy the specified file.

### Syntax

```
copy {flash|usbflash1|usbflash2} {filename} {destination}
```

### Parameter

flash|usbflash1|usbflash2 — The flash type of the source file.

filename — File name.

destination — Copied file path.

### Command Mode

Privileged EXEC Mode and Any Configuration Mode

### Privilege Requirement

Only Admin, Operator and Power User level users have access to these commands.

### Example

Copy the specified file:

```
Switch#copy flash test.txt usbflash1
```

## 6.2 cd

### Description

The **cd** command is used to change the current file path.

### Syntax

```
cd {filename|flash|usbflash1|usbflash2} [filename]
```

### Parameter

filename|flash|usbflash1|usbflash2 — The path that needs to be switched. If you enter filename, the file will be found in the current path by default.

filename — Specify the file in the corresponding flash.

### Command Mode

Privileged EXEC Mode and Any Configuration Mode

### Privilege Requirement

Only Admin, Operator and Power User level users have access to these commands.

### Example

Change the current file path:

```
Switch# cd usbflash1 test
```

## 6.3 dir

### Description

The **dir** command is used to list files and subdirectories contained in the specified working directory.

### Syntax

```
dir [flash|usbflash1|usbflash2] [filename]
```

### Parameter

flash|usbflash1|usbflash2 — Specify path.

filename — Specify the file in the corresponding flash.

### Command Mode

Privileged EXEC Mode and Any Configuration Mode

### Privilege Requirement

Only Admin, Operator and Power User level users have access to these commands.

### Example

List files and subdirectories contained in the specified working directory:

```
Switch#dir flash
```

## 6.4 pwd

### Description

The **pwd** command is used to display the absolute path name of the current working directory.

## Syntax

`pwd`

## Command Mode

Privileged EXEC Mode and Any Configuration Mode

## Privilege Requirement

Only Admin, Operator and Power User level users have access to these commands.

## Example

Display the absolute path name of the current working directory:

```
Switch#pwd
```

# 6.5 rename

## Description

The **rename** command is used to rename a file.

## Syntax

```
rename {srcFilename} {dstFilename}
```

## Parameter

srcFilename — Source file name.

dstFilename — Renamed file name.

## Command Mode

Privileged EXEC Mode and Any Configuration Mode

## Privilege Requirement

Only Admin, Operator and Power User level users have access to these commands.

## Example

Rename a file:

```
Switch#rename test1 test2
```

# 6.6 delete

## Description

The **delete** command is used to delete a file.

## Syntax

**delete** {filename|flash|usbflash1|usbflash2} [filename]

## Parameter

filename|flash|usbflash1|usbflash2 — The file that needs to be deleted. If you enter filename, the file will be found in the current working path by default.

filename — Specify the file in the corresponding flash.

## Command Mode

Privileged EXEC Mode and Any Configuration Mode

## Privilege Requirement

Only Admin, Operator and Power User level users have access to these commands.

## Example

Delete a file:

```
Switch# delete text.txt
```

# 6.7 ftp

## Description

The **ftp** command is used to enter the FTP (File Transfer Protocol) view.

## Syntax

**ftp**

## Command Mode

Privileged EXEC Mode and Any Configuration Mode

## Privilege Requirement

Only Admin, Operator and Power User level users have access to these commands.

## Example

Enter the FTP view:

```
Switch#ftp
```

## 6.8 open

### Description

The **open** command is used to connect to FTP server.

### Syntax

```
open [ipv6] {hostIp}
```

### Parameter

ipv6—— Specify the FTP server type as IPv6.

hostIp —— FTP server IP.

### Command Mode

FTP Configuration Mode

### Privilege Requirement

Only Admin, Operator and Power User level users have access to these commands.

### Example

Connect to FTP server:

```
Switch(ftp)#open 192.168.0.146
```

## 6.9 put

### Description

The **put** command is used to upload files to FTP server.

### Syntax

```
put {srcFilename} {dstFilename}
```

### Parameter

srcFilename —— Source file name.

dstFilename —— Destination file name.

### Command Mode

FTP Configuration Mode

### Privilege Requirement

Only Admin, Operator and Power User level users have access to these commands.

## Example

Upload files to FTP server:

```
Switch(ftp)#put src.c dst.c
```

## 6.10 get

### Description

The **get** command is used to download files from FTP server.

### Syntax

```
get {srcFilename} {dstFilename}
```

### Parameter

srcFilename — Source file name.

dstFilename — Destination file name.

### Command Mode

FTP Configuration Mode

### Privilege Requirement

Only Admin, Operator and Power User level users have access to these commands.

## Example

Download files from FTP server:

```
Switch(ftp)#get src.c dst.c
```

## 6.11 close

### Description

The **close** command is used to close current FTP connection.

### Syntax

```
close
```

### Command Mode

Privileged EXEC Mode and Any Configuration Mode

### Privilege Requirement

Only Admin, Operator and Power User level users have access to these commands.



## Example

Close current FTP connection:

```
Switch#close
```

# Chapter 7 Management Port Configuration

## Commands (Only for Certain Devices)

### 7.1 management-port protocol

#### Description

The **management-port protocol** command is used to enable or disable the IPv4 DHCP function on the management port.

#### Syntax

```
management-port protocol {dhcp|none}
```

#### Parameter

*dhcp*——Enable the DHCP function

*none*—— Disable the DHCP function

#### Command Mode

Global Configuration Mode

#### Privilege Requirement

Only Admin, Operator and Power User level users have access to these commands.

#### Example

Enable the IPv4 DHCP function on the management port:

```
Switch(config)#management-port protocol dhcp
```

### 7.2 management-port ip

#### Description

The **management-port ip** command is used to configure the IPv4 address of the management port. To delete the address, please use the **no management-port ip** command.

#### Syntax

```
management-port ip {ip-addr}{mask}
```

```
no management-port ip
```

#### Parameter

*ip-addr*—— IPv4 address

*mask*— IP mask

## Command Mode

Global Configuration Mode

## Privilege Requirement

Only Admin, Operator and Power User level users have access to these commands.

## Example

Configure the IPv4 address of the management port:

```
Switch(config)#management-port ip 192.168.10.1 255.255.255.0
```

# 7.3 management-port ipv6 enable

## Description

The **management-port ipv6 enable** command is used to enable the management-port ipv6 function. To disable the function, please use the **no management-port ipv6 enable** command.

## Syntax

**management-port ipv6 enable**

**no management-port ipv6 enable**

## Command Mode

Global Configuration Mode

## Privilege Requirement

Only Admin, Operator and Power User level users have access to these commands.

## Example

Enable the management-port ipv6 function:

```
Switch(config)#management-port ipv6 enable
```

## 7.4 management-port ipv6 address

### Description

The **management-port ipv6 address** command is used to configure the IPv6 address of the management port. To delete the address, please use the **no management-port ipv6 address** command.

### Syntax

```
management-port ipv6 address {ipv6-addr} [eui64]
```

```
no management-port ipv6 address {ipv6-addr} [eui64]
```

### Parameter

*ipv6-addr* — IPv6 address, you need to specify the prefix length.

*eui64* — Create the address in eui64 mode.

### Command Mode

Global Configuration Mode

### Privilege Requirement

Only Admin, Operator and Power User level users have access to these commands.

### Example

Configure the IPv6 address of the management port:

```
Switch(config)#management-port ipv6 address 2001::1/64 eui64
```

## 7.5 show management-port

### Description

The **show management-port** command is used to display the configuration information of the management port.

### Syntax

```
show management-port
```

### Command Mode

Privileged EXEC Mode and Any Configuration Mode

### Privilege Requirement

None.

## Example

Display the configuration information of the management port:

```
Switch# show management-port
```

## Chapter 8 EEE Configuration Commands

EEE (Energy Efficient Ethernet) is used to save power consumption of the switch during periods of low data activity. You can simply enable this feature on ports to allow power reduction.

### 8.1 eee

#### Description

The **eee** command is used to enable EEE on the port. To disable EEE on the port, please use **no eee** command.

#### Syntax

**eee**

**no eee**

#### Command Mode

Interface Configuration Mode

#### Privilege Requirement

Only Admin, Operator and Power User level users have access to these commands.

#### Example

Enable EEE on port 1/0/1:

```
Switch(config)#interface gigabitEthernet 1/0/1
```

```
Switch(config-if)#eee
```

### 8.2 show interface eee

#### Description

The **show interface eee** command is used to display the EEE configuration on each port.

#### Syntax

```
show interface eee [ fastEthernet port | gigabitEthernet port |  
two-gigabitEthernet port | ten-gigabitEthernet port ]
```

#### Command Mode

Privileged EXEC Mode and Any Configuration Mode

## Privilege Requirement

None.

## Example

Display the EEE configuration of each port

```
Switch# show interface eee
```

# Chapter 9 SDM Template Commands

This chapter describes how to configure the Switch Database Management (SDM) templates to allocate hardware resources on the switch for different uses.

## 9.1 sdm prefer

### Description

The **sdm prefer** command is used to specify the SDM template to be used. The SDM template is used to allocate system resources to best support the features being used in your application. To return to use the default template, please use the **sdm prefer default** command. The template change will take effect after a reboot.

### Syntax

```
sdm prefer { default | enterpriseV4 | enterpriseV6 | enterpriseMix |  
pca-default }
```

### Parameter

default — Specify the SDM template used in the switch as “default”.

enterpriseV4 — Specify the SDM template used in the switch as “enterpriseV4”.

enterpriseV6 — Specify the SDM template used in the switch as “enterpriseV6”.

enterpriseMix — Specify the SDM template used in the switch as “enterpriseMix”, which provides both IPv4/IPv6-ACL support and IMPBv4/v6 support.

pca-default — Specify the SDM template used in the switch as “pca-default”, which provides packet-content-ACL support.

### Command Mode

Global Configuration Mode

### Privilege Requirement

Only Admin level users have access to these commands.



## User Guidelines

Some models may not support **pca-default** template. Changes to the SDM preferences cannot take effect until reboot the switch.

## Example

Specify the SDM template as enterpriseV4:

```
Switch(config)# sdm prefer enterpriseV4
```

# 9.2 show sdm prefer

## Description

The **show sdm prefer** command is used to display resource allocation of the current SDM template in use, or the SDM templates that can be used.

## Syntax

```
show sdm prefer { used | default | enterpriseV4 | enterpriseV6 | enterpriseMix  
| pca-default }
```

## Parameter

**used** — Display the resource allocation of the template currently in use, and the template that will become active after a reboot.

**default** — Display the resource allocation of the default template.

**enterpriseV4** — Display the resource allocation of the enterpriseV4 template.

**enterpriseV6** — Display the resource allocation of the enterpriseV6 template.

**enterpriseMix** — Specify the SDM template used in the switch as "enterpriseMix", which provides both IPv4/IPv6-ACL support and IMPBv4/v6 support.

**pca-default** — Specify the SDM template used in the switch as "pca-default", which provides packet-content-ACL support.

## Command Mode

Privileged EXEC Mode and Any Configuration Mode

## Privilege Requirement

Only Admin level users have access to these commands.

## Example

Display the resource allocation of the template currently in use, and the template that will become active after a reboot:

```
Switch(config)#show sdm prefer used
```

# Chapter 10 Time Range Commands

With this feature, you can configure a time range and bind it to a PoE port or an ACL rule.

## 10.1 time-range

### Description

The **time-range** command is used to create time-range entry for the switch and enter Time-range Create Configuration Mode. After a time-range entry is created, you need to specify the date and time. A time-range can implement multiple time-ranges simultaneously as long as they do not conflict with each other. To delete the corresponding time-range configuration, please use **no time-range** command.

### Syntax

**time-range** *name*

**no time-range** *name*

### Command Mode

Global Configuration Mode

### Parameter

*name*—— The time-range name, ranging from 1 to 16 characters.

### Privilege Requirement

Only Admin, Operator and Power User level users have access to these commands.

### Example

Create a time-range named "tRange1" for the switch:

```
Switch(config)# time-range tRange1
```

## 10.2 absolute

### Description

The **absolute** command is used to create an absolute time-range for the time-range of the switch. To delete the corresponding absolute time-range configuration, please use **no absolute** command.

## Syntax

**absolute from** *start-date* **to** *end-date*

**no absolute** [*index*]

## Parameter

*start-date* — The start date in Absoluteness Mode, in the format of MM/DD/YYYY.

*end-date* — The end date in Absoluteness Mode, in the format of MM/DD/YYYY.

## Command Mode

Time-Range Create Configuration Mode

## Privilege Requirement

Only Admin, Operator and Power User level users have access to these commands.

## Example

Create an absolute time-range for the switch and specify the date extending from May 5th, 2017 through Oct. 5th, 2017:

```
Switch(config)#time-range tRange1
```

```
Switch(config-time-range)#absolute from 05/05/2017 to 10/05/2017
```

# 10.3 periodic

## Description

The **periodic** command is used to create a periodic mode time-range for the time-range of the switch. To delete the corresponding periodic mode time-range configuration, please use **no periodic** command.

## Syntax

**periodic start** *start-time* **end** *end-time* **day-of-the-week** *week-day*

**no periodic** [*index*]

## Parameter

*start-time* — Specify the start time in the format of HH:MM

*end-time* — Specify the end time in the format of HH:MM

*week-day* — In the format of 1-3, 6, daily, off-day, or working-day. For example, 1-3,6 represents Monday, Tuesday, Wednesday and Saturday; daily represents every day; off-day represents the weekends; working-day represents the working days.

## Command Mode

Time-Range Create Configuration Mode

## Privilege Requirement

Only Admin, Operator and Power User level users have access to these commands.

## Example

Configure the time-range tSeg1 with time from 8:30 to 12:00 at weekends:

```
Switch(config)#time-range tSeg1
Switch(config-time-range)#periodic start 08:30 end 12:00
day-of-the-week 6-7
```

# 10.4 holiday (time-range mode)

## Description

The **holiday** command is used to create holiday mode time-range for the time-range of the switch. When the holiday which is excluded from time-range occurs, the switch will not supply power.

## Syntax

```
holiday { exclude | include }
```

## Parameter

exclude — The time range will not take effect on holiday.

include — The time range will take effect on holiday.

## Command Mode

Time-Range Create Configuration Mode

## Privilege Requirement

Only Admin, Operator and Power User level users have access to these commands.

## Example

Create a time-range entry named "tRange3" and configure time-range to exclude the holiday:

```
Switch(config)#time-range tRange3
Switch(config-time-range)#holiday exclude
```

## 10.5 holiday

### Description

The **holiday** command is used to create holiday for the switch. To delete the corresponding holiday configuration, please use **no holiday** command.

### Syntax

**holiday** *name* **start-date** *start-date* **end-date** *end-date*

**no holiday** *name*

### Parameter

*name* — The holiday name, ranging from 1 to 16 characters.

*start-date* — The start date of the holiday, in the format of MM/DD, for instance, 05/01.

*end-date* — The end date of the holiday, in the format of MM/DD, for instance, 05/01.

### Command Mode

Global Configuration Mode

### Privilege Requirement

Only Admin, Operator and Power User level users have access to these commands.

### Example

Create a holiday named "holiday1" and configure the start date as October 1st and the end date as October 3rd:

```
Switch(config)# holiday holiday1 start-date 10/01 end-date 10/03
```

## 10.6 show holiday

### Description

The **show holiday** command is used to display the defined holiday.

### Syntax

**show holiday**

### Command Mode

Privileged EXEC Mode and Any Configuration Mode

### Privilege Requirement

None.

## Example

Display the defined holiday:

```
Switch# show holiday
```

# 10.7 show time-range

## Description

The **show time-range** command is used to display the defined time-range.

## Syntax

```
show time-range [ time-range-name ]
```

## Parameter

*time-range-name* — Specify the time range name with 1 to 16 characters.

## Command Mode

Privileged EXEC Mode and Any Configuration Mode

## Privilege Requirement

None.

## Example

Display the defined time-range:

```
Switch# show time-range
```

# Chapter 11 Port Configuration Commands

Ethernet Configuration Commands can be used to configure the Bandwidth Control, Negotiation Mode and Storm Control for Ethernet ports.

## 11.1 interface

### Description

The **interface** command is used to enter the Interface Configuration Mode and configure the corresponding port.

### Syntax

```
interface fastEthernet / gigabitEthernet / two-gigabitEthernet /  
ten-gigabitEthernet port Parameter
```

*fastEthernet port*—— The 100M Ethernet port number.

*gigabitEthernet port*—— The Gigabit Ethernet port number.

*ten-gigabitEthernet port*—— The 10-Gigabit Ethernet port number.

*two-gigabitEthernet port*—— The 2.5-Gigabit Ethernet port number.

*port-channel num*—— The Ethernet channel number.

### Command Mode

Global Configuration Mode

### Privilege Requirement

Only Admin, Operator and Power User level users have access to these commands.

### Example

To enter the Interface gigabitEthernet Configuration Mode and configure port 2:

```
Switch(config)# interface gigabitEthernet 1/0/2
```



## 11.2 interface range

### Description

The **interface range** command is used to enter the interface range Configuration Mode and configure multiple Ethernet ports at the same time.

### Syntax

```
interface range fastEthernet | gigabitEthernet | two-gigabitEthernet | ten-gigabitEthernet port-list
```

### Parameter

*fastEthernet port*—— The 100M Ethernet port number.

*gigabitEthernet port*—— The Gigabit Ethernet port number.

*ten-gigabitEthernet port*—— The 10-Gigabit Ethernet port number.

*two-gigabitEthernet port* —— The 2.5-Gigabit Ethernet port number.

*port-list*—— The list of Ethernet ports.

### Command Mode

Global Configuration Mode

### Privilege Requirement

Only Admin, Operator and Power User level users have access to these commands.

### User Guidelines

Command in the **Interface Range gigabitEthernet** Mode is executed independently on all ports in the range. It does not affect the execution on the other ports at all if the command results in an error on one port.

### Example

To enter the Interface range gigabitEthernet Configuration Mode, and configure ports 1, 2, 3, 6, 7 and 9 at the same time by adding them to one port-list:

```
Switch(config)# interface range gigabitEthernet 1/0/1-3,1/0/6-7,1/0/9
```

## 11.3 description

### Description

The **description** command is used to add a description to the Ethernet port. To clear the description of the corresponding port, please use **no description** command.

### Syntax

```
description string  
no description
```

### Parameter

*string*—— Content of a port description, ranging from 1 to 16 characters.

### Command Mode

Interface Configuration Mode (interface gigabitEthernet / interface range gigabitEthernet / interface port-channel / interface range port-channel)

### Privilege Requirement

Only Admin, Operator and Power User level users have access to these commands.

### Example

Add a description Port\_5 to port 1/0/5:

```
Switch(config)# interface gigabitEthernet 1/0/5  
Switch(config-if)# description Port_5
```

## 11.4 shutdown

### Description

The **shutdown** command is used to disable an Ethernet port. To enable this port again, please use **no shutdown** command.

### Syntax

```
shutdown  
no shutdown
```

## Command Mode

Interface Configuration Mode (interface gigabitEthernet / interface range gigabitEthernet / interface port-channel / interface range port-channel)

## Privilege Requirement

Only Admin, Operator and Power User level users have access to these commands.

## Example

Disable port 1/0/3:

```
Switch(config)# interface gigabitEthernet 1/0/3
Switch(config-if)# shutdown
```

# 11.5 flow-control

## Description

The **flow-control** command is used to enable the flow-control function for a port. To disable the flow-control function for this corresponding port, please use **no flow-control** command. With the flow-control function enabled, the Ingress Rate and Egress Rate can be synchronized to avoid packet loss in the network.

## Syntax

**flow-control**

**no flow-control**

## Command Mode

Interface Configuration Mode (interface gigabitEthernet / interface range gigabitEthernet / interface port-channel / interface range port-channel)

## Privilege Requirement

Only Admin and Operator level users have access to these commands.

## Example

Enable the flow-control function for port 1/0/3:

```
Switch(config)# interface gigabitEthernet 1/0/3
Switch(config-if)# flow-control
```

## 11.6 duplex

### Description

The **duplex** command is used to configure the Duplex Mode for an Ethernet port. To return to the default configuration, please use **no duplex** command.

### Syntax

**duplex** { auto | full | half }

**no duplex**

### Parameter

auto | full | half — The duplex mode of the Ethernet port. There are three options: auto-negotiation mode, full-duplex mode and half-duplex mode. By default, the Gigabit Ethernet port is auto-negotiation mode.

### Command Mode

Interface Configuration Mode (interface gigabitEthernet / interface range gigabitEthernet / interface port-channel / interface range port-channel)

### Privilege Requirement

Only Admin and Operator level users have access to these commands.

### Example

Configure the Duplex Mode as full-duplex for port 1/0/3:

```
Switch(config)# interface gigabitEthernet 1/0/3
```

```
Switch(config-if)# duplex full
```

## 11.7 jumbo-size

### Description

The **jumbo-size** command is used to specify the size of jumbo frames.

### Syntax

**jumbo-size** *size*

### Parameter

*size* — The value of jumbo frames. It ranges from 1518 to 9216 bytes, and the default is 1518 bytes.

### Command Mode

Global Configuration Mode

## Privilege Requirement

Only Admin, Operator and Power User level users have access to these commands.

## Example

Globally configure the size of jumbo frames as 9216:

```
Switch(config)# jumbo-size 9216
```

# 11.8 speed

## Description

The **speed** command is used to configure the Speed Mode for an Ethernet port. To return to the default configuration, please use **no speed** command.

## Syntax

```
speed { 10 | 100 | 1000 | 2500 | 5000 | 10000 | auto }
```

```
no speed
```

## Parameter

10 | 100 | 1000 | 2500 | 5000 | 10000 | auto — The speed mode of the Ethernet port. There are seven options: 10Mbps, 100Mbps, 1000Mbps, 2500Mbps, 5000Mbps, 10000Mbps and Auto negotiation mode (default).

## Command Mode

Interface Configuration Mode (interface fastEthernet | gigabitEthernet | two-gigabitEthernet | ten-gigabitEthernet / interface range fastEthernet | gigabitEthernet | two-gigabitEthernet | ten-gigabitEthernet / interface port-channel / interface range port-channel)

## Privilege Requirement

Only Admin and Operator level users have access to these commands.

## Example

Configure the Speed Mode as 100Mbps for port 1/0/3:

```
Switch(config)# interface gigabitEthernet 1/0/3
```

```
Switch(config-if)# speed 100
```

## 11.9 clear counters

### Description

The **clear counters** command is used to clear the statistics information of all the Ethernet ports and port channels.

### Syntax

**clear counters**

```
clear counters interface [ fastEthernet | gigabitEthernet |  
two-gigabitEthernet | ten-gigabitEthernet port ] [ port-channel  
port-channel-id]
```

### Parameter

*port*—— The Ethernet port number.

*port-channel-id*—— The ID of the port channel.

### Command Mode

Privileged EXEC Mode and Any Configuration Mode

### Privilege Requirement

Only Admin and Operator level users have access to these commands.

### Example

Clear the statistic information of all ports and port channels:

```
Switch(config)# clear counters
```

## 11.10 show fiber-ports



**Note:** This command is only available on certain devices.

### Description

The **show fiber-ports** command is used to display the information of all optical modules.

### Syntax

**show fiber-ports**

### Command Mode

Privileged EXEC Mode and Any Configuration Mode

### Privilege Requirement

None.

## Example

Display the information of all fiber ports:

```
Switch(config)# show fiber-ports
```

# 11.11 show interface status

## Description

The **show interface status** command is used to display the connection status of the Ethernet port/port channel.

## Syntax

```
show interface status [ fastEthernet port ] [ gigabitEthernet port ]  
[ two-gigabitEthernet port ] [ ten-gigabitEthernet port ] [ port-channel  
port-channel-id]
```

## Parameter

*port*—— The Ethernet port number.

*port-channel-id*—— The ID of the port channel..

## Command Mode

Privileged EXEC Mode and Any Configuration Mode

## Privilege Requirement

None.

## Example

Display the connection status of all ports and port channels:

```
Switch(config)# show interface status
```

Display the connection status of port 1/0/1:

```
Switch(config)# show interface status gigabitEthernet 1/0/1
```

# 11.12 show interface counters

## Description

The **show interface counters** command is used to display the statistics information of all ports/port channels.

## Syntax

```
show interface counters [ fastEthernet | gigabitEthernet |  
two-gigabitEthernet | ten-gigabitEthernet port ] [ port-channel  
port-channel-id]
```

## Parameter

*port*—— The Ethernet port number.

*port-channel-id*—— The ID of the port channel.

## Command Mode

Privileged EXEC Mode and Any Configuration Mode

## Privilege Requirement

None.

## Example

Display the statistics information of all Ethernet ports and port channels:

```
Switch(config)# show interface counters
```

Display the statistics information of port 1/0/2:

```
Switch(config)# show interface counters gigabitEthernet 1/0/2
```

# 11.13 show interface configuration

## Description

The **show interface configuration** command is used to display the configurations of all ports and port channels, including Port-status, Flow Control, Negotiation Mode and Port-description.

## Syntax

```
show interface configuration [ fastEthernet | gigabitEthernet |  
two-gigabitEthernet | ten-gigabitEthernet port ] [ port-channel  
port-channel-id]
```

## Parameter

*port*—— The Ethernet port number.

*port-channel-id*—— The ID of the port channel.

## Command Mode

Privileged EXEC Mode and Any Configuration Mode

## Privilege Requirement

None.

## Example

Display the configurations of all Ethernet ports and port channels:



```
Switch(config)# show interface configuration
```

Display the configurations of port 1/0/2:

```
Switch(config)# show interface configuration gigabitEthernet 1/0/2
```

# Chapter 12 Port Isolation Commands

Port Isolation provides a method of restricting traffic flow to improve the network security by forbidding the port to forward packets to the ports that are not on its forwarding port list.

## 12.1 port isolation

### Description

The **port isolation** command is used to configure the forward port/port channel list of a port/port channel, so that this port/port channel can only communicate with the ports/port channels on its list. To delete the corresponding configuration, please use **no port isolation** command.

### Syntax

```
port isolation { [ fa-forward-list fa-forward-list ] [ gi-forward-list gi-forward-list ] [ tw-forward-list tw-forward-list ] [ te-forward-list te-forward-list ] } [ po-forward-list po-forward-list ]
```

```
no port isolation
```

### Parameter

*fa-forward-list* / *gi-forward-list* / *tw-forward-list* / *te-forward-list* — The list of Ethernet ports.

*po-forward-list* — The list of port channels.

### Command Mode

Interface Configuration Mode (interface gigabitEthernet / interface range gigabitEthernet / interface port-channel / interface range port-channel)

### Privilege Requirement

Only Admin and Operator level users have access to these commands.

### Example

Set port 1, 2, 4 and port channel 2 to the forward list of port 1/0/5:

```
Switch(config)# interface gigabitEthernet 1/0/5
Switch(config-if)# port isolation gi-forward-list 1/0/1-2,1/0/4
po-forward-list 2
```

Set all Ethernet ports and port channels to forward list of port 1/0/2, namely restore to the default setting:

```
Switch(config)# interface gigabitEthernet 1/0/2
```

```
Switch(config-if)# no port isolation
```

## 12.2 show port isolation interface

### Description

The **show port isolation interface** command is used to display the forward port list of a port/port channel.

### Syntax

```
show port isolation interface [fastEthernet port | gigabitEthernet port | two-gigabitEthernet port | ten-gigabitEthernet port | port-channel port-channel-id]
```

### Parameter

*port* — The number of Ethernet port you want to show its forward port list, in the format of 1/0/2.

*port-channel-id* — The ID of port channel you want to show its forward port list, ranging from 1 to 6.

### Command Mode

Privileged EXEC Mode and Any Configuration Mode

### Privilege Requirement

None.

### Example

Display the forward-list of port 1/0/2:

```
Switch# show port isolation interface gigabitEthernet 1/0/2
```

Display the forward-list of all Ethernet ports and port channels:

```
Switch# show port isolation interface
```

# Chapter 13 Loopback Detection Commands

With loopback detection feature enabled, the switch can detect loops using loopback detection packets. When a loop is detected, the switch will display an alert or further block the corresponding port according to the configuration.

## 13.1 loopback-detection (global)

### Description

The **loopback-detection** command is used to enable the loopback detection function globally. To disable it, please use **no loopback detection** command.

### Syntax

**loopback-detection**  
**no loopback-detection**

### Command Mode

Global Configuration Mode

### Privilege Requirement

Only Admin, Operator and Power User level users have access to these commands.

### Example

Enable the loopback detection function globally:

```
Switch(config)# loopback-detection
```

## 13.2 loopback-detection interval

### Description

The **loopback-detection interval** command is used to define the interval of sending loopback detection packets from switch ports to network, aiming at detecting network loops periodically.

### Syntax

**loopback-detection interval** *interval-time*

### Parameter

*interval-time* — The interval of sending loopback detection packets. It ranges from 1 to 1000 seconds. By default, this value is 30.

## Command Mode

Global Configuration Mode

## Privilege Requirement

Only Admin, Operator and Power User level users have access to these commands.

## Example

Specify the interval-time as 50 seconds:

```
Switch(config)# loopback-detection interval 50
```

# 13.3 loopback-detection recovery-time

## Description

The **loopback-detection recovery-time** command is used to configure the time after which the blocked port would automatically recover to normal status.

## Syntax

```
loopback-detection recovery-time recovery-time
```

## Parameter

*recovery-time* — The time after which the blocked port would automatically recover to normal status, and the loopback detection would restart. It ranges from 2 to 1000000 seconds. By default, this value is 90.

## Command Mode

Global Configuration Mode

## Privilege Requirement

Only Admin, Operator and Power User level users have access to these commands.

## Example

Configure the recovery-time as 70 seconds:

```
Switch(config)# loopback-detection recovery-time 70
```

## 13.4 loopback-detection (interface)

### Description

The **loopback-detection** command is used to enable the loopback detection function of the specified port. To disable it, please use **no loopback-detection** command.

### Syntax

```
loopback-detection  
no loopback-detection
```

### Command Mode

Interface Configuration Mode (interface fastEthernet | gigabitEthernet | two-gigabitEthernet | ten-gigabitEthernet / interface range fastEthernet | gigabitEthernet | two-gigabitEthernet | ten-gigabitEthernet / interface port-channel / interface range port-channel)

### Privilege Requirement

Only Admin, Operator and Power User level users have access to these commands.

### Example

Enable the loopback detection function of ports 1-3:

```
Switch(config)# interface range gigabitEthernet 1/0/1-3  
Switch(Config-if-range)# loopback-detection
```

## 13.5 loopback-detection config process-mode

### Description

The **loopback-detection config process-mode** command is used to configure the process-mode for the ports by which the switch copes with the detected loops. You also need to configure the recovery mode to remove the block status of the port or VLAN when the process-mode is Port Based or VLAN Based.

## Syntax

```
loopback-detection config process-mode { alert | port-based | vlan-based }  
recovery-mode { auto | manual }
```

## Parameter

**alert** — When a loop is detected, the switch will send a trap message and generate an entry on the log file. It is the default setting.

**port-based** — When a loop is detected, the switch will send a trap message and generate an entry on the log file. In addition, the switch will block the port on which the loop is detected and no packets can pass through the port.

**vlan-based** — When a loop is detected, the switch will send a trap message and generate an entry on the log file. In addition, the switch will block the VLAN in which the loop is detected and only the packets of the blocked VLAN cannot pass through the port.

**auto** — Block status can be automatically removed after recovery time.

**manual** — Block status can only be removed manually.

## Command Mode

Interface Configuration Mode (interface gigabitEthernet | interface range gigabitEthernet | interface port-channel | interface range port-channel)

## Privilege Requirement

Only Admin, Operator and Power User level users have access to these commands.

## Example

Configure the loopback detection process-mode as port-based, and configure the recovery mode as manual for port 2:

```
Switch(config)# interface gigabitEthernet 1/0/2  
Switch(config-if)# loopback-detection config process-mode port-based  
recovery-mode manual
```

# 13.6 loopback-detection recover

## Description

The **loopback-detection recover** command is used to remove the block status of selected ports, recovering the blocked ports to normal status,

## Syntax

**loopback-detection recover**

## Command Mode

Interface Configuration Mode (interface gigabitEthernet | interface range gigabitEthernet | interface port-channel | interface range port-channel )

## Privilege Requirement

Only Admin, Operator and Power User level users have access to these commands.

## Example

Recover the blocked port 1/0/2 to normal status:

```
Switch(config)# interface gigabitEthernet 1/0/2
Switch(config-if)# loopback-detection recover
```

# 13.7 show loopback-detection global

## Description

The **show loopback-detection global** command is used to display the global configuration of loopback detection function such as loopback detection global status, loopback detection interval and loopback detection recovery time.

## Syntax

**show loopback-detection global**

## Command Mode

Privileged EXEC Mode and Any Configuration Mode

## Privilege Requirement

None.

## Example

Display the global configuration of loopback detection function:

```
Switch# show loopback-detection global
```



## 13.8 show loopback-detection interface

### Description

The **show loopback-detection interface** command is used to display the configuration of loopback detection function and the status of the specified Ethernet port.

### Syntax

```
show loopback-detection interface [ fastEthernet port | gigabitEthernet port | two-gigabitEthernet port | ten-gigabitEthernet port | port-channel lagid] [ detail ]
```

### Parameter

*port* — The Ethernet port number.

*lagid* — The number of LAG, ranging from 1 to 14.

**detail** — Displays the loop status and block status of the VLAN which the specified port belongs to.

### Command Mode

Privileged EXEC Mode and Any Configuration Mode

### Privilege Requirement

None.

### Example

Display the configuration of loopback detection function and the status of all ports:

```
Switch# show loopback-detection interface
```

Display the configuration of loopback detection function and the status of port 5:

```
Switch# show loopback-detection interface gigabitEthernet 1/0/5
```

## Chapter 14 Stack Commands (Only for Certain Devices)

Stack is a device virtualization technology that connects two and above switches supporting stack features via cables through their stack ports, which logically virtualize them to one device as a whole to forward data in the network in Layer 2 and Layer 3 protocols. Through this feature, switches can be stacked to improve reliability, expand port numbers, increase bandwidth, simplify networking, and etc.

In a stack system, the switches can be categorized mainly into two roles: Master Switch and Member Switch. The master switch manages and controls devices in the whole stack system while the member switch only forwards data as a standby device of the master switch.

As the following figure shows, the switches are connected to form a stack which works as a unified system that enables multiple devices to collaborate under the management of the master switch as a whole.

### 14.1 switch stack-name

#### Description

The **switch stack-name** command is used to specify the name of the stack system.

#### Syntax

```
switch stack-name {name}
```

#### Parameter

*name* — Specify the name of the stack system.

#### Command Mode

Global Configuration Mode

#### Privilege Requirement

Only Admin, Operator and Power User level users have access to these commands.

#### Example

Specify the name of the stack system:

```
Switch(config)#switch stack-name "test"
```

## 14.2 switch stack-group

### Description

The **switch stack-group** command is used to access the viewing page of a specified stack port group configuration of the specified device.

### Syntax

```
switch {unitid} stack-group {groupid}
```

### Parameter

*unitid*—— Device ID in the stack system, ranging from 1-4.

*groupid*—— ID of the stack port group, ranging from 1-4.

### Command Mode

Global Configuration Mode

### Privilege Requirement

Only Admin, Operator and Power User level users have access to these commands.

### Example

Enter the viewing page of a stack port group 1 on switch 1:

```
Switch(config)#switch 1 stack-group 1
```

## 14.3 group-info

### Description

The **group-info** command is used to view the specified stack port group configuration of the specified device.

### Syntax

```
group-info
```

### Parameter

*group-info*—— Display the information of the stack group.

### Command Mode

Stack-Group Mode

### Privilege Requirement

Only Admin, Operator and Power User level users have access to these commands.

## Example

View the information of the stack port group 1 on switch 2.

```
Switch(config)# switch 2 stack-group 1
```

```
Switch(stack-group)#group-info
```

## 14.4 interface port

### Description

The **interface port** command is used to enable the stack function for a specified slot. To disable this function, please use the **no interface port** command.

### Syntax

```
interface port
```

```
no interface port
```

### Parameter

*port*— Port which the stack function to be enabled/disabled on

### Command Mode

Stack-Group Mode

### Privilege Requirement

Only Admin, Operator and Power User level users have access to these commands.

## Example

Configure 1/0/28 as a stack port and join stack-group 1 of unit 2:

```
Switch(stack-group)# interface 1/0/28
```

## 14.5 switch priority

### Description

The **switch priority** command is used to configure the stack priority of the device with specified unit ID.

### Syntax

```
switch {unitid} priority {priority}
```

### Parameter

*unitid*— Device ID in the stack system, ranging from 1 to 4.

*Priority*— Stack priority. The higher the priority, the more likely the device is to become the master device. The value ranges from 1 to 255.

### Command Mode

Global Configuration Mode

### Privilege Requirement

Only Admin, Operator and Power User level users have access to these commands.

### Example

Configure the stack priority of unit 1 as 5:

```
Switch(config)#switch 1 priority 5
```

## 14.6 switch renumber

### Description

The **switch renumber** command is used to modify the stack unit ID of a specified device, which will take effect after the switch reboots.

### Syntax

```
switch {unitid} renumber {new-unitid}
```

### Parameter

*unitid*— ID in the stack system, ranging from 1 to 4.

*new-unitid*— New device ID to be configured, ranging from 1 to 4.

### Command Mode

Global Configuration Mode

### Privilege Requirement

Only Admin, Operator and Power User level users have access to these commands.

### Example

Renumber the stack unit ID of unit 1 as 2:

```
Switch(config)# switch 1 renumber 2
```

```
WARNING: Changing the Unit number may result in a configuration change for that unit. The interface configuration associated with the old unit number will remain as a provisioned configuration. Do you want to continue?[Y/N] y
```

Changing Unit Number 1 to Unid Number 1. New Unit Number will be effective after next reboot

## 14.7 switch provision

### Description

The **switch provision** command is used to create a preconfigured entry specifying `unitid` and `device-type`. After creation, you can use other configuration commands to configure the unit. The configuration will take effect after the stack is connected. To delete the entry, please use the **no switch provision** command.

### Syntax

```
switch {unitid} provision {device-type}
```

```
no switch {unitid} provision {device-type}
```

### Parameter

*unitid* — Device ID, which should be less than 32 characters and range from 1 to 4.

*device-type* — Device type. The provision device needs to be of the same type as the connected device.

### Command Mode

Global Configuration Mode

### Privilege Requirement

Only Admin, Operator and Power User level users have access to these commands.

### Example

Configure provision entries:

```
Switch(config)#switch 1 provision 3
```

## 14.8 show switch stack-ports

### Description

The **show switch stack-ports** command is used to display the stack port information of all members of the stack group.

### Syntax

```
show switch stack-ports
```

## Command Mode

Privileged EXEC Mode and Any Configuration Mode

## Privilege Requirement

Only Admin, Operator and Power User level users have access to these commands.

## Example

View the stack port information of all members of the stack group:

```
Switch(config)#show switch stack-ports
```

# 14.9 show switch

## Description

The **show switch** command is used to display the information of all devices in the stack system.

## Syntax

```
show switch
```

## Command Mode

Privileged EXEC Mode and Any Configuration Mode

## Privilege Requirement

Only Admin, Operator and Power User level users have access to these commands.

## Example

View the information of all devices in the stack system:

```
Switch(config)#show switch
```

# 14.10 show switch unitid

## Description

The **show switch unitid** command is used to display the information about specified stack member devices.

## Syntax

```
show switch {unitid}
```

## Command Mode

Privileged EXEC Mode and Any Configuration Mode

## Privilege Requirement

Only Admin, Operator and Power User level users have access to these commands.

## Example

View the information about unit 1:

```
Switch(config)#show switch 1
```

# 14.11 show switch neighbors

## Description

The **show switch neighbors** command is used to display the group ID of the stack port and the unit ID of its neighboring member device in the current stack system.

## Syntax

```
show switch neighbors
```

## Command Mode

Privileged EXEC Mode and Any Configuration Mode

## Privilege Requirement

Only Admin, Operator and Power User level users have access to these commands.

## Example

View the the group ID of the stack port and the unit ID of its neighboring member device in the current stack system:

```
Switch(config)#show switch neighbors
```



## Chapter 15 DDM Commands (Only for Certain Devices)



**Note:** DDM commands are only available on certain devices.

The DDM (Digital Diagnostic Monitoring) function allows the user to monitor the status of the SFP modules inserted into the SFP ports on the switch. The user can choose to shut down the monitoring SFP port automatically when specified parameter exceeds the alarm threshold or warning threshold. The monitoring parameters include: Temperature, Voltage, Bias Current, Tx Power and Rx Power.

### 15.1 ddm state enable

#### Description

The **ddm state enable** command is used to enable the DDM function on the specified SFP port.

Use the **no ddm state enable** command to disable the DDM function on this port.

#### Syntax

**ddm state enable**

**no ddm state enable**

#### Default Setting

Enabled on all the SFP ports.

#### Command Mode

Interface Configuration Mode (interface gigabitEthernet / interface range gigabitEthernet)

#### Example

Enable DDM function on port 1/0/25:

```
Switch(config)#interface gigabitEthernet 1/0/25
```

```
Switch(config-if)#ddm state enable
```

## 15.2 ddm shutdown

### Description

The **ddm shutdown** command is used to configure whether to shut down the port when an exceeding alarm threshold or warning threshold event is encountered.

### Syntax

```
ddm shutdown { none | warning | alarm }
```

### Parameter

none — The port will never be shut down regardless of the exceeding alarm threshold and warning threshold events.

warning — Shut down the port when an exceeding warning threshold event is encountered.

alarm — Shut down the port when an exceeding alarm threshold event is encountered.

### Default Setting

none, which means the port will never be shut down regardless of the exceeding alarm threshold and warning threshold events.

### Command Mode

Interface Configuration Mode (interface gigabitEthernet / interface range gigabitEthernet )

### Example

Shut down the port 1/0/25 when an exceeding warning threshold event is encountered:

```
Switch(config)#interface gigabitEthernet 1/0/25
```

```
Switch(config-if)#ddm shutdown warning
```

## 15.3 ddm temperature\_threshold

### Description

The **ddm temperature\_threshold** command is used to configure the threshold of the DDM temperature value.

## Syntax

```
ddm temperature_threshold { high_alarm | high_warning | low_alarm |  
low_warning } value
```

## Parameter

**high\_alarm** — Specify the highest threshold for the alarm. When the operating parameter rises above the value hereinafter, action associated with the alarm will be taken.

**high\_warning** — Specify the highest threshold for the warning. When the operating parameter rises above the value hereinafter, action associated with the warning will be taken.

**low\_alarm** — Specify the lowest threshold for the alarm. When the operating parameter falls below the value hereinafter, action associated with the alarm will be taken.

**low\_warning** — Specify the lowest threshold for the warning. When the operating parameter falls below the value hereinafter, action associated with the warning will be taken.

*value* — Enter the threshold value in Celsius.

## Default Setting

None.

## Command Mode

Interface Configuration Mode (interface gigabitEthernet / interface range gigabitEthernet )

## Example

Configure the high\_alarm threshold of DDM temperature on the port 1/0/25 as 5:

```
Switch(config)#interface gigabitEthernet 1/0/25  
Switch(config-if)#ddm temperature_threshold high_alarm 5
```

# 15.4 ddm voltage\_threshold

## Description

The **ddm voltage\_threshold** command is used to configure the threshold of the DDM voltage value.

## Syntax

```
ddm voltage_threshold { high_alarm | high_warning | low_alarm |  
low_warning } value
```

## Parameter

**high\_alarm** — Specify the highest threshold for the alarm. When the operating parameter rises above the value hereinafter, action associated with the alarm will be taken.

**high\_warning** — Specify the highest threshold for the warning. When the operating parameter rises above the value hereinafter, action associated with the warning will be taken.

**low\_alarm** — Specify the lowest threshold for the alarm. When the operating parameter falls below the value hereinafter, action associated with the alarm will be taken.

**low\_warning** — Specify the lowest threshold for the warning. When the operating parameter falls below the value hereinafter, action associated with the warning will be taken.

*value* — Enter the threshold value in Volt.

## Default Setting

None.

## Command Mode

Interface Configuration Mode (interface gigabitEthernet / interface range gigabitEthernet )

## Example

Configure the high\_alarm threshold of DDM voltage on the port 1/0/25 as 5:

```
Switch(config)#interface gigabitEthernet 1/0/25  
Switch(config-if)#ddm voltage_threshold high_alarm 5
```

## 15.5 ddm

### **bias\_current\_threshold**

## Description

The **ddm bias\_current\_threshold** command is used to configure the threshold of the DDM Bias Current value.

## Syntax

```
ddm bias_current_threshold { high_alarm | high_warning | low_alarm |  
low_warning } value
```

## Parameter

**high\_alarm** — Specify the highest threshold for the alarm. When the operating parameter rises above the value hereinafter, action associated with the alarm will be taken.

**high\_warning** — Specify the highest threshold for the warning. When the operating parameter rises above the value hereinafter, action associated with the warning will be taken.

**low\_alarm** — Specify the lowest threshold for the alarm. When the operating parameter falls below the value hereinafter, action associated with the alarm will be taken.

**low\_warning** — Specify the lowest threshold for the warning. When the operating parameter falls below the value hereinafter, action associated with the warning will be taken.

*value* — Enter the threshold value in mA.

## Default Setting

None.

## Command Mode

Interface Configuration Mode (interface fastEthernet / interface range fastEthernet / interface gigabitEthernet / interface range gigabitEthernet)

## Example

Configure the **high\_alarm** threshold of DDM Bias Current on the port 1/0/25 as 5:

```
Switch(config)#interface gigabitEthernet 1/0/25  
Switch(config-if)#ddm bias_current_threshold high_alarm 5
```

# 15.6 ddm tx\_power\_threshold

## Description

The **ddm tx\_power\_threshold** command is used to configure the threshold of the DDM Tx Power value.

## Syntax

```
ddm tx_power_threshold { high_alarm | high_warning | low_alarm |  
low_warning } value
```

## Parameter

**high\_alarm** — Specify the highest threshold for the alarm. When the operating parameter rises above the value hereinafter, action associated with the alarm will be taken.

**high\_warning** — Specify the highest threshold for the warning. When the operating parameter rises above the value hereinafter, action associated with the warning will be taken.

**low\_alarm** — Specify the lowest threshold for the alarm. When the operating parameter falls below the value hereinafter, action associated with the alarm will be taken.

**low\_warning** — Specify the lowest threshold for the warning. When the operating parameter falls below the value hereinafter, action associated with the warning will be taken.

*value* — Enter the threshold value in mW.

## Default Setting

None.

## Command Mode

Interface Configuration Mode (interface gigabitEthernet / interface range gigabitEthernet )

## Example

Configure the high\_alarm threshold of DDM Tx Power on the port 1/0/25 as 5:

```
Switch(config)#interface gigabitEthernet 1/0/25  
Switch(config-if)#ddm tx_power_threshold high_alarm 5
```

# 15.7 ddm rx\_power\_threshold

## Description

The **ddm rx\_power\_threshold** command is used to configure the threshold of the DDM Rx Power value.

## Syntax

```
ddm rx_power_threshold { high_alarm | high_warning | low_alarm |  
low_warning } value
```

## Parameter

`high_alarm` — Specify the highest threshold for the alarm. When the operating parameter rises above the value hereinafter, action associated with the alarm will be taken.

`high_warning` — Specify the highest threshold for the warning. When the operating parameter rises above the value hereinafter, action associated with the warning will be taken.

`low_alarm` — Specify the lowest threshold for the alarm. When the operating parameter falls below the value hereinafter, action associated with the alarm will be taken.

`low_warning` — Specify the lowest threshold for the warning. When the operating parameter falls below the value hereinafter, action associated with the warning will be taken.

*value* — Enter the threshold value in mW.

## Default Setting

None.

## Command Mode

Interface Configuration Mode (interface gigabitEthernet / interface range gigabitEthernet )

## Example

Configure the `high_alarm` threshold of DDM Rx Power on the port 1/0/25 as 5:

```
Switch(config)#interface gigabitEthernet 1/0/25
Switch(config-if)#ddm rx_power_threshold high_alarm 5
```

# 15.8 show ddm configuration

## Description

The **show ddm configuration** command is used to display the DDM configuration.

## Syntax

```
show ddm configuration { state | temperature | voltage | bias_current | tx_power | rx_power }
```

## Parameter

`state` — Display the DDM configuration state.

`temperature` — Displays the threshold of the DDM temperature value.

voltage — Displays the threshold of the DDM Voltage value.

bias\_current — Displays the threshold of the DDM Bias Current value.

tx\_power — Displays the threshold of the DDM Tx Power value.

rx\_power — Displays the threshold of the DDM Rx Power value.

### Command Mode

Privileged EXEC Mode and Any Configuration Mode

### Example

View the DDM configuration state:

```
Switch(config)#show ddm configuration state
```

View the threshold of the DDM Voltage value:

```
Switch(config)#show ddm configuration voltage
```

## 15.9 show ddm status

### Description

The **show ddm status** command is used to display the DDM status, which is the digital diagnostic monitoring status of SFP modules inserting into the switch's SFP ports.

### Syntax

```
show ddm status
```

### Command Mode

Privileged EXEC Mode and Any Configuration Mode

### Example

View the DDM status:

```
Switch(config)#show ddm status
```

## 15.10 show fiber-ports



**Note:** This command is only available on certain devices.

### Description

The **show fiber-ports** command is used to display the information of all fiber ports.

### Syntax

```
show fiber-ports
```



## Command Mode

Privileged EXEC Mode and Any Configuration Mode

## Privilege Requirement

None.

## Example

Display the information of all fiber ports:

```
Switch(config)# show fiber-ports
```

# Chapter 16 Etherchannel Commands

Etherchannel Commands are used to configure LAG and LACP function.

LAG (Link Aggregation Group) is to combine a number of ports together to make a single high-bandwidth data path, which can highly extend the bandwidth. The bandwidth of the LAG is the sum of bandwidth of its member port.

LACP (Link Aggregation Control Protocol) is defined in IEEE802.3ad and enables the dynamic link aggregation and disaggregation by exchanging LACP packets with its partner. The switch can dynamically group similarly configured ports into a single logical link, which will highly extend the bandwidth and flexibly balance the load.

## 16.1 channel-group

### Description

The **channel-group** command is used to add a port to the EtherChannel Group and configure its mode. To delete the port from the EtherChannel Group, please use **no channel-group** command.

### Syntax

**channel-group** *num* **mode** { on | active | passive }

**no channel-group**

### Parameter

*num* — The number of the EtherChannel Group, which ranges from 1 to 8 for L2/L2+ switches, 1 to 64 for L3 access switches, and 1 to 120 for L3 aggregation switches.

on — Enable the static LAG.

active — Enable the active LACP mode.

passive — Enable the passive LACP mode.

### Command Mode

Interface Configuration Mode (interface fastEthernet | gigabitEthernet | two-gigabitEthernet | ten-gigabitEthernet / interface range fastEthernet | gigabitEthernet | two-gigabitEthernet | ten-gigabitEthernet)

## Privilege Requirement

Only Admin, Operator and Power User level users have access to these commands.

## Example

Add ports 2-4 to EtherChannel Group 1 and enable the static LAG:

```
Switch(config)# interface range gigabitEthernet 1/0/2-4
Switch(config-if-range)# channel-group 1 mode on
```

# 16.2 port-channel load-balance

## Description

The **port-channel load-balance** command is used to configure the Aggregate Arithmetic for LAG. To return to the default configurations, please use **no port-channel load-balance** command.

## Syntax

```
port-channel load-balance { src-mac | dst-mac | src-dst-mac | src-ip | dst-ip |
src-dst-ip }
```

```
no port-channel load-balance
```

## Parameter

src-mac — The source MAC address. When this option is selected, the Aggregate Arithmetic will be based on the source MAC address of the packets.

dst-mac — The destination MAC address. When this option is selected, the Aggregate Arithmetic will be based on the destination MAC address of the packets.

src-dst-mac — The source and destination MAC address. When this option is selected, the Aggregate Arithmetic will be based on the source and destination MAC addresses of the packets. The Aggregate Arithmetic for LAG is "src-dst-mac" by default.

src-ip — The source IP address. When this option is selected, the Aggregate Arithmetic will be based on the source IP address of the packets.

dst-ip — The destination IP address. When this option is selected, the Aggregate Arithmetic will be based on the destination IP address of the packets.

src-dst-ip — The source and destination IP address. When this option is selected, the Aggregate Arithmetic will be based on the source and destination IP addresses of the packets.

### Command Mode

Global Configuration Mode

### Privilege Requirement

Only Admin, Operator and Power User level users have access to these commands.

### Example

Configure the Aggregate Arithmetic for LAG as "src-dst-ip":

```
Switch(config)# port-channel load-balance src-dst-ip
```

## 16.3 lacp system-priority

### Description

The **lacp system-priority** command is used to configure the LACP system priority globally. To return to the default configurations, please use **no lacp system-priority** command.

### Syntax

```
lacp system-priority pri
```

```
no lacp system-priority
```

### Parameter

*pri* — The system priority, ranging from 0 to 65535. It is 32768 by default.

### Command Mode

Global Configuration Mode

### Privilege Requirement

Only Admin, Operator and Power User level users have access to these commands.

### Example

Configure the LACP system priority as 1024 globally:

```
Switch(config)# lacp system-priority 1024
```

## 16.4 lacp port-priority

### Description

The **lacp port-priority** command is used to configure the LACP port priority for specified ports. To return to the default configurations, please use **no lacp port-priority** command.

### Syntax

```
lacp port-priority pri  
no lacp port-priority
```

### Parameter

*pri*—— The port priority, ranging from 0 to 65535. It is 32768 by default.

### Command Mode

Interface Configuration Mode (interface gigabitEthernet / interface range gigabitEthernet)

### Privilege Requirement

Only Admin, Operator and Power User level users have access to these commands.

### Example

Configure the LACP port priority as 1024 for ports 1-3:

```
Switch(config)# interface range gigabitEthernet 1/0/1-3  
Switch(config-if-range)# lacp port-priority 1024
```

Configure the LACP port priority as 2048 for port 4:

```
Switch(config)# interface gigabitEthernet 1/0/4  
Switch(config-if)# lacp port-priority 2048
```

## 16.5 show etherchannel

### Description

The **show etherchannel** command is used to display the EtherChannel information.

### Syntax

```
show etherchannel [ channel-group-num ] { detail | summary }
```

## Parameter

*channel-group-num* — The EtherChannel Group number, which ranges from 1 to 8 for L2/L2+ switches, 1 to 64 for L3 access switches, and 1 to 120 for L3 aggregation switches. By default, it is empty, and will display the information of all EtherChannel Groups.

detail — The detailed information of EtherChannel.

summary — The EtherChannel information in summary.

## Command Mode

Privileged EXEC Mode and Any Configuration Mode

## Privilege Requirement

None.

## Example

Display the detailed information of EtherChannel Group 1:

```
Switch(config)# show etherchannel 1 detail
```

# 16.6 show etherchannel load-balance

## Description

The **show etherchannel load-balance** command is used to display the Aggregate Arithmetic of LAG.

## Syntax

```
show etherchannel load-balance
```

## Command Mode

Privileged EXEC Mode and Any Configuration Mode

## Privilege Requirement

None.

## Example

Display the Aggregate Arithmetic of LAG:

```
Switch(config)# show etherchannel load-balance
```

## 16.7 show lacp

### Description

The **show lacp** command is used to display the LACP information for a specified EtherChannel Group.

### Syntax

```
show lacp [ channel-group-num ] { internal / neighbor }
```

### Parameter

*channel-group-num* — The EtherChannel Group number, which ranges from 1 to 8 for L2/L2+ switches, 1 to 64 for L3 access switches, and 1 to 120 for L3 aggregation switches. By default, it is empty, and will display the information of all LACP groups.

internal — The internal LACP information.

neighbor — The neighbor LACP information.

### Command Mode

Privileged EXEC Mode and Any Configuration Mode

### Privilege Requirement

None.

### Example

Display the internal LACP information of EtherChannel Group 1:

```
Switch(config)# show lacp 1 internal
```

## 16.8 show lacp sys-id

### Description

The **show lacp sys-id** command is used to display the LACP system priority globally.

### Syntax

```
show lacp sys-id
```

### Command Mode

Privileged EXEC Mode and Any Configuration Mode

## Privilege Requirement

None.

## Example

Display the LACP system priority:

```
Switch(config)# show lacp sys-id
```



# Chapter 17 MAC Address Commands

MAC Address configuration can improve the network security by configuring the Port Security and maintaining the address information by managing the Address Table.

## 17.1 mac address-table static

### Description

The **mac address-table static** command is used to add the static MAC address entry. To remove the corresponding entry, please use **no mac address-table static** command. The static address can be added or removed manually, independent of the aging time. In the stable networks, the static MAC address entries can facilitate the switch to reduce broadcast packets and enhance the efficiency of packets forwarding remarkably.

### Syntax

```
mac address-table static mac-addr vid vid interface { fastEthernet port | gigabitEthernet port | two-gigabitEthernet port | ten-gigabitEthernet port | hundred-gigabitEthernet port }  
no mac address-table static { mac-addr [vid vid] | vid vid | interface { fastEthernet port | gigabitEthernet port | hundred-gigabitEthernet port | ten-gigabitEthernet port | twentyFive-gigabitEthernet port | two-gigabitEthernet port } }
```

### Parameter

*mac-addr*——The MAC address of the entry you desire to add.

*vid*—— The VLAN ID number of your desired entry. It ranges from 1 to 4094.

*port*—— The Ethernet port number of your desired entry.

### Command Mode

Global Configuration Mode

### Privilege Requirement

Only Admin, Operator and Power User level users have access to these commands.

### Example

Add a static Mac address entry to bind the MAC address 00:02:58:4f:6c:23, VLAN1 and port 1 together:

```
Switch(config)# mac address-table static 00:02:58:4f:6c:23 vid 1 interface
gigabitEthernet 1/0/1
```

## 17.2 no mac address-table dynamic

### Description

The **no mac address-table dynamic** command is used to delete the specified dynamic MAC address, or dynamic MAC addresses based on the VLAN or the port.

### Syntax

```
no mac address-table dynamic { mac-addr | vid vid | interface {fastEthernet
port | gigabitEthernet port | two-gigabitEthernet port | ten-gigabitEthernet
port}}
```

### Parameter

*mac-addr*——The MAC address you desire to delete.

*vid*——The VLAN ID on which you desire to delete MAC addresses.

*port*——The Ethernet port on which you desire to delete MAC addresses.

### Command Mode

Global Configuration Mode

### Privilege Requirement

Only Admin, Operator and Power User level users have access to these commands.

### Example

Delete the MAC addresses on VLAN 1:

```
Switch(config)# no mac address-table dynamic vid 1
```

## 17.3 mac address-table aging-time

### Description

The **mac address-table aging-time** command is used to configure aging time for the dynamic address. To return to the default configuration, please use **no mac address-table aging-time** command.

## Syntax

**mac address-table aging-time** *aging-time*

**no mac address-table aging-time**

## Parameter

*aging-time* — The aging time for the dynamic address. The value of it can be 0 or ranges from 10 to 630 seconds. When 0 is entered, the Auto Aging function is disabled. It is 300 by default.

## Command Mode

Global Configuration Mode

## Privilege Requirement

Only Admin, Operator and Power User level users have access to these commands.

## Example

Configure the aging time as 500 seconds:

```
Switch(config)# mac address-table aging-time 500
```

# 17.4 mac address-table filtering

## Description

The **mac address-table filtering** command is used to add the filtering address entry. To delete the corresponding entry, please use **no mac address-table filtering** command. The filtering address function is to forbid the undesired package to be forwarded. The filtering address can be added or removed manually, independent of the aging time.

## Syntax

**mac address-table filtering** *mac-addr* **vid** *vid*

**no mac address-table filtering** [*mac-addr*] [**vid** *vid*]

## Parameter

*mac-addr* — The MAC address to be filtered.

*vid* — The corresponding VLAN ID of the MAC address. It ranges from 1 to 4094.

## Command Mode

Global Configuration Mode

## Privilege Requirement

Only Admin, Operator and Power User level users have access to these commands.

## Example

Add a filtering address entry of which VLAN ID is 1 and MAC address is 00:1e:4b:04:01:5d:

```
Switch(config)# mac address-table filtering 00:1e:4b:04:01:5d vid 1
```

# 17.5 mac address-table notification



**Note:** This command is only available on certain devices.

## Description

The **mac address-table notification** command is used to configure global settings of MAC address table notification.

## Syntax

```
mac address-table notification { [ global-status enable | disable ]  
[ table-full-status enable | disable ] [ interval time ] }
```

## Parameter

**global-status** enable | disable — Enable/Disable the notification function globally.

**table-full-status** enable | disable — Enable/Disable the MAC threshold notification. With this feature enabled, a SNMP notification is generated and sent to the network management system (NMS) when the threshold of the switch's MAC address table is reached or exceeded.

**interval** *time* — Specify the notification trap interval between each set of traps that are generated to the NMS. The interval ranges from 1 to 1000 seconds, and it's 1 second by default.

## Command Mode

Global Configuration Mode

## Privilege Requirement

Only Admin, Operator and Power User level users have access to these commands.

## Example

Enable the global MAC address notification and table full notification, specify the notification sending interval as 2 seconds:

```
Switch(config)# mac address-table notification global-status enable
table-full-status enable interval 2
```

# 17.6 mac address-table max-mac-count

## Description

The **mac address-table max-mac-count** command is used to configure the Port Security. To return to the default configurations, please use **no mac address-table max-mac-count** command. Port Security is to protect the switch from the malicious MAC address attack by limiting the maximum number of the MAC addresses that can be learned on the port. The port with Port Security feature enabled will learn the MAC address dynamically. When the learned MAC address number reaches the maximum, the port will stop learning. Therefore, the other devices with the MAC address unlearned cannot access to the network via this port.

## Syntax

```
mac address-table max-mac-count [ [ max-number num ] [ mode { dynamic | static | permanent } ] [ status { forward | drop | disable } ] [ exceed-max-learned enable | disable ] }
```

```
no mac address-table max-mac-count [ max-number | mode | status ]
```

## Parameter

*num* — The maximum number of MAC addresses that can be learned on the port. It ranges from 0 to 64. By default, this value is 64.

dynamic | static | permanent — Learn mode for MAC addresses. There are three modes, including Dynamic mode, Static mode and Permanent mode. When Dynamic mode is selected, the learned MAC address will be deleted automatically after the aging time. When Static mode is selected, the learned MAC address will be out of the influence of the aging time and can only be deleted manually. The learned entries will be cleared after the switch is rebooted. When permanent mode is selected, the learned MAC address will be out of the influence of the aging time and can only be deleted manually too. However, the learned entries will be saved even the switch is rebooted.

status — Select the action to be taken when the number of the MAC addresses reaches the maximum learning number on the port. By default, this function is disabled.

- forward: The packets will be forward but not be learned when learned MAC number exceeds the maximum MAC address number on this port.
- drop: The packets will be dropped when learned MAC number exceeds the maximum MAC address number on this port.
- disable: The MAC address threshold on this port is disabled.

**exceed-max-learned** enable | disable — Enable/Disable the new-mac-learned notification on this port. With this feature enabled, a SNMP notification is generated and sent to the network management system (NMS) when the port learns a new MAC address.

### Command Mode

Interface Configuration Mode (interface gigabitEthernet / interface range gigabitEthernet)

### Privilege Requirement


Only Admin, Operator and Power User level users have access to these commands.

### Example

Enable Port Security function for port 1/0/1, select Static mode as the learn mode, and specify the maximum number of MAC addresses that can be learned on this port as 30. When the number of MAC address entries reaches 30 on this port, new entry will be dropped:

```
Switch(config)# interface gigabitEthernet 1/0/1
Switch(config-if)# mac address-table max-mac-count max-number 30
mode static status drop
```

## 17.7 mac address-table notification (interface)

 **Note:** This command is only available on certain devices.

### Description

The **mac address-table notification** command is used to configure the MAC change notification on port.

## Syntax

```
mac address-table notification { [ learn-mode-change enable | disable ]  
[ new-mac-learned enable | disable ] [ exceed-max-learned enable |  
disable ] }
```

## Parameter

**learn-mode-change** enable | disable — Enable/Disable the learn-mode-change notification. With this feature enabled, a SNMP notification is generated and sent to the network management system (NMS) when the learning mode of this port changes. To configure the learning mode configuration, please refer to [mac address-table max-mac-count](#).

**new-mac-learned** enable | disable — Enable/Disable the new-mac-learned notification on this port. With this feature enabled, a SNMP notification is generated and sent to the network management system (NMS) when the port learns a new MAC address.

**exceed-max-learned** enable | disable — Enable/Disable the new-mac-learned notification on this port. With this feature enabled, a SNMP notification is generated and sent to the network management system (NMS) when the port learns a new MAC address.

## Command Mode

Interface Configuration Mode (interface gigabitEthernet / interface range gigabitEthernet)

## Privilege Requirement

Only Admin, Operator and Power User level users have access to these commands.

## Example

Enable the learn-mode-change notification on port 1/0/2:

```
Switch(config)# mac address-table notification global-status enable  
Switch(config)# interface gigabitEthernet 1/0/2  
Switch(config-if)# mac address-table notification learn-mode-change  
enable
```

## 17.8 mac address-table security



**Note:** This command is only available on certain devices.

## Description

The **mac address-table security** command is used to configure the maximum number of MAC address can be learned in specified VLANs.

## Syntax

```
mac address-table security vid vid max-learn number { forward | drop }
```

## Parameter

*vid*— Specify the VLAN ID to configure its MAC address table.

*number*— Configure the threshold of the MAC address table in this VLAN. It ranges from 0 to 16383.

forward | drop | disable — Choose the mode when learned MAC number exceeds the threshold of the MAC address table in this VLAN.

- Drop: The packets will be dropped when learned MAC number exceeds the threshold of the MAC address table in this VLAN.
- Forward: The packets will be forward but not be learned when learned MAC number exceeds the threshold of the MAC address table in this VLAN.

## Command Mode

Global Configuration Mode

## Privilege Requirement

Only Admin, Operator and Power User level users have access to these commands.

## Example

Configure the max learned MAC address number is VLAN 2 as 1000, and drop the packets that have no match in the MAC address table:

```
Switch(config)# mac address-table security vid 2 max-learn 1000 drop
```

# 17.9 mac address-table vlan-security



**Note:** This command is only available on certain devices.

## Description

The **mac address-table security** command is used to configure the maximum number of MAC address can be learned in specified VLANs.



## Syntax

```
mac address-table vlan-security { vid vid max-learn number | mode  
{ forward | drop }}
```

## Parameter

*vid*— Specify the VLAN ID to configure its MAC address table.

*number*— Configure the threshold of the MAC address table in this VLAN. It ranges from 0 to 16383.

forward | drop | disable — Choose the mode when learned MAC number exceeds the threshold of the MAC address table in this VLAN.

- Drop: The packets will be dropped when learned MAC number exceeds the threshold of the MAC address table in this VLAN.
- Forward: The packets will be forward but not be learned when learned MAC number exceeds the threshold of the MAC address table in this VLAN.
- Disable: The threshold of the MAC address table is disabled.

## Command Mode

Global Configuration Mode

## Privilege Requirement

Only Admin, Operator and Power User level users have access to these commands.

## Example

Configure the max learned MAC address number is VLAN 2 as 1000:

```
Switch(config)# mac address-table vlan-security vid 2 max-learn 1000
```

# 17.10 show mac address-table

## Description

The **show mac address-table** command is used to display the information of all address entries.

## Syntax

```
show mac address-table [ { dynamic | static | filtering } ]
```

## Parameter

dynamic | static | filtering — The type of your desired entry. By default, all the entries are displayed.

## Command Mode

Privileged EXEC Mode and Any Configuration Mode

## Privilege Requirement

None.

## Example

Display the information of all address entries:

```
Switch(config)# show mac address-table
```

# 17.11 clear mac address-table

## Description

The **show mac address-table** command is used to clear the specified address entries.

## Syntax

```
clear mac address-table { dynamic | static | filtering }
```

## Parameter

dynamic | static | filtering — The type of your desired entry.

## Command Mode

Privileged EXEC Mode and Any Configuration Mode

## Privilege Requirement

Only Admin, Operator and Power User level users have access to these commands.

## Example

Clear the information of all static address entries:

```
Switch(config)# clear mac address-table static
```

# 17.12 show mac address-table aging-time

## Description

The **show mac address-table aging-time** command is used to display the Aging Time of the MAC address.

## Syntax

```
show mac address-table aging-time
```

## Command Mode

Privileged EXEC Mode and Any Configuration Mode

## Privilege Requirement

None.

## Example

Display the Aging Time of the MAC address:

```
Switch(config)# show mac address-table aging-time
```

# 17.13 show mac address-table max-mac-count

## Description

The **show mac address-table max-mac-count interface gigabitEthernet** command is used to display the security configuration of all ports or the specified port.

## Syntax

```
show mac address-table max-mac-count { all | interface { fastEthernet port |  
gigabitEthernet port | hundred-gigabitEthernet port | port-channel  
port-channel-id | ten-gigabitEthernet port | twentyFive-gigabitEthernet port |  
two-gigabitEthernet port}}
```

## Parameter

**all** — Displays the security information of all the Ethernet ports.

***port*** — The Ethernet port number.

## Command Mode

Privileged EXEC Mode and Any Configuration Mode

## Privilege Requirement

None.

## Example

Display the security configuration of all ports:

```
Switch(config)# show mac address-table max-mac-count all
```

Display the security configuration of port 1/0/1:

```
Switch(config)# show mac address-table max-mac-count interface  
gigabitEthernet 1/0/1
```

## 17.14 show mac address-table interface

### Description

The **show mac address-table interface** command is used to display the address configuration of the specified port/port channel.

### Syntax

```
show mac address-table interface { fastEthernet port | gigabitEthernet port | hundred-gigabitEthernet port | port-channel port-channel-id | ten-gigabitEthernet port | twentyFive-gigabitEthernet port | two-gigabitEthernet port}
```

### Parameter

*port*—— The Ethernet port number.

*port-channel-id*—— The ID of the port channel.

### Command Mode

Privileged EXEC Mode and Any Configuration Mode

### Privilege Requirement

None.

### Example

Display the address configuration of port 1/0/1:

```
Switch(config)# show mac address-table interface gigabitEthernet 1/0/1
```

## 17.15 show mac address-table count

### Description

The **show mac address-table count** command is used to display the total amount of MAC address table.

### Syntax

```
show mac address-table count [ vlan vlan-id]
```

### Parameter

*vlan-id* —— Specify the VLAN which the MAC entries belong to.

## Command Mode

Privileged EXEC Mode and Any Configuration Mode

## Privilege Requirement

None.

## Example

Display the total MAC entry information in different VLANs:

```
Switch(config)# show mac address-table count
```

# 17.16 show mac address-table address

## Description

The **show mac address-table address** command is used to display the information of the specified MAC address.

## Syntax

```
show mac address-table address mac-addr [ interface { fastEthernet port | gigabitEthernet port | port-channel port-channel-id } | vid vlan-id ]
```

## Parameter

*mac-addr*——The specified MAC address.

*port*—— The Ethernet port number.

*port-channel-id*—— The ID of the port channel.

*vlan-id*—— Specify the VLAN which the entry belongs to.

## Command Mode

Privileged EXEC Mode and Any Configuration Mode

## Privilege Requirement

None.

## Example

Display the information of the MAC address 00:00:00:00:23:00 in VLAN 1:

```
Switch(config)#show mac address-table address 00:00:00:00:23:00 vid 1
```

## 17.17 show mac address-table vlan

### Description

The **show mac address-table vlan** command is used to display the MAC address configuration of the specified vlan.

### Syntax

```
show mac address-table vlan vid
```

### Parameter

*vid*——The specified VLAN id.

### Command Mode

Privileged EXEC Mode and Any Configuration Mode

### Privilege Requirement

None.

### Example

Display the MAC address configuration of vlan 1:

```
Switch(config)# show mac address-table vlan 1
```

## 17.18 show mac address-table notification



**Note:** This command is only available on certain devices.

### Description

The **show mac address-table notification** command is used to display the MAC notification configuration globally or on the specified port.

### Syntax

```
show mac address-table notification all
```

### Parameter

*all* —— Displays the notification information globally and of all the Ethernet ports.

*port*—— Displays the notification information on the specified port.

## Command Mode

Privileged EXEC Mode and Any Configuration Mode

## Privilege Requirement

None.

## Example

Display the notification configuration of all the ports:

```
Switch(config)# show mac address-table notification all
```

# 17.19 show mac address-table security



**Note:** This command is only available on certain devices.

## Description

The **show mac address-table security** command is used to display the MAC address security configuration globally or of the specified VLAN.

## Syntax

```
show mac address-table security [ vid vid]
```

## Parameter

*vid*—The specified VLAN id.

## Command Mode

Privileged EXEC Mode and Any Configuration Mode

## Privilege Requirement

None.

## Example

Display the MAC address security configuration of VLAN 1:

```
Switch(config)# show mac address-table security vid 1
```

# Chapter 18 IEEE 802.1Q VLAN Commands

VLAN (Virtual Local Area Network) technology is developed for the switch to divide the LAN into multiple logical LANs flexibly. Hosts in the same VLAN can communicate with each other, regardless of their physical locations. VLAN can enhance performance by conserving bandwidth, and improve security by limiting traffic to specific domains.

## 18.1 vlan

### Description

The **vlan** command is used to create IEEE 802.1Q VLAN and enter VLAN Configuration Mode. To delete the IEEE 802.1Q VLAN, please use **no vlan** command.

### Syntax

```
vlan vlan-list  
no vlan vlan-list
```

### Parameter

*vlan-list*—— Specify IEEE 802.1Q VLAN ID list, ranging from 2 to 4094, in the format of 2-3, 5. It is multi-optional.

### Command Mode

Global Configuration Mode

### Privilege Requirement

Only Admin, Operator and Power User level users have access to these commands.

### Example

Create VLAN 2-10 and VLAN 100:

```
Switch(config)# vlan 2-10,100
```

Delete VLAN 2:

```
Switch(config)# no vlan 2
```



## 18.2 name

### Description

The **name** command is used to assign a description to a VLAN. To clear the description, please use **no name** command.

### Syntax

```
name descript  
no name
```

### Parameter

*descript* —String to describe the VLAN, which contains 16 characters at most.

### Command Mode

VLAN Configuration Mode(VLAN)

### Privilege Requirement

Only Admin, Operator and Power User level users have access to these commands.

### Example

Specify the name of VLAN 2 as "group1":

```
Switch(config)# vlan 2  
Switch(config-vlan)# name group1
```

## 18.3 vlan\_trunk (globally)

### Description

The **vlan\_trunk** command is used to enable VLAN Trunk globally. When enabled, the switch will automatically create all VLANs (2-4094). To disable VLAN Trunk, use the **no vlan\_trunk** command.

### Syntax

```
vlan_trunk  
no vlan_trunk
```

### Command Mode

Global Configuration Mode

## Privilege Requirement

Only Admin, Operator and Power User level users have access to these commands.

## Example

Enable VLAN Trunk globally:

```
Switch(config)#vlan_trunk
```

# 18.4 vlan\_trunk (interface)

## Description

The **vlan\_trunk** command is used to enable VLAN Trunk for the desired port. When enabled, all packets in VLANs can pass through this port. For VLANs that have been added through switchport general allowed vlan command, data will be forwarded according to the configured egress rule. For VLANs that have not been manually added, data will be forwarded through the egress rule "tagged". To disable VLAN Trunk, use the **no vlan\_trunk** command. By default, it is disabled.

## Syntax

```
vlan_trunk  
no vlan_trunk
```

## Command Mode

Interface Configuration Mode (interface gigabitEthernet / interface range gigabitEthernet / interface port-channel / interface range port-channel)

## Privilege Requirement

Only Admin, Operator and Power User level users have access to these commands.

## Example

Enable VLAN Trunk for port 1/0/3:

```
Switch(config)#interface gigabitEthernet 1/0/3  
Switch(config-if)#vlan_trunk
```

## 18.5 switchport general allowed vlan

### Description

The **switchport general allowed vlan** command is used to add the desired port to IEEE 802.1Q VLAN, or to remove a port from the corresponding VLAN.

### Syntax

**switchport general allowed vlan** *vlan-list* { tagged | untagged }

**no switchport general allowed vlan** *vlan-list*

### Parameter

*vlan-list* — VLAN ID list, ranging from 2 to 4094, in the format of 2-3, 5. It is multi-optional. "all" can also be entered to indicate all configured VLANs.

tagged | untagged — egress-rule. When the *vlan-list* is entered with "all", the egress-rule is "tagged" by default and cannot be modified.

### Command Mode

Interface Configuration Mode (interface gigabitEthernet / interface range gigabitEthernet / interface port-channel / interface range port-channel)

### Privilege Requirement

Only Admin, Operator and Power User level users have access to these commands.

### Example

Configure Gigabit Ethernet port 1/0/4 whose link type is "general" to VLAN 2 and its egress-rule as "tagged":

```
Switch(config)#interface gigabitEthernet 1/0/4
Switch(config-if)#switchport general allowed vlan 2 tagged
```

## 18.6 switchport pvid

### Description

The **switchport pvid** command is used to configure the PVID for the switch ports.

## Syntax

**switchport pvid** *vlan-id*

## Parameter

*vlan-id*—— VLAN ID, ranging from 1 to 4094.

## Command Mode

Interface Configuration Mode (interface gigabitEthernet / interface range gigabitEthernet / interface port-channel / interface range port-channel)

## Privilege Requirement

Only Admin, Operator and Power User level users have access to these commands.

## Example

Specify the PVID of port 1/0/2 as 2:

```
Switch(config)# interface gigabitEthernet 1/0/2
Switch(config-if)# switchport pvid 2
```

# 18.7 switchport check ingress

## Description

The **switchport check ingress** command is used to enable the Ingress Checking function for the switch ports. With this function enabled, the port will accept the packet of which the VLAN ID is in the port's VLAN list and discard others. With this function disabled, the port will forward the packet directly. To disable this function, please use **no switchport check ingress** command.

## Syntax

**switchport check ingress**  
**no switchport check ingress**

## Command Mode

Interface Configuration Mode (interface gigabitEthernet / interface range gigabitEthernet / interface port-channel / interface range port-channel)

## Privilege Requirement

Only Admin, Operator and Power User level users have access to these commands.

## Example

Enable Ingress Checking on the port 1/0/2:

```
Switch(config)# interface gigabitEthernet 1/0/2
Switch(config-if)# switchport check ingress
```

# 18.8 switchport acceptable frame

## Description

The **switchport acceptable frame** command is used to specify the acceptable frame type for the switch ports and the ports will perform this operation before Ingress Checking. To restore to the default setting, please use **no switchport acceptable frame** command.

## Syntax

```
switchport acceptable frame { all | tagged }
no switchport acceptable frame
```

## Parameter

all | tagged — the acceptable frame type.

## Command Mode

Interface Configuration Mode (interface gigabitEthernet / interface range gigabitEthernet / interface port-channel / interface range port-channel)

## Privilege Requirement

Only Admin, Operator and Power User level users have access to these commands.

## Example

Specify the acceptable frame type of Gigabit Ethernet port 1/0/4 as "tagged":

```
Switch(config)#interface gigabitEthernet 1/0/4
Switch(config-if)#switchport acceptable frame general
```

## 18.9 show vlan summary

### Description

The **show vlan summary** command is used to display the summarized information of IEEE 802.1Q VLAN.

### Syntax

```
show vlan summary
```

### Command Mode

Privileged EXEC Mode and Any Configuration Mode

### Privilege Requirement

None.

### Example

Display the summarized information of IEEE 802.1Q VLAN:

```
Switch(config)# show vlan summary
```

## 18.10 show vlan brief

### Description

The **show vlan brief** command is used to display the brief information of IEEE 802.1Q VLAN.

### Syntax

```
show vlan brief
```

### Command Mode

Privileged EXEC Mode and Any Configuration Mode

### Privilege Requirement

None.

### Example

Display the brief information of IEEE 802.1Q VLAN:

```
Switch(config)# show vlan brief
```

## 18.11 show vlan

### Description

The **show vlan** command is used to display the information of IEEE 802.1Q VLAN.

### Syntax

```
show vlan [ id vlan-id]
```

### Parameter

*vlan-id* — Specify IEEE 802.1Q VLAN ID, ranging from 1 to 4094. It is multi-optional. Using the **show vlan** command without parameter displays the detailed information of all VLANs.

### Command Mode

Privileged EXEC Mode and Any Configuration Mode

### Privilege Requirement

None.

### Example

Display the information of vlan 5:

```
Switch(config)# show vlan id 5
```

## 18.12 show interface switchport

### Description

The **show interface switchport** command is used to display the IEEE 802.1Q VLAN configuration information of the specified port/port channel.

### Syntax

```
show interface switchport [fastEthernet port | gigabitEthernet port |  
ten-gigabitEthernet port | port-channel port-channel-id]
```

### Parameter

*port* — The port number.

*port-channel-id* — The ID of the port channel.

### Command Mode

Privileged EXEC Mode and Any Configuration Mode

## Privilege Requirement

None.

## Example

Display the VLAN configuration information of all ports and port channels:

```
Switch(config)# show interface switchport
```



# Chapter 19 MAC-based VLAN Commands

MAC VLAN (Virtual Local Area Network) is the way to classify the VLANs based on MAC Address. A MAC address is relative to a single VLAN ID. The untagged packets and the priority-tagged packets coming from the MAC address will be tagged with this VLAN ID.

## 19.1 mac-vlan mac-address

### Description

The **mac-vlan mac-address** command is used to create a MAC-based VLAN entry. To delete a MAC-based VLAN entry, please use the **no mac-vlan mac-address** command.

### Syntax

```
mac-vlan mac-address mac-addr vlan vlan-id [description descript]  
no mac-vlan mac-address mac-addr
```

### Parameter

*mac-addr*—— MAC address, in the format of XX:XX:XX:XX:XX:XX.

*vlan-id*—— Specify IEEE 802.1Q VLAN ID, ranging from 1 to 4094.

*descript*—— Give a description to the MAC address for identification, which contains 8 characters at most.

### Command Mode

Global Configuration Mode

### Privilege Requirement

Only Admin, Operator and Power User level users have access to these commands.

### Example

Create VLAN 2 with the MAC address 00:11:11:01:01:12 and the name "TP":

```
Switch(config)#mac-vlan mac-address 00:11:11:01:01:12 vlan 2  
description TP
```

## 19.2 mac-vlan

### Description

The **mac-vlan** command is used to enable a port for the MAC-based VLAN feature. Only the port is enabled can the configured MAC-based VLAN take effect. To disable the MAC-based VLAN function, please use **no mac-vlan** command. All the ports are disabled by default.

### Syntax

```
mac-vlan
no mac-vlan
```

### Command Mode

Interface Configuration Mode (interface gigabitEthernet / interface range gigabitEthernet / interface port-channel / interface range port-channel)

### Privilege Requirement

Only Admin, Operator and Power User level users have access to these commands.

### Example

Enable the Gigabit Ethernet port 1/0/3 for the MAC-based VLAN feature:

```
Switch(config)#interface gigabitEthernet 1/0/3
Switch(config-if)#mac-vlan
```

## 19.3 show mac-vlan

### Description

The **show mac-vlan** command is used to display the information of the MAC-based VLAN entry. MAC address and VLAN ID can be used to filter the displayed information.

### Syntax

```
show mac-vlan { all | mac-address mac-addr | vlan vlan-id }
```

### Command Mode

Privileged EXEC Mode and Any Configuration Mode

## Privilege Requirement

None.

## Parameter

*mac-addr*—— MAC address, in the format of XX:XX:XX:XX:XX:XX.

*vlan-id*—— Specify IEEE 802.1Q VLAN ID, ranging from 1 to 4094.

## Example

Display the information of all the MAC-based VLAN entry:

```
Switch(config)#show mac-vlan all
```

# 19.4 show mac-vlan interface

## Description

The **show mac-vlan interface** command is used to display the port state of MAC-based VLAN.

## Syntax

```
show mac-vlan interface
```

## Command Mode

Privileged EXEC Mode and Any Configuration Mode

## Privilege Requirement

None.

## Example

Display the enable state of all the ports:

```
Switch(config)#show mac-vlan interface
```

# Chapter 20 Protocol-based VLAN Commands

Protocol VLAN (Virtual Local Area Network) is the way to classify VLANs based on Protocols. A Protocol is relative to a single VLAN ID. The untagged packets and the priority-tagged packets matching the protocol template will be tagged with this VLAN ID.

## 20.1 protocol-vlan template

### Description

The **protocol-vlan template** command is used to create Protocol-based VLAN template. To delete Protocol-based VLAN template, please use **no protocol-vlan template** command.

### Syntax

**For L2/L2+ switches:**

**protocol-vlan template name** *protocol-name* **frame** { **ether\_2 ether-type type** | **snap ether-type type** | **llc dsap dsap\_type ssap ssap\_type** }

**no protocol-vlan template** *template-idx*

**For L3 switches:**

**protocol-vlan template name** *protocol-name* **frame** { **ether\_2 ether-type type** | **snap ether-type type** | **llc dsap dsap\_type ssap ssap\_type** }

**no protocol-vlan template** *template-name*

### Parameter

*protocol-name* — Give a name for the Protocol-based VLAN Template , which contains 8 characters at most.

**ether\_2 ether-type type** — Specify the Ethernet type.

**snap ether-type type** — Specify the Ethernet type.

**llc dsap dsap\_type ssap ssap\_type** — Specify the DSAP type and the SSAP type.

*template-idx* — The number of the Protocol-based VLAN Template. You can get the template corresponding to the number by the [show protocol-vlan template](#) command.

*template-name* — The name of the Protocol-base VLAN Template. You can get the template corresponding to the number by the [show protocol-vlan template](#) command.

## Command Mode

Global Configuration Mode

## Privilege Requirement

Only Admin, Operator and Power User level users have access to these commands.

## Example

Create a Protocol-based VLAN template named "TP" whose Ethernet protocol type is 0x2024:

```
Switch(config)#protocol-vlan template name TP frame ether_2 ether-type
2024
```

# 20.2 protocol-vlan vlan

## Description

The **protocol-vlan vlan** command is used to create a Protocol-based VLAN entry. To delete a Protocol-based VLAN entry, please use **no protocol-vlan vlan** command.

## Syntax

**For L2/L2+ switches:**

**protocol-vlan vlan** *vlan-id* **priority** *priority* **template** *template-idx*

**no protocol-vlan vlan** *group-idx*

**For L3 switches:**

**protocol-vlan vlan** *vlan-id* **priority** *priority* **template** *template-name*

**no protocol-vlan vlan** *group-name*

## Parameter

*vlan-id*— Specify IEEE 802.1Q VLAN ID, ranging from 1-4094.

*priority*— Specify the 802.1p priority for the packets that belong to the protocol VLAN, ranging from 0–7. The switch will determine the forwarding sequence according to this value. The packets with larger value of 802.1p priority have the higher priority.

*template-idx*—The number of the Protocol-based VLAN Template. You can get the template corresponding to the number by the [show protocol-vlan template](#) command.

*group-idx* —The number of the Protocol-based VLAN entry. You can get the Protocol-based VLAN entry corresponding to the number by the [show protocol-vlan vlan](#) command.

*template-name* —The name of the Protocol-based VLAN Template. You can get the template corresponding to the number by the [show protocol-vlan template](#) command.

*group-name* —The name of the Protocol-based VLAN entry. You can get the Protocol-based VLAN entry corresponding to the number by the [show protocol-vlan vlan](#) command.

## Command Mode

Global Configuration Mode

## Privilege Requirement

Only Admin, Operator and Power User level users have access to these commands.

## Example

Create Protocol-based VLAN 2 and bind it with Protocol-based VLAN Template 3:

```
Switch(config)#protocol-vlan vlan 2 template 3
```

# 20.3 protocol-vlan group

## Description

The **protocol-vlan** command is used to add the port to a specified protocol group. To remove the port from this protocol group, please use **no protocol-vlan group** command.

## Syntax

**For L2/L2+\_ switches:**

**protocol-vlan group** *index*

**no protocol-vlan group** *index*

**For L3\_ switches:**

**protocol-vlan group** *name*

**no protocol-vlan group** *name*

## Parameter

*index*—— Specify the protocol group ID.

*name*—— Specify the protocol group name.

## Command Mode

Interface Configuration Mode (interface gigabitEthernet / interface range gigabitEthernet / interface port-channel / interface range port-channel)

## Privilege Requirement

Only Admin, Operator and Power User level users have access to these commands.

## Example

Add Gigabit Ethernet port 20 to protocol group 1:

```
Switch(config)#interface gigabitEthernet 1/0/20
Switch(config-if)#protocol-vlan group 1
```

# 20.4 show protocol-vlan template

## Description

The **show protocol-vlan template** command is used to display the information of the Protocol-based VLAN templates.

## Syntax

```
show protocol-vlan template
```

## Command Mode

Privileged EXEC Mode and Any Configuration Mode

## Privilege Requirement

None.

## Example

Display the information of the Protocol-based VLAN templates:

```
Switch(config)#show protocol-vlan template
```

## 20.5 show protocol-vlan vlan

### Description

The **show protocol-vlan vlan** command is used to display the information about Protocol-based VLAN entry.

### Syntax

```
show protocol-vlan vlan
```

### Command Mode

Privileged EXEC Mode and Any Configuration Mode

### Privilege Requirement

None.

### Example

Display information of the Protocol-based VLAN entry:

```
Switch(config)#show protocol-vlan vlan
```



# Chapter 21 Private VLAN Commands (Only for Certain Devices)



**Note:** Private VLAN commands are only available on certain devices.

Private VLANs are configured specially for saving VLAN resource of uplink devices and decreasing broadcast.

## 21.1 private-vlan primary

### Description

The **private-vlan primary** command is used to configure the designated VLAN as the primary VLAN of the Private VLAN. To remove the primary VLAN property of the current VLAN, please use **no private-vlan primary** command.

### Syntax

```
private-vlan primary  
no private-vlan primary
```

### Command Mode

VLAN Configuration Mode (VLAN)

### Privilege Requirement

Only Admin and Operator level users have access to these commands.

### Example

Configure the VLAN 3 as the primary VLAN of the private VLAN:

```
Switch(config)#vlan 3  
Switch(config-vlan)#private-vlan primary
```

## 21.2 private-vlan community

### Description

The **private-vlan community** command is used to configure the designated VLAN as the community VLAN of the Private VLAN. To remove the

community VLAN property of the current VLAN, please use **no private-vlan community** command.

### Syntax

**private-vlan community**  
**no private-vlan community**

### Command Mode

VLAN Configuration Mode (VLAN)

### Privilege Requirement

Only Admin and Operator level users have access to these commands.

### Example

Configure the VLAN 4 as the community VLAN of the private VLAN:

```
Switch(config)#vlan 4
Switch(config-vlan)#private-vlan community
```

## 21.3 private-vlan isolated

### Description

The **private-vlan isolated** command is used to configure the designated VLAN as the isolated VLAN of the Private VLAN. To remove the isolated VLAN property of the current VLAN, please use **no private-vlan isolated** command.

### Syntax

**private-vlan isolated**  
**no private-vlan isolated**

### Command Mode

VLAN Configuration Mode (VLAN)

### Privilege Requirement

Only Admin and Operator level users have access to these commands.

### Example

Configure the VLAN 3 as the isolated VLAN of the private VLAN:

```
Switch(config)#vlan 3
```

```
Switch(config-vlan)#private-vlan isolated
```

## 21.4 private-vlan association

### Description

The **private-vlan association** command is used to associate primary VLAN with secondary VLAN. To exterminate the currently association, please use **no private-vlan association** command.

### Syntax

```
private-vlan association vlan_list
```

```
no private-vlan association vlan_list
```

### Parameter

*vlan\_list*—— Secondary VLAN ID, ranging from 2 to 4094.

### Command Mode

VLAN Configuration Mode (VLAN)

### Privilege Requirement

Only Admin and Operator level users have access to these commands.

### Example

Associate primary VLAN 3 with community VLAN 4 as a private VLAN:

```
Switch(config)#vlan 3
```

```
Switch(config-vlan)#private-vlan association 4
```

## 21.5 switchport private-vlan

### Description

The **switchport private-vlan** command is used to configure the private VLAN mode for the switchport. To invalid the configuration, please use **no switchport private-vlan** command.

### Syntax

```
switchport private-vlan { promiscuous | host }
```

```
no switchport private-vlan
```

## Parameter

promiscuous | host — Configure the private VLAN mode for the switchport.

## Command Mode

Interface Configuration Mode (interface gigabitEthernet / interface range gigabitEthernet / interface port-channel / interface range port-channel)

## Privilege Requirement

Only Admin and Operator level users have access to these commands.

## Example

Configure Gigabit Ethernet port 3 as "host":

```
Switch(config)#interface gigabitEthernet 1/0/3
```

```
Switch(config-if)#switchport private-vlan host
```

# 21.6 switchport private-vlan host-association

## Description

The **switchport private-vlan host-association** command is used to add host type port to private VLAN. To remove the port from Private VLAN, please use **no switchport private-vlan host-association** command.

## Syntax

```
switchport private-vlan host-association primary_vlan_id
```

```
secondary_vlan_id vlantype
```

```
no switchport private-vlan host-association
```

## Parameter

*primary-vlan-id* — Primary VLAN ID, ranging from 2 to 4094.

*secondary-vlan-id* — Secondary VLAN ID, ranging from 2 to 4094.

*vlantype* — Specify the type of the secondary VLAN, either *community* or *isolated*.

## Command Mode

Interface Configuration Mode (interface gigabitEthernet / interface range gigabitEthernet / interface port-channel / interface range port-channel)

## Privilege Requirement

Only Admin and Operator level users have access to these commands.

## Example

Configure host type Gigabit Ethernet port 1/0/3 as a member of primary VLAN 3 and secondary VLAN 4, with the type of VLAN 4 as community:

```
Switch(config)#interface gigabitEthernet 1/0/3
Switch(config-if)#switchport private-vlan host-association 3 4 community
```

# 21.7 switchport private-vlan mapping

## Description

The **switchport private-vlan mapping** command is used to add promiscuous type port to private VLAN. To remove the port from Private VLAN, please use **no switchport private-vlan mapping** command.

## Syntax

```
switchport private-vlan mapping primary_vlan_id secondary_vlan_id
no switchport private-vlan mapping
```

## Parameter

*primary-vlan-id*—— Primary VLAN ID, ranging from 2 to 4094.

*secondary-vlan-id*—— Secondary VLAN ID, ranging from 2 to 4094.

## Command Mode

Interface Configuration Mode (interface gigabitEthernet / interface range gigabitEthernet / interface port-channel / interface range port-channel)

## Privilege Requirement

Only Admin and Operator level users have access to these commands.

## Example

Configure promiscuous type Gigabit Ethernet port 1/0/3 as a member of primary VLAN 3 and secondary VLAN 4:

```
Switch(config)#interface gigabitEthernet 1/0/3
Switch(config-if)#switchport private-vlan mapping 3 4
```

## 21.8 show vlan private-vlan

### Description

The **show vlan private-vlan** command is used to display the Private VLAN configuration information of the switch.

### Syntax

```
show vlan private-vlan
```

### Command Mode

Privileged EXEC Mode and Any Configuration Mode

### Privilege Requirement

Only Admin and Operator level users have access to these commands.

### Example

Display the configuration information of all Private VLAN:

```
Switch(config)#show vlan private-vlan
```

## 21.9 show vlan private-vlan interface

### Description

The **show vlan private-vlan interface** command is used to display the Private VLAN configuration information of the specified port(s).

### Syntax

```
show vlan private-vlan interface [fastEthernet port | gigabitEthernet port |  
ten-gigabitEthernet port | port-channel port-channel-id]
```

### Parameter

*port*—— The port number.

*port-channel-id*—— The ID of the port channel.

### Command Mode

Privileged EXEC Mode and Any Configuration Mode

## Privilege Requirement

Only Admin and Operator level users have access to these commands.

## Example

Display the configuration information of all the Ethernet ports:

```
Switch(config)#show vlan private-vlan interface
```

# Chapter 22 VLAN-VPN Commands (Only for Certain Devices)



**Note:** VLAN-VPN commands are only available on certain devices.

VLAN-VPN (Virtual Private Network) function, the implement of a simple and flexible Layer 2 VPN technology, allows the packets with VLAN tags of private networks to be encapsulated with VLAN tags of public networks at the network access terminal of the Internet Service Provider. And these packets will be transmitted with double-tag across the public networks.

## 22.1 dot1q-tunnel

### Description

The **dot1q-tunnel** command is used to enable the VLAN-VPN function globally. To disable the VLAN-VPN function, please use the **no dot1q-tunnel** command.

### Syntax

```
dot1q-tunnel
no dot1q-tunnel
```

### Command Mode

Global Configuration Mode

### Privilege Requirement

Only Admin, Operator and Power User level users have access to these commands.

### Example

Enable the VLAN-VPN function globally:

```
Switch(config)#dot1q-tunnel
```



## 22.2 switchport dot1q-tunnel tpid

### Description

The **switchport dot1q-tunnel tpid** command is used to configure Global TPID for the ports. To restore to the default value, please use the **no switchport dot1q-tunnel tpid** command.

### Syntax

```
switchport dot1q-tunnel tpid tpid  
no switchport dot1q-tunnel tpid
```

### Parameter

*tpid* — The value of Global TPID. It must be 4 Hex integers. By default, it is 8100.

### Command Mode

Interface Configuration Mode (interface gigabitEthernet / interface range gigabitEthernet / interface port-channel / interface range port-channel)

### Privilege Requirement

Only Admin, Operator and Power User level users have access to these commands.

### Example

Configure TPID of port 1/0/2 as 0x9100:

```
Switch(config)#interface gigabitEthernet 1/0/2  
Switch(config-if)#switchport dot1q-tunnel tpid 9100
```

## 22.3 dot1q-tunnel mapping

### Description

The **dot1q-tunnel mapping** command is used to enable the VLAN Mapping feature globally. To disable this function, please use the **no dot1q-tunnel mapping** command. By default, the VLAN Mapping feature is disabled.

## Syntax

**dot1q-tunnel mapping**  
**no dot1q-tunnel mapping**

## Command Mode

Global Configuration Mode

## Privilege Requirement

Only Admin, Operator and Power User level users have access to these commands.

## Example

Enable the VLAN mapping feature globally:

```
Switch(config)#dot1q-tunnel mapping
```

# 22.4 switchport dot1q-tunnel mode

## Description

The **switchport dot1q-tunnel mode** command is used to configure the VPN port's mode. To close this VPN port, please use the **no switchport dot1q-tunnel mode** command. By default, no port has been configured as the VPN port. The VPN port mode uni and nni cannot switch to each other directly, so please close the VPN port and switch to the other mode if needed.

## Syntax

**switchport dot1q-tunnel mode** { uni | nni }  
**no switchport dot1q-tunnel mode**

## Parameter

*uni*—The port connected to the clients.

*nni*—The port connected to the ISP.

## Command Mode

Interface Configuration Mode (interface gigabitEthernet / interface range gigabitEthernet / interface port-channel / interface range port-channel)

## Privilege Requirement

Only Admin, Operator and Power User level users have access to these commands.

## Example

Configure the Gigabit Ethernet port 1/0/3 as the VPN UNI ports:

```
Switch(config)#interface gigabitEthernet 1/0/3
```

```
Switch(config-if)#switchport dot1q-tunnel mode uni
```

## 22.5 switchport dot1q-tunnel missdrop (only for certain devices)



### Note:

For some devices, Missdrop can only be enabled on UNI ports.

For other devices, Missdrop can only be enabled on NNI ports.

## Description

The **switchport dot1q-tunnel missdrop** command is used to enable the VLAN-VPN missdrop function for a specific port. To disable the VLAN-VPN missdrop function, please use the **no switchport dot1q-tunnel missdrop** command.

## Syntax

```
switchport dot1q-tunnel missdrop  
no switchport dot1q-tunnel missdrop
```

## Command Mode

Interface Configuration Mode (interface gigabitEthernet / interface range gigabitEthernet / interface port-channel / interface range port-channel)

## Privilege Requirement

Only Admin, Operator and Power User level users have access to these commands.

## Example

Enable the VLAN-VPN missdrop function for Gigabit Ethernet port 1/0/3:

```
Switch(config)#interface gigabitEthernet 1/0/3
Switch(config-if)#switchport dot1q-tunnel missdrop
```

## 22.6 switchport dot1q-tunnel use\_inner\_priority

### Description

The **switchport dot1q-tunnel use\_inner\_priority** command is used to use the inner 802.1p priority. To disable this function, please use the **no switchport dot1q-tunnel use\_inner\_priority** command.

### Syntax

```
switchport dot1q-tunnel use_inner_priority
no switchport dot1q-tunnel use_inner_priority
```

### Command Mode

Interface Configuration Mode (interface gigabitEthernet / interface range gigabitEthernet / interface port-channel / interface range port-channel)

### Privilege Requirement

Only Admin, Operator and Power User level users have access to these commands.

### Example

Enable the use inner priority function for Gigabit Ethernet port 1/0/3:

```
Switch(config)#interface gigabitEthernet 1/0/3
Switch(config-if)#switchport dot1q-tunnel use_inner_priority
```

## 22.7 switchport dot1q-tunnel mapping



### Note:

For some devices, choose a UNI port to enable VLAN mapping.  
For other devices, choose a NNI port to enable VLAN mapping.

## Description

The **switchport dot1q-tunnel mapping** command is used to add the VLAN Mapping entry on a specified port. To delete the VLAN Mapping entry on this port, please use the **no switchport dot1q-tunnel mapping** command.

## Syntax

```
switchport dot1q-tunnel mapping c-vlan sp-vlan [descript]  
no switchport dot1q-tunnel mapping [c-vlan]
```

## Parameter

*c-vlan*—— Customer VLAN ID, ranging from 1 to 4094.

*sp-vlan*—— Service Provider VLAN ID, ranging from 1 to 4094.

*descript*—— Give a Description to the VLAN Mapping entry, which contains 16 characters at most.

## Command Mode

Interface Configuration Mode (interface gigabitEthernet / interface range gigabitEthernet / interface port-channel / interface range port-channel)

## Privilege Requirement

Only Admin, Operator and Power User level users have access to these commands.

## Example

Add a VLAN Mapping entry on the Gigabit Ethernet port 1/0/3 with the Customer VLAN as VLAN 2 and the Service Provider VLAN as VLAN 3:

```
Switch(config)#interface gigabitEthernet 1/0/3  
Switch(config-if)#switchport dot1q-tunnel mapping 2 3
```

# 22.8 switchport dot1q-tunnel replace

## Description

The **switchport dot1q-tunnel replace** command is used to replace the customer VLAN ID with a VLAN ID of service provider on a specified port, rather than adds an outer tag. To delete the VLAN Replace entry on this port, please use the **no switchport dot1q-tunnel replace** command.

## Syntax

```
switchport dot1q-tunnel replace c-vlan sp-vlan [descript]  
no switchport dot1q-tunnel replace c-vlan sp-vlan [descript]
```

## Parameters

*c-vlan*—— Customer VLAN ID, ranging from 1 to 4094.  
*sp-vlan*—— Service Provider VLAN ID, ranging from 1 to 4094.  
*descript*—— Give a Description to the VLAN Mapping entry, which contains 16 characters at most.

## Command Mode

Interface Configuration Mode (interface gigabitEthernet / interface range gigabitEthernet / interface port-channel / interface range port-channel)

## Privilege Requirement

Only Admin, Operator and Power User level users have access to these commands.

## User Guidelines

Before configuring VLAN Replace, enable VLAN Mapping globally.

## Example

Add a VLAN Replace entry on the Gigabit Ethernet port 1/0/3 to replace the Customer VLAN (VLAN 2) with the Service Provider VLAN (VLAN 3):

```
Switch(config)# switchport dot1q-tunnel replace 2 3
```

# 22.9 switchport dot1q-tunnel replace-out

## Description

The **switchport dot1q-tunnel replace-out** command is used to replace the VLAN ID of service provider with a customer VLAN ID on a specified port. To delete the VLAN Replace entry on this port, please use the **no switchport dot1q-tunnel replace-out** command.

## Syntax

```
switchport dot1q-tunnel replace-out sp-vlan c-vlan [descript]  
no switchport dot1q-tunnel replace-out sp-vlan c-vlan [descript]
```

## Parameters

*sp-vlan*—— Service Provider VLAN ID, ranging from 1 to 4094.

*c-vlan*—— Customer VLAN ID, ranging from 1 to 4094.

*descript*—— Give a Description to the VLAN Mapping entry, which contains 16 characters at most.

## Command Mode

Interface Configuration Mode (interface gigabitEthernet / interface range gigabitEthernet / interface port-channel / interface range port-channel)

## Privilege Requirement

Only Admin, Operator and Power User level users have access to these commands.

## User Guidelines

Before configuring VLAN Replace-Out, enable VLAN Mapping globally.

## Example

Add a VLAN Replace entry on the Gigabit Ethernet port 1/0/3 to replace the Service Provider VLAN (VLAN 2) with the Customer VLAN (VLAN 3):

```
Switch(config)# switchport dot1q-tunnel replace-out 2 3
```

# 22.10 show dot1q-tunnel

## Description

The **show dot1q-tunnel** command is used to display the global configuration information of the VLAN VPN.

## Syntax

```
show dot1q-tunnel
```

## Command Mode

Privileged EXEC Mode and Any Configuration Mode

## Privilege Requirement

None.

## Example

Display the global configuration information of the VLAN VPN:

```
Switch(config)#show dot1q-tunnel
```

## 22.11 show dot1q-tunnel mapping

### Description

The **show dot1q-tunnel mapping** command is used to display the information of VLAN Mapping entry.

### Syntax

```
show dot1q-tunnel mapping
```

### Command Mode

Privileged EXEC Mode and Any Configuration Mode

### Privilege Requirement

None.

### Example

Display the information of VLAN Mapping entry:

```
Switch(config)#show dot1q-tunnel mapping
```

## 22.12 show dot1q-tunnel interface

### Description

The **show dot1q-tunnel mapping interface** command is used to display the VLAN VPN port type.

### Syntax

```
show dot1q-tunnel interface
```

### Command Mode

Privileged EXEC Mode and Any Configuration Mode

### Privilege Requirement

None.



## Example

Display the port type of all VLAN VPN ports:

```
Switch(config)#show dot1q-tunnel interface
```

## Chapter 23 ERPS Commands

ERPS (Ethernet Ring Protection Switching) is an Ethernet ring link layer technology with high reliability and stability. It can prevent broadcast storms caused by the data loop if the Ethernet ring is complete. With a high convergence speed, it can quickly restore the communication paths among the nodes in the ring network when a link failure happens.

### 23.1 erps ring

#### Description

The **erps ring** command is used to enable the ERPS ring function globally and create an ERPS ring. To disable the ERPS ring function, please use **no erps ring** command.

#### Syntax

```
erps ring ring-id  
no erps ring ring-id
```

#### Parameter

*ring-id*—The ID of the ERPS ring, ranging from 1 to 8.

#### Command Mode

Global Configuration Mode

#### Privilege Requirement

Only Admin, Operator and Power User level users have access to these commands.

#### Example

Enable the ERPS ring function globally:

```
Switch(config)#erps ring 1
```

### 23.2 control-vlan

#### Description

The **control-vlan** command is used to configure a control VLAN for an ERPS ring to forward RAPS PDUs.

## Syntax

**control-vlan** *vlan-id*

## Parameter

*vlan-id*—Specify the ID of a control VLAN for ERPS ring, ranging from 1 to 4094.

## Command Mode

Global Configuration Mode

## Privilege Requirement

Only Admin, Operator and Power User level users have access to these commands.

## Example

Configure control VLAN 2 in ERPS ring 1:

```
Switch(config)#erps ring 1
Switch(ring-config)#control-vlan 2
```

# 23.3 description

## Description

The **description** command is used to add description information of an ERPS ring.

## Syntax

**description** *description*

## Command Mode

ERPS Ring Configuration Mode

## Privilege Requirement

Only Admin, Operator and Power User level users have access to these commands.

## Example

Add description information "ring 1":

```
Switch(ring-config)#description "ring 1"
```

## 23.4 guard-timer

### Description

The **guard-timer** command is used to configure the Guard timer in an ERPS ring. By default, the Guard timer is 200 centiseconds in an ERPS ring. To disable the guard-timer function, please use **no guard-timer** command.

### Syntax

```
guard-timer time  
no guard-timer
```

### Parameter

*time* — The time setting for guard-timer, ranging from 1 to 200, In centiseconds.

### Command Mode

ERPS Ring Configuration Mode

### Privilege Requirement

Only Admin, Operator and Power User level users have access to these commands.

### Example

Configure the time for guard-timer as 100:

```
Switch(ring-config)#guard-timer 100
```

## 23.5 wtr-timer

### Description

The **wtr-timer** command is used to configure the Wait to Restore (WTR) timer in an ERPS ring. By default, the WTR timer is 5 minutes in an ERPS ring. To disable the wtr-timer function, please use **no wtr-timer** command.

### Syntax

```
wtr-timer time  
no wtr-timer
```

### Parameter

*time* — The time setting for wtr-timer, ranging from 1 to 12.

### Command Mode

ERPS Ring Configuration Mode

## Privilege Requirement

Only Admin, Operator and Power User level users have access to these commands.

## Example

Configure the time for wtr-timer as 1:

```
Switch(ring-config)#wtr-timer 1
```

## 23.6 holdoff-timer

### Description

The **holdoff-timer** command is used to configure the Holdoff timer in an ERPS ring. By default, the Holdoff timer is 0 deciseconds in an ERPS ring. When a fault occurs, the fault is not immediately reported to ERPS. Instead, the Holdoff timer starts. If the fault persists after the timer expires, the fault will be reported to ERPS. To disable the holdoff-timer function, please use **no holdoff-timer** command.

### Syntax

**holdoff-timer** *time*

**no holdoff-timer**

### Parameter

*time* — The time setting for holdoff-timer, ranging from 1 to 100.

### Command Mode

ERPS Ring Configuration Mode

## Privilege Requirement

Only Admin, Operator and Power User level users have access to these commands.

## Example

Configure the time for holdoff-timer as 10:

```
Switch(ring-config)#holdoff-timer 10
```

## 23.7 protected-instance

### Description

The **protected-instance** command is used to configure the Ethernet ring protection (ERP) instances in an ERPS ring. To disable the protected-instance function, please use **no protected-instance** command. By default, no ERP instance is configured in an ERPS ring.

### Syntax

**protected-instance** *instance*

**no protected-instance** *instance*

### Parameter

*instance*—— The protected instance for the ERPS ring, ranging from 1 to 8.

### Command Mode

ERPS Ring Configuration Mode

### Privilege Requirement

Only Admin, Operator and Power User level users have access to these commands.

### Example

Configure the protected instance as 1, and map VLAN10-20 to instance 1:

```
Switch(ring)#spanning-tree mode mstp
Switch(ring)#spanning-tree mst configuration
Switch(ring)#instance 1 vlan 10-20
Switch(ring-config)#protected-instance 1
```

## 23.8 raps-mel

### Description

The **raps-mel** command is used to configure the value of the MEL field in Ring Auto Protection Switching (RAPS) Protocol Data Units (PDUs) of the ERPS ring. By default, the value of the MEL field in RAPS PDUs is 7.

### Syntax

**raps-mel** *mel*

## Parameter

*mel*— MEL value of the ERPS ring, ranging from 0 to 7.

## Command Mode

ERPS Ring Configuration Mode

## Privilege Requirement

Only Admin, Operator and Power User level users have access to these commands.

## Example

Configure the MEL value as 1:

```
Switch(ring-config)#raps-mel 1
```

# 23.9 revertive

## Description

The **revertive** command is used to configure the revertive switching or non-revertive switching of the ERPS ring. To disable this function, please use the **revertive disable** command. By default, ERPS rings use revertive switching.

## Syntax

**revertive enable**

**revertive disable**

## Command Mode

ERPS Ring Configuration Mode

## Privilege Requirement

Only Admin, Operator and Power User level users have access to these commands.

## Example

Enable the revertive function:

```
Switch(ring-config)#revertive enable
```

## 23.10 sub-ring

### Description

The **sub-ring** command is used to configure the ERPS ring as a sub-ring. To disable this function, please use the **no sub-ring** command.

### Syntax

**sub-ring**

**no sub-ring**

### Command Mode

ERPS Ring Configuration Mode

### Privilege Requirement

Only Admin, Operator and Power User level users have access to these commands.

### Example

Enable the sub-ring function:

```
Switch(ring-config)#sub-ring
```

## 23.11 tc-notify erps

### Description

The **tc-notify erps** command is used to enable the network topology change notification function. To disable this function, please use the **no tc-notify erps** command. By default, this function is disabled.

### Syntax

**tc-notify erps ring** *ring-id*

**no tc-notify erps ring** *ring-id*

### Parameter

*ring-id*— the ring ID of the notification, ranging from 1 to 8.

### Command Mode

ERPS Ring Configuration Mode

### Privilege Requirement

Only Admin, Operator and Power User level users have access to these commands.



## Example

Enable the network topology change notification function of ring 1:

```
Switch(ring-config)#tc-notify erps ring 1
```

## 23.12 tc-protection interval

### Description

The **tc-protection interval** command is used to configure the network topology change protection interval for sending topology change notification messages. To disable this function, please use the **no tc-protection interval** command.

### Syntax

```
tc-protection interval interval
```

```
no tc-protection interval interval
```

### Parameter

*interval*— the time interval for tc-protection, ranging from 1 to 600.

### Command Mode

ERPS Ring Configuration Mode

### Privilege Requirement

Only Admin, Operator and Power User level users have access to these commands.

## Example

Configure the tc-protection interval of the ERPS ring as 1:

```
Switch(ring-config)#tc-protection interval 1
```

## 23.13 tc-protection threshold

### Description

The **tc-protection threshold** command is used to configure the number of times ERPS parses topology change notifications and updates forwarding entries in the topology change protection interval. To disable this function, please use the **no tc-protection threshold** command.

### Syntax

```
tc-protection threshold threshold
```

**no tc-protection threshold**

### Parameter

*threshold*— the threshold for tc-protection, ranging from 1 to 255.

### Command Mode

ERPS Ring Configuration Mode

### Privilege Requirement

Only Admin, Operator and Power User level users have access to these commands.

### Example

Configure the tc-protection threshold of the ERPS ring as 1:

```
Switch(ring-config)#tc-protection threshold 1
```

## 23.14 version

### Description

The **version** command is used to configure the ERPS version.

### Syntax

**version** *version*

### Parameter

*version*— the version of the ERPS function, ranging from 1 to 2.

### Command Mode

ERPS Ring Configuration Mode

### Privilege Requirement

Only Admin, Operator and Power User level users have access to these commands.

### Example

Configure the ERPS version as 2:

```
Switch(ring-config)#version 2
```

## 23.15 virtual-channel

### Description

The **virtual-channel** command is used to configure the virtual channel (VC) mode for RAPS PDU transmission in a sub-ring. To disable this function, please use the **no virtual-channel** command.

### Syntax

**virtual-channel**

**no virtual-channel**

### Command Mode

ERPS Ring Configuration Mode

### Privilege Requirement

Only Admin, Operator and Power User level users have access to these commands.

### Example

Enable the virtual-channel function:

```
Switch(ring-config)#virtual-channel
```

## 23.16 erps ring rpl

### Description

The **erps ring rpl** command is used to add a port to the ERPS ring and specify the role of the port. To remove the role of the port, please use the **no erps ring rpl** command.

### Syntax

**erps ring** *ring id*[**rpl** *owner*|*neighbour*]

### Parameter

*ring id*— the ID of the ring that the port joins.

*owner*— configure the role of the port as owner.

*neighbour*— configure the role of the port as neighbour.

### Command Mode

Interface Configuration Mode (interface gigabitEthernet | interface range gigabitEthernet | interface port-channel | interface range port-channel )

## Privilege Requirement

Only Admin, Operator and Power User level users have access to these commands.

## Example

Configure the role of port 1/0/2 in ring 1 as owner:

```
Switch(config)# interface gigabitEthernet 1/0/2
Switch(config-if)#erps ring 1 rpl owner
```

# 23.17 erps ring protect-switch

## Description

The **erps ring protect-switch** command is used to configure a port blocking mode for the ERPS port.

## Syntax

```
erps ring ring id[protect-switch force|manual]
```

## Parameter

*ring id*— the ID of the ERPS ring, ranging from 1-255.

*force*—block a port forcibly.

*manual*— indicate the MS mode for blocking an ERPS port.

## Command Mode

Interface Configuration Mode (interface gigabitEthernet | interface range gigabitEthernet | interface port-channel | interface range port-channel )

## Privilege Requirement

Only Admin, Operator and Power User level users have access to these commands.

## Example

Configure the switch mode of port 1/0/2 in ring 1 as force:

```
Switch(config)# interface gigabitEthernet 1/0/2
Switch(config-if)#erps ring 1 protect-switch force
```

## 23.18 show erps ring

### Description

The **show erps ring** command is used to display the erps ring information..

### Syntax

```
show erps ring {ring-id | all}
```

### Parameter

*ring id*— show the information of a specified ring, ranging from 1 to 8.

*all*— show the information of all rings.

### Command Mode

Privileged EXEC Mode and Any Configuration Mode

### Privilege Requirement

Only Admin, Operator and Power User level users have access to these commands.

### Example

Show the information of all rings:

```
Switch(config)#show erps ring all
```

# Chapter 24 GVRP Commands

GVRP (GARP VLAN registration protocol) is an implementation of GARP (generic attribute registration protocol). GVRP allows the switch to automatically add or remove the VLANs via the dynamic VLAN registration information and propagate the local VLAN registration information to other switches, without having to individually configure each VLAN.

## 24.1 gvrp

### Description

The **gvrp** command is used to enable the GVRP function globally. To disable the GVRP function, please use **no gvrp** command.

### Syntax

**gvrp**  
**no gvrp**

### Command Mode

Global Configuration Mode

### Privilege Requirement

Only Admin, Operator and Power User level users have access to these commands.

### Example

Enable the GVRP function globally:

```
Switch(config)#gvrp
```

## 24.2 gvrp (interface)

### Description

The **gvrp** command is used to enable the GVRP function for the desired port. To disable it, please use **no gvrp** command. The GVRP feature can only be enabled for the trunk-type ports.

### Syntax

**gvrp**

**no gvrp**

### Command Mode

Interface Configuration Mode (interface gigabitEthernet / interface range gigabitEthernet / interface port-channel / interface range port-channel)

### Privilege Requirement

Only Admin, Operator and Power User level users have access to these commands.

### Example

Enable the GVRP function for Gigabit Ethernet ports 1/0/2-6:

```
Switch(config)#interface range gigabitEthernet 1/0/2-6
Switch(config-if-range)#gvrp
```

## 24.3 gvrp registration

### Description

The **gvrp registration** command is used to configure the GVRP registration type for the desired port. To restore to the default value, please use **no gvrp registration** command.

### Syntax

```
gvrp registration { normal | fixed | forbidden }
no gvrp registration
```

### Parameter

normal | fixed | forbidden — Registration mode. By default, the registration mode is "normal".

### Command Mode

Interface Configuration Mode (interface gigabitEthernet / interface range gigabitEthernet / interface port-channel / interface range port-channel)

### Privilege Requirement

Only Admin, Operator and Power User level users have access to these commands.

## Example

Configure the GVRP registration mode as "fixed" for Gigabit Ethernet ports 1/0/2-6:

```
Switch(config)#interface range gigabitEthernet 1/0/2-6
Switch(config-if-range)#gvrp registration fixed
```

## 24.4 gvrp timer

### Description

The **gvrp timer** command is used to set a GVRP timer for the desired port. To restore to the default setting of a GARP timer, please use **no gvrp timer** command.

### Syntax

```
gvrp timer { leaveall | join | leave } value
```

```
no gvrp timer [leaveall | join | leave]
```

### Parameter

leaveall | join | leave — They are the three timers: leave All, join and leave. Once the LeaveAll Timer is set, the port with GVRP enabled can send a LeaveAll message after the timer times out, so that other GARP ports can re-register all the attribute information. After that, the LeaveAll timer will start to begin a new cycle. To guarantee the transmission of the Join messages, a GARP port sends each Join message two times. The Join Timer is used to define the interval between the two sending operations of each Join message. Once the Leave Timer is set, the GARP port receiving a Leave message will start its Leave timer, and deregister the attribute information if it does not receive a Join message again before the timer times out.

*value* —The value of the timer. The LeaveAll Timer ranges from 1000 to 30000 centiseconds and the default value is 1000 centiseconds. The Join Timer ranges from 20 to 1000 centiseconds and the default value is 20 centiseconds. The Leave Timer ranges from 60 to 3000 centiseconds and the default value is 60 centiseconds.

### Command Mode

Interface Configuration Mode (interface gigabitEthernet / interface range gigabitEthernet / interface port-channel / interface range port-channel)



## Privilege Requirement

Only Admin, Operator and Power User level users have access to these commands.

## Example

Set the GARP leaveall timer of Gigabit Ethernet port 1/0/6 as 2000 centiseconds and restore the join timer of it to the default value:

```
Switch(config)#interface gigabitEthernet 1/0/6
```

```
Switch(config-if)#gvrp timer leaveall 2000
```

```
Switch(config-if)#no gvrp timer join
```

## 24.5 show gvrp interface

### Description

The **show gvrp interface** command is used to display the GVRP configuration information of a specified Ethernet port or of all Ethernet ports.

### Syntax

```
show gvrp interface [fastEthernet port | gigabitEthernet port | ten-gigabitEthernet port | port-channel port-channel-id]
```

### Parameter

*port*—— The port number.

*port-channel-id*—— The ID of the port channel.

### Command Mode

Privileged EXEC Mode and Any Configuration Mode

### Privilege Requirement

None.

### Example

Display the GVRP configuration information of Gigabit Ethernet port 1:

```
Switch(config)#show gvrp interface gigabitEthernet 1/0/1
```

Display the GVRP configuration information of all Ethernet ports:

```
Switch(config)#show gvrp interface
```

## 24.6 show gvrp global

### Description

The **show gvrp global** command is used to display the global GVRP status.

### Syntax

```
show gvrp global
```

### Command Mode

Privileged EXEC Mode and Any Configuration Mode

### Privilege Requirement

None.

### Example

Display the global GVRP status:

```
Switch(config)#show gvrp global
```

# Chapter 25 IGMP Snooping Commands

IGMP Snooping (Internet Group Management Protocol Snooping) is a multicast control mechanism running on Layer 2 switch. It can effectively prevent multicast groups being broadcasted in the network.

## 25.1 ip igmp snooping (global)

### Description

The **ip igmp snooping** command is used to configure IGMP Snooping globally. To disable the IGMP Snooping function, please use **no ip igmp snooping** command.

### Syntax

**ip igmp snooping**  
**no ip igmp snooping**

### Command Mode

Global Configuration Mode

### Privilege Requirement

Only Admin, Operator and Power User level users have access to these commands.

### Example

Enable IGMP Snooping function:

```
Switch(config)# ip igmp snooping
```

## 25.2 ip igmp snooping version

### Description

The **ip igmp snooping version** command is used to configure IGMP version globally. To return to the default configuration, please use **no ip igmp snooping version** command.

### Syntax

**ip igmp snooping version {v1 | v2 | v3 }**  
**no ip igmp snooping version**

## Parameter

v1 | v2 | v3— Specify the IGMP version. By default, it is IGMP v3.

v1: The switch works as an IGMPv1 Snooping switch. It can only process IGMPv1 messages from the host. Report messages of other versions are ignored.

v2: The switch works as an IGMPv2 Snooping switch. It can process both IGMPv1 and IGMPv2 messages from the host. IGMPv3 messages are ignored.

v3: The switch works as an IGMPv3 Snooping switch. It can process IGMPv1, IGMPv2 and IGMPv3 messages from the host.

## Command Mode

Global Configuration Mode

## Privilege Requirement

Only Admin, Operator and Power User level users have access to these commands.

## Example

Specify the IGMP version as v2:

```
Switch (config)# ip igmp snooping version v2
```

# 25.3 ip igmp snooping drop-unknown

## Description

The **ip igmp snooping drop-unknown** command is used to configure the way how the switch processes multicast streams that are sent to unknown multicast groups as Discard. By default, it is Forward. To return to the default configuration, please use **no ip igmp snooping drop-unknown** command.

## Syntax

**ip igmp snooping drop-unknown**

**no ip igmp snooping drop-unknown**

## Command Mode

Global Configuration Mode

## Privilege Requirement

Only Admin, Operator and Power User level users have access to these commands.

## Example

Specify the operation to process unknown multicast as discard:

```
Switch(config)# ip igmp snooping drop-unknown
```

## 25.4 ip igmp snooping header-validation

### Description

The **ip igmp snooping header-validation** command is used to enable IGMP Header Validation globally. To disable the IGMP Header Validation function, please use **no ip igmp snooping header-validation** command.

Generally, for IGMP packets, the TTL value should be 1, ToS field should be 0xC0, and Router Alert option should be 0x94040000. The fields to be validated depend on the IGMP version being used. IGMPv1 only checks the TTL field. IGMPv2 checks the TTL field and the Router Alert option. IGMPv3 checks TTL field, ToS field and Router Alert option. Packets that fail the validation process will be dropped.

### Syntax

**ip igmp snooping header-validation**

**no ip igmp snooping header-validation**

### Command Mode

Global Configuration Mode

### Privilege Requirement

Only Admin, Operator and Power User level users have access to these commands.

## Example

Enable IGMP Header Validation:

```
Switch(config)# ip igmp snooping header-validation
```

## 25.5 ip igmp snooping vlan-config

### Description

The **ip igmp snooping vlan-config** command is used to enable VLAN IGMP Snooping function or to modify IGMP Snooping parameters. To disable the

VLAN IGMP Snooping function, please use **no ip igmp snooping vlan-config** command. To restore the default values, please use **no ip igmp snooping vlan-config** with specified parameters.

## Syntax

```
ip igmp snooping vlan-config vlan-id-list [ rtime router-time | mtime member-time | ltime leave-time ]
```

```
no ip igmp snooping vlan-config vlan-id-list [ rtime | mtime | ltime ]
```

## Parameter

*vlan-id-list* — The ID list of the VLAN desired to modify configuration, ranging from 1 to 4094, in the format of 1-3, 5.

*router-time* — The Router Port Aging Time. Within this time, if the switch does not receive IGMP query message from the router port, it will consider this port is not a router port any more. Valid values are from 60 to 600 in seconds, and the default value is 300 seconds.

*member-time* — The Member Port Aging Time. Within this time, if the switch does not receive IGMP report message from the member port, it will consider this port is not a member port any more. Valid values are from 60 to 600 in seconds, and the default value is 260 seconds.

*leave-time* — The Leave Time. Valid values are from 1 to 30 in seconds, and the default value is 1 second. When the switch receives a leave message from a port to leave a multicast group, it will wait for a Leave Time before removing the port from the multicast group. During the period, if the switch receives any report messages from the port, the port will not be removed from the multicast group. Exceptions are as follows:

- If the member port ages out before the Leave Time ends and no report messages are received, the port will be removed from the multicast group once its Member Port Aging Time ends.
- The Leave Time mechanism will not take effect when Fast Leave takes effect.

## Command Mode

Global Configuration Mode

## Privilege Requirement

Only Admin, Operator and Power User level users have access to these commands.

## Example

Enable the IGMP Snooping function and modify Router Port Aging Time as 300 seconds, Member Port Aging Time as 200 seconds for VLAN 1-3:

```
Switch(config)# ip igmp snooping vlan-config 1-3 rtime 300
```

```
Switch(config)# ip igmp snooping vlan-config 1-3 mtime 200
```

## 25.6 ip igmp snooping vlan-config (immediate-leave)

### Description

This command is used to enable the Fast Leave feature for specific VLANs. To disable Fast Leave on the VLANs, please use **no ip igmp snooping vlan-config *vlan-id-list* immediate-leave** command. This function is disabled by default.

### Syntax

```
ip igmp snooping vlan-config vlan-id-list immediate-leave
```

```
no ip igmp snooping vlan-config vlan-id-list immediate-leave
```

### Parameter

*vlan-id-list* — The ID list of the VLAN desired to modify configuration, ranging from 1 to 4094, in the format of 1-3, 5.

### Command Mode

Global Configuration Mode

### Privilege Requirement

Only Admin, Operator and Power User level users have access to these commands.

## Example

Enable the Fast Leave for VLAN 1-3:

```
Switch(config)# ip igmp snooping vlan-config 1-3 immediate-leave
```

## 25.7 ip igmp snooping vlan-config (report-suppression)

### Description

This command is used to enable the IGMP Report Suppression function for specific VLANs. When enabled, the switch will only forward the first IGMP report message for each multicast group to the IGMP querier and suppress subsequent IGMP report messages for the same multicast group during one query interval. This feature prevents duplicate report messages from being sent to the IGMP querier. To disable the IGMP report suppression function and forward all the IGMP reports to the Layer 3 device in specific VLANs, please use **no ip igmp snooping vlan-config *vlan-id-list* report-suppression** command. This function is disabled by default.

### Syntax

**ip igmp snooping vlan-config *vlan-id-list* report-suppression**

**no ip igmp snooping vlan-config *vlan-id-list* report-suppression**

### Parameter

*vlan-id-list* — The ID list of the VLAN desired to modify configuration, ranging from 1 to 4094, in the format of 1-3, 5.

### Command Mode

Global Configuration Mode

### Privilege Requirement

Only Admin, Operator and Power User level users have access to these commands.

### Example

Enable the IGMP Report Suppression for VLAN 1-3:

```
Switch(config)# ip igmp snooping vlan-config 1-3 report-suppression
```



## 25.8 ip igmp snooping vlan-config (router-ports-forbidd)

### Description

This command is used to forbid the specified ports as being router ports in the specified VLAN(s). To delete the forbidden router ports, please use **no ip igmp snooping vlan-config *vlan-id-list* router-ports-forbidd** command.

### Syntax

**ip igmp snooping vlan-config *vlan-id-list* router-ports-forbidd interface { gigabitEthernet *port-list* | port-channel *port-channel-list* }**

**no ip igmp snooping vlan-config *vlan-id-list* router-ports-forbidd interface [ gigabitEthernet *port-list* | port-channel *port-channel-list* ]**

### Parameter

*vlan-id-list* — The ID list of the VLAN desired to modify configuration, ranging from 1 to 4094, in the format of 1-3, 5.

*port-list* — Forbid the specified ports as being router ports. Packets sent from multicast routers to these ports will be discarded.

*port-channel-list* — Forbid the specified port-channels as being router ports. Packets sent from multicast routers to these port-channels will be discarded.

### Command Mode

Global Configuration Mode

### Privilege Requirement

Only Admin, Operator and Power User level users have access to these commands.

### Example

Forbid the Ethernet ports 1/0/1-3 as being router ports in VLAN 1 :

```
Switch(config)# ip igmp snooping vlan-config 1 router-ports-forbidd  
interface gigabitEthernet 1/0/1-3
```

## 25.9 ip igmp snooping vlan-config (rport interface)

### Description

This command is used to specify the static router ports for specific VLANs. To delete the static router ports, please use **no ip igmp snooping vlan-config *vlan-id-list* rport interface** command.

### Syntax

```
ip igmp snooping vlan-config vlan-id-list rport interface { gigabitEthernet port-list | port-channel port-channel-list }  
no ip igmp snooping vlan-config vlan-id-list rport interface { gigabitEthernet port-list | port-channel port-channel-list }
```

### Parameter

*vlan-id-list* — The ID list of the VLAN desired to modify configuration, ranging from 1 to 4094, in the format of 1-3, 5.

*port-list* — The list of Ethernet ports.

*port-channel-list* — The ID of the port channels.

### Command Mode

Global Configuration Mode

### Privilege Requirement

Only Admin, Operator and Power User level users have access to these commands.

### Example

Set the router port as 1/0/1 for VLAN 1-2:

```
Switch(config)# ip igmp snooping vlan-config 1-2 rport interface  
gigabitEthernet 1/0/1
```

## 25.10 ip igmp snooping vlan-config (static)

### Description

This command is used to configure interfaces to statically join a multicast group. To remove interfaces from a static multicast group, please use **no ip igmp snooping vlan-config *vlan-id-list* static** command.

## Syntax

```
ip igmp snooping vlan-config vlan-id-list static ip interface  
{ gigabitEthernet port-list | port-channel port-channel-list }  
no ip igmp snooping vlan-config vlan-id-list static ip interface  
{ gigabitEthernet port-list | port-channel port-channel-list }
```

## Parameter

*vlan-id-list* — The ID list of the VLAN desired to modify configuration, ranging from 1 to 4094, in the format of 1-3, 5.

*ip* — Specify the IP address of the multicast group that the hosts want to join.

*port-list* — The list of Ethernet ports.

*port-channel-list* — The ID of the port channels.

## Command Mode

Global Configuration Mode

## Privilege Requirement

Only Admin, Operator and Power User level users have access to these commands.

## Example

Configure port ports 1/0/1-3 in VLAN 2 to statically join multicast group 225.0.0.1:

```
Switch(config)# ip igmp snooping vlan-config 2 static 225.0.0.1 interface  
gigabitEthernet 1/0/1-3
```

# 25.11 ip igmp snooping vlan-config (querier)

## Description

This command is used to enable the IGMP Snooping Querier feature for specific VLANs. To disable the IGMP Snooping Querier feature on the VLANs, please use **no ip igmp snooping vlan-config** *vlan-id-list* **querier** command without any parameters. To restore the default values, please use **no ip igmp snooping vlan-config** *vlan-id-list* **querier** command with specified parameters.

## Syntax

```
ip igmp snooping vlan-config vlan-id-list querier [ max-response-time response-time | query-interval interval | general-query source-ip ip-addr | last-member-query-count count | last-member-query-interval interval ]
```

```
no ip igmp snooping vlan-config vlan-id-list querier [ max-response-time | query-interval | general-query source-ip | last-member-query-count ]
```

## Parameter

*vlan-id-list* — The ID list of the VLAN desired to modify configuration, ranging from 1 to 4094, in the format of 1-3, 5.

*response-time* — The host's maximum response time to general query messages. Valid values are from 1 to 25 seconds, and the default value is 10 seconds.

**query-interval** *interval* — The interval between general query messages sent by the switch. Valid values are from 10 to 300 seconds, and the default value is 60 seconds.

*ip-addr* — The source IP address of the general query messages sent by the switch. It should be a unicast address. By default, it is 0.0.0.0.

*count* — The number of group-specific queries to be sent. With IGMP Snooping Querier enabled, when the switch receives an IGMP leave message, it obtains the address of the multicast group that the host wants to leave from the message. Then the switch sends out group-specific queries to this multicast group through the port receiving the leave message. If specified count of group-specific queries are sent and no report message is received, the switch will delete the multicast address from the multicast forwarding table. Valid values are from 1 to 5, and the default value is 2.

**last-member-query-interval** *interval* — The interval between group-specific queries.. Valid values are from 1 to 5 seconds, and the default value is 1 second.

## Command Mode

Global Configuration Mode

## Privilege Requirement

Only Admin, Operator and Power User level users have access to these commands.

## Example

Enable the IGMP Snooping Querier for VLAN 3, and configure the query interval as 100 seconds:

```
Switch(config)# ip igmp snooping vlan-config 3 querier
```

```
Switch(config)# ip igmp snooping vlan-config 3 querier query interval 100
```

## 25.12 ip igmp snooping (interface)

### Description

The **ip igmp snooping** command is used to enable the IGMP Snooping function for the desired port. To disable the IGMP Snooping function, please use **no ip igmp snooping** command.

### Syntax

```
ip igmp snooping
```

```
no ip igmp snooping
```

### Command Mode

Interface Configuration Mode (interface gigabitEthernet / interface range gigabitEthernet / interface port-channel / interface range port-channel)

### Privilege Requirement

Only Admin, Operator and Power User level users have access to these commands.

### Example

Enable IGMP Snooping function of port 1/0/3:

```
Switch(config)# interface gigabitEthernet 1/0/3
```

```
Switch(config-if)# ip igmp snooping
```

## 25.13 ip igmp snooping

### max-groups

### Description

The **ip igmp snooping max-groups** command is used to configure the maximum number of groups that a port can join in. The **ip igmp snooping max-groups action** is used to configure the action that the port takes when it receives an IGMP report message and the maximum number of entries is in the forwarding table. To remove the maximum group limitation and return to the default of no limitation on the specified port, please use the **no ip igmp snooping max-groups** command. To return to the default action of dropping

the report, please use the **no ip igmp snooping max-groups action** command. These commands only apply to the dynamic multicast groups.

## Syntax

**ip igmp snooping max-groups** *maxgroup*

**ip igmp snooping max-groups action** { drop | replace }

**no ip igmp snooping max-groups**

**no ip igmp snooping max-groups action**

## Parameter

*maxgroup* — Specify the maximum numbers of groups that the port can join. It ranges from 0 to 1000 and the default value is 1000.

drop — When the number of the dynamic multicast groups that a port joins has exceeded the max-group, the port will not join any new multicast group.

replace — When the number of the dynamic multicast groups that a port joins has exceeded the max-group, the newly joined multicast group will replace an existing multicast group with the lowest multicast group address.

## Command Mode

Interface Configuration Mode (interface gigabitEthernet / interface range gigabitEthernet / interface port-channel / interface range port-channel)

## Privilege Requirement

Only Admin, Operator and Power User level users have access to these commands.

## Example

Specify the maximum numbers of groups that ports 1/0/2-5 can join as 10, and configure the throttling action as replace:

```
Switch(config)#interface range gigabitEthernet 1/0/2-5
Switch(config-if-range)#ip igmp snooping max-groups 10
Switch(config-if-range)#ip igmp snooping max-groups action replace
```

## 25.14 ip igmp snooping immediate-leave

### Description

The **ip igmp snooping immediate-leave** command is used to configure the Fast Leave function for port. To disable the Fast Leave function, please use **no ip igmp snooping immediate-leave** command.

### Syntax

```
ip igmp snooping immediate-leave  
no ip igmp snooping immediate-leave
```

### Command Mode

Interface Configuration Mode (interface gigabitEthernet / interface range gigabitEthernet / interface port-channel / interface range port-channel)

### Privilege Requirement

Only Admin, Operator and Power User level users have access to these commands.

### Example

Enable the Fast Leave function for port 1/0/3:

```
Switch(config)# interface gigabitEthernet 1/0/3  
Switch(config-if)# ip igmp snooping immediate-leave
```

## 25.15 ip igmp snooping authentication



**Note:** This command is only available on certain devices.

### Description

The **ip igmp snooping authenticaiton** command is used to authenticate the users who want to join the limited multicast source. To disable the multicast authentication, please use **no ip igmp snooping authentication** command.

### Syntax

```
ip igmp snooping authentication  
no ip igmp snooping authentication
```

## Command Mode

Interface Configuration Mode (interface gigabitEthernet / interface range gigabitEthernet / interface port-channel / interface range port-channel)

## Privilege Requirement

Only Admin, Operator and Power User level users have access to these commands.

## User Guidelines

The IGMP Authentication feature will take effect only when AAA function is enabled and the RADIUS server is configured. For how to enable AAA function and configure RADIUS server, please refer to [aaa enable](#) and [radius-server host](#).

## Example

Enable IGMP authentication on port 1/0/3:

```
Switch(config)# interface gigabitEthernet 1/0/3
Switch(config-if)# ip igmp snooping authentication
```

# 25.16 ip igmp snooping accounting



**Note:** This command is only available on certain devices.

## Description

The **ip igmp snooping accounting** command is used to enable IGMP accounting globally. To disable the IGMP accounting, please use **no ip igmp snooping accounting** command.

## Syntax

**ip igmp snooping accounting**

**no ip igmp snooping accounting**

## Command Mode

Global Configuration Mode

## Privilege Requirement

Only Admin, Operator and Power User level users have access to these commands.



## Example

Enable IGMP accounting globally:

```
Switch(config)# ip igmp snooping accounting
```

## 25.17 ip igmp profile

### Description

The **ip igmp profile** command is used to create the configuration profile. To delete the corresponding profile, please use **no ip igmp profile** command.

### Syntax

```
ip igmp profile id
```

```
no ip igmp profile id
```

### Parameter

*id*—— Specify the id of the configuration profile, ranging from 1 to 999.

### Command Mode

Global Configuration Mode

### Privilege Requirement

Only Admin, Operator and Power User level users have access to these commands.

## Example

Create the profile 1:

```
Switch(config)# ip igmp profile 1
```

## 25.18 deny

### Description

The **deny** command is used to configure the filtering mode of profile as deny.

### Syntax

```
deny
```

### Command Mode

Profile Configuration Mode

## Privilege Requirement

Only Admin, Operator and Power User level users have access to these commands.

## Example

Configure the filtering mode of profile 1 as deny:

```
Switch(config)# ip igmp profile 1
Switch(config-igmp-profile)#deny
```

## 25.19 permit

### Description

The **permit** command is used to configure the filtering mode of profile as permit.

### Syntax

```
permit
```

### Command Mode

Profile Configuration Mode

## Privilege Requirement

Only Admin, Operator and Power User level users have access to these commands.

## Example

Configure the filtering mode of profile 1 as permit:

```
Switch(config)# ip igmp profile 1
Switch(config-igmp-profile)#permit
```

## 25.20 range

### Description

The **range** command is used to configure the range of the profile's filtering multicast address. To delete the corresponding filtering multicast address, please use **no range** command. A profile contains 16 filtering IP-range entries at most.

## Syntax

**range** *start-ip end-ip*  
**no range** *start-ip end-ip*

## Parameter

*start-ip*—— The start filtering multicast IP address.  
*end-ip*—— The end filtering multicast IP address.

## Command Mode

Profile Configuration Mode

## Privilege Requirement

Only Admin, Operator and Power User level users have access to these commands.

## Example

Configure one of the filter multicast address entry as range 225.1.1.1 to 226.3.2.1 in profile 1:

```
Switch(config)# ip igmp profile 1  
Switch(config-igmp-profile)#range 225.1.1.1 226.3.2.1
```

# 25.21 ip igmp filter

## Description

The **ip igmp filter** command is used to bind the specified profile to the interface. To delete the binding, please use **no ip igmp filter** command.

## Syntax

**ip igmp filter** *profile-id*  
**no ip igmp filter**

## Parameter

*profile-id*—— Specify the profile ID, ranging from 1 to 999.

## Command Mode

Interface Configuration Mode (interface gigabitEthernet / interface range gigabitEthernet / interface port-channel / interface range port-channel)

## Privilege Requirement

Only Admin, Operator and Power User level users have access to these commands.

## Example

Bind profile 1 to interface gigabitEthernet 1/0/2:

```
Switch(config)# interface gigabitEthernet 1/0/2
Switch(config-if)# ip igmp filter 1
```

## 25.22 clear ip igmp snooping statistics

### Description

The **clear ip igmp snooping statistics** command is used to clear the statistics of the IGMP packets.

### Syntax

```
clear ip igmp snooping statistics
```

### Command Mode

Privileged EXEC Mode and Any Configuration Mode

### Privilege Requirement

Only Admin, Operator and Power User level users have access to these commands.

### Example

Clear the statistics of the IGMP packets:

```
Switch(config)# clear ip igmp snooping statistics
```

## 25.23 show ip igmp snooping

### Description

The **show ip igmp snooping** command is used to display the global configuration of IGMP snooping.

### Syntax

```
show ip igmp snooping
```

### Command Mode

Privileged EXEC Mode and Any Configuration Mode

### Privilege Requirement

None.

## Example

Display the global configuration of IGMP:

```
Switch# show ip igmp snooping
```

# 25.24 show ip igmp snooping interface

## Description

The **show ip igmp snooping interface** command is used to display the port configuration of IGMP snooping. If no interface is specified, it displays all interfaces' IGMP snooping configurations.

## Syntax

```
show ip igmp snooping interface [ gigabitEthernet [port-list] | port-channel [ port-channel-list ] ] { authentication | basic-config | max-groups | packet-stat }
```

## Parameter

*port-list* — The list of Ethernet ports.

*Port-channel-list* — The list of port channels.

authentication | basic-config | max-groups | packet-stat — The related configuration information selected to display.

**Note:** Authentication is only available on certain devices.

## Command Mode

Privileged EXEC Mode and Any Configuration Mode

## Privilege Requirement

None.

## Example

Display the IGMP basic configuration configuration of all ports and port channels:

```
Switch# show ip igmp snooping interface basic-config
```

Display the IGMP basic configuration of port 1/0/2:

```
Switch# show ip igmp snooping interface gigabitEthernet 1/0/2 basic-config
```

Display the IGMP packet statistics of ports 1/0/1-4:

```
Switch# show ip igmp snooping interface gigabitEthernet 1/0/1-4
packet-stat
```

## 25.25 show ip igmp snooping vlan

### Description

The **show ip igmp snooping vlan** command is used to display the VLAN configuration of IGMP snooping.

### Syntax

```
show ip igmp snooping vlan [ vlan-id ]
```

### Parameter

*vlan-id*—The VLAN ID selected to display.

### Command Mode

Privileged EXEC Mode and Any Configuration Mode

### Privilege Requirement

None.

### Example

Display the IGMP snooping configuration information of VLAN 2:

```
Switch# show ip igmp snooping vlan 2
```

## 25.26 show ip igmp snooping groups

### Description

The **show ip igmp snooping groups** command is used to display the information of all IGMP snooping groups. It can be extended to some other commands to display the dynamic and static multicast information of a selected VLAN.

### Syntax

```
show ip igmp snooping groups [ vlan vlan-id ] [ multicast_addr | count |
dynamic | dynamic count | static | static count ]
```

### Parameter

*vlan-id*—The VLAN ID selected to display the information of all multicast items.

*multicast\_addr*— IP address of the multicast group.

count— The numbers of all multicast groups.

dynamic— Display dynamic multicast groups.

dynamic count— The numbers of all dynamic multicast groups.

static— Display static multicast groups.

static count— The numbers of all static multicast groups.

## Command Mode

Privileged EXEC Mode and Any Configuration Mode

## Privilege Requirement

None.

## Example

Display the information of all IGMP snooping groups:

```
Switch#show ip igmp snooping groups
```

Display all the multicast entries in VLAN 5:

```
Switch(config)#show ip igmp snooping groups vlan 5
```

Display the count of multicast entries in VLAN 5:

```
Switch(config)#show ip igmp snooping groups vlan 5 count
```

Display the dynamic multicast groups of VLAN 5

```
Switch(config)#show ip igmp snooping groups vlan 5 dynamic
```

Display the static multicast groups of VLAN 5

```
Switch(config)#show ip igmp snooping groups vlan 5 static
```

Display the count of dynamic multicast entries of VLAN 5

```
Switch(config)#show ip igmp snooping groups vlan 5 dynamic count
```

Display the count of static multicast entries of VLAN 5

```
Switch(config)#show ip igmp snooping groups vlan 5 static count
```

## 25.27 show ip igmp profile

### Description

The **show ip igmp profile** command is used to display the configuration information of all the profiles or a specific profile.

## Syntax

**show ip igmp profile** [ *id* ]

## Parameter

*id*— Specify the ID of the profile, ranging from 1 to 999.

## Command Mode

Privileged EXEC Mode and Any Configuration Mode

## Privilege Requirement

None.

## Example

Display the configuration information of all profiles:

```
Switch(config)# show ip igmp profile
```



# Chapter 26 Layer 3 IGMP Commands (Only for Certain Devices)

## 26.1 ip igmp (global)

### Description

The **ip igmp** command is used to enable IGMP globally. To disable the IGMP function, please use **no ip igmp** command.

### Syntax

**ip igmp**

**no ip igmp**

### Command Mode

Global Configuration Mode

### Privilege Requirement

Only Admin, Operator and Power User level users have access to these commands.

### Example

Enable IGMP function globally:

```
Switch(config)# ip igmp
```

## 26.2 ip igmp (on specific ports)

### Description

The **ip igmp** command is used to enable IGMP on specific ports. To disable the IGMP function, please use **no ip igmp** command.

### Syntax

**ip igmp**

**no ip igmp**

### Command Mode

Interface Configuration Mode

### Privilege Requirement

Only Admin, Operator and Power User level users have access to these commands.

## Example

Enable IGMP function on VLAN 2:

```
Switch(config)#interface vlan 2
```

```
Switch(config-if)#ip igmp
```

## 26.3 ip igmp header-validation

### Description

The **ip igmp header-validation** command is used to enable IGMP message header validation functions: TTL (Time To Live), ToS (Type of Service), and Router Alert options. For IGMPv1, only the TTL field is validated. For IGMPv2, the TTL and Router Alert fields are validated. For IGMPv3, the TTL, ToS and Router Alert fields are validated. To disable the IGMP function, please use **no ip igmp header-validation** command.

### Syntax

```
ip igmp header-validation
```

```
no ip igmp header-validation
```

### Command Mode

Global Configuration Mode

### Privilege Requirement

Only Admin, Operator and Power User level users have access to these commands.

## Example

Enable IGMP message header validation:

```
Switch(config)# ip igmp header-validation
```

## 26.4 ip igmp version

### Description

The **ip igmp version** command is used to configure IGMP version globally. To return to the default configuration IGMPv3, please use **no ip igmp version** command.

### Syntax

```
ip igmp version {v1 | v2 | v3 }
```

```
no ip igmp version
```

## Parameter

v1 | v2 | v3— Specify the IGMP version. By default, it is IGMP v3.

v1: The switch works as an IGMPv1 switch. It can only process IGMPv1 messages from the host. Report messages of other versions are ignored.

v2: The switch works as an IGMPv2 switch. It can process both IGMPv1 and IGMPv2 messages from the host. IGMPv3 messages are ignored.

v3: The switch works as an IGMPv3 switch. It can process IGMPv1, IGMPv2 and IGMPv3 messages from the host.

## Command Mode

Global Configuration Mode

## Privilege Requirement

Only Admin, Operator and Power User level users have access to these commands.

## Example

Specify the IGMP version as v2:

```
Switch (config)#ip igmp version v2
```

# 26.5 ip igmp last-member-query-count

## Description

The **ip igmp last-member-query-count** command is used to configure the number of times special group query messages sent on the specified interface. To restore the default value, please use **no ip igmp last-member-query-count** command.

## Syntax

```
ip igmp last-member-query-count count
```

```
no ip igmp last-member-query-count
```

## Parameter

*count*: The number of times IGMP group-specific query messages are sent, ranging from 1-20. The default value is 2.

## Command Mode

Interface Configuration Mode

## Privilege Requirement

Only Admin, Operator and Power User level users have access to these commands.

## Example

Configure the number of times special group query messages sent on VLAN 2 as 3:

```
Switch (config)#interface vlan 2
Switch (config-if)#ip igmp last-member-query-count 3
```

# 26.6 ip igmp

## last-member-query-interval

## Description

The **ip igmp last-member-query-interval** command is used to configure the time interval for sending special group query messages on the specified interface. To restore the default value, please use **no ip igmp last-member-query-interval** command.

## Syntax

```
ip igmp last-member-query-interval interval
no ip igmp last-member-query-interval
```

## Parameter

*interval*: The interval for sending IGMP group-specific query messages. The value range is 10-255 (1/10 second). The default value is 10 (1/10 second).

## Command Mode

Interface Configuration Mode

## Privilege Requirement

Only Admin, Operator and Power User level users have access to these commands.

## Example

Configure the time interval for sending special group query messages sent on VLAN 2 to 2 seconds:

```
Switch (config)#interface vlan 2
Switch (config-if)#ip igmp last-member-query-interval 20
```

## 26.7 ip igmp query-interval

### Description

The **ip igmp query-interval** command is used to configure the IGMP general query interval on a specified interface. To restore the default value, please use **no ip igmp query-interval** command.

### Syntax

```
ip igmp query-interval interval
```

```
no ip igmp query-interval
```

### Parameter

*interval*: The time interval for sending IGMP general query messages on the specified interface. The value range is 1-3600 seconds. The default value is 125 seconds.

### Command Mode

Interface Configuration Mode

### Privilege Requirement

Only Admin, Operator and Power User level users have access to these commands.

### Example

Configure the interval for sending IGMP general query messages on VLAN 2 to 50 seconds:

```
Switch (config)#interface vlan 2
Switch (config-if)#ip igmp query-interval 50
```

## 26.8 ip igmp query-max-response-time

### Description

The **ip igmp query-max-response-time** command is used to configure the maximum response time to IGMP general query messages on the specified interface. To restore the default value, please use **no ip igmp query-max-response-time** command.

### Syntax

```
ip igmp query-max-response-time time
```

## **no ip igmp query-max-response-time**

### **Parameter**

*time*: The maximum response time for general group query messages on the specified interface, the value range is 10-255 (1/10 seconds), the default value is 100 (1/10 seconds).

### **Command Mode**

Interface Configuration Mode

### **Privilege Requirement**

Only Admin, Operator and Power User level users have access to these commands.

### **Example**

Configure the maximum response time for general group query messages on VLAN 2 to 5 seconds:

```
Switch (config)#interface vlan 2
Switch (config-if)#ip igmp query-max-response-time 50
```

## **26.9 ip igmp robustness**

### **Description**

The **ip igmp robustness** command is used to configure the robustness coefficient on the specified interface. To restore the default value, please use **no ip igmp robustness** command.

### **Syntax**

**ip igmp robustness** *robustness*

**no ip igmp robustness**

### **Parameter**

*robustness*: Specify the IGMP robustness coefficient, the value range is 1-255, and the default value is 2.

### **Command Mode**

Interface Configuration Mode

### **Privilege Requirement**

Only Admin, Operator and Power User level users have access to these commands.

### **Example**

Configure the robustness coefficient on VLAN 2 to 3:

```
Switch (config)#interface vlan 2
```

```
Switch (config-if)#ip igmp robustness 3
```

## 26.10 ip igmp

### startup-query-interval

#### Description

The **ip igmp startup-query-interval** command is used to configure the time interval for sending initial query packets on the specified interface. To restore the default value, please use **no ip igmp startup-query-interval** command.

#### Syntax

```
ip igmp startup-query-interval interval
```

```
no ip igmp startup-query-interval
```

#### Parameter

*interval*. The interval for sending IGMP initial query messages. The value range is 1-300 seconds. The default value is 31 seconds.

#### Command Mode

Interface Configuration Mode

#### Privilege Requirement

Only Admin, Operator and Power User level users have access to these commands.

#### Example

Configure the time interval for sending initial query packets on VLAN 2 to 10 seconds:

```
Switch (config)#interface vlan 2
```

```
Switch (config-if)#ip igmp query-interval 10
```

## 26.11 ip igmp

### last-member-query-count

#### Description

The **ip igmp last-member-query-count** command is used to configure the number of initial query packets sent on the specified interface. To restore the default value, please use **no ip igmp last-member-query-count** command.

## Syntax

**ip igmp last-member-query-count** *count*

**no ip igmp last-member-query-count**

## Parameter

*count*: The number of times IGMP initial query message is sent, the value range is 1-20, the default value is 2

## Command Mode

Interface Configuration Mode

## Privilege Requirement

Only Admin, Operator and Power User level users have access to these commands.

## Example

Configure the number of initial query packets sent on VLAN 2 to 3:

```
Switch (config)#interface vlan 2
```

```
Switch (config-if)# ip igmp last-member-query-count 3
```

# 26.12 show ip igmp

## Description

The **show ip igmp** command is used to display basic IGMP information.

## Syntax

**show ip igmp**

## Command Mode

Privileged EXEC Mode and Any Configuration Mode

## Privilege Requirement

None.

## Example

Display basic IGMP information:

```
Switch(config)#show ip igmp
```



## 26.13 show ip igmp groups

### Description

The **show ip igmp groups** command is used to display the information of all dynamic multicast groups or specified multicast groups.

### Syntax

```
show ip igmp groups {group-address} [detail]
```

### Parameter

*group-address*: Multicast group address

**detail**: Detailed information of dynamic multicast group

### Command Mode

Privileged EXEC Mode and Any Configuration Mode

### Privilege Requirement

None.

### Example

Display the information of dynamic multicast 224.0.2.40:

```
Switch(config)#show ip igmp groups 224.0.2.40 [detail]
```

## 26.14 show ip igmp groups interface

### Description

The **ip igmp groups interface vlan** command is used to display all dynamic multicast group information on the specified port.

### Syntax

```
show ip igmp groups interface { fastEthernet | gigabitEthernet | ten-gigabitEthernet } port [detail]
```

### Parameter

fastEthernet | gigabitEthernet | ten-gigabitEthernet: Interface type

*port*: Port number

**detail**: Detailed information of dynamic multicast group

## Command Mode

Privileged EXEC Mode and Any Configuration Mode

## Privilege Requirement

None.

## Example

Display detailed configuration information of all dynamic multicast groups on port 1/0/1:

```
Switch(config)#show ip igmp groups interface gigabitEthernet 1/0/1 detail
```

# 26.15 show ip igmp groups interface vlan

## Description

The **show ip igmp groups interface vlan** command is used to display all dynamic multicast group information on the specified VLAN interface.

## Syntax

```
show ip igmp groups interface vlan vlan-id [detail]
```

## Parameter

*vlan-id*: VLAN port ID

**detail**: Detailed information of dynamic multicast group

## Command Mode

Privileged EXEC Mode and Any Configuration Mode

## Privilege Requirement

None.

## Example

Display the configuration information of all dynamic multicast groups on VLAN 1:

```
Switch(config)#show ip igmp groups interface vlan 1
```

## 26.16 show ip igmp groups interface vlan

### Description

The **show ip igmp interface** command is used to display IGMP configuration information on a specified port.

### Syntax

```
show ip igmp interface { fastEthernet | gigabitEthernet | ten-gigabitEthernet }  
port [ statistic ]
```

### Parameter

fastEthernet | gigabitEthernet | ten-gigabitEthernet: Interface type

*port*: Port number

*statistic*: Statistics of IGMP packets received on the specified port

### Command Mode

Privileged EXEC Mode and Any Configuration Mode

### Privilege Requirement

None.

### Example

Display statistics of IGMP packets received on port 1/0/1:

```
Switch(config)#show ip igmp interface gigabitEthernet 1/0/1 statistic
```

## 26.17 show ip igmp interface vlan

### Description

The **show ip igmp interface vlan** command is used to display IGMP configuration information on the specified VLAN interface.

### Syntax

```
show ip igmp interface vlan vlan-id [ statistic ]
```

### Parameter

*vlan-id*: VLAN port ID

*statistic*: Statistics of IGMP packets received on the specified port

## Command Mode

Privileged EXEC Mode and Any Configuration Mode

## Privilege Requirement

None.

## Example

Display IGMP configuration information on VLAN 2:

```
Switch(config)#show ip igmp interface vlan 2
```

# Chapter 27 PIM Commands (Only for Certain Devices)

Protocol Independent Multicast, abbreviated as PIM, uses unicast routing information to provide multicast forwarding functions in a layer 3 network. PIM works in dense mode.

## 27.1 ip multicast-routing

### Description

The **ip multicast-routing** command is used to enable the IP multicast-routing function globally. To disable this function, please use the **no ip multicast-routing** command.

### Syntax

**ip multicast-routing**  
**no ip multicast-routing**

### Command Mode

Global Configuration Mode

### Privilege Requirement

Only Admin, Operator and Power User level users have access to these commands.

### Example

Enable the IP multicast-routing function globally:

```
Switch(config)#ip multicast-routing
```

## 27.2 ip pim (globally)

### Description

The **ip pim** command is used to enable IP PIM globally. To disable the IP PIM function, please use **no ip pim** command.

### Syntax

**ip pim** {dense-mode }  
**no ip pim** {dense-mode }

### Parameter

dense-mode: Enable PIM DM globally.

## Command Mode

Global Configuration Mode

## Privilege Requirement

Only Admin, Operator and Power User level users have access to these commands.

## Example

Enable PIM DM globally:

```
Switch (config)#ip pim dense-mode
```

## 27.3 ip pim (on specific ports)

### Description

The **ip pim** command is used to configure IP PIM on a specified port. To disable the IP PIM function, please use **no ip pim** command.

### Syntax

**ip pim**

**no ip pim**

### Command Mode

Interface Configuration Mode

### Privilege Requirement

Only Admin, Operator and Power User level users have access to these commands.

### Example

Enable PIM DM on port 2:

```
Switch (config)#interface vlan 2
```

```
Switch (config-if)#ip pim
```

## 27.4 ip pim hello-interval

### Description

The **ip pim hello-interval** command is used to configure the time interval for sending Hello messages on the interface. To restore the default value, please use **no ip pim hello-interval** command.

## Syntax

**ip pim query-interval** *interval*

**no ip pim query-interval** *interval*

## Parameter

*interval*: The time interval for sending Hello messages, ranging from 1 to 18725 seconds. The default value is 30 seconds.

## Command Mode

Interface Configuration Mode

## Privilege Requirement

Only Admin, Operator and Power User level users have access to these commands.

## Example

Configure the interval for VLAN interface 2 to send Hello messages to 100 seconds:

```
Switch (config)#interface vlan 2
Switch (config-if)# ip pim hello-interval 100
```

# 27.5 show ip multicast

## Description

The **show ip multicast** command is used to display the global configuration information of IP multicast.

## Syntax

**show ip multicast**

## Command Mode

Privileged EXEC Mode and Any Configuration Mode

## Privilege Requirement

None.

## Example

Display the global configuration information of IP multicast:

```
Switch(config)#show ip multicast
```

## 27.6 show ip mroute

### Description

The **show ip mroute** command is used to display the multicast routing table.

### Syntax

```
show ip mroute [ [ group ip-addr ] | [ source ip-addr ] | detail | static [ source source-ip ] | [ summary ] ]
```

### Parameter

*group ip-addr*: Multicast group IP address

*source ip-addr*: Multicast source IP address

**detail**: Displays detailed multicast routing table

**static** [ **source** *source-ip* ]: Displays all static multicast routing entries or static multicast routing entries with a specified source IP address

**summary**: Displays summary information of multicast routing entries

### Command Mode

Privileged EXEC Mode and Any Configuration Mode

### Privilege Requirement

None.

### Example

Display all multicast routing entries:

```
Switch(config)#show ip mroute
```

## 27.7 show ip pim interface

### Description

The **show ip pim interface** command is used to display the IP PIM interface information.

### Syntax

```
show ip pim interface { fastEthernet | gigabitEthernet | ten-gigabitEthernet } port vlanid vlan-id
```

### Parameter

fastEthernet | gigabitEthernet | ten-gigabitEthernet: Interface type



*port*: Port number

*vlan-id*: VLAN ID

### Command Mode

Privileged EXEC Mode and Any Configuration Mode

### Privilege Requirement

None.

### Example

Display the information on PIM VLAN 2:

```
Switch(config)#show ip pim interface vlan 2
```

## 27.8 show ip pim neighbor

### Description

The **show ip pim neighbor** command is used to display the IP PIM neighbor information.

### Syntax

```
show ip pim neighbor { fastEthernet | gigabitEthernet | ten-gigabitEthernet }  
port vlanid vlan-id
```

### Parameter

fastEthernet | gigabitEthernet | ten-gigabitEthernet: Interface type

*port*: Port number

*vlan-id*: VLAN ID

### Command Mode

Privileged EXEC Mode and Any Configuration Mode

### Privilege Requirement

None.

### Example

Display all PIM neighbor information:

```
Switch(config)#show ip pim neighbor
```

## 27.9 show ip pim statistic

### Description

The **show ip pim neighbor** command is used to display the IP PIM statistic information.

### Syntax

```
show ip pim statistic { fastEthernet | gigabitEthernet | ten-gigabitEthernet }  
port vlanid vlan-id
```

### Parameter

fastEthernet | gigabitEthernet | ten-gigabitEthernet: Interface type

*port*: Port number

*vlan-id*: VLAN ID

### Command Mode

Privileged EXEC Mode and Any Configuration Mode

### Privilege Requirement

None.

### Example

Display packet count information of all PIM interfaces:

```
Switch(config)#show ip pim statistic
```

## Chapter 28 Static Multicast Routing Commands (Only for Certain Devices)

Multicast routing creates multicast routing table entries based on existing unicast routing information or multicast static routing. When creating multicast routing table entries, multicast routing protocols use the RPF (Reverse Path Forward) checking mechanism to ensure that multicast data can be forwarded along the correct path. Multicast static route entries are one of the important basis for RPF inspection and are mainly used to change or connect RPF routes.

### 28.1 ip mroute

#### Description

The **ip mroute** command is used to add/modify static multicast routing entries globally. To delete the specified static multicast routing entry, please use the **no ip mroute** command.

#### Syntax

```
ip mroute { source-address } { mask } { rpf-address } [ distance ]
```

```
no ip mroute { source-address } { mask }
```

#### Parameter

*source-address*: IP address of the multicast source, in the format 192.168.0.1

*mask*: Subnet mask for the multicast source IP address

*rpf-address*: Specify the ingress interface of the RPF entry

*distance*: Management parameters of static multicast routing entries, ranging from 0 to 255. The smaller the value, the higher the priority. If the value of the static multicast route is smaller than the value of other RPF entries, the static multicast route takes effect. The default value is 1.

#### Command Mode

Global Configuration Mode

#### Privilege Requirement

Only Admin, Operator and Power User level users have access to these commands.

## Example

Add a static multicast routing entry with the source address 192.168.0.1, the subnet mask 255.255.255.255, the incoming interface of the RPF entry 192/168.1.1, and the management parameter 1:

```
Switch(config)#ip mroute 192.168.0.1 255.255.255.255 192.168.1.1 1
```

## 28.2 show ip mroute static

### Description

The **show ip mroute static** command is used to display the IP mroute static information.

### Syntax

```
show ip mroute static { source source-ip }
```

### Command Mode

Privileged EXEC Mode and Any Configuration Mode

### Privilege Requirement

Only Admin, Operator and Power User level users have access to these commands.

## Example

Display all static multicast routing entries:

```
Switch(config)#show ip mroute static
```

# Chapter 29 MLD Snooping Commands

MLD Snooping (Multicast Listener Discovery Snooping) is a multicast control mechanism running on Layer 2 switch. It can effectively prevent multicast groups being broadcasted in the IPv6 network.

## 29.1 ipv6 mld snooping (global)

### Description

The **ipv6 mld snooping** command is used to enable MLD Snooping function globally. If this function is disabled, all related MLD Snooping function would not work. To disable this function, please use **no ipv6 mld snooping** command.

### Syntax

**ipv6 mld snooping**  
**no ipv6 mld snooping**

### Command Mode

Global Configuration Mode

### Privilege Requirement

Only Admin and Operator level users have access to these commands.

### Example

Enable MLD Snooping:

```
Switch(config)# ipv6 mld snooping
```

## 29.2 ipv6 mld snooping drop-unknown

### Description

The **ipv6 mld snooping drop-unknown** command is used to enable the unknown multicast packets filter function. To disable this function, please use **no ipv6 mld snooping drop-unknown** command. By default, it is disabled.

### Syntax

**ipv6 mld snooping drop-unknown**  
**no ipv6 mld snooping drop-unknown**

## Command Mode

Global Configuration Mode

## Privilege Requirement

Only Admin and Operator level users have access to these commands.

## Example

Enable unknown multicast filter function:

```
Switch(config)# ipv6 mld snooping drop-unknown
```

# 29.3 ipv6 mld snooping vlan-config

## Description

The **ipv6 mld snooping vlan-config** command is used to enable VLAN MLD Snooping function or to modify MLD Snooping parameters. To disable the VLAN MLD Snooping function, please use **no ipv6 mld snooping vlan-config** command.

## Syntax

```
ipv6 mld snooping vlan-config vlan-id-list [ rtime router-time | mtime member-time | ltime leave-time ]
```

```
no ipv6 mld snooping vlan-config vlan-id-list [ rtime | mtime | ltime ]
```

## Parameter

*vlan-id-list* — The ID list of the VLAN desired to modify configuration, ranging from 1 to 4094, in the format of 1-3, 5.

*router-time* — The Router Port Aging Time. Within this time, if the switch does not receive any MLD query messages from the router port, it will consider this port is not a router port any more. Valid values are from 60 to 600 in seconds, and the default value is 300 seconds.

*member-time* — The Member Port Aging Time. Within this time, if the switch does not receive any MLD report messages from the member port, it will consider this port is not a member port any more. Valid values are from 60 to 600 in seconds, and the default value is 260 seconds.

*leave-time* — The Leave Time. Valid values are from 1 to 30 in seconds, and the default value is 1 second. When the switch receives a done message from a port to leave a multicast group, it will wait for a Leave Time before removing the port from the multicast group. During the period, if the switch receives

any report messages from the port, the port will not be removed from the multicast group. Exceptions are as follows:

- If the member port ages out before the Leave Time ends and no report messages are received, the port will be removed from the multicast group once its Member Port Aging Time ends.
- The Leave Time mechanism will not take effect when Fast Leave takes effect.

### Command Mode

Global Configuration Mode

### Privilege Requirement

Only Admin and Operator level users have access to these commands.

### Example

Enable the MLD Snooping function and modify Router Port Time as 300 seconds, Member Port Time as 200 seconds for VLAN 1-3:

```
Switch(config)# ipv6 mld snooping vlan-config 1-3 rtime 300
Switch(config)# ipv6 mld snooping vlan-config 1-3 mtime 200
```

## 29.4 ipv6 mld snooping vlan-config (immediate-leave)

### Description

This command is used to enable the Fast Leave feature for specific VLANs. To disable Fast Leave on the VLANs, please use **no ipv6 mld snooping vlan-config *vlan-id-list* immediate-leave** command. This function is disabled by default.

### Syntax

```
ipv6 mld snooping vlan-config vlan-id-list immediate-leave
no ipv6 mld snooping vlan-config vlan-id-list immediate-leave
```

### Parameter

*vlan-id-list* — The ID list of the VLAN desired to modify configuration, ranging from 1 to 4094, in the format of 1-3, 5.

### Command Mode

Global Configuration Mode

## Privilege Requirement

Only Admin, Operator and Power User level users have access to these commands.

## Example

Enable the Fast Leave for VLAN 1-3:

```
Switch(config)# ipv6 mld snooping vlan-config 1-3 immediate-leave
```

# 29.5 ipv6 mld snooping vlan-config (report-suppression)

## Description

This command is used to enable the MLD Report Suppression function for specific VLANs. When enabled, the switch will only forward the first MLD report message for each multicast group to the MLD querier and suppress subsequent MLD report messages for the same multicast group during one query interval. This feature prevents duplicate report messages from being sent to the MLD querier. To disable the MLD report suppression function and forward all the MLD reports to the Layer 3 device in specific VLANs, please use **no ipv6 mld snooping vlan-config *vlan-id-list* report-suppression** command. This function is disabled by default.

## Syntax

```
ipv6 mld snooping vlan-config vlan-id-list report-suppression
```

```
no ipv6 mld snooping vlan-config vlan-id-list report-suppression
```

## Parameter

*vlan-id-list* — The ID list of the VLAN desired to modify configuration, ranging from 1 to 4094, in the format of 1-3, 5.

## Command Mode

Global Configuration Mode

## Privilege Requirement

Only Admin, Operator and Power User level users have access to these commands.

## Example

Enable the MLD Report Suppression for VLAN 1-3:



```
Switch(config)# ipv6 mld snooping vlan-config 1-3 report-suppression
```

## 29.6 ipv6 mld snooping vlan-config (router-ports-forbidden)

### Description

This command is used to forbid the specified ports as being router ports in the specified VLAN(s). To delete the forbidden router ports, please use **no ipv6 mld snooping vlan-config *vlan-id-list* router-ports-forbidd** command.

### Syntax

```
ipv6 mld snooping vlan-config vlan-id-list router-ports-forbidd interface  
{ gigabitEthernet port-list | port-channel port-channel-list }  
no ipv6 mld snooping vlan-config vlan-id-list router-ports-forbidd  
interface [ gigabitEthernet port-list | port-channel port-channel-list ]
```

### Parameter

*vlan-id-list* — The ID list of the VLAN desired to modify configuration, ranging from 1 to 4094, in the format of 1-3, 5.

*port-list* — Forbid the specified ports as being router ports. Packets sent from multicast routers to these ports will be discarded.

*port-channel-list* — Forbid the specified port-channels as being router ports. Packets sent from multicast routers to these port-channels will be discarded.

### Command Mode

Global Configuration Mode

### Privilege Requirement

Only Admin, Operator and Power User level users have access to these commands.

### Example

Forbid the Ethernet ports 1/0/1-3 as being router ports in VLAN 1:

```
Switch(config)# ipv6 mld snooping vlan-config 1 router-ports-forbidd  
interface gigabitEthernet 1/0/1-3
```

## 29.7 ipv6 mld snooping vlan-config (rport interface)

### Description

This command is used to specify the static router ports for specific VLANs. To delete the static router ports, please use **no ipv6 mld snooping vlan-config *vlan-id-list* rport interface** command.

### Syntax

```
ipv6 mld snooping vlan-config vlan-id-list rport interface { gigabitEthernet port-list | port-channel port-channel-list }  
no ipv6 mld snooping vlan-config vlan-id-list rport interface { gigabitEthernet port-list | port-channel port-channel-list }
```

### Parameter

*vlan-id-list* — The ID list of the VLAN desired to modify configuration, ranging from 1 to 4094, in the format of 1-3, 5.

*port-list* — The list of Ethernet ports.

*port-channel-list* — The ID of the port channels.

### Command Mode

Global Configuration Mode

### Privilege Requirement

Only Admin, Operator and Power User level users have access to these commands.

### Example

Set the router port as 1/0/1 for VLAN 1-2:

```
Switch(config)# ipv6 mld snooping vlan-config 1-2 rport interface  
gigabitEthernet 1/0/1
```

## 29.8 ipv6 mld snooping vlan-config (static)

### Description

This command is used to configure interfaces to statically join a multicast group. To remove interfaces from a static multicast group, please use **no ipv6 mld snooping vlan-config *vlan-id-list* static** command.

## Syntax

```
ipv6 mld snooping vlan-config vlan-id-list static ip interface  
{ gigabitEthernet port-list | port-channel port-channel-list }  
  
no ipv6 mld snooping vlan-config vlan-id-list static ip interface  
{ gigabitEthernet port-list | port-channel port-channel-list}
```

## Parameter

*vlan-id-list* — The ID list of the VLAN desired to modify configuration, ranging from 1 to 4094, in the format of 1-3, 5.

*ip* — Specify the IP address of the multicast group that the hosts want to join.

*port-list* — The list of Ethernet ports.

*port-channel-list* — The ID of the port channels.

## Command Mode

Global Configuration Mode

## Privilege Requirement

Only Admin, Operator and Power User level users have access to these commands.

## Example

Configure port ports 1/0/1-3 in VLAN 2 to statically join multicast group ff80::1234:1:

```
Switch(config)# ipv6 mld snooping vlan-config 2 static ff80::1234:1  
interface gigabitEthernet 1/0/1-3
```

# 29.9 ipv6 mld snooping vlan-config (querier)

## Description

This command is used to enable the MLD Snooping Querier feature for specific VLANs. To disable the MLD Snooping Querier feature on the VLANs, please use **no ipv6 mld snooping vlan-config *vlan-id-list* querier** command without any parameters. To restore the default values, please use **no ipv6 mld snooping vlan-config *vlan-id-list* querier** command with specified parameters.

## Syntax

```
ipv6 mld snooping vlan-config vlan-id-list querier [ max-response-time  
response-time | query-interval interval | general-query source-ip ip-addr |  
last-listener-query-count count | last-listener-query-interval interval ]
```

```
no ipv6 mld snooping vlan-config vlan-id-list querier [ max-response-time |  
query-interval | general-query source-ip | last-listener-query-count |  
last-listener-query-interval ]
```

## Parameter

*vlan-id-list* — The ID list of the VLAN desired to modify configuration, ranging from 1 to 4094, in the format of 1-3, 5.

*response-time* — The host's maximum response time to general query messages. Valid values are from 1 to 25 seconds, and the default value is 10 seconds.

**query-interval** *interval* — The interval between general query messages sent by the switch. Valid values are from 10 to 300 seconds, and the default value is 60 seconds.

*ip-addr* — The source IP address of the general query messages sent by the switch. It should be a unicast address. By default, it is fe80::2ff:ffff:fe00:1.

*count* — The number of group-specific queries to be sent. With MLD Snooping Querier enabled, when the switch receives an MLD done message, it obtains the address of the multicast group that the host wants to leave from the message. Then the switch sends out group-specific queries to this multicast group through the port receiving the done message. If specified count of group-specific queries are sent and no report message is received, the switch will delete the multicast address from the multicast forwarding table. Valid values are from 1 to 5, and the default value is 2.

**last-member-query-interval** *interval* — The interval between group-specific queries. Valid values are from 1 to 5 seconds, and the default value is 1 second.

## Command Mode

Global Configuration Mode

## Privilege Requirement

Only Admin, Operator and Power User level users have access to these commands.

## Example

Enable the MLD Snooping Querier for VLAN 3, and configure the query interval as 100 seconds:

```
Switch(config)# ipv6 mld snooping vlan-config 3 querier
Switch(config)# ipv6 mld snooping vlan-config 3 querier query interval
100
```

## 29.10 ipv6 mld snooping (interface)

### Description

The **ipv6 mld snooping** command is used to enable MLD Snooping function on the desired port. To disable this function, please use **no ipv6 mld snooping** command.

### Syntax

```
ipv6 mld snooping
no ipv6 mld snooping
```

### Command Mode

Interface Configuration Mode (interface gigabitEthernet / interface range gigabitEthernet / interface port-channel / interface range port-channel)

### Privilege Requirement

Only Admin and Operator level users have access to these commands.

## Example

Enable MLD Snooping on port 1/0/3:

```
Switch(config)# interface gigabitEthernet 1/0/3
Switch(config-if)# ipv6 mld snooping
```

## 29.11 ipv6 mld snooping max-groups

### Description

The **ipv6 mld snooping max-groups** command is used to configure the maximum number of groups that a port can join in. The **ipv6 mld snooping max-groups action** is used to configure the action that the port takes when it

receives an MLD report message and the maximum number of entries is in the forwarding table. To remove the maximum group limitation and return to the default of no limitation on the specified port, please use the **no ipv6 mld snooping max-groups** command. To return to the default action of dropping the report, please use the **no ipv6 mld snooping max-groups action** command. These commands only apply to the dynamic multicast groups.

## Syntax

**ipv6 mld snooping max-groups** *maxgroup*

**ipv6 mld snooping max-groups action** { drop | replace }

**no ipv6 mld snooping max-groups**

**no ipv6 mld snooping max-groups action**

## Parameter

*maxgroup* — Specify the maximum numbers of groups that the port can join. It ranges from 0 to 1000 and the default value is 1000.

drop — When the number of the dynamic multicast groups that a port joins has exceeded the max-group, the port will not join any new multicast group.

replace — When the number of the dynamic multicast groups that a port joins has exceeded the max-group, the newly joined multicast group will replace an existing multicast group with the lowest multicast group address.

## Command Mode

Interface Configuration Mode (interface gigabitEthernet / interface range gigabitEthernet / interface port-channel / interface range port-channel)

## Privilege Requirement

Only Admin and Operator level users have access to these commands.

## Example

Specify the maximum numbers of groups that ports 1/0/2-5 can join as 10, and configure the throttling action as replace:

```
Switch(config)#interface range gigabitEthernet 1/0/2-5
```

```
Switch(config-if-range)#ipv6 mld snooping max-groups 10
```

```
Switch(config-if-range)#ipv6 mld snooping max-groups action replace
```

## 29.12 ipv6 mld snooping immediate-leave

### Description

The **ipv6 mld snooping immediate-leave** command is used to configure the Fast Leave function for port. To disable the Fast Leave function, please use **no ipv6 mld snooping immediate-leave** command.

### Syntax

```
ipv6 mld snooping immediate-leave  
no ipv6 mld snooping immediate-leave
```

### Command Mode

Interface Configuration Mode (interface gigabitEthernet / interface range gigabitEthernet / interface port-channel / interface range port-channel)

### Privilege Requirement

Only Admin and Operator level users have access to these commands.

### Example

Enable the Fast Leave function for port 1/0/3:

```
Switch(config)# interface gigabitEthernet 1/0/3  
Switch(config-if)# ipv6 mld snooping immediate-leave
```

## 29.13 ipv6 mld profile

### Description

The **ipv6 mld profile** command is used to create the configuration profile. To delete the corresponding profile, please use **no ipv6 mld profile** command.

### Syntax

```
ipv6 mld profile id  
no ipv6 mld profile id
```

### Parameter

*id*—— Specify the id of the configuration profile, ranging from 1 to 999.

### Command Mode

Global Configuration Mode

## Privilege Requirement

Only Admin and Operator level users have access to these commands.

## Example

Create the profile 1:

```
Switch(config)# ipv6 mld profile 1
```

## 29.14 deny

### Description

The **deny** command is used to configure the filtering mode of profile as deny.

### Syntax

```
deny
```

### Command Mode

Profile Configuration Mode

## Privilege Requirement

Only Admin and Operator level users have access to these commands.

## Example

Configure the filtering mode of profile 1 as deny:

```
Switch(config)# ipv6 mld profile 1  
Switch(config-MLD-profile)#deny
```

## 29.15 permit

### Description

The **permit** command is used to configure the filtering mode of profile as permit.

### Syntax

```
permit
```

### Command Mode

Profile Configuration Mode



## Privilege Requirement

Only Admin and Operator level users have access to these commands.

## Example

Configure the filtering mode of profile 1 as permit:

```
Switch(config)# ipv6 mld profile 1
Switch(config-igmp-profile)#permit
```

# 29.16 range

## Description

The **range** command is used to configure the range of the profile's filtering multicast address. To delete the corresponding filtering multicast address, please use **no range** command. A profile contains 16 filtering IP-range entries at most.

## Syntax

```
range start-ip end-ip
no range start-ip end-ip
```

## Parameter

*start-ip*—— Start IPv6 multicast address of the filter entry..  
*end-ip*—— End IPv6 multicast address of the filter entry.

## Command Mode

Profile Configuration Mode

## Privilege Requirement

Only Admin and Operator level users have access to these commands.

## Example

Configure one of the filter multicast address entry as range ff80::1234 to ff80::1235 in profile 1:

```
Switch(config)# ipv6 mld profile 1
Switch(config-igmp-profile)#range ff80::1234 ff80::1235
```

## 29.17 ipv6 mld filter

### Description

The **ipv6 mld filter** command is used to bind the specified profile to the interface. To delete the binding, please use **no ipv6 mld filter** command.

### Syntax

```
ipv6 mld filter profile-id  
no ipv6 mld filter
```

### Parameter

*profile-id*—— Specify the profile ID, ranging from 1 to 999.

### Command Mode

Interface Configuration Mode (interface gigabitEthernet / interface range gigabitEthernet / interface port-channel / interface range port-channel)

### Privilege Requirement

Only Admin and Operator level users have access to these commands.

### Example

Bind profile 1 to interface gigabitEthernet 1/0/2:

```
Switch(config)# interface gigabitEthernet 1/0/2  
Switch(config-if)# ipv6 mld filter 1
```

## 29.18 clear ipv6 mld snooping statistics

### Description

The **clear ipv6 mld snooping statistics** command is used to clear the statistics of the MLD packets.

### Syntax

```
clear ipv6 mld snooping statistics
```

### Command Mode

Privileged EXEC Mode and Any Configuration Mode

### Privilege Requirement

Only Admin, Operator and Power User level users have access to these commands.

## Example

Clear the statistics of the MLD packets:

```
Switch(config)# clear ipv6 mld snooping statistics
```

## 29.19 show ipv6 mld snooping

### Description

The **show ipv6 mld snooping** command is used to display the global configuration of MLD Snooping.

### Syntax

```
show ipv6 mld snooping
```

### Command Mode

Privileged EXEC Mode and Any Configuration Mode

### Privilege Requirement

None.

### Example

Display the global configuration of MLD Snooping:

```
Switch(config)# show ipv6 mld snooping
```

## 29.20 show ipv6 mld snooping interface

### Description

The **show ipv6 mld snooping interface** command is used to display the port configuration of MLD snooping.

### Syntax

```
show ipv6 mld snooping interface [ gigabitEthernet [ port | port-list ] ]  
{ basic-config | max-groups | packet-stat }
```

```
show ipv6 mld snooping interface [ port-channel [ port-channel-list ] ]  
{ basic-config | max-groups }
```

### Parameter

*port* — The Ethernet port number.

*port-list* — The list of Ethernet ports.

basic-config | max-groups | packet-stat — The related configuration information selected to display.

## Command Mode

Privileged EXEC Mode and Any Configuration Mode

## Privilege Requirement

None.

## Example

Display the MLD basic configuration configuration of all ports and port channels:

```
Switch# show ipv6 mld snooping interface basic-config
```

Display the MLD basic configuration of port 1/0/2:

```
Switch# show ipv6 mld snooping interface gigabitEthernet 1/0/2  
basic-config
```

Display the MLD packet statistics of ports 1/0/1-4:

```
Switch# show ipv6 mld snooping interface gigabitEthernet 1/0/1-4  
packet-stat
```

# 29.21 show ipv6 mld snooping vlan

## Description

The **show ipv6 mld snooping vlan** command is used to display VLAN information of MLD Snooping.

## Syntax

```
show ipv6 mld snooping vlan [ vlan-id ]
```

## Parameter

*vlan-id*—— The VLAN ID selected to display, ranging from 1 to 4094.

## Command Mode

Privileged EXEC Mode and Any Configuration Mode

## Privilege Requirement

None.

## Example

Display all of the VLAN information:

```
Switch(config)# show ipv6 mld snooping vlan
```

## 29.22 show ipv6 mld snooping groups

### Description

The **show ipv6 mld snooping groups** command is used to display multicast groups.

### Syntax

```
show ipv6 mld snooping groups [ vlan { vlan-id } ] [ ipv6_multicast_addr |  
count | dynamic | dynamic count | static | static count ]
```

### Parameter

*vlan-id* —The VLAN ID selected to display the information of all multicast items.

*ipv6\_multicast\_addr* — IPv6 address of the multicast group.

count — The numbers of all multicast groups.

dynamic — Display dynamic multicast groups.

dynamic count — The numbers of all dynamic multicast groups.

static — Display static multicast groups.

static count — The numbers of all static multicast groups.

### Command Mode

Privileged EXEC Mode and Any Configuration Mode

### Privilege Requirement

None.

### Example

Display all of the multicast groups:

```
Switch(config)# show ipv6 mld snooping groups
```

## 29.23 show ipv6 mld profile

### Description

The **show ipv6 mld profile** command is used to display the configuration information of all the profiles or a specific profile.

### Syntax

```
show ipv6 mld profile [ id ]
```

## Parameter

*id*— Specify the ID of the profile, ranging from 1 to 999.

## Command Mode

Privileged EXEC Mode and Any Configuration Mode

## Privilege Requirement

None.

## Example

Display the configuration information of all profiles:

```
Switch(config)# show ipv6 mld profile
```

# Chapter 30 MVR Commands

MVR (Multicast VLAN Registration) allows a single multicast VLAN to be shared for multicast member ports in different VLANs in IPv4 network. In IGMP Snooping, if member ports are in different VLANs, a copy of the multicast streams is sent to each VLAN that has member ports. While MVR provides a dedicated multicast VLAN to forward multicast traffic over the Layer 2 network, to avoid duplication of multicast streams for clients in different VLANs. Clients can dynamically join or leave the multicast VLAN without interfering with their relationships in other VLANs.

## 30.1 mvr (global)

### Description

The **mvr** command is used to enable MVR globally. To disable MVR, please use **no mvr** command.

### Syntax

**mvr**

**no mvr**

### Command Mode

Global Configuration Mode

### Privilege Requirement

Only Admin, Operator and Power User level users have access to these commands.

### Example

Enable MVR globally:

```
Switch(config)# mvr
```

## 30.2 mvr group

### Description

The **mvr group** command is used to add multicast groups to MVR. To delete multicast groups from MVR, please use **no mvr group** command. You can configure up to 511 multicast groups.

### Syntax

**mvr group** *ip-addr* [*count*]

**no mvr group** *ip-addr* [*count*]

### Parameter

*ip-addr* — The start IP address of the contiguous series of multicast groups.

*count* — The number of the multicast groups to be added to the MVR. Valid values are from 1 to 256, and the default value is 1.

### Command Mode

Global Configuration Mode

### Privilege Requirement

Only Admin, Operator and Power User level users have access to these commands.

### Example

Add multicast groups 225.1.2.3 -239.1.2.5 to MVR:

```
Switch (config)# mvr group 225.1.2.3 3
```

## 30.3 mvr mode

### Description

The **mvr mode** command is used to configure the MVR mode as compatible or dynamic. By default, it is compatible. To return to the default configuration, please use **no mvr mode** command.

### Syntax

**mvr mode** { compatible | dynamic }

**no mvr mode**

### Parameter

**compatible** — In this mode, the switch does not forward report or leave messages from the hosts to the IGMP querier. So the IGMP querier cannot learn the multicast groups membership information from the switch. You have to statically configure the IGMP querier to transmit all the required multicast streams to the switch via the multicast VLAN.

**dynamic** — In this mode, after receiving report or leave messages from the hosts, the switch will forward them to the IGMP querier via the multicast VLAN (with appropriate translation of the VLAN ID). So the IGMP querier can learn the multicast groups membership information through the report and leave messages, and transmit the multicast streams to the switch via the multicast VLAN according to the multicast forwarding table.



## Command Mode

Global Configuration Mode

## Privilege Requirement

Only Admin, Operator and Power User level users have access to these commands.

## Example

Configure the MVR mode as dynamic:

```
Switch(config)# mvr mode dynamic
```

# 30.4 mvr querytime

## Description

The **mvr querytime** command is used to configure the maximum time to wait for IGMP report on a receiver port before removing the port from multicast group membership. To return to the default configuration, please use **no mvr querytime** command.

## Syntax

**mvr querytime** *time*

**no mvr querytime**

## Parameter

*time* — The query response time. Valid values are from 1 to 100 tenths of a second, and the default value is 5 tenths of a second.

## Command Mode

Global Configuration Mode

## Privilege Requirement

Only Admin, Operator and Power User level users have access to these commands.

## Example

Configure the query response time of MVR as 1 second, that is 10 tenths of a second:

```
Switch(config)# mvr querytime 10
```

## 30.5 mvr vlan

### Description

The **mvr vlan** command is used to specify the multicast VLAN. By default, it is VLAN 1. To return to the default configuration, please use **no mvr vlan** command.

### Syntax

**mvr vlan** *vlan-id*

**no mvr vlan**

### Parameter

*vlan-id*— The ID of the multicast VLAN. Valid values are from 1 to 4094.

### Command Mode

Global Configuration Mode

### Privilege Requirement

Only Admin, Operator and Power User level users have access to these commands.

### Example

Configure the multicast VLAN as VLAN 10:

```
Switch(config)# mvr vlan 10
```

## 30.6 mvr (interface)

### Description

This command is used to enable MVR for specific interfaces. To disable MVR for the interfaces, please use **no mvr** command. By default, it is disabled.

### Syntax

**mvr**

**no mvr**

### Command Mode

Interface Configuration Mode (interface gigabitEthernet / interface range gigabitEthernet)

### Privilege Requirement

Only Admin, Operator and Power User level users have access to these commands.

## Example

Enable MVR for port 1/0/1:

```
Switch(config)# interface gigabitEthernet 1/0/1
Switch(config-if)#mvr
```

## 30.7 mvr type

### Description

The **mvr type** command is used to configure the MVR port type as receiver or source. By default, the port is a non-MVR port. If you attempt to configure a non-MVR port with MVR characteristics, the operation fails. To return to the default configuration, please use **no mvr type** command.

### Syntax

```
mvr type { source | receiver }
```

```
no mvr type
```

### Parameter

source — Configure the uplink ports that receive and send multicast data on the multicast VLAN as source ports. Source ports should belong to the multicast VLAN.

receiver — Configure the ports that are connecting to the hosts as receiver ports. A receiver port can only belong to one VLAN, and cannot belong to the multicast VLAN.

### Command Mode

Interface Configuration Mode (interface gigabitEthernet / interface range gigabitEthernet)

### Privilege Requirement

Only Admin, Operator and Power User level users have access to these commands.

## Example

Configure the port 1/0/3 as a receiver port:

```
Switch(config)# interface gigabitEthernet 1/0/3
Switch(config-if)#mvr type receiver
```

## 30.8 mvr immediate

### Description

The **mvr immediate** command is used to enable the Fast Leave feature of MVR for specified port. To disable the Fast Leave feature of MVR for specific ports, please use **no mvr immediate** command.

### Syntax

**mvr immediate**

**no mvr immediate**

### Command Mode

Interface Configuration Mode (interface gigabitEthernet / interface range gigabitEthernet)

### Privilege Requirement

Only Admin, Operator and Power User level users have access to these commands.

### User Guidelines

Only receiver ports support Fast Leave. Before enabling Fast Leave for a port, make sure there is only a single receiver device connecting to the port.

### Example

Enable the Fast Leave feature of MVR for port 1/0/3:

```
Switch(config)# interface gigabitEthernet 1/0/3
Switch(config-if)#mvr immediate
```

## 30.9 mvr vlan (group)

### Description

This command is used to statically add ports to an MVR group. Then the ports can receive multicast traffic sent to the IP multicast address via the multicast VLAN.

### Syntax

**mvr vlan *vlan-id* group *ip-addr***

### Parameter

*vlan-id*—— The ID of the multicast VLAN. Valid values are from 1 to 4094.

*ip-addr*—— The IP address of the multicast group.

## Command Mode

Interface Configuration Mode (interface gigabitEthernet / interface range gigabitEthernet)

## Privilege Requirement

Only Admin, Operator and Power User level users have access to these commands.

## User Guidelines

This command applies to only receiver ports. The switch adds or removes the receiver ports to the corresponding multicast groups by snooping the report and leave messages from the hosts. You can also statically add a receiver port to an MVR group.

## Example

Add port 1/0/3 to MVR group 225.1.2.3 statically. The multicast VLAN is VLAN 10:

```
Switch(config)# interface gigabitEthernet 1/0/3
Switch(config-if)#mvr vlan 10 group 225.1.2.3
```

# 30.10 mvr vlan (rule)

## Description

This command is used to change the VLAN of the receiver port, which will remove the receiver port from the original VLAN..

## Syntax

```
mvr vlan vlan-idrule [untagged|tagged]
```

## Parameter

*vlan-id*—— New VLAN ID, ranging from 1 to 4094.

*untagged*—— Add a new VLAN in the untagged way.

*tagged*—— Add a new VLAN in the tagged way.

## Command Mode

Interface Configuration Mode (interface gigabitEthernet / interface range gigabitEthernet)

## Privilege Requirement

Only Admin, Operator and Power User level users have access to these commands.

## Example

Change the VLAN of port 1/0/3 to 100 in the untagged way:

```
Switch(config)# interface gigabitEthernet 1/0/3
```

```
Switch(config-if)#mvr vlan 100 rule untagged
```

## 30.11 mvr mode dynamic auto-enable

### Description

The **mvr mode dynamic auto-enable** command is used to enable automatic addition of source ports to all multicast groups. To disable this function, please use **no mvr mode dynamic auto-enable** command.

### Syntax

```
mvr mode dynamic auto-enable
```

```
no mvr mode dynamic auto-enable
```

### Command Mode

Global Configuration Mode

### Privilege Requirement

Only Admin, Operator and Power User level users have access to these commands.

### Example

Enable automatic addition of source ports to all multicast groups:

```
Switch(config)#mvr mode dynamic auto-enable
```

## 30.12 show mvr

### Description

The **show mvr** command is used to display the global configuration of MVR.

### Syntax

```
show mvr
```

### Command Mode

Privileged EXEC Mode and Any Configuration Mode

## Privilege Requirement

None.

## Example

Display the global configuration of mvr:

```
Switch# show mvr
```

## 30.13 show mvr interface

### Description

The **show mvr interface** command is used to display the MVR configurations of specific interfaces.

### Syntax

```
show mvr interface gigabitEthernet [port | port-list]
```

### Parameter

*port*—The Ethernet port number.

*port-list*—The list of Ethernet ports.

### Command Mode

Privileged EXEC Mode and Any Configuration Mode

## Privilege Requirement

None.

## Example

Display the MVR configuration of port 1/0/3:

```
Switch# show mvr interface gigabitEthernet 1/0/3
```

## 30.14 show mvr members

### Description

The **show mvr members** command is used to display the membership information of all MVR groups or the specified MVR group.

### Syntax

```
show mvr members [ ip-addr ] [ status active | inactive ]
```

### Parameter

*ip-addr*—The multicast IP address of the MVR group.

active—Display all active MVR groups.

inactive——Display all inactive MVR groups.

### **Command Mode**

Privileged EXEC Mode and Any Configuration Mode

### **Privilege Requirement**

None.

### **Example**

Display the membership information of all MVR groups:

```
Switch# show mvr members
```



# Chapter 31 MSTP Commands

MSTP (Multiple Spanning Tree Protocol), compatible with both STP and RSTP and subject to IEEE 802.1s, can disbranch a ring network. STP is to block redundant links and backup links as well as optimize paths.

## 31.1 debug spanning-tree

### Description

The **debug spanning-tree** command is used to enable debugging of spanning-tree activities. To disable the debugging function, please use **no debug spanning-tree** command.

### Syntax

**debug spanning-tree** { all | bpdu receive | bpdu transmit | cmpmsg | errors | flush | init | migration | proposals | roles | state | tc }

**no debug spanning-tree** { all | bpdu receive | bpdu transmit | cmpmsg | errors | flush | init | migration | proposals | roles | state | tc }

### Parameters

all — Display all the spanning-tree debug messages.

bpdu receive — Display the debug messages of the received spanning-tree bridge protocol data unit (BPDU).

bpdu transmit — Display the debug messages of the sent spanning-tree BPDU.

cmpmsg — Display the message priority debug messages.

errors — Display the MSTP error debug messages.

flush — Display the address table flushing debug messages.

init — Display the data structure initialization debug messages.

migration — Display the version migration debug messages.

proposals — Display the MSTP handshake debug messages.

roles — Display the MSTP interface role switchling debug messages.

state — Display the MSTP interface state change debug messages.

tc — Display the MSTP topology event debug messages.

### Command Mode

Privileged EXEC Mode

## Privilege Requirement

Only Admin level users have access to these commands.

## Example

Display all the spanning-tree debug messages:

```
Switch# debug spanning-tree all
```

# 31.2 spanning-tree (global)

## Description

The **spanning-tree** command is used to enable STP function globally. To disable the STP function, please use **no spanning-tree** command.

## Syntax

**spanning-tree**

**no spanning-tree**

## Command Mode

Global Configuration Mode

## Privilege Requirement

Only Admin, Operator and Power User level users have access to these commands.

## Example

Enable the STP function:

```
Switch(config)# spanning-tree
```

# 31.3 spanning-tree (interface)

## Description

The **spanning-tree** command is used to enable STP function for a port. To disable the STP function, please use **no spanning-tree** command.

## Syntax

**spanning-tree**

**no spanning-tree**

## Command Mode

Interface Configuration Mode (interface gigabitEthernet / interface range gigabitEthernet / interface port-channel / interface range port-channel)

## Privilege Requirement

Only Admin, Operator and Power User level users have access to these commands.

## Example

Enable the STP function for port 1/0/2:

```
Switch(config)# interface gigabitEthernet 1/0/2
Switch(config-if)# spanning-tree
```

# 31.4 spanning-tree common-config

## Description

The **spanning-tree common-config** command is used to configure the parameters of the ports for comparison in the CIST and the common parameters of all instances. To return to the default configuration, please use **no spanning-tree common-config** command. CIST (Common and Internal Spanning Tree) is the spanning tree in a switched network, connecting all devices in the network.

## Syntax

```
spanning-tree common-config [ port-priority pri ] [ ext-cost ext-cost ]
[ int-cost int-cost ] [ portfast { enable | disable } ] [ point-to-point { auto | open
| close } ]
no spanning-tree common-config
```

## Parameter

*pri* — Port Priority, which must be multiple of 16 ranging from 0 to 240. By default, the port priority is 128. Port Priority is an important criterion on determining if the port connected to this port will be chosen as the root port. In the same condition, the port with the highest priority will be chosen as the root port. The lower value has the higher priority.

*ext-cost* — External Path Cost, which is used to choose the path and calculate the path costs of ports in different MST regions. It is an important criterion on determining the root port. The lower value has the higher priority. It ranges from 0 to 2000000. By default, it is 0 which is mean auto.

*int-cost* — Internal Path Cost, which is used to choose the path and calculate the path costs of ports in an MST region. It is an important criterion on determining the root port. The lower value has the higher priority. By

default, it is automatic. It ranges from 0 to 2000000. By default, it is 0 which means auto.

**portfast** — Enable/ Disable Edge Port. By default, it is disabled. The edge port can transit its state from blocking to forwarding rapidly without waiting for forward delay.

**point-to-point** — The P2P link status, with auto, open and close options. By default, the option is auto. If the two ports in the P2P link are root port or designated port, they can transit their states to forwarding rapidly to reduce the unnecessary forward delay.

### Command Mode

Interface Configuration Mode (interface gigabitEthernet / interface range gigabitEthernet / interface port-channel / interface range port-channel)

### Privilege Requirement

Only Admin, Operator and Power User level users have access to these commands.

### Example

Enable the STP function of port 1, and configure the Port Priority as 64, ExtPath Cost as 100, IntPath Cost as 100, and then enable Edge Port:

```
Switch(config)# interface gigabitEthernet 1/0/1
Switch(config-if)# spanning-tree common-config port-priority 64 ext-cost
100 int-cost 100 portfast enable point-to-point open
```

## 31.5 spanning-tree mode

### Description

The **spanning-tree mode** command is used to configure the STP mode of the switch. To return to the default configurations, please use **no spanning-tree mode** command.

### Syntax

```
spanning-tree mode { stp | rstp | mstp }
no spanning-tree mode
```

### Parameter

**stp** — Spanning Tree Protocol, the default value.  
**rstp** — Rapid Spanning Tree Protocol  
**mstp** — Multiple Spanning Tree Protocol

## Command Mode

Global Configuration Mode

## Privilege Requirement

Only Admin, Operator and Power User level users have access to these commands.

## Example

Configure the spanning-tree mode as mstp:

```
Switch(config)# spanning-tree mode mstp
```

# 31.6 spanning-tree mst configuration

## Description

The **spanning-tree mst configuration** command is used to access MST Configuration Mode from Global Configuration Mode, as to configure the VLAN-Instance mapping, region name and revision level. To return to the default configuration of the corresponding Instance, please use **no spanning-tree mst configuration** command.

## Syntax

**spanning-tree mst configuration**

**no spanning-tree mst configuration**

## Command Mode

Global Configuration Mode

## Privilege Requirement

Only Admin, Operator and Power User level users have access to these commands.

## Example

Enter into the MST configuration mode:

```
Switch(config)# spanning-tree mst configuration
```

```
Switch(Config-mst)#
```

## 31.7 instance

### Description

The **instance** command is used to configure the VLAN-Instance mapping. To remove the VLAN-instance mapping or disable the corresponding instance, please use **no instance** command. When an instance is disabled, the related mapping VLANs will be removed.

### Syntax

```
instance instance-id vlan vlan-id
```

```
no instance instance-id [vlan vlan-id]
```

### Parameters

*instance-id*—— Instance ID, ranging from 1 to 8.

*vlan-id* —— The VLAN ID selected to mapping with the corresponding instance.

### Command Mode

MST Configuration Mode

### Privilege Requirement

Only Admin, Operator and Power User level users have access to these commands.

### Example

Map the VLANs 1-100 to Instance 1:

```
Switch(config)# spanning-tree mst configuration
```

```
Switch(config-mst)# instance 1 vlan 1-100
```

Disable Instance 1, namely remove all the mapping VLANs 1-100:

```
Switch(config)# spanning-tree mst configuration
```

```
Switch(config-mst)# no instance 1
```

Remove VLANs 1-50 in mapping VLANs 1-100 for Instance 1:

```
Switch(config)# spanning-tree mst configuration
```

```
Switch(config-mst)# no instance 1 vlan 1-50
```

## 31.8 name

### Description

The **name** command is used to configure the region name of MST instance.

## Syntax

**name** *name*

## Parameters

*name* — The region name, used to identify MST region. It ranges from 1 to 32 characters.

## Command Mode

MST Configuration Mode

## Privilege Requirement

Only Admin, Operator and Power User level users have access to these commands.

## Example

Configure the region name of MST as "region1":

```
Switch(config)# spanning-tree mst configuration
Switch(config-mst)# name region1
```

# 31.9 revision

## Description

The **revision** command is used to configure the revision level of MST instance.

## Syntax

**revision** *revision*

## Parameters

*revision* — The revision level for MST region identification, ranging from 0 to 65535.

## Command Mode

MST Configuration Mode

## Privilege Requirement

Only Admin, Operator and Power User level users have access to these commands.

## Example

Configure the revision level of MST as 100:

```
Switch(config)# spanning-tree mst configuration
Switch(config-mst)# revision 100
```

## 31.10 spanning-tree mst instance

### Description

The **spanning-tree mst instance** command is used to configure the priority of MST instance. To return to the default value of MST instance priority, please use **no spanning-tree mst instance** command.

### Syntax

**spanning-tree mst instance** *instance-id* **priority** *pri*

**no spanning-tree mst instance** *instance-id* **priority**

### Parameter

*instance-id*—— Instance ID, ranging from 1 to 8.

*pri* —— MSTI Priority, which must be multiple of 4096 ranging from 0 to 61440. By default, it is 32768. MSTI priority is an important criterion on determining if the switch will be chosen as the root bridge in the specific instance.

### Command Mode

Global Configuration Mode

### Privilege Requirement

Only Admin, Operator and Power User level users have access to these commands.

### Example

Enable the MST Instance 1 and configure its priority as 4096:

```
Switch(config)# spanning-tree mst instance 1 priority 4096
```

## 31.11 spanning-tree mst

### Description

The **spanning-tree mst** command is used to configure MST Instance Port. To return to the default configuration of the corresponding Instance Port, please use **no spanning-tree mst** command. A port can play different roles in different spanning tree instance. You can use this command to configure the parameters of the ports in different instance IDs as well as view status of the ports in the specified instance.

### Syntax

**spanning-tree mst instance** *instance-id*[[ **port-priority** *pri*] | [ **cost** *cost*]]



**no spanning-tree mst instance** *instance-id*

### Parameter

*instance-id*— Instance ID, ranging from 1 to 8.

*pri*— Port Priority, which must be multiple of 16 ranging from 0 to 240. By default, it is 128. Port Priority is an important criterion on determining if the port will be chosen as the root port by the device connected to this port.

*cost* — Path Cost, ranging from 0 to 200000. The lower value has the higher priority. Its default value is 0 meaning "auto".

### Command Mode

Interface Configuration Mode (interface gigabitEthernet / interface range gigabitEthernet / interface port-channel / interface range port-channel)

### Privilege Requirement

Only Admin, Operator and Power User level users have access to these commands.

### Example

Configure the priority of port 1 in MST Instance 1 as 64, and path cost as 2000:

```
Switch(config)# interface gigabitEthernet 1/0/1
Switch(config-if)# spanning-tree mst instance 1 port-priority 64 cost 2000
```

## 31.12 spanning-tree priority

### Description

The **spanning-tree priority** command is used to configure the bridge priority. To return to the default value of bridge priority, please use **no spanning-tree priority** command.

### Syntax

```
spanning-tree priority pri
no spanning-tree priority
```

### Parameter

*pri*— Bridge priority, ranging from 0 to 61440. It is 32768 by default.

### Command Mode

Global Configuration Mode

## Privilege Requirement

Only Admin, Operator and Power User level users have access to these commands.

## Example

Configure the bridge priority as 4096:

```
Switch(config)# spanning-tree priority 4096
```

# 31.13 spanning-tree timer

## Description

The **spanning-tree timer** command is used to configure forward-time, hello-time and max-age of Spanning Tree. To return to the default configurations, please use **no spanning-tree timer** command.

## Syntax

```
spanning-tree timer {[ forward-time forward-time ] [ hello-time hello-time ]  
[ max-age max-age ]}
```

```
no spanning-tree timer
```

## Parameter

*forward-time* — Forward Delay, which is the time for the port to transit its state after the network topology is changed. Forward Delay ranges from 4 to 30 in seconds and it is 15 by default. Otherwise,  $2 * (\text{Forward Delay} - 1) \geq \text{Max Age}$ .

*hello-time* — Hello Time, which is the interval to send BPDU packets, and used to test the links. Hello Time ranges from 1 to 10 in seconds and it is 2 by default. Otherwise,  $2 * (\text{Hello Time} + 1) \leq \text{Max Age}$ .

*max-age* — The maximum time the switch can wait without receiving a BPDU before attempting to reconfigure, ranging from 6 to 40 in seconds. By default, it is 20.

## Command Mode

Global Configuration Mode

## Privilege Requirement

Only Admin, Operator and Power User level users have access to these commands.

## Example

Configure forward-time, hello-time and max-age for Spanning Tree as 16 seconds, 3 seconds and 22 seconds respectively:

```
Switch(config)# spanning-tree timer forward-time 16 hello-time 3  
max-age 22
```

## 31.14 spanning-tree hold-count

### Description

The **spanning-tree hold-count** command is used to configure the maximum number of BPDU packets transmitted per Hello Time interval. To return to the default configurations, please use **no spanning-tree hold-count** command.

### Syntax

```
spanning-tree hold-count value  
no spanning-tree hold-count
```

### Parameter

*value*— The maximum number of BPDU packets transmitted per Hello Time interval, ranging from 1 to 20 in pps. By default, it is 5.

### Command Mode

Global Configuration Mode

### Privilege Requirement

Only Admin, Operator and Power User level users have access to these commands.

### Example

Configure the hold-count of STP as 8pps:

```
Switch(config)# spanning-tree hold-count 8
```

## 31.15 spanning-tree max-hops

### Description

The **spanning-tree max-hops** command is used to configure the maximum number of hops that occur in a specific region before the BPDU is discarded. To return to the default configurations, please use **no spanning-tree max-hops** command.

### Syntax

```
spanning-tree max-hops value  
no spanning-tree max-hops
```

## Parameter

*value* — The maximum number of hops that occur in a specific region before the BPDU is discarded, ranging from 1 to 40 in hop. By default, it is 20.

## Command Mode

Global Configuration Mode

## Privilege Requirement

Only Admin, Operator and Power User level users have access to these commands.

## Example

Configure the max-hops of STP as 30:

```
Switch(config)# spanning-tree max-hops 30
```

# 31.16 spanning-tree bpdudfilter

## Description

The **spanning-tree bpdudfilter** command is used to enable the BPDU filter function for a port. With the BPDU Filter function enabled, the port does not forward BPDUs from the other switches. To disable the BPDU filter function, please use **no spanning-tree bpdudfilter** command.

## Syntax

**spanning-tree bpdudfilter**

**no spanning-tree bpdudfilter**

## Command Mode

Interface Configuration Mode (interface gigabitEthernet / interface range gigabitEthernet / interface port-channel / interface range port-channel)

## Privilege Requirement

Only Admin, Operator and Power User level users have access to these commands.

## Example

Enable the BPDU filter function for port 1/0/2:

```
Switch(config)# interface gigabitEthernet 1/0/2
```

```
Switch(config-if)# spanning-tree bpdudfilter
```

## 31.17 spanning-tree bpduflood

### Description

The **spanning-tree bpduflood** command is used to enable the BPDU forward function for a port. With the function enabled, the port still can forward spanning tree BPDUs when the spanning tree function is disabled on this port. To disable the BPDU filter function, please use **no spanning-tree bpduflood** command.

### Syntax

**spanning-tree bpduflood**

**no spanning-tree bpduflood**

### Command Mode

Interface Configuration Mode (interface gigabitEthernet / interface range gigabitEthernet / interface port-channel / interface range port-channel)

### Privilege Requirement

Only Admin, Operator and Power User level users have access to these commands.

### Example

Enable the BPDU forward function for port 1/0/2:

```
Switch(config)# interface gigabitEthernet 1/0/2
```

```
Switch(config-if)# spanning-tree bpduflood
```

## 31.18 spanning-tree bpduguard

### Description

The **spanning-tree bpduguard** command is used to enable the BPDU protect function for a port. With the BPDU protect function enabled, the port will set itself automatically as ERROR-PORT when it receives BPDU packets, and the port will disable the forwarding function for a while. To disable the BPDU protect function, please use **no spanning-tree bpduguard** command.

### Syntax

**spanning-tree bpduguard**

**no spanning-tree bpduguard**

## Command Mode

Interface Configuration Mode (interface gigabitEthernet / interface range gigabitEthernet / interface port-channel / interface range port-channel)

## Privilege Requirement

Only Admin, Operator and Power User level users have access to these commands.

## Example

Enable the BPDU protect function for port 1/0/2:

```
Switch(config)# interface gigabitEthernet 1/0/2
Switch(config-if)# spanning-tree bpduguard
```

# 31.19 spanning-tree guard loop

## Description

The **spanning-tree guard loop** command is used to enable the Loop Protect function for a port. Loop Protect is to prevent the loops in the network brought by recalculating STP because of link failures and network congestions. To disable the Loop Protect function, please use **no spanning-tree guard loop** command.

## Syntax

```
spanning-tree guard loop
no spanning-tree guard loop
```

## Command Mode

Interface Configuration Mode (interface gigabitEthernet / interface range gigabitEthernet / interface port-channel / interface range port-channel)

## Privilege Requirement

Only Admin, Operator and Power User level users have access to these commands.

## Example

Enable the Loop Protect function for port 2:

```
Switch(config)# interface gigabitEthernet 1/0/2
Switch(config-if)# spanning-tree guard loop
```

## 31.20 spanning-tree guard root

### Description

The **spanning-tree guard root** command is used to enable the Root Protect function for a port. With the Root Protect function enabled, the root bridge will set itself automatically as ERROR-PORT when receiving BPDU packets with higher priority, in order to maintain the role of root ridge. To disable the Root Protect function, please use **no spanning-tree guard root** command.

### Syntax

**spanning-tree guard root**

**no spanning-tree guard root**

### Command Mode

Interface Configuration Mode (interface gigabitEthernet / interface range gigabitEthernet / interface port-channel / interface range port-channel)

### Privilege Requirement

Only Admin, Operator and Power User level users have access to these commands.

### Example

Enable the Root Protect function for port 2:

```
Switch(config)# interface gigabitEthernet 1/0/2
```

```
Switch(config-if)# spanning-tree guard root
```

## 31.21 spanning-tree guard tc

### Description

The **spanning-tree guard tc** command is used to enable the TC Protect of Spanning Tree function for a port. To disable the TC Protect of Spanning Tree function, please use **no spanning-tree guard tc** command. A switch removes MAC address entries upon receiving TC-BPDUs. If a malicious user continuously sends TC-BPDUs to a switch, the switch will be busy with removing MAC address entries, which may decrease the performance and stability of the network. With the Protect of Spanning Tree function enabled, you can configure the number of TC-BPDUs in a required time, so as to avoid the process of removing MAC addresses frequently.

### Syntax

**spanning-tree guard tc**

**no spanning-tree guard tc**

### Command Mode

Interface Configuration Mode (interface gigabitEthernet / interface range gigabitEthernet / interface port-channel / interface range port-channel)

### Privilege Requirement

Only Admin, Operator and Power User level users have access to these commands.

### Example

Enable the TC Protect of Spanning Tree for port 2:

```
Switch(config)# interface gigabitEthernet 1/0/2
Switch(config-if)# spanning-tree guard tc
```

## 31.22 spanning-tree mcheck

### Description

The **spanning-tree mcheck** command is used to enable mcheck.

### Syntax

**spanning-tree mcheck**

### Command Mode

Interface Configuration Mode (interface gigabitEthernet / interface range gigabitEthernet / interface port-channel / interface range port-channel)

### Privilege Requirement

Only Admin, Operator and Power User level users have access to these commands.

### Example

Enable mcheck for port 2:

```
Switch(config)# interface gigabitEthernet 1/0/2
Switch(config-if)# spanning-tree mcheck
```

## 31.23 show spanning-tree active

### Description

The **show spanning-tree active** command is used to display the active information of spanning-tree.



## Syntax

**show spanning-tree active**

## Command Mode

Privileged EXEC Mode and Any Configuration Mode

## Privilege Requirement

None.

## Example

Display the active information of spanning-tree:

```
Switch(config)# show spanning-tree active
```

# 31.24 show spanning-tree bridge

## Description

The **show spanning-tree bridge** command is used to display the bridge parameters.

## Syntax

**show spanning-tree bridge** [ forward-time | hello-time | hold-count | max-age | max-hops | mode | priority | state ]

## Command Mode

Privileged EXEC Mode and Any Configuration Mode

## Privilege Requirement

None.

## Example

Display the bridge parameters:

```
Switch(config)# show spanning-tree bridge
```

# 31.25 show spanning-tree interface

## Description

The **show spanning-tree interface** command is used to display the spanning-tree information of all ports or a specified port.

## Syntax

```
show spanning-tree interface [ gigabitEthernet port | port-channel port-channel-id ] [ edge | ext-cost | int-cost | mode | p2p | priority | role | state | status ]
```

## Parameter

*port*— The Ethernet port number.

*port-channel-id*— The ID of the port channel.

## Command Mode

Privileged EXEC Mode and Any Configuration Mode

## Privilege Requirement

None.

## Example

Display the spanning-tree information of all ports:

```
Switch(config)# show spanning-tree interface
```

Display the spanning-tree information of port 1/0/2:

```
Switch(config)# show spanning-tree interface gigabitEthernet 1/0/2
```

Display the spanning-tree mode information of port 1/0/2:

```
Switch(config)# show spanning-tree interface gigabitEthernet 1/0/2 mode
```

# 31.26 show spanning-tree interface-security

## Description

The **show spanning-tree interface-security** command is used to display the protect information of all ports or a specified port.

## Syntax

```
show spanning-tree interface-security [ gigabitEthernet port | port-channel port-channel-id ] [ bpdupfilter | bpdupflood | bpduguard | loop | root | tc ]
```

## Parameter

*port*— The Ethernet port number.

*port-channel-id*— The ID of the port channel.

## Command Mode

Privileged EXEC Mode and Any Configuration Mode

## Privilege Requirement

None.

## Example

Display the protect information of all ports:

```
Switch(config)# show spanning-tree interface-security
```

Display the protect information of port 1:

```
Switch(config)# show spanning-tree interface-security gigabitEthernet  
1/0/1
```

Display the interface security bpdufilter information:

```
Switch(config)# show spanning-tree interface-security bpdufilter
```

# 31.27 show spanning-tree mst

## Description

The **show spanning-tree mst** command is used to display the related information of MST Instance.

## Syntax

```
show spanning-tree mst { configuration [ digest ] | instance instance-id  
[ interface [ gigabitEthernet port | port-channel port-channel-id ] ] }
```

## Parameter

*instance-id*— Instance ID desired to show, ranging from 1 to 8.

*port*— The Ethernet port number.

*port-channel-id*— The ID of the port channel.

## Command Mode

Privileged EXEC Mode and Any Configuration Mode

## Privilege Requirement

None.

## Example

Display the region information and mapping information of VLAN and MST Instance:

```
Switch(config)# show spanning-tree mst configuration
```

Display the related information of MST Instance 1:

```
Switch(config)#show spanning-tree mst instance 1
```

Display all the ports information of MST Instance 1:

```
Switch(config)#show spanning-tree mst instance 1 interface
```



## Chapter 32 Debug Commands

### 32.1 debug tppacket packet-print (only for certain devices)

#### Description

The **debug tppacket packet-print** command is used to enable the message printing function, which will only happen on the serial port and will affect switch performance. To disable this function, please use **no debug tppacket packet-print** command.

#### Syntax

```
debug tppacket packet-print  
no tppacket packet-print
```

#### Command Mode

Privileged EXEC Mode

#### Privilege Requirement

Only Admin level users have access to these commands.

#### User Guidelines

This command may cause network connections to be interrupted and some functions may not work properly, so please don't open it at will.

#### Example

Enable the message printing function:

```
Switch# debug tppacket packet-print
```

### 32.2 debug spanning-tree

#### Description

The **debug spanning-tree** command is used to enable debugging of spanning-tree activities. To disable the debugging function, please use **no debug spanning-tree** command.

## Syntax

**debug spanning-tree** { all | bpdu receive | bpdu transmit | cmpmsg | errors | flush | init | migration | proposals | roles | state | tc }

**no debug spanning-tree** { all | bpdu receive | bpdu transmit | cmpmsg | errors | flush | init | migration | proposals | roles | state | tc }

## Parameters

all — Display all the spanning-tree debug messages.

bpdu receive — Display the debug messages of the received spanning-tree bridge protocol data unit (BPDU).

bpdu transmit — Display the debug messages of the sent spanning-tree BPDU.

cmpmsg — Display the message priority debug messages.

errors — Display the MSTP error debug messages.

flush — Display the address table flushing debug messages.

init — Display the data structure initialization debug messages.

migration — Display the version migration debug messages.

proposals — Display the MSTP handshake debug messages.

roles — Display the MSTP interface role switchling debug messages.

state — Display the MSTP interface state change debug messages.

tc — Display the MSTP topology event debug messages.

## Command Mode

Privileged EXEC Mode

## Privilege Requirement

Only Admin level users have access to these commands.

## Example

Display all the spanning-tree debug messages:

```
Switch# debug spanning-tree all
```

# Chapter 33 LLDP Commands

LLDP function enables network devices to advertise their own device information periodically to neighbors on the same LAN. The information of the LLDP devices in the LAN can be stored by its neighbor in a standard MIB, so it is possible for the information to be accessed by a Network Management System (NMS) using SNMP.

## 33.1 lldp

### Description

The **lldp** command is used to enable LLDP function. To disable the LLDP function, please use **no lldp** command.

### Syntax

**lldp**

**no lldp**

### Command Mode

Global Configuration Mode

### Privilege Requirement

Only Admin, Operator and Power User level users have access to these commands.

### Example

Enable LLDP function globally:

```
Switch(config)#lldp
```

## 33.2 lldp forward\_message

### Description

The **lldp forward\_message** command is used to enable the switch to forward LLDP messages when LLDP function is disabled. To disable the LLDP messages forwarding function, please use **no lldp forward\_message** command.

### Syntax

**lldp forward\_message**

**no lldp forward\_message**



## Command Mode

Global Configuration Mode

## Privilege Requirement

Only Admin, Operator and Power User level users have access to these commands.

## Example

Enable the switch to forward LLDP messages when LLDP function is disabled globally:

```
Switch(config)#lldp forward_message
```

# 33.3 lldp hold-multiplier

## Description

The **lldp hold-multiplier** command is used to configure the Hold Multiplier parameter. The aging time of the local information in the neighbor device is determined by the actual TTL value used in the sending LLDPDU.  $TTL = \text{Hold Multiplier} * \text{Transmit Interval}$ . To return to the default configuration, please use **no lldp hold-multiplier** command.

## Syntax

**lldp hold-multiplier** *multiplier*

**no lldp hold-multiplier**

## Parameter

*multiplier* — Configure the Hold Multiplier parameter. It ranges from 2 to 10. By default, it is 4.

## Command Mode

Global Configuration Mode

## Privilege Requirement

Only Admin, Operator and Power User level users have access to these commands.

## Example

Specify Hold Multiplier as 5:

```
Switch(config)#lldp hold-multiplier 5
```

## 33.4 Ildp timer

### Description

The **lldp timer** command is used to configure the parameters about transmission. To return to the default configuration, please use **no lldp timer** command.

### Syntax

```
lldp timer { tx-interval tx-interval / tx-delay tx-delay / reinit-delay reinit-delay / notify-interval notify-interval / fast-count fast-count }
```

```
no lldp timer { tx-interval | tx-delay | reinit-delay | notify-interval | fast-count }
```

### Parameter

*tx-interval* — Configure the interval for the local device to transmit LLDPDU to its neighbors. The value ranges from 5 to 32768 and the default value is 30 seconds.

*tx-delay* — Configure a value from 1 to 8192 in seconds to specify the time for the local device to transmit LLDPDU to its neighbors after changes occur so as to prevent LLDPDU being sent frequently. By default, it is 2 seconds.

*reinit-delay* — This parameter indicates the amount of delay from when LLDP status becomes "disable" until re-initialization will be attempted. The value ranges from 1 to 10 and the default value is 2.

*notify-interval* — Specify the interval of Trap message which will be sent from local device to network management system. The value ranges from 5 to 3600 and the default value is 5 seconds.

*fast-count* — When the port's LLDP state transforms from Disable (or Rx\_Only) to Tx&Rx (or Tx\_Only), the fast start mechanism will be enabled, that is, the transmit interval will be shorten to a second, and several LLDPDUs will be sent out (the number of LLDPDUs equals this parameter). The value ranges from 1 to 10 and the default value is 3.

### Command Mode

Global Configuration Mode

### Privilege Requirement

Only Admin, Operator and Power User level users have access to these commands.

### Example

Specify the Transmit Interval of LLDPDU as 45 seconds and Trap message to NMS as 120 seconds:

```
Switch(config)#lldp timer tx-interval 45
```

```
Switch(config)#lldp timer notify-interval 120
```

## 33.5 lldp receive

### Description

The **lldp receive** command is used to enable the designated port to receive LLDPDU. To disable the function, please use **no lldp receive** command.

### Syntax

```
lldp receive
```

```
no lldp receive
```

### Command Mode

Interface Configuration Mode (interface gigabitEthernet / interface range gigabitEthernet)

### Privilege Requirement

Only Admin, Operator and Power User level users have access to these commands.

### Example

Enable port 1/0/1 to receive LLDPDU:

```
Switch(config)#interface gigabitEthernet 1/0/1
```

```
Switch(config-if)#lldp receive
```

## 33.6 lldp transmit

### Description

The **lldp transmit** command is used to enable the designated port to transmit LLDPDU. To disable the function, please use **no lldp transmit** command.

### Syntax

```
lldp transmit
```

```
no lldp transmit
```

### Command Mode

Interface Configuration Mode (interface gigabitEthernet / interface range gigabitEthernet)

## Privilege Requirement

Only Admin, Operator and Power User level users have access to these commands.

## Example

Enable Gigabit Ethernet port 1/0/1 to transmit LLDPDU:

```
Switch(config)# interface gigabitEthernet 1/0/1
Switch(config-if)#lldp transmit
```

# 33.7 lldp snmp-trap

## Description

The **lldp snmp-trap** command is used to enable the port's SNMP notification. If enabled, the port will notify the trap event to network management system. To disable the ports' SNMP notification, please use **no lldp snmp-trap** command.

## Syntax

```
lldp snmp-trap
no lldp snmp-trap
```

## Command Mode

Interface Configuration Mode (interface gigabitEthernet / interface range gigabitEthernet)

## Privilege Requirement

Only Admin, Operator and Power User level users have access to these commands.

## Example

Enable the SNMP notification for Gigabit Ethernet port 1/0/1:

```
Switch(config)#interface gigabitEthernet 1/0/1
Switch(config-if)#lldp snmp-trap
```

## 33.8 lldp tlv-select

### Description

The **lldp tlv-select** command is used to configure TLVs to be included in outgoing LLDPDU. To exclude TLVs, please use **no lldp tlv-select** command. By default, All TLVs are included in outgoing LLDPDU.

### Syntax

```
lldp tlv-select { [ port-description ] [ system-capability ] [ system-description ]  
[ system-name ] [ management-address ] [ port-vlan ] [ protocol-vlan ]  
[ vlan-name ] [ link-aggregation ] [ mac-phy-cfg ] [ max-frame-size ] [ power ]  
[ all ] }
```

```
no lldp tlv-select { [ port-description ] [ system-capability ]  
[ system-description ] [ system-name ] [ management-address ] [ port-vlan ]  
[ protocol-vlan ] [ vlan-name ] [ link-aggregation ] [ mac-phy-cfg ]  
[ max-frame-size ] [ power ] [ all ] }
```

### Command Mode

Interface Configuration Mode (interface gigabitEthernet / interface range gigabitEthernet)

### Privilege Requirement

Only Admin, Operator and Power User level users have access to these commands.

### Example

Exclude "management-address" and "port-vlan-id" TLVs in LLDPDU outgoing from Gigabit Ethernet port 1/0/1:

```
Switch(config)# interface gigabitEthernet 1/0/1
```

```
Switch(config-if)# no lldp tlv-select management-address port-vlan
```

## 33.9 lldp management-address

### Description

The **lldp management-address** command is used to configure the port's management address to be included in management address TLV. The NMS uses management addresses to identify the devices. To delete the port's management address, please use **no lldp management address** command.

## Syntax

**lldp management-address** { *ip-address* }

**no lldp management-address**

## Command Mode

Interface Configuration Mode (interface gigabitEthernet / interface range gigabitEthernet)

## Privilege Requirement

Only Admin, Operator and Power User level users have access to these commands.

## Example

Configure the port's management address as 192.168.1.100 for port 1/0/1:

```
Switch(config)# interface gigabitEthernet 1/0/1
```

```
Switch(config-if)# lldp management-address 192.168.0.100
```

# 33.10 lldp med-fast-count

## Description

The **lldp med-fast-count** command is used to configure the number of the LLDP-MED frames that will be sent out. When LLDP-MED fast start mechanism is activated, multiple LLDP-MED frames will be transmitted based on this parameter. The default value is 4. To return to the default configuration, please use **no lldp med-fast-count** command.

## Syntax

**lldp med-fast-count** *count*

**no lldp med-fast-count**

## Parameter

*count*—— Configure the Fast Start Count parameter. It ranges from 1 to 10. By default, it is 4.

## Command Mode

Global Configuration Mode

## Privilege Requirement

Only Admin and Operator level users have access to these commands.

## Example

Specify Fast Start Count as 5:

```
Switch(config)# lldp med-fast-count 5
```

## 33.11 lldp med-status

### Description

The **lldp med-status** command is used to enable the LLDP-MED feature for the corresponding port. After the LLDP-MED feature is enabled, the port's Admin Status will be changed to Tx&Rx. To disable the LLDP-MED feature for the corresponding port, please use **no lldp med-status** command.

### Syntax

```
lldp med-status
```

```
no lldp med-status
```

### Command Mode

Interface Configuration Mode (interface gigabitEthernet / interface range gigabitEthernet)

### Privilege Requirement

Only Admin, Operator and Power User level users have access to these commands.

### Example

Enable the LLDP-MED feature for port 1/0/2:

```
Switch(config)# interface gigabitEthernet 1/0/2
```

```
Switch(config-if)# lldp med-status
```

## 33.12 lldp med-tlv-select

### Description

The **lldp med-tlv-select** command is used to configure LLDP-MED TLVs to be included in outgoing LLDPDU for the corresponding port. To exclude LLDP-MED TLVs, please use **no lldp med-tlv-select** command. By default, All TLVs are included in outgoing LLDPDU.

### Syntax

```
lldp med-tlv-select { [inventory-management] [location] [network-policy]  
[power-management] [all] }
```

```
no lldp med-tlv-select { [inventory-management] [location] [network-policy]  
[power-management] [all] }
```

## Command Mode

Interface Configuration Mode (interface gigabitEthernet / interface range gigabitEthernet)

## Privilege Requirement

Only Admin, Operator and Power User level users have access to these commands.

## Example

Exclude "network policy" and "inventory" TLVs in LLDPDU outgoing from port 1/0/2:

```
Switch(config)# interface gigabitEthernet 1/0/2
Switch(config-if)# no lldp med-tlv-select network-policy inventory-
management
```

# 33.13 lldp med-location

## Description

The lldp med-location command is used to configure the Location Identification TLV's content in outgoing LLDPDU of the port.

## Syntax

```
lldp med-location { emergency-number identifier | civic-address
[ [ language language ] [ province-state province-state ] [ lci-county-name
county-name ] [ lci-city city ] [ street street ] [ house-number house-number ]
[ name name ] [ postal-zipcode postal-zipcode ] [ room-number room-number ]
[ post-office-box post-office-box ] [ additional additional ] [ country-code
country-code ] [ what { dhcp-server | endpoint | switch } ] }
```

## Parameter

emergency-number — Emergency Call Service ELIN identifier, which is used during emergency call setup to a traditional CAMA or ISDN trunk-based PSAP. The length of this field ranges from 10 to 25 characters.

civic-address — The civic address is defined to reuse the relevant sub-fields of the DHCP option for civic Address based Location Configuration Information as specified by IETF.

## Command Mode

Interface Configuration Mode (interface gigabitEthernet / interface range gigabitEthernet)



## Privilege Requirement

Only Admin, Operator and Power User level users have access to these commands.

## Example

Configure the civic address in the Location Identification TLV's content in outgoing LLDPDU of port 1/0/2. Configure the language as English and city as London:

```
Switch(config)# interface gigabitEthernet 1/0/2
Switch(config-if)# lldp med-location civic-address language English Ici-city
London
```

## 33.14 show lldp

### Description

The **show lldp** command is used to display the global configuration of LLDP.

### Syntax

```
show lldp
```

### Command Mode

Privileged EXEC Mode and Any Configuration Mode

### Privilege Requirement

None.

### Example

Display the global configuration of LLDP:

```
Switch#show lldp
```

## 33.15 show lldp interface

### Description

The **show lldp interface** command is used to display LLDP configuration of the corresponding port. By default, the LLDP configuration of all the ports will be displayed.

### Syntax

```
show lldp interface [ gigabitEthernet port ]
```

## Parameters

*port*— The Ethernet port number.

## Command Mode

Privileged EXEC Mode and Any Configuration Mode

## Privilege Requirement

None.

## Example

Display the LLDP configuration of Gigabit Ethernet port 1/0/1:

```
Switch#show lldp interface gigabitEthernet 1/0/1
```

# 33.16 show lldp local-information interface

## Description

The **show lldp local-information interface** command is used to display the LLDP information of the corresponding port. By default, the LLDP information of all the ports will be displayed.

## Syntax

```
show lldp local-information interface [ gigabitEthernet port ]
```

## Parameters

*port*— The Ethernet port number.

## Command Mode

Privileged EXEC Mode and Any Configuration Mode

## Privilege Requirement

None.

## Example

Display the LLDP information of 1/0/1:

```
Switch#show lldp local-information interface gigabitEthernet 1/0/1
```

## 33.17 show lldp neighbor-information interface

### Description

The **show lldp neighbor-information interface** command is used to display the neighbor information of the corresponding port. By default, the neighbor information of all the ports will be displayed.

### Syntax

```
show lldp neighbor-information interface [ gigabitEthernet port]
```

### Parameters

*port*— The Ethernet port number.

### Command Mode

Privileged EXEC Mode and Any Configuration Mode

### Privilege Requirement

None.

### Example

Display the neighbor information of Gigabit Ethernet port 1/0/1:

```
Switch#show lldp neighbor-information interface gigabitEthernet 1/0/1
```

## 33.18 show lldp traffic interface

### Description

The **show lldp traffic interface** command is used to display the LLDP statistic information between the local device and neighbor device of the corresponding port. By default, the LLDP statistic information of all the ports will be displayed.

### Syntax

```
show lldp traffic interface [ gigabitEthernet port]
```

### Parameters

*port*— The Ethernet port number.

## Command Mode

Privileged EXEC Mode and Any Configuration Mode

## Privilege Requirement

None.

## Example

Display the LLDP statistic information of Gigabit Ethernet port 1/0/1:

```
Switch#show lldp traffic interface gigabitEthernet 1/0/1
```

## Chapter 34 L2PT Commands (Only for Certain Devices)



**Note:** L2PT commands are only available on certain devices.

L2PT (Layer 2 Protocol Tunneling) is a feature for service providers to transmit packets from different customers across their ISP networks and maintain Layer 2 protocol configurations of each customer. The supported Layer 2 protocols are STP (Spanning Tree Protocol), GVRP (GARP VLAN Registration Protocol), CDP (Cisco Discovery Protocol), VTP (VLAN Trunking Protocol), PAgP (Port Aggregation Protocol), UDLD (UniDirectional Link Detection) and PVST+(Per VLAN Spanning Tree Plus).

### 34.1 I2protocol-tunnel

#### Description

The **I2protocol-tunnel** command is used to enable the layer 2 protocol tunneling (L2PT) function globally. To disable the L2PT function, please use **no I2protocol-tunnel** command.

#### Syntax

**I2protocol-tunnel**  
**no I2protocol-tunnel**

#### Command Mode

Global Configuration Mode

#### Privilege Requirement

Only Admin and Operator level users have access to these commands.

#### Example

Enable the L2PT function globally:

```
Switch(config)# I2protocol-tunnel
```

## 34.2 I2protocol-tunnel type

### Description

The **I2protocol-tunnel type** command is used to configure the L2PT function on a specified port. To disable the L2PT function on the specified port, please use **no I2protocol-tunnel** command.

### Syntax

**I2protocol-tunnel type nni**

**I2protocol-tunnel type uni** { 01000ccccccc | 01000ccccccd | gvrp | stp | lacp  
| all } [ **threshold** *threshold*]

**no I2protocol-tunnel**

### Parameter

**nni** — Specify the port type according to its connecting device in the network. Specify the port's type as NNI if it is connecting to the ISP network.

**uni** — Specify the port type according to its connecting device in the network. Specify the port's type as UNI if it is connecting to the user's local network.

01000ccccccc | 01000ccccccd | gvrp | stp | lacp | all — Select the supported Layer 2 protocol type. Packets of the specified protocol will be encapsulated with their destination MAC address before they are sent to the ISP network. Packets will be decapsulated to restore their Layer 2 protocol and MAC address information before they are sent to the customer network.

- 01000ccccccc: Enable protocol tunneling for the packets with destination MAC address 01-00-0C-CC-CC-CC. 01-00-0CC-CC-CC-CC is used as the destination MAC address of the CDP/VTP/PAgP/UDLD packets.
- 01000ccccccd: Enable protocol tunneling for the packets with destination MAC address 01-00-0C-CC-CC-CD. 01-00-0CC-CC-CC-CD is used as the destination MAC address of Cisco PVST+ BPDUs.
- gvrp: Enable protocol tunneling for the GVRP packets.
- stp: Enable protocol tunneling for the STP packets.
- lacp: Enable protocol tunneling for the LACP packets.
- all: All the above Layer 2 protocols are supported for tunneling.

- **threshold** —Configure the threshold for packets-per-second accepted for encapsulation. Packets beyond the threshold will be dropped. It ranges from 0 to 1000.

### Command Mode

Interface Configuration Mode (interface gigabitEthernet / interface range gigabitEthernet / interface port-channel / interface range port-channel)

### Privilege Requirement

Only Admin and Operator level users have access to these commands.

### Example

Configure port 1/0/3 as a UNI port for STP packets with the threshold as 1000 packets/second:

```
Switch(config)#interface gigabitEthernet 1/0/3
Switch(config-if)# l2protocol-tunnel type uni stp threshold 1000
```

## 34.3 show l2protocol-tunnel global

### Description

The **show l2protocol-tunnel global** command is used to display the global L2PT status.

### Syntax

```
show l2protocol-tunnel global
```

### Command Mode

Privileged EXEC Mode and Any Configuration Mode

### Privilege Requirement

None.

### Example

Display the global L2PT status:

```
Switch(config)# show l2protocol-tunnel global
```

## 34.4 show l2protocol-tunnel interface

### Description

The **show l2protocol-tunnel interface** command is used to display the L2PT configuration information of a specified Ethernet port or of all Ethernet ports.

### Syntax

```
show l2protocol-tunnel interface [ gigabitEthernet port | port-channel port-channel-id]
```

### Parameter

*port*— The port number.

*port-channel-id*— The ID of the port channel.

### Command Mode

Privileged EXEC Mode and Any Configuration Mode

### Privilege Requirement

None.

### Example

Display the L2PT configuration information of Gigabit Ethernet port 1/0/1:

```
Switch(config)#show l2protocol-tunnel interface gigabitEthernet 1/0/1
```

Display the L2PT configuration information of all Ethernet ports:

```
Switch(config)#show l2protocol-tunnel interface
```

## 34.5 l2protocol-tunnel dst-mac

### Description

The **l2protocol-tunnel dst-mac** command is used to customize the dst-mac, which can come from the destination mac address of messages after l2pt encapsulation. To restore the dst-mac to default, please use the **no l2protocol-tunnel dst-mac** command.

### Syntax

```
l2protocol-tunnel dst-mac mac-addr
```

```
no l2protocol-tunnel dst-mac mac-addr
```



## Parameter

*mac-addr*— specify a legal mac address.

## Command Mode

Global Configuration Mode

## Privilege Requirement

Only Admin and Operator level users have access to these commands.

## Example

Customize the I2pt destination mac address as 58-11-22-0F-6D-B1:

```
Switch(config)#I2protocol-tunnel dst-mac 58-11-22-0F-6D-B1
```

# 34.6 show I2protocol-tunnel dst-mac

## Description

The **show I2protocol-tunnel dst-mac** command is used to display the current dst-mac.

## Syntax

```
show I2protocol-tunnel dst-mac
```

## Command Mode

Global Configuration Mode

## Privilege Requirement


Only Admin and Operator level users have access to these commands.

## Example

Display the current dst-mac:

```
Switch(config)#show I2protocol-tunnel dst-mac
```

## Chapter 35 PPPoE ID-Insertion Commands (Only for Certain Devices)

 **Note:** PPPoE ID-Insertion commands are only available on certain devices.

The PPPoE ID-Insertion feature provides a way to extract a Vendor-specific tag as an identifier for the authentication, authorization, and accounting (AAA) access requests on an Ethernet interface. When enabled, the switch attaches a tag to the PPPoE discovery packets, which is called the PPPoE Vendor-Specific tag and it contains a unique line identifier. There are two formats of Vendor-specific tags: Circuit-ID format and Remote-ID format. The BRAS receives the tagged packet, decodes the tag, and uses the Circuit-ID/Remote-ID field of that tag as a NAS-Port-ID attribute in the RADIUS server for PPP authentication and AAA (authentication, authorization, and accounting) access requests. The switch will remove the Circuit-ID/Remote-ID tag from the received PPPoE Active Discovery Offer and Session-confirmation packets from the BRAS.

### 35.1 pppoe id-insertion (global)

#### Description

The **pppoe id-insertion** command is used to enable the PPPoE ID-Insertion function globally. To disable the PPPoE ID-Insertion function, please use **no pppoe id-insertion** command.

#### Syntax

**pppoe id-insertion**  
**no pppoe id-insertion**

#### Command Mode

Global Configuration Mode

#### Privilege Requirement

Only Admin, Operator and Power User level users have access to these commands.

#### Example

Enable the PPPoE ID-Insertion function:

```
Switch(config)# pppoe id-insertion
```

## 35.2 pppoe circuit-id (interface)

### Description

The **pppoe circuit-id** command is used to enable the PPPoE Circuit-ID Insertion function for a specified port. To disable the PPPoE Circuit-ID Insertion function on a specified port, please use **no pppoe circuit-id** command.

### Syntax

```
pppoe circuit-id  
no pppoe circuit-id
```

### Command Mode

Interface Configuration Mode (interface gigabitEthernet / interface range gigabitEthernet)

### Privilege Requirement

Only Admin, Operator and Power User level users have access to these commands.

### Example

Enable the PPPoE Circuit-ID Insertion function for the Gigabit Ethernet port 1/0/1:

```
Switch (config)# interface gigabitEthernet 1/0/1  
Switch (config-if)# pppoe circuit-id
```

## 35.3 pppoe circuit-id type

### Description

The **pppoe circuit-id type** command is used to configure the type of PPPoE Circuit-ID for a specified port. By default, the PPPoE Circuit-ID type is "ip".

### Syntax

```
pppoe circuit-id type { mac | ip | udf [Value] | udf-only [Value] }
```

### Parameter

mac | ip | udf | udf-only — The type of PPPoE Circuit-ID for the port.

mac: The MAC address of the switch will be used to encode the Circuit-ID option.

ip: The IP address of the switch will be used to encode the Circuit-ID option. This is the default value.

udf: A user specified string with the maximum length of 40 characters will be used to encode the Circuit-ID option.

udf-only: Only the user specified string with the maximum length of 40 will be used to encode the Circuit-ID option.

*Value*—— The value of udf/udf-only. The maximum length is 40 characters.

## Command Mode

Interface Configuration Mode (interface gigabitEthernet / interface range gigabitEthernet)

## Privilege Requirement

Only Admin, Operator and Power User level users have access to these commands.

## Example

Configure the type of PPPoE Circuit-ID as "mac" for the Gigabit Ethernet port 1/0/1:

```
Switch (config)# interface gigabitEthernet 1/0/1
Switch (config-if)# pppoe circuit-id type mac
```

# 35.4 pppoe remote-id

## Description

The **pppoe remote-id** command is used to enable the PPPoE Remote-ID Insertion and configure the Remote-ID value for a specified port. To disable the PPPoE Remote-ID Insertion function on a specified port, please use **no pppoe remote-id** command. By default, the PPPoE Remote-ID Insertion is disabled.

## Syntax

```
pppoe remote-id [Value]
no pppoe remote-id
```

## Parameter

*Value* —— The value of UDF. The maximum length is 40 characters. If not specified, the default value will be the PPPoE client's MAC address.

## Command Mode

Interface Configuration Mode (interface gigabitEthernet / interface range gigabitEthernet)

## Privilege Requirement

Only Admin, Operator and Power User level users have access to these commands.

## Example

Configure the remote-ID as "mac" for the Gigabit Ethernet port 1/0/1:

```
Switch (config)# interface gigabitEthernet 1/0/1
Switch (config-if)# pppoe remote-id mac
```

# 35.5 show pppoe id-insertion global

## Description

The **show pppoe id-insertion global** command is used to display the global configuration of PPPoE Circuit-ID Insertion function.

## Syntax

```
show pppoe id-insertion global
```

## Command Mode

Privileged EXEC Mode and Any Configuration Mode

## Privilege Requirement

None.

## Example

Display the configuration of PPPoE Circuit-ID Insertion function globally:

```
Switch # show pppoe circuit-id global
```

## 35.6 show pppoe id-insertion interface

### Description

The **show pppoe id-insertion interface** command is used to display all ports' or the specified port's configuration information of PPPoE Circuit-ID Insertion function.

### Syntax

```
show pppoe id-insertion interface [gigabitEthernet port]
```

### Parameter

*port*— The Fast/Gigabit Ethernet port number.

### Command Mode

Privileged EXEC Mode and Any Configuration Mode

### Privilege Requirement

None.

### Example

Display the configuration information of PPPoE Circuit-ID Insertion function of all Ethernet ports:

```
Switch# show pppoe id-insertion interface
```

Display the configuration of PPPoE Circuit-ID Insertion function of the Gigabit Ethernet port 1/0/1 :

```
Switch# show pppoe id-insertion interface gigabitEthernet 1/0/1
```

# Chapter 36 Static Routes Commands

## 36.1 ip routing

### Description

This **ip routing** command is used to enable IPv4 routing globally. To disable IPv4 routing, please use the **no ip routing** command.

### Syntax

**ip routing**

**no ip routing**

### Command Mode

Global Configuration Mode

### Privilege Requirement

Only Admin, Operator and Power User level users have access to these commands.

### Example

Enable IPv4 routing feature for the switch:

```
Switch(config)# ip routing
```

## 36.2 interface vlan

### Description

This **interface vlan** command is used to create the VLAN interface. To delete the specified VLAN interface, please use the **no interface vlan** command.

### Syntax

**interface vlan** { *vid* }

**no interface vlan** { *vid* }

### Parameter

*vid*— The ID of the VLAN.

### Command Mode

Global Configuration Mode

## Privilege Requirement

Only Admin, Operator and Power User level users have access to these commands.

## Example

Create the VLAN interface 2:

```
Switch(config)# interface vlan 2
```

## 36.3 interface loopback

### Description

This **interface loopback** command is used to create the loopback interface. To delete the specified loopback interface, please use the **no interface loopback** command.

### Syntax

```
interface loopback { id }  
no interface loopback { id }
```

### Parameter

*id*—— The ID of the loopback interface, ranging from 1 to 64.

### Command Mode

Global Configuration Mode

### Privilege Requirement

Only Admin, Operator and Power User level users have access to these commands.

## Example

Create the loopback interface 1:

```
Switch(config)# interface loopback 1
```

## 36.4 switchport

### Description

This **switchport** command is used to switch the Layer 3 interface into the Layer 2 port. To switch the Layer 2 port into the Layer 3 routed port, please use the **no switchport** command.



## Syntax

**switchport**

**no switchport**

## Command Mode

Interface Configuration Mode (interface gigabitEthernet / interface range gigabitEthernet / interface port-channel / interface range port-channel)

## Privilege Requirement

Only Admin, Operator and Power User level users have access to these commands.

## Example

Switch port 1/0/9 into the routed port:

```
Switch(config)# interface gigabitEthernet 1/0/9
Switch(config-if)# no switchport
```

# 36.5 interface range port-channel

## Description

This **interface range port-channel** command is used to create multiple port-channel interfaces.

## Syntax

**interface range port-channel** *port-channel-list*

## Parameter

*port-channel-list* — The list of the port-channel interface, ranging from 1 to 14, in the format of 1-3, 5.

## Command Mode

Global Configuration Mode

## Privilege Requirement

Only Admin, Operator and Power User level users have access to these commands.

## Example

Create the port-channel interfaces 1, 3, 4 and 5:

```
Switch(config)# interface port-channel 1,3-5
```

## 36.6 description

### Description

This **description** command is used to add a description to the Layer 3 interface, including routed port, port-channel interface, loopback interface and VLAN interface. To clear the description of the corresponding interface, please use the **no description** command.

### Syntax

**description** *string*

**no description**

### Parameter

*string* — Content of an interface description, ranging from 1 to 32 characters.

### Command Mode

Interface Configuration Mode

### Privilege Requirement

Only Admin, Operator and Power User level users have access to these commands.

## Example

Add a description system-if to the routed port 1/0/9 :

```
Switch(config)# interface gigabitEthernet 1/0/9
Switch(config-if)# no switchport
Switch(config-if)# description system-if
```

## 36.7 shutdown

### Description

This **shutdown** command is used to shut down the specified interface. The interface type include: routed port, port-channel interface, loopback interface

and VLAN interface. To enable the specified interface, please use the **no shutdown** command.

### Syntax

**shutdown**

**no shutdown**

### Command Mode

Interface Configuration Mode

### Privilege Requirement

Only Admin, Operator and Power User level users have access to these commands.

### Example

Shut down the routed port 1/0/9:

```
Switch(config)# interface gigabitEthernet 1/0/9
Switch(config-if)# no switchport
Switch(config-if)# shutdown
```

## 36.8 interface port-channel

### Description

This **interface port-channel** command is used to create the port-channel interface. To delete the specified port-channel interface, please use the **no interface port-channel** command.

### Syntax

**interface port-channel** { *port-channel-id* }

**no interface port-channel** { *port-channel-id* }

### Parameter

*port-channel-id* — The ID of the port-channel interface, ranging from 1 to 14.

### Command Mode

Global Configuration Mode

## Privilege Requirement

Only Admin, Operator and Power User level users have access to these commands.

## Example

Create the port-channel interface 1:

```
Switch(config)# interface port-channel 1
```

# 36.9 ip route

## Description

This **ip route** command is configure the static route. To clear the corresponding entry, please use the **no ip route** command.

## Syntax

```
ip route { dest-address } { mask } { next-hop-address } [ distance ]
```

```
no ip route { dest-address } { mask } { next-hop-address }
```

## Parameter

*dest-address* — The destination IP address.

*mask* — The subnet mask.

*next-hop-address* — The address of the next-hop.

*distance* — The distance metric of this route, ranging from 1 to 255. The smaller the distance is, the higher the priority is.

## Command Mode

Global Configuration Mode

## Privilege Requirement

Only Admin, Operator and Power User level users have access to these commands.

## Example

Create a static route with the destination IP address as 192.168.2.0, the subnet mask as 255.255.255.0 and the next-hop address as 192.168.0.2:

```
Switch(config)# ip route 192.168.2.0 255.255.255.0 192.168.0.2
```

## 36.10 ipv6 routing

### Description

This **ipv6 routing** command is enable the IPv6 routing feature globally. To disable IPv6 routing, please use the **no ipv6 routing** command.

### Syntax

**ipv6 routing**

**no ipv6 routing**

### Command Mode

Global Configuration Mode

### Privilege Requirement

Only Admin, Operator and Power User level users have access to these commands.

### Example

Enable IPv6 routing globally:

```
Switch(config)# ipv6 routing
```

## 36.11 ipv6 route

### Description

This **ipv6 route** command is configure the IPv6 static route. To clear the corresponding entry, please use the **no ipv6 route** command.

### Syntax

**ipv6 route** { *ipv6-dest-address* } { *next-hop-address* } [ *distance* ]

**no ipv6 route** { *ipv6-dest-address* } { *next-hop-address* }

### Parameter

*ipv6-dest-address* — The IPv6 address of the destination network.

*next-hop-address* — The IPv6 address of the next-hop.

*distance* — The distance metric of this route, ranging from 1 to 255. The smaller the distance is, the higher the priority is.

## Command Mode

Global Configuration Mode

## Privilege Requirement

Only Admin, Operator and Power User level users have access to these commands.

## Example

Create a static route with the destination network IP address as 3200::/64 and the next-hop address as 3100::1234:

```
Switch(config)# ipv6 route 3200::/64 3100::1234
```

## 36.12 show interface vlan

### Description

The **show interface vlan** command is used to display the information of the specified interface VLAN.

### Syntax

```
show interface vlan vid
```

### Parameter

*vid*— The VLAN ID.

### Command Mode

Privileged EXEC Mode and Any Configuration Mode

### Privilege Requirement

None.

### Example

Display the information of VLAN 2:

```
Switch(config)#show interface vlan 2
```

## 36.13 show ip interface

### Description

This **show ip interface** command is used to display the detailed information of the specified Layer 3 interface.

## Syntax

```
show ip interface [ gigabitEthernet port / port-channel port-channel-id /  
loopback id | vlan vlan-id]
```

## Parameter

*port*— The port number.

*port-channel-id* — The ID of the port channel. Member ports in this port channel should all be routed ports.

*id*— The loopback interface ID.

*vlan-id*— The VLAN interface ID.

## Command Mode

Privileged EXEC Mode and Any Configuration Mode

## Privilege Requirement

None.

## Example

Display the detailed information of the VLAN interface 2:

```
Switch(config)# show ip interface vlan 2
```

# 36.14 show ip interface brief

## Description

This **show ip interface brief** command is used to display the summary information of the Layer 3 interfaces.

## Syntax

```
show ip interface brief
```

## Command Mode

Privileged EXEC Mode and Any Configuration Mode

## Privilege Requirement

None.

## Example

Display the summary information of the Layer 3 interfaces:

```
Switch(config)# show ip interface brief
```

## 36.15 show ip route

### Description

This **show ip route** command is used to display the route entries of the specified type.

### Syntax

```
show ip route [ static | connected ]
```

### Parameter

static | connected — Specify the route type. If not specified, all types of route entries will be displayed.

static: The static routes.

connected: The connected routes.

### Command Mode

Privileged EXEC Mode and Any Configuration Mode

### Privilege Requirement

None.

### Example

Display the static routes:

```
Switch(config)# show ip route static
```

## 36.16 show ip route specify

### Description

This **show ip route specify** command is used to display the valid routing information to the specified IP address or network segments.

### Syntax

```
show ip route specify { ip } [ mask ] [ longer-prefixes ]
```

### Parameter

*ip* — Specify the destination IP address.

*mask* — Specify the destination IP address together with the parameter *ip*.

**longer-prefixes** — Specify the destination subnets that match the network segment determined by the *ip* and *mask* parameters.



## Command Mode

Privileged EXEC Mode and Any Configuration Mode

## Privilege Requirement

None.

## Example

Display the shortest route to 192.168.0.100:

```
Switch(config)# show ip route specify 192.168.0.100
```

Look up the route entry with the destination as 192.168.0.0/24:

```
Switch(config)# show ip route specify 192.168.0.0 255.255.255.0
```

Display the routes to all the subnets that belongs to 192.168.0.0/16:

```
Switch(config)# show ip route specify 192.168.0.0 255.255.0.0  
longer-prefixes
```

# 36.17 show ip route summary

## Description

This **show ip route summary** command is used to display the summary information of the route entries classified by their sources.

## Syntax

```
show ip route summary
```

## Command Mode

Privileged EXEC Mode and Any Configuration Mode

## Privilege Requirement

None.

## Example

Display the summary information of route entries:

```
Switch(config)# show ip route summary
```

## 36.18 show ipv6 interface

### Description

This command is used to display the configured IPv6 information of the management interface, including ipv6 function status, link-local address and global address, IPv6 multicast groups etc.

### Syntax

```
show ipv6 interface
```

### Command Mode

Privileged EXEC Mode and Any Configuration Mode

### Privilege Requirement

None.

### Example

Display the IPv6 information of the management interface:

```
Switch(config)# show ipv6 interface
```

## 36.19 show ipv6 route

### Description

This **show ipv6 route** command is used to display the IPv6 route entries of the specified type.

### Syntax

```
show ipv6 route [ static | connected ]
```

### Parameter

static | connected — Specify the route type. If not specified, all types of route entries will be displayed.

static: The static routes.

connected: The connected routes.

### Command Mode

Privileged EXEC Mode and Any Configuration Mode

## Privilege Requirement

None.

## Example

Display the IPv6 static routes:

```
Switch(config)# show ipv6 route static
```

# 36.20 show ipv6 route summary

## Description

This **show ipv6 route summary** command is used to display the summary information of the IPv6 route entries classified by their sources.

## Syntax

```
show ipv6 route summary
```

## Command Mode

Privileged EXEC Mode and Any Configuration Mode

## Privilege Requirement

None.

## Example

Display the summary information of IPv6 route entries:

```
Switch(config)# show ipv6 route summary
```

## Chapter 37 RIP Configuration Commands (Only for Certain Devices)

RIP (Routing Information Protocol) is a routing protocol suitable for small networks and has lower requirements in terms of bandwidth, configuration, and management. As a routing protocol based on distance vector algorithm, RIP uses hop count as the measurement standard.

### 37.1 router rip

#### Description

This **router rip** command is used to enable the RIP function on the switch. To disable this function, please use the **no router rip** command.

#### Syntax

**router rip**

**no router rip**

#### Command Mode

Global Configuration Mode

#### Privilege Requirement

Only Admin, Operator and Power User level users have access to these commands.

#### Example

Enable the RIP function on the switch:

```
Switch(config)#router rip
```

### 37.2 network

#### Description

The **network** command is used to enable the RIP function on the corresponding interface of the configured network segment. To disable the RIP function on the corresponding interface, please use **no network** command.

## Syntax

**network** *network number*

**no network** *network number*

## Parameter

*network number*: Network number, the format is 192.168.0.0. If you enter an IP address, the network number will be automatically obtained based on the mask length of the natural network segment. Entering 0.0.0.0 means enabling the RIP function on all interfaces.

## Command Mode

Router Configuration Mode

## Privilege Requirement

Only Admin and Operator level users have access to these commands.

## Example

Enable the rip function of network segment 192.168.0.0:

```
Switch(config-router)#network 192.168.0.0
```

# 37.3 version

## Description

The **version** command is used to configure the version of packets sent and received by RIP. By default, the switch sends RIPv2 packets and receives RIPv1 and RIPv2 packets. To restore the default message version settings, please use the **no version** command.

## Syntax

**version** {1|2}

**no version**

## Parameter

1: Send and receive RIPv1 messages.

2: Send and receive RIPv2 messages.

## Command Mode

Router Configuration Mode

## Privilege Requirement

Only Admin and Operator level users have access to these commands.

## Example

Configure the RIP message version as RIPv1:

```
Switch(config-router)#version 1
```

# 37.4 timer basic

## Description

The **timer basic** command is used to configure the RIP timer. To restore the timer configuration to its default, please use the **no timer basic** command.

## Syntax

**timer basic** *update-value* *timeout-value* *garbage-collect-value*

**no timer basic**

## Parameter

*update-value*: Routing table update time, ranging from 5 to 86400 seconds. The default value is 30.

*timeout-value*: Routing table aging time, ranging from 5 to 86400 seconds. The default value is 180.

*garbage-collect-value*: The expiration time after the routing entry is unreachable. When the entry is unreachable, the routing entry is removed from the routing table after the expiration time. The range is 5~86400 seconds, and the default value is 120.

## Command Mode

Router Configuration Mode

## Privilege Requirement

Only Admin and Operator level users have access to these commands.

## Example

Set the routing table update time to 50 seconds, the routing table aging time to 100 seconds, and the routing entry expiration time to 100 seconds:

```
Switch(config-router)#timer basic 50 100 100
```

## 37.5 distance

### Description

The **distance** command is used to configure the management distance of RIP routing. To restore the default configuration, please use the **no distance** command.

### Syntax

**distance** *distance*

**no distance**

### Parameter

*distance*: Management distance of RIP routing, ranging from 1 to 255. The default value is 120.

### Command Mode

Router Configuration Mode

### Privilege Requirement

Only Admin and Operator level users have access to these commands.

### Example

Configure the management distance of RIP routing to 100:

```
Switch(config-router)#distance 100
```

## 37.6 auto-summary

### Description

The **auto-summary** command is used to enable the automatic summary function of RIP. After this function is enabled, routing entries will be automatically summarized into natural network segments, which can reduce the number of routing entries issued for each update. To disable this function, use the **no auto-summary** command.

### Syntax

**auto-summary**

**no auto-summary**

### Command Mode

Router Configuration Mode

## Privilege Requirement

Only Admin and Operator level users have access to these commands.

## Example

Enable the automatic summary function of RIP:

```
Switch(config-router)#auto-summary
```

## 37.7 default-metric

### Description

The **default-metric** command is used to set the default metric for redirection routes. To restore the default configuration, please use the **no default-metric** command.

### Syntax

**default-metric** *metric*

**no default-metric**

### Parameter

*metric*: The default metric of the redirect route, ranging from 1 to 15, and the default value is 1.

### Command Mode

Router Configuration Mode

## Privilege Requirement

Only Admin and Operator level users have access to these commands.

## Example

Set the default metric for redirection routes to 5:

```
Switch(config-router)#default-metric 5
```

## 37.8 redistribute

### Description

The **redistribute** command is used to set the metric for redirection routes. To restore the default configuration, please use the **no redistribute** command.

### Syntax

**redistribute** { ospf *process-id* | connected | static } [ **metric** *metric-value* ]

**no redistribute** { ospf *process-id* | connected | static } [ **metric** ]



## Parameter

*ospf*: Enable RIP redirect OSPF routing function.

*process-id*: Redirected OSPF process number.

*connected*: Enable RIP redirect direct routing function.

*static*: Enable RIP redirect static routing function.

*metric-value*: The metric of the redirect route.

## Command Mode

Router Configuration Mode

## Privilege Requirement

Only Admin and Operator level users have access to these commands.

## Example

Set RIP to redirect ospf process 1, and set metric to 3:

```
Switch(config-router)#redistribute ospf 1 metric 3
```

# 37.9 allow-ecmp

## Description

The **allow-ecmp** command is used to enable the ECMP function. To disable this function, please use the **no allow-ecmp** command.

## Syntax

**allow-ecmp**

**no allow-ecmp**

## Command Mode

Router Configuration Mode

## Privilege Requirement

Only Admin and Operator level users have access to these commands.

## Example

Enable the ECMP function of RIP:

```
Switch(config-router)#allow-ecmp
```

## 37.10 default-information originate

### Description

The **default-information originate** command is used to introduce a default route into RIP. To disable this function, please use the **no default-information originate** command.

### Syntax

**default-information originate**

**no default-information originate**

### Command Mode

Router Configuration Mode

### Privilege Requirement

Only Admin and Operator level users have access to these commands.

### Example

Introduce a default route into RIP:

```
Switch(config-router)#default-information originate
```

## 37.11 neighbor

### Description

The **neighbor** command is used to configure the neighbor of RIP. After configuring the neighbor, RIP will send RIP packets to the neighbor through unicast packets. To clear the neighbor configuration, please use the **no neighbor** command.

### Syntax

**neighbor** *ip-address*

**no neighbor** *ip-address*

### Parameter

*ip-address*: IP address of RIP's neighbor.

### Command Mode

Router Configuration Mode

### Privilege Requirement

Only Admin and Operator level users have access to these commands.

## Example

Specify 192.168.0.100 as the RIP neighbor:

```
Switch(config-router)#neighbor 192.168.0.100
```

## 37.12 passive-interface

### Description

The **passive-interface** command is used to configure the interface not to send RIP packets but only to receive RIP packets. A unicast response will be sent out when a neighbor is configured at the same time. To disable this function, please use the **no passive-interface** command.

### Syntax

```
passive-interface interface { fastEthernet | gigabitEthernet |  
hundred-gigabitEthernet | loopback | port-channel | ten-gigabitEthernet |  
twentyFive-gigabitEthernet | two-gigabitEthernet | vlan } interface-value
```

```
no passive-interface interface { fastEthernet | gigabitEthernet |  
hundred-gigabitEthernet | loopback | port-channel | ten-gigabitEthernet |  
twentyFive-gigabitEthernet | two-gigabitEthernet | vlan } interface-value
```

### Parameter

*interface-value*: Specify the interface to be configured as passive-interface.

### Command Mode

Router Configuration Mode

### Privilege Requirement

Only Admin and Operator level users have access to these commands.

## Example

Configure VLAN 2 as passive-interface:

```
Switch(config-router)# passive-interface interface vlan 2
```

## 37.13 ip rip authentication mode

### Description

The **ip rip authentication mode** command is used to configure the authentication mode of RIP messages, and its no command is used to clear the configuration of authentication mode. The authentication function only takes effect when the authentication mode and password are configured.

## Syntax

**ip rip authentication mode** { md5 | simple }

**no ip rip authentication mode**

## Parameter

md5: Configure the authentication mode of RIP to md5 authentication.

simple: Configure the authentication mode of RIP to plain text authentication.

## Command Mode

Interface Configuration Mode

## Privilege Requirement

Only Admin and Operator level users have access to these commands.

## Example

Set the RIP authentication mode of VLAN 2 to md5 authentication:

```
Switch(config)#interface vlan 2
```

```
Switch(config-if)#ip rip authentication mode md5
```

# 37.14 ip rip authentication string

## Description

The **ip rip authentication string** command is used to configure the password and key ID for RIP authentication. The key ID is only used for md5 authentication. This command cannot be configured at the same time as the ip rip authentication key-chain command. To clear the password and key ID of RIP authentication, please use the **no ip rip authentication string** command.

## Syntax

**ip rip authentication string** *password* [ **key-id** *key-id-value* ]

**no ip rip authentication string**

## Parameter

*password*: RIP authentication password, 16 characters at most.

*key-id-value*: Key ID for RIP authentication, ranging from 1 to 255. The default value is 1.

## Command Mode

Interface Configuration Mode

## Privilege Requirement

Only Admin and Operator level users have access to these commands.

## Example

Configure the rip authentication password of interface VLAN 2 as tplink and the key ID as 2:

```
Switch(config)#interface vlan 2
Switch(config-if)#ip rip authentication string tplink key-id 2
```

## 37.15 ip rip authentication key-chain

### Description

The **ip rip authentication key-chain** command is used to configure the password and key ID for RIP authentication by binding key-chain. This command cannot be configured at the same time as the ip rip authentication string command. To clear key-chain binding, please use the **no ip rip authentication key-chain** command.

### Syntax

```
ip rip authentication key-chain key-chain-name
no ip rip authentication key-chain
```

### Parameter

*key-chain-name*: The name of the key-chain to be bound.

### Command Mode

Interface Configuration Mode

### Privilege Requirement

Only Admin and Operator level users have access to these commands.

### Example

Configure key chain as 1, set key as 0, the corresponding password as tplink, and bind the RIP authentication of VLAN 1 to key chain 1:

```
Switch(config)#key chain 1
Switch (config-keychain)#key 0 key-string tplink
Switch (config-keychain)#exit
Switch (config)#interface vlan 1
Switch (config-if)#ip rip authentication key-chain 1
```

## 37.16 ip rip receive version

### Description

The **ip rip receive version** command is used to configure the version of RIP packets received by the interface. If the receive version of an interface is not configured, it will be determined by the global configuration. To restore the default configuration, please use the **no ip rip receive version** command.

### Syntax

```
ip rip receive version { 1 | 2 }
```

```
no ip rip receive version
```

### Parameter

1: Configure the receive version of the interface to RIPv1.

2: Configure the receive version of the interface to RIPv2.

### Command Mode

Interface Configuration Mode

### Privilege Requirement

Only Admin and Operator level users have access to these commands.

### Example

Set the receive version of VLAN 1 to RIPv1:

```
Switch (config)#interface vlan 1
```

```
Switch (config-if)#ip rip receive version 1
```

## 37.17 ip rip send version

### Description

The **ip rip send version** command is used to configure the version of RIP packets sent by the interface. If the send version of an interface is not configured, it will be determined by the global configuration. To restore the default configuration, please use the **no ip rip receive version** command.

### Syntax

```
ip rip send version { 1 | 2 }
```

```
no ip rip send version
```

### Parameter

1: Configure the send version of the interface to RIPv1.

2: Configure the send version of the interface to RIPv2.

### Command Mode

Interface Configuration Mode

### Privilege Requirement

Only Admin and Operator level users have access to these commands.

### Example

Set the send version of VLAN 1 to RIPv1:

```
Switch (config)#interface vlan 1
Switch (config-if)#ip rip send version 1
```

## 37.18 ip rip split-horizon

### Description

The **ip rip split-horizon** command is used to configure the split horizon function of the interface. This function is enabled by default. When this function is enabled, RIP will not send routing entries learned from this interface out of this interface. When this function is disabled, RIP will only send routing entries according to the routing table. To disable this function, please use the **no ip rip split-horizon** command.

### Syntax

```
ip rip split-horizon [ poison-reverse ]
```

```
no ip rip split-horizon
```

### Parameter

poison-reverse: Enable the poison-reverse function of the interface. After this function is enabled, the entries learned from the interface will have the metric set to 16 before being sent out. Disable the poison reversal function by configuring the ip rip split-horizon command.

### Command Mode

Interface Configuration Mode

### Privilege Requirement

Only Admin and Operator level users have access to these commands.

### Example

Configure the poison-reverse function of VLAN 1:

```
Switch (config)#interface vlan 1
```

```
Switch (config-if)#ip rip split-horizon poison-reverse
```

## 37.19 ip rip v2-broadcast

### Description

The **ip rip v2-broadcast** command is used to enable the RIPv2 packet broadcast function of the interface. By default, RIPv2 messages are sent through multicast. After this function is enabled on an interface, RIPv2 messages on the interface are sent through broadcast. To disable this function, please use the **no ip rip v2-broadcast** command.

### Syntax

```
ip rip v2-broadcast
```

```
no ip rip v2-broadcast
```

### Command Mode

Interface Configuration Mode

### Privilege Requirement

Only Admin and Operator level users have access to these commands.

### Example

Enable the RIPv2 packet broadcast function of VLAN 1:

```
Switch (config)#interface vlan 1
```

```
Switch (config-if)#ip rip v2-broadcast
```

## 37.20 show ip rip

### Description

The **show ip rip** command is used to display the RIP routing table.

### Syntax

```
show ip rip
```

### Command Mode

Privileged EXEC Mode and Any Configuration Mode

### Privilege Requirement

None.



## Example

View the RIP routing table:

```
Switch#show ip rip
```

## 37.21 show ip rip status

### Description

The **show ip rip status** command is used to display the RIP status.

### Syntax

```
show ip rip status
```

### Command Mode

Privileged EXEC Mode and Any Configuration Mode

### Privilege Requirement

None.

## Example

View the RIP status:

```
Switch#show ip rip status
```

## 37.22 clear ip rip

### Description

The **clear ip rip** command is used to clear the routing entries for RIP learning and re-request routing information from other devices.

### Syntax

```
clear ip rip
```

### Command Mode

Privileged EXEC Mode and Any Configuration Mode

### Privilege Requirement

None.

## Example

Clear the routing entries for RIP learning and rerequest routing information from other devices:

```
Switch#clear ip rip
```

# Chapter 38 RIPng Configuration Commands (Only for Certain Devices)

RIPng (RIP next generation) is a routing protocol that improves the RIP protocol in order to solve the compatibility problem between the RIP protocol and IPv6.

## 38.1 router ripng

### Description

This **router ripng** command is used to enable the RIPng function. Only when the RIPng function is enabled can the global configuration of the RIPng function be performed. When the RIPng function is disabled, the global configuration of the RIPng function will be cleared. To disable this function, please use the **no router ripng** command.

### Syntax

**router ripng**

**no router ripng**

### Command Mode

Global Configuration Mode

### Privilege Requirement

Only Admin, Operator and Power User level users have access to these commands.

### Example

Enable the RIPng function on the switch:

```
Switch(config)#router ripng
```

## 38.2 ipv6 rip enable

### Description

The **ipv6 rip enable** command is used to enable the ripng function of the interface. This command only takes effect after the global switch of RIPng is enabled. To disable this function, please use **no ipv6 rip enable** command.

## Syntax

**ipv6 rip enable**

**no ipv6 rip enable**

## Command Mode

Interface Configuration Mode

## Privilege Requirement

Only Admin and Operator level users have access to these commands.

## Example

Enable the RIPng function of VLAN 1:

```
Switch(config)#interface vlan 1
```

```
Switch(config-if)# ipv6 rip enable
```

# 38.3 timer basic

## Description

The **timer basic** command is used to configure the RIPng timer. To restore the timer configuration to its default, please use the **no timer basic** command.

## Syntax

**timer basic** *update-value timeout-value garbage-collect-value*

**no network**

## Parameter

*update-value*: Routing table update time, ranging from 5 to 86400 seconds. The default value is 30.

*timeout-value*: Routing table aging time, ranging from 5 to 86400 seconds. The default value is 180.

*garbage-collect-value*: The expiration time after the routing entry is unreachable. When the entry is unreachable, the routing entry is removed from the routing table after the expiration time. The range is 5~86400 seconds, and the default value is 120.

## Command Mode

Router Configuration Mode

## Privilege Requirement

Only Admin and Operator level users have access to these commands.

## Example

Set the routing table update time to 50 seconds, the routing table aging time to 100 seconds, and the routing entry expiration time to 100 seconds:

```
Switch(config-router)#timer basic 50 100 100
```

## 38.4 default-metric

### Description

The **default-metric** command is used to set the default metric for redirect routes. To restore the default configuration, please use the **no default-metric** command.

### Syntax

**default-metric** *metric*

**no default-metric**

### Parameter

*metric*: The default metric of the redirect route, ranging from 1 to 15, and the default value is 1.

### Command Mode

Router Configuration Mode

### Privilege Requirement

Only Admin and Operator level users have access to these commands.

### Example

Set the default metric for redirection routes to 5:

```
Switch(config-router)#default-metric 5
```

## 38.5 redistribute

### Description

The **redistribute** command is used to set RIPng to redirect external routes. Its no command has two forms: if it does not contain the metric parameter, it is used to disable the redirection function of the corresponding external route. If it contains the metric parameter, it is used to restore the metric used for redirect routes to the default value.

### Syntax

**redistribute** { ospfv3 | static } [ **metric** *metric-value* ]

**no redistribute** { ospfv3 | static } [ **metric** ]

### Parameter

ospfv3: Enable RIPng redirect OSPFv3 routing function.

static: Enable RIPng redirect static routing function.

*metric-value*: The metric of the redirect route.

### Command Mode

Router Configuration Mode

### Privilege Requirement

Only Admin and Operator level users have access to these commands.

### Example

Set RIPng to redirect OSPFv3, and set metric to 3:

```
Switch(config-router)#redistribute ospfv3 metric 3
```

## 38.6 allow-ecmp

### Description

The **allow-ecmp** command is used to enable the ECMP function. To disable this function, please use the **no allow-ecmp** command.

### Syntax

**allow-ecmp**

**no allow-ecmp**

### Command Mode

Router Configuration Mode

### Privilege Requirement

Only Admin and Operator level users have access to these commands.

### Example

Enable the ECMP function of RIPng:

```
Switch(config-router)#allow-ecmp
```

## 38.7 default-information originate

### Description

The **default-information originate** command is used to introduce a default route into RIPng. To disable this function, please use the **no default-information originate** command.

### Syntax

**default-information originate**

**no default-information originate**

### Command Mode

Router Configuration Mode

### Privilege Requirement

Only Admin and Operator level users have access to these commands.

### Example

Introduce a default route into RIPng:

```
Switch(config-router)#default-information originate
```

## 38.8 passive-interface

### Description

The **passive-interface** command is used to configure the interface not to send RIPng packets but only to receive RIPng packets. A unicast response will be sent out when a neighbor is configured at the same time. To disable this function, please use the **no passive-interface** command.

### Syntax

**passive-interface interface** { fastEthernet | gigabitEthernet | hundred-gigabitEthernet | loopback | port-channel | ten-gigabitEthernet | twentyFive-gigabitEthernet | two-gigabitEthernet | vlan } *interface-value*

**no passive-interface interface** { fastEthernet | gigabitEthernet | hundred-gigabitEthernet | loopback | port-channel | ten-gigabitEthernet | twentyFive-gigabitEthernet | two-gigabitEthernet | vlan } *interface-value*

### Parameter

*interface-value*: Specify the interface to be configured as passive-interface.

## Command Mode

Router Configuration Mode

## Privilege Requirement

Only Admin and Operator level users have access to these commands.

## Example

Configure VLAN 2 as passive-interface:

```
Switch(config-router)# passive-interface interface vlan 2
```

# 38.9 ip rip split-horizon

## Description

The **ipv6 rip split-horizon** command is used to configure the split horizon function of the interface. This function is enabled by default. When this function is enabled, RIPng will not send routing entries learned from this interface out of this interface. When this function is disabled, RIPng will only send routing entries according to the routing table. To disable this function, please use the **no ipv6 rip split-horizon** command.

## Syntax

```
ipv6 rip split-horizon [ poison-reverse ]
```

```
no ipv6 rip split-horizon
```

## Parameter

poison-reverse: Enable the poison-reverse function of the interface. After this function is enabled, the entries learned from the interface will have the metric set to 16 before being sent out. Disable the poison reversal function by configuring the ipv6 rip split-horizon command.

## Command Mode

Interface Configuration Mode

## Privilege Requirement

Only Admin and Operator level users have access to these commands.

## Example

Configure the poison-reverse function of VLAN 1:

```
Switch (config)#interface vlan 1
```

```
Switch (config-if)#ipv6 rip split-horizon poison-reverse
```

## 38.10 show ipv6 rip

### Description

The **show ipv6 rip** command is used to display the RIPng routing table.

### Syntax

```
show ipv6 rip
```

### Command Mode

Privileged EXEC Mode and Any Configuration Mode

### Privilege Requirement

None.

### Example

View the RIPng routing table:

```
Switch#show ipv6 rip
```

## 38.11 show ipv6 rip status

### Description

The **show ipv6 rip status** command is used to display the RIPng status.

### Syntax

```
show ipv6 rip status
```

### Command Mode

Privileged EXEC Mode and Any Configuration Mode

### Privilege Requirement

None.

### Example

View the RIPng status:

```
Switch#show ipv6 rip status
```

## 38.12 clear ipv6 rip

### Description

The **clear ipv6 rip** command is used to clear the routing entries for RIPng learning and re-request routing information from other devices.



## **Syntax**

**clear ipv6 rip**

## **Command Mode**

Privileged EXEC Mode and Any Configuration Mode

## **Privilege Requirement**

None.

## **Example**

Clear the routing entries for RIPng learning and rerequest routing information from other devices:

```
Switch#clear ipv6 rip
```

# Chapter 39 OSPF Configuration Commands (Only for Certain Devices)

OSPF is an Interior Gateway Protocol (IGP) designed expressly for IP networks, supporting IP subnetting and tagging of externally derived routing information. OSPF also allows packet authentication and uses IP multicast when sending and receiving packets.

Currently, OSPF Version 2 (RFC2328) is used for the IPv4 protocol; Use OSPF Version 3 (RFC2740) for IPv6 protocol. Unless otherwise specified, the OSPF referred to in this chapter is OSPF Version 2.

## 39.1 router ospf

### Description

This **router ospf** command is used to create an OSPF routing process and enter the router configuration mode. Each OSPF routing process is an independent instance running the OSPF protocol, and they works separately. To delete the specified OSPF routing process, please use the **no router ospf** command.

### Syntax

```
router ospf process-id
```

```
no router ospf process-id
```

### Parameter

*process-id*: Process ID, ranging from 1 to 65535. Sixteen processes can be created at most.

### Command Mode

Global Configuration Mode

### Privilege Requirement

Only Admin, Operator and Power User level users have access to these commands.

### Example

Create an OSPF routing process with the process ID as 1:

```
Switch(config)#router ospf 1
```

## 39.2 router-id

### Description

The **router-id** command is used to configure the router ID. To delete the configured router-id, please use the **no router-id** command.

### Syntax

**Router-id** *router-id*

**no router-id**

### Parameter

*router-id*. The route ID in the format of dotted decimal notation. 0.0.0.0 is illegal.

### Command Mode

Router Configuration Mode

### Privilege Requirement

Only Admin, Operator and Power User level users have access to these commands.

### Example

Configure the router ID of OSPF routing process 1 as 1.1.1.1:

```
Switch(config)#router ospf 1
Switch(config-router)#router-id 1.1.1.1
```

## 39.3 network

### Description

This **network** command is used to configure the network of a specified area. All the interfaces fallen into the configured network will belong to this area. To delete the specified network and its corresponding interfaces from this area, please use the **no network** command.

### Syntax

**network** *ip-address wildcard-mask area area-id*

**no network** *ip-address wildcard-mask area area-id*

## Parameter

*ip-address*. The IP address of the network.

*wildcard-mask*. The wildcard mask of the network (such as 0.0.0.255). The subnet mask is also compatible (such as 255.0.0.0).

*area-id*. The area ID, in the format of an IP address in dotted decimal notation or decimal value ranging from 0 to 4294967295.

## Command Mode

Router Configuration Mode

## Privilege Requirement

Only Admin, Operator and Power User level users have access to these commands.

## Example

Configure the network 192.168.0.0/24 in the area 0.0.0.0:

```
Switch(config)#router ospf 1
Switch(config-router)# network 192.168.0.0 255.255.255.0 area 0.0.0.0
```

# 39.4 maximum-paths

## Description

The **maximum-paths** command is used to configure the maximum number of the equal-cost multipath routings. To restore to default value, please use the **no maximum-paths** command.

## Syntax

**maximum-paths** *number*

**no maximum-paths**

## Parameter

*number*. The maximum number of the equal-cost multipath routings, ranging from 1 to 32. The default value is 32.

## Command Mode

Router Configuration Mode

## Example

Configure the maximum number of the equal-cost multipath routings as 2:

```
Switch(config)#router ospf 1
```

```
Switch(config-router)#maximum-paths 2
```

## 39.5 redistribute

### Description

The **redistribute** command is used to configure the ASBR to redistribute the external routes from other routing protocols to the OSPF domain in type-5 LSAs. To restore the certain optional parameters to default values, please use the **no redistribute** command with corresponding parameters.

### Syntax

```
redistribute { connected | static / rip | ospf process-id } [ metric cost ]  
[ metric-type type ]
```

```
no redistribute { connected | static / rip | ospf process-id } [ metric cost ]  
[ metric-type type ]
```

### Parameter

*connected*: Specify the external route type as connected.

*static*: Specify the external route type as static.

*rip*: Specify the external route type as RIP.

*ospf*: Specify the external route type as OSPF.

*process-id*: The OSPF routing process ID, ranging from 1 to 65535. It's not allowed to

redirect to the own process, for example, OSPF process 1 cannot redirect itself.

*cost*: The cost of the external routes, ranging from 1 to 16777214. Its default value is

defined in the command default-metric.

*type*: The type of the external routes, either 1 or 2. The default value is 2.

### Command Mode

Router Configuration Mode

## Example

Redistribute the RIP routes from the external and advertise them as type 1 external routes in the OSPF domain:

```
Switch(config)#router ospf 1
Switch(config-router)#redistribute rip metric-type 1
```

## 39.6 default-metric

### Description

The **default-metric** command is used to configure the default cost of the redistributing external route. To restore to the default value, please use the **no default-metric** command.

### Syntax

```
default-metric cost
no default-metric
```

### Parameter

*cost*: The default cost of the redistributing external route, ranging from 1 to 16777214.

### Command Mode

Router Configuration Mode

## Example

Configure the default cost of the redistributing external route as 12:

```
Switch(config)#router ospf 1
Switch(config-router)#default-metric 12
```

## 39.7 default-metric

### Description

The **default-information originate** command is used to advertise the default route as AS-External LSA. To cancel the advertisement of the default route, please use the **no default-information originate** command without any optional parameters. To restore the certain parameters to default values,

please use the **no default-information originate** command with corresponding parameters.

## Syntax

```
default-information originate [ always ] [ metric cost ] [ metric-type type ]  
no default-information originate [ always ] [ metric cost ] [ metric-type type ]
```

## Parameter

**always:** OSPF will advertise the default route whether there is default route in the IP routing table or not. If the parameter is not configured, OSPF will advertise the default route only when there is default route in the IP routing table.

*cost:* The default cost of the default route, ranging from 1 to 16777214. Its default value is 1.

*type:* The type of the external routes, either 1 or 2. The default value is 2.

## Command Mode

Router Configuration Mode

## Example

Configure OSPF to advertise the default route whether there is default route in the IP routing table or not:

```
Switch(config)#router ospf 1  
Switch(config-router)#default-information originate always
```

## 39.8 auto-cost

### Description

The **auto-cost** command is used to enable the auto computing function of the interface cost and configure the reference bandwidth. The interface cost is the ratio of the reference bandwidth to the interface bandwidth. To restore the reference bandwidth to default value, please use the **no auto-cost reference-bandwidth** command.

### Syntax

```
auto-cost reference-bandwidth bandwidth  
no auto-cost reference-bandwidth
```

## Parameter

*bandwidth*. The reference bandwidth, ranging from 1 to 4294967 Mbps. Its default value is 100Mbps.

## Command Mode

Router Configuration Mode

## Example

Enable the auto computing function of the interface cost and configure the reference bandwidth as 10000 Mbps:

```
Switch(config)#router ospf 1
Switch(config-router)#auto-cost reference-bandwidth 10000
```

# 39.9 distance

## Description

The **distance** command is used to configure the OSPF administrative distance. To restore to the default distance, please use the **no distance** command. The administrative distance represents the priority of the routes. The smaller administrative distance corresponds to higher priority. When different routing protocols possess the same route to the same destination, the route with the highest priority will be selected to add to the IP routing table according to the administrative distance.

## Syntax

```
distance administrative-distance
no distance
```

## Parameter

*administrative-distance*. Routing administrative distance, ranging from 1 to 255. Its default value is 110. When this value is set to 255, it indicates that the source of routing information is unreliable and all related routes are ignored.

## Command Mode

Router Configuration Mode

## Example

Configure the OSPF routing administrative distance as 100:



```
Switch(config)#router ospf 1
Switch(config-router)#distance 100
```

## 39.10 timers throttle spf

### Description

The **timers throttle spf** command is used to configure the computing delay and interval of the SPF, thus preventing the consumption of the CPU and memory caused by frequent SPF computing. To restore to the default value, please use the **no timers throttle spf** command.

### Syntax

```
timers throttle spf spf-delay spf-holdtime spf-max-holdtime
no timers throttle spf
```

### Parameter

*spf-delay*: The delay time of the SPF computing, ranging from 1 to 600000 milliseconds. The default value is 0 milliseconds.

*spf-holdtime*: The minimum interval between two SPF computings, ranging from 1 to 600000 milliseconds. The default value is 50 milliseconds.

*spf-max-holdtime*: The Maximum interval between two SPF computings, ranging from 1 to 600000 milliseconds. The default value is 5000 milliseconds.

### Command Mode

Router Configuration Mode

### Example

Configure the computing delay and interval of the SPF as 10 seconds:

```
Switch(config)#router ospf 1
Switch(config-router)#timers throttle spf 10000 10000 50000
```

## 39.11 compatible rfc 1583

### Description

The **compatible rfc 1583** command is used to configure the OSPF's compatibility for the routing rules in the RFC 1583. To cancel the

compatibility, please use the **no compatible rfc1583** command. It is compatible by default.

## Syntax

**compatible rfc1583**

**no compatible rfc1583**

## Command Mode

Router Configuration Mode

## Example

Configure the OSPF's compatibility for the routing rules in RFC 1583:

```
Switch(config)#router ospf 1
Switch(config-router)#compatible rfc1583
```

# 39.12 area stub

## Description

The **area stub** command is used to define an area as a stub area. To restore the stub area to a normal one, please use the **no area stub** command. To restore the certain parameters to default values, please use the **no area stub** command with corresponding parameters.

## Syntax

**area *area-id* stub [ no-summary ]**

**no area *area-id* stub [ no-summary ]**

## Parameter

*area-id*: The area ID, in the format of an IP address in dotted decimal notation or decimal value ranging from 1 to 4294967295.

**no-summary**: Configure the stub are as a totally stub area, where the ABR advertises neither the destinations in other areas nor the external routes. The stub area is not a totally stub area by default

## Command Mode

Router Configuration Mode

## Example

Configure the area 1 as a totally stub area:

```
Switch(config)#router ospf 1
Switch(config-router)# area 1 stub no-summary
```

## 39.13 area nssa

### Description

The **area nssa** command is used to define an area as a NSSA area. To restore the NSSA area to a normal one, please use the **no area nssa** command without any optional parameters. To restore the certain parameters to default values, please use the **no area nssa** command with corresponding parameters.

### Syntax

```
area area-id nssa [no summary | default-information-originate [ metric cost] [ metric-type type]]
```

```
no area-id nssa [no summary | default-information-originate [ metric cost] [ metric-type type]]
```

### Parameter

*area-id*: The area ID, in the format of an IP address in dotted decimal notation or decimal value ranging from 1 to 4294967295.

**no-summary**: Configure the NSSA area as a totally NSSA area, where the ABR advertises neither the destinations in other areas nor the external routes. The NSSA area is not a totally NSSA area by default.

**default-information-originate**: Enable or disable advertising default route into NSSA area by sending a NSSA-External LSA. OSPF will not advertise default route if this parameter is not specified

*cost*: The default cost of the default route, ranging from 1 to 16777214. Its default value is 1.

*type*: The type of the external routes, either 1 or 2. The default value is 2.

### Command Mode

Router Configuration Mode

## Example

Configure the Area 1 as a totally NSSA area:

```
Switch(config)#router ospf 1
Switch(config-router)# area 1 nssa no-summary
```

## 39.14 area default-cost

### Description

The **area default-cost** command is used to configure the cost of default route sent from ABR to stub or NSSA area.

### Syntax

```
area area-id default-cost cost
no area area-id default-cost
```

### Parameter

*area-id*: The area ID, in the format of an IP address in dotted decimal notation or decimal value ranging from 1 to 4294967295.

*cost*: The cost value. It ranges from 1 to 16777214 and the default value is 1.

### Command Mode

Router Configuration Mode

### Example

Configure the cost of default route sent to Area 1 as 10:

```
Switch(config)#router ospf 1
Switch(config-router)#area 1 nssa
Switch(config-router)#area 1 default-cost 10
```

## 39.15 area range

### Description

The **area range** command is used to configure a summary route. To delete this route, please use the **no area range** command. By default no route is summarized.

This command is only used with the ABR to summarize the route information of a certain area. The ABR only sends one summarized route of the routes in the aggregated segment to the other areas. An area can be configured with multiple summary segments, which can be aggregated by OSPF.

If the no area range command is configured, the formally summarized routes will be redistributed.

## Syntax

```
area area-id range ip-address mask [ advertise ] [ cost cost ]  
[ not-advertise ]
```

```
no area area-id range ip-address mask [ advertise ] [ cost cost ]  
[ not-advertise ]
```

## Parameter

*area-id*: The area ID, in the format of an IP address in dotted decimal notation or decimal value ranging from 0 to 4294967295.

*ip-address*: The destination of the aggregated route.

*mask*: The network mask of the aggregated route, in the format of dotted decimal notation.

**advertise**: Allow route aggregation of ABR broadcast.

**not-advertise**: Suppress route aggregation of ABR broadcast.

*cost*: The cost of the aggregated route, ranging from 1 to 16777214. The default value is the maximum one of all the aggregated routes. The cost parameter can be configured only when the advertise parameter is enabled. When configured as not-advise, the cost parameter will be restored to the default value.

## Command Mode

Router Configuration Mode

## Example

Configure one aggregated route 100.100.0.0/16 with the cost 10 in the Area 0:

```
Switch(config)#router ospf 1  
Switch(config-router)#area 0 range 100.100.0.0 255.255.0.0 cost 10
```

## 39.16 area authentication

### Description

The **area authentication** command is used to configure the authentication type of the ospf process. The process is not authenticated by default. To restore to default value, please use the **no area authentication** command.

### Syntax

```
area area-id authentication [ message-digest ]
```

```
no area authentication
```

### Parameter

*area-id*: The area ID, in the format of an IP address in dotted decimal notation or decimal value ranging from 0 to 4294967295.

message-digest: Configure the configuration type as MD5.

If no authentication mode is specified here, the default mode will be simple authentication.

### Command Mode

Router Configuration Mode

### Example

Configure the authentication method to MD5 in the Area 0:

```
Switch(config)#router ospf 1  
Switch(config-router)#area 0 authentication message-digest
```

## 39.17 area virtual-link

### Description

The **area virtual-link** command is used to configure the virtual-link. To delete the configured virtual-link, please use the **no area virtual-link** without any optional parameters. To restore the certain parameters to default values, please use the **no area virtual-link** command with corresponding parameters.

## Syntax

```
area transit-area virtual-link router-id [ dead-interval dead-interval ]  
[ hello-interval hello-interval ] [ retransmit-interval rtx-interval ]  
[ transmit-delay trans-delay]
```

```
no area transit-area virtual-link router-id
```

## Parameter

*transit-area*: The area ID, in the format of an IP address in dotted decimal notation or decimal value ranging from 1 to 4294967295.

*router-id*: The ID of the neighboring router on the opposite end of the virtual link, in the format of dotted decimal notation.

*hello-interval*: The interval of the hello packets, ranging from 1 to 65535 seconds and the default value is 10 seconds.

*dead-interval*: The time after which the neighbor becomes invalid. It ranges from 1 to 65535 seconds and the default value is 4 times as the hello-interval.

*rtx-interval*: The retransmission interval of the LSA, DD and LSR packets. It ranges from 1 to 65535 seconds and the default value is 5 seconds.

*trans-delay*: The LSA transmission delay. It ranges from 1 to 65535 seconds and the default value is 1 seconds.

## Command Mode

Router Configuration Mode

## Example

Configure a virtual-link with the transmission area as Area 1 and the ID of the neighboring router on the other endpoint as 1.1.1.1:

```
Switch(config)#router ospf 1  
Switch(config-router)#area 1 virtual-link 1.1.1.1
```

# 39.18 area virtual-link authentication

## Description

The **area virtual-link authentication** command is used to configure the authentication type of the virtual link. The virtual link is not authenticated by

default. To restore to default value, please use the **no area virtual-link authentication** command.

## Syntax

```
area transit-area virtual-link router-id authentication [ message-digest | null ]
```

```
no area transit-area virtual-link router-id authentication
```

## Parameter

*transit-area*: The transition area ID in the format of an IP address in dotted decimal notation or decimal value ranging from 1 to 4294967295.

*router-id*: The ID of the neighboring router on the other endpoint of the virtual link, in the format of dotted decimal notation.

message-digest: Configure the configuration type as MD5.

null: No authentication. By default it is no authentication.

If no authentication mode is specified here, the default mode will be simple authentication.

## Command Mode

Router Configuration Mode

## Example

Configure simple authentication as the authentication mode of a virtual-link with the transmission area as Area 2 and the ID of the neighboring router on the other endpoint as 3.3.3.3:

```
Switch(config)#router ospf 1  
Switch(config-router)#area 2 virtual-link 3.3.3.3 authentication
```

# 39.19 area virtual-link authentication-key

## Description

The **area virtual-link authentication-key** command is used to configure the simple authentication key. To delete the key, please use the **no area virtual-link authentication-key** command.



## Syntax

**area** *transit-area* **virtual-link** *router-id* **authentication-key** [0|7]*password*

**no area** *transit-area* **virtual-link** *router-id* **authentication-key**

## Parameter

*transit-area*: The transition area ID in the format of an IP address in dotted decimal notation or decimal value ranging from 1 to 4294967295.

*router-id*: The ID of the neighboring router on the other endpoint of the virtual link, in the format of dotted decimal notation.

[0|7]: Key form, 0 represents plaintext, 7 represents ciphertext.

*password*: A string from 1 to 8 alphanumeric characters or symbols. The password is case-sensitive, and cannot contain question marks. By default, it is empty.

## Command Mode

Router Configuration Mode

## Example

Configure the authentication mode of a virtual-link as simple authentication, with the transmission area as Area 2 and the ID of the neighboring router on the other endpoint as 3.3.3.3, and the authentication key as 123456:

```
Switch(config)#router ospf 1
Switch(config-router)#area 2 virtual-link 3.3.3.3 authentication-key
123456
```

# 39.20 area virtual-link message-digest-key

## Description

The **area virtual-link message-digest-key** is used to configure the MD5 authentication ID and key of the virtual-link. To delete the specified configuration, please use the **no area virtual-link message-digest-key** command.

## Syntax

```
area transit-area virtual-link router-id message-digest-key id md5 [0|7]  
password
```

```
no area transit-area virtual-link router-id message-digest-key id
```

## Parameter

*transit-area*: The transition area ID in the format of an IP address in dotted decimal notation or decimal value ranging from 1 to 4294967295.

*router-id*: The ID of the neighboring router on the other endpoint of the virtual link, in the format of dotted decimal notation.

*id*: The key ID of the MD5, ranging from 1 to 255.

[0|7]: Key form, 0 represents plaintext, 7 represents ciphertext.

*password*: A string from 1 to 16 alphanumeric characters or symbols. The password is case-sensitive, and cannot contain question marks. By default, it is empty.

## Command Mode

Router Configuration Mode

## Example

Configure the authentication mode of a virtual-link as md5 authentication, with the transmission area as Area 2 and the ID of the neighboring router on the other endpoint as 3.3.3.3, with the authentication ID as 2 and the authentication key as 123456:

```
Switch(config)#router ospf 1  
Switch(config-router)#area 2 virtual-link 3.3.3.3 message-digest- key 2  
md5 123456
```

## 39.21 ip ospf cost

### Description

The **ip ospf cost** is used to configure the interface cost. To restore to the default value, please use the **no ip ospf cost** command.

### Syntax

```
ip ospf cost cost
```

```
no ip ospf cost
```

## Parameter

*cost* — The interface cost, ranging from 1 to 65535. The default value is calculated according to the bandwidth.

## Command Mode

Interface Configuration Mode

## Example

Configure the cost of interface VLAN 2 as 10:

```
Switch(config)#interface vlan 2
Switch(config-if)# ip ospf cost 10
```

## 39.22 ip ospf retransmit-interval

### Description

The **ip ospf retransmit-interval** command is used to configure the interval to retransmit the LSA, DD and LSR packets on the specified interface. To restore to default value, please use the **no ip ospf retransmit-interval** command.

### Syntax

```
ip ospf retransmit-interval interval
no ip ospf retransmit-interval
```

### Parameter

*interval* — The retransmit interval, ranging from 1 to 65535 seconds. The default value is 5 seconds.

### Command Mode

Interface Configuration Mode

### Example

Configure the retransmission interval of interface VLAN 2 as 10 seconds:

```
Switch(config)#interface vlan 2
Switch(config-if)#ip ospf retransmit-interval 10
```

## 39.23 ip ospf transmit-delay

### Description

The **ip ospf transmit-delay** is used to configure the transmission delay of LSA on the specified interface. To restore to default value, please use the **no ip ospf transmit-delay**.

### Syntax

```
ip ospf transmit-delay delay  
no ip ospf transmit-delay
```

### Parameter

*delay*— The LSA transmission delay, ranging from 1 to 65535 seconds. The default value is 1 second.

### Command Mode

Interface Configuration Mode

### Example

Configure the LSA transmission delay of interface VLAN 2 as 2 seconds.

```
Switch(config)#interface vlan 2  
Switch(config-if)#ip ospf retransmit-delay 2
```

## 39.24 ip ospf priority

### Description

The **ip ospf priority** is used to configure the priority of the specified interface. To restore to the default value, please use the **no ip ospf priority** command.

### Syntax

```
ip ospf priority pri  
no ip ospf priority
```

### Parameter

*pri* — The priority of the interface, ranging from 0 to 255 and the default value is 1. Interface with the priority 0 cannot be elected as DR or BDR.

## Command Mode

Interface Configuration Mode

## Example

Configure the priority of the interface VLAN 2 as 1:

```
Switch(config)#interface vlan 2
Switch(config-if)#ip ospf priority 1
```

# 39.25 ip ospf hello-interval

## Description

The **ip ospf hello-interval** is used to configure the hello intervals on the specified interface. To restore to the default value, please use the **no ip ospf hello-interval** command.

## Syntax

```
ip ospf hello-interval interval
no ip ospf hello-interval
```

## Parameter

*Interval* — The interval of the hello packets, ranging from 1 to 65535 seconds and the default value is 10 seconds.

## Command Mode

Interface Configuration Mode

## Example

Configure the interval of the hello packets sent on interface VLAN 2 as 20 seconds:

```
Switch(config)#interface vlan 2
Switch(config-if)#ip ospf hello-interval 20
```

## 39.26 ip ospf dead-interval

### Description

The **ip ospf dead-interval** command is used to set the number of seconds after the last device hello packet was seen before its neighbors declare the OSPF router to be down. To restore to default value, please use the **no ip ospf dead-interval** command.

### Syntax

```
ip ospf dead-interval interval  
no ip ospf dead-interval
```

### Parameter

*Interval* — The interval of the hello packets, ranging from 1 to 65535 seconds and the default value is 10 seconds.

### Command Mode

Interface Configuration Mode

### Example

Configure the neighbor's failure interval on interface VLAN 2 as 50 seconds:

```
Switch(config)#interface vlan 2  
Switch(config-if)#ip ospf dead-interval 50
```

## 39.27 ip ospf authentication

### Description

The **ip ospf authentication** command is used to configure the authentication mode of the specified interface. To restore to default value, please use the **no ip ospf authentication** command.

### Syntax

```
ip ospf authentication [ message-digest ] [ null ]  
no ip ospf authentication
```

### Parameter

**message-digest** — Specify the authentication type as MD5.

**null** — No authentication. By default it is no authentication.

If no authentication mode is specified here, the default mode will be simple authentication.

## Command Mode

Interface Configuration Mode

## Example

Configure the authentication type of interface VLAN 2 as MD5:

```
Switch(config)#interface vlan 2
Switch(config-if)#ip ospf authentication message-digest
```

# 39.28 ip ospf authentication-key

## Description

The **ip ospf authentication-key** command is used to configure the key of the simple authentication. To cancel this configuration, please use the **no ip ospf authentication-key** command.

## Syntax

```
ip ospf authentication-key password
no ip ospf authentication-key
```

## Parameter

*password* — Super password, a string from 1 to 8 alphanumeric characters or symbols. The password is case sensitive, allows spaces but ignores leading spaces, and cannot contain question marks. By default, it is empty.

## Command Mode

Interface Configuration Mode

## Example

Configure the authentication mode of interface VLAN 2 as simple authentication, and the password as 123:

```
Switch(config)#interface vlan 2
Switch(config-if)#ip ospf authentication-key 123
```

## 39.29 ip ospf message-digest-key

### Description

The **ip ospf message-digest-key** is used to configure the ID and password of the md5 authentication on the specified interface. To cancel the configuration, please use **no ip ospf message-digest-key** command.

### Syntax

```
ip ospf message-digest-key id md5 password  
no ip ospf message-digest-key id
```

### Parameter

*id*—— The ID of the md5 authentication key, ranging from 1 to 255.  
*password*—— A string from 1 to 16 alphanumeric characters or symbols. The password is case sensitive, and cannot contain question marks. Key configuration is required to take effect.

### Command Mode

Interface Configuration Mode

### Example

Configure md5 authentication key ID as 1 and password as abc on interface VLAN 2:

```
Switch(config)#interface vlan 2  
Switch(config-if)#ip ospf message-digest-key 1 md5 abc
```

## 39.30 ip ospf network

### Description

The **ip ospf network** command is used to configure the network type on the specified interface. To restore to default, please use the **no ip ospf network** command.

### Syntax

```
ip ospf network { broadcast | non-broadcast | point-to-multipoint |  
point-to-point }  
no ip ospf network
```



## Parameter

broadcast — The broadcast network type. It is the default value.

non-broadcast — The NBMA network type.

point-to-multipoint — The point-to-multipoint network type.

point-to-point — The point-to-point network type.

## Command Mode

Interface Configuration Mode

## Example

Configure the network type on interface VLAN 2 as broadcast:

```
Switch(config)#interface vlan 2
Switch(config-if)#ip ospf network broadcast
```

# 39.31 ip ospf mtu-ignore

## Description

The **ip ospf mtu-ignore** command is used to ignore the MTU check in the DD exchanging process. This check is scheduled by default and the adjacency relationship will not establish if the MTUs are not matched. To restore to the default value, please use the **no ip ospf mtu-ignore** command.

## Syntax

**ip ospf mtu-ignore**

**no ip ospf mtu-ignore**

## Command Mode

Interface Configuration Mode

## Example

Configure interface VLAN 2 to ignore the MTU field check in the DD exchange process:

```
Switch(config)#interface vlan 2
Switch(config-if)#ip ospf mtu-ignore
```

## 39.32 ip ospf passive

### Description

The **ip ospf passive** command is used to prevent an interface from sending OSPF packets. To restore to the default settings, please use **no ip ospf passive** command. The interface is allowed to send OSPF packets by default.

### Syntax

```
ip ospf passive
no ip ospf passive
```

### Command Mode

Interface Configuration Mode

### Example

Prevent interface VLAN 2 from sending OSPF packets:

```
Switch(config)#interface vlan 2
Switch(config-if)#ip ospf passive
```

## 39.33 clear ip ospf

### Description

The **clear ip ospf** command is used to reset the OSPF process, which will clear all the dynamic information. The **clear ip ospf process** command will reset all the OSPF processes.

### Syntax

```
clear ip ospf [process-id]
clear ip ospf process
```

### Parameter

*process-id*—— The process ID, ranging from 1 to 65535.

### Command Mode

Privileged EXEC Mode

### Example

Reset all the OSPF processes:

```
Switch#clear ip ospf process
```

```
Reset selected OSPF processes? (Y/N):y
```

## 39.34 show ip ospf

### Description

The **show ip ospf** is used to display the global information of the OSPF process.

### Syntax

```
show ip ospf [ process-id ]
```

### Parameter

*process-id* — The process ID, ranging from 1 to 65535. The global information of all the OSPF processes will be displayed if no process-id is specified.

### Command Mode

Privileged EXEC Mode and Any Configuration Mode

### Example

Display the global information of all the OSPF processes:

```
Switch#show ip ospf
```

## 39.35 show ip ospf database

### Description

The **show ip ospf database** command is used to display the LSDB. The detailed LSA information will be displayed if the LSA type is specified. The LSDB summary information will be displayed if the LSA type is not specified.

### Syntax

```
show ip ospf [ process-id ] database [ asbr-summary | external | network |  
nssa-external | router | summary ]
```

### Parameter

*process-id* — The process ID, ranging from 1 to 65535. The LSDBs of all processes will be displayed if no process ID is specified.

asbr-summary | external | network | nssa-external | router | summary — The LSA type.

### Command Mode

Privileged EXEC Mode and Any Configuration Mode

### Example

Display the detailed information of router-LSA in process 1:

```
Switch#show ip ospf 1 database router
```

## 39.36 show ip ospf interface

### Description

The **show ip ospf interface** command is used to display the interface information.

### Syntax

```
show ip ospf [ process-id ] interface [ interface-name interface-number ]
```

### Parameter

*process-id* — The process ID. The information of all the processes will be displayed if process ID is not specified.

*interface-name interface-number* — Specify the interface name and number to display the interface's detailed information.

### Command Mode

Privileged EXEC Mode and Any Configuration Mode

### Example

Display the information of the interfaces in all the OSPF processes:

```
Switch#show ip ospf interface
```

## 39.37 show ip ospf neighbor

### Description

The **show ip ospf neighbor** command is used to display information of the OSPF neighbor.

## Syntax

```
show ip ospf [ process-id ] neighbor [ detail | interface-name
interface-number]
```

## Parameter

*process-id* — The process ID, ranging from 1 to 65535. The neighbors' information of all processes will be displayed if no process ID is specified.

**detail** — The detailed information of the neighbor.

*interface-name interface-number* — Specify the interface name and number to display the neighbor's detailed information on this interface.

## Command Mode

Privileged EXEC Mode and Any Configuration Mode

## Example

Display the neighbors' detailed information in process 1:

```
Switch#show ip ospf 1 neighbor detail
```

# 39.38 show ip ospf border-routers

## Description

The **show ip ospf border-routers** is used to display the routing tables of the ABR/ASBR.

## Syntax

```
show ip ospf [ process-id] border-routers
```

## Parameter

*process-id* — The process ID, ranging from 1 to 65535. The ABR/ASBR routing tables of all processes will be displayed if no process ID is specified.

## Command Mode

Privileged EXEC Mode and Any Configuration Mode

## Example

Display the ABR/ASBR routing tables of all the OSPF processes:

```
Switch#show ip ospf border-routers
```

## 39.39 show ip ospf route

### Description

The **show ip ospf route** command is used to display the OSPF routing table.

### Syntax

```
show ip ospf route
```

### Command Mode

Privileged EXEC Mode and Any Configuration Mode

### Example

Display the routing tables of OSPF:

```
Switch#show ip ospf route
```

# Chapter 40 OSPFv3 Configuration Commands (Only for Certain Devices)

OSPF is an Interior Gateway Protocol (IGP) designed expressly for IP networks, supporting IP subnetting and tagging of externally derived routing information. OSPF also allows packet authentication and uses IP multicast when sending and receiving packets.

Currently, OSPF Version 2 (RFC2328) is used for the IPv4 protocol; Use OSPF Version 3 (RFC2740) for IPv6 protocol. OSPFv3 is short for OSPF Version 3 and is the OSPF routing protocol running on IPv6 (RFC5340, same as RFC2740).

## 40.1 ipv6 router ospf

### Description

The **ipv6 router ospf** command is used to enable an OSPFv3 routing process and enter the router configuration mode. To delete the specified OSPFv3 routing process, please use the **no ipv6 router ospf** command.

### Syntax

```
ipv6 router ospf  
no ipv6 router ospf
```

### Command Mode

Global Configuration Mode

### Example

Enable an OSPFv3 routing process:

```
Switch(config)#ipv6 router ospf
```

## 40.2 router-id

### Description

The **router-id** command is used to configure the router ID. The **no router-id** command is used to delete the configured router ID. If no router ID is configured manually or the configured router ID is deleted, the highest IPV6 address among all loopback interfaces will be chosen as the router ID.

## Syntax

**Router-id** *router-id*

**no router-id**

## Parameter

*router-id* — The route ID in the format of dotted decimal notation. 0.0.0.0 is illegal.

## Command Mode

Router Configuration Mode

## Privilege Requirement

Only Admin, Operator and Power User level users have access to these commands.

## Example

Configure the router ID of OSPFv3 routing process 1 as 1.1.1.1:

```
Switch(config)#ipv6 router ospf 1
Switch(config-router)#router-id 1.1.1.1
```

# 40.3 maximum-paths

## Description

The **maximum-paths** command is used to configure the maximum number of the equal-cost multipath routings. To restore to default value, please use the **no maximum-paths** command.

## Syntax

**maximum-paths** *number*

**no maximum-paths**

## Parameter

*number* — The maximum number of the equal-cost multipath routings, ranging from 1 to 32. The default value is 32.

## Command Mode

Router Configuration Mode

## Example

Configure the maximum number of the equal-cost multipath routings as 2:



```
Switch(config)#ipv6 router ospf
Switch(config-router)#maximum-paths 2
```

## 40.4 redistribute

### Description

The **redistribute** command is used to configure the ASBR to redistribute the external routes from other routing protocols to the OSPFv3 domain in type-5 LSAs. To restore the certain optional parameters to default values, please use the **no redistribute** command with corresponding parameters.

### Syntax

```
redistribute { connected | static | rip }
no redistribute { connected | static | rip }
```

### Parameter

**connected** — Specify the external route type as connected.  
**static** — Specify the external route type as static.  
**rip** — Specify the external route type as RIPNG.

### Command Mode

Router Configuration Mode

### Example

Redistribute the RIPNG routes from the external in the OSPFv3 domain.

```
Switch(config)#ipv6 router ospf
Switch(config-router)#redistribute rip
```

## 40.5 default-information originate

### Description

The **default-information originate** command is used to advertise the default route as AS-External LSA. To cancel the advertisement of the default route, please use the **no default-information originate** command without any optional parameters. To restore the certain parameters to default values,

please use the **no default-information originate** command with corresponding parameters.

## Syntax

```
default-information originate [ always ] [ metric cost ] [ metric-type type ]  
no default-information originate [ always ] [ metric cost ] [ metric-type type ]
```

## Parameter

**always** — OSPFv3 will advertise the default route whether there is default route in the IPv6 routing table or not. If the parameter is not configured, OSPFv3 will advertise the default route only when there is default route in the IPv6 routing table.

*cost* — The default cost of the default route, ranging from 1 to 16777214. Its default value is 1.

*type* — The type of the external routes, either 1 or 2. The default value is 2.

## Command Mode

Router Configuration Mode

## Example

Configure OSPF to advertise the default route whether there is default route in the IP routing table or not:

```
Switch(config)#router ospf 1  
Switch(config-router)#default-information originate always
```

## 40.6 auto-cost

### Description

The **auto-cost** command is used to enable the auto computing function of the interface cost and configure the reference bandwidth. The interface cost is the ratio of the reference bandwidth to the interface bandwidth. To restore the reference bandwidth to default value, please use the **no auto-cost reference-bandwidth** command.

### Syntax

```
auto-cost reference-bandwidth bandwidth  
no auto-cost reference-bandwidth
```

## Parameter

*bandwidth* — The reference bandwidth, ranging from 1 to 4294967 Mbps. Its default value is 100Mbps.

## Command Mode

Router Configuration Mode

## Example

Enable the auto computing function of the interface cost and configure the reference bandwidth as 10000 Mbps:

```
Switch(config)#ipv6 router ospf
Switch(config-router)#auto-cost reference-bandwidth 10000
```

# 40.7 distance

## Description

The **distance** command is used to configure the OSPFv3 administrative distance. To restore to the default distance, please use the **no distance** command. The administrative distance represents the priority of the routes. The smaller administrative distance corresponds to higher priority. When different routing protocols possess the same route to the same destination, the route with the highest priority will be selected to add to the IPv6 routing table according to the administrative distance.

## Syntax

```
distance administrative-distance
no distance
```

## Parameter

*administrative-distance* — Routing administrative distance, ranging from 1 to 254. Its default value is 110.

## Command Mode

Router Configuration Mode

## Example

Configure the OSPFV3 routing administrative distance as 100:

```
Switch(config)#ipv6 router ospf
```

```
Switch(config-router)#distance 100
```

## 40.8 distance ospf

### Description

The **distance ospf** command is used to configure the OSPFv3 distance for different types of routes. To restore to the default distance, please use the **no distance** command.

### Syntax

```
distance ospf { external distance | inter-area distance | intra-area distance }  
no distance
```

### Parameter

**external** — External type 5 and type 7 routes.

**inter-area** — Inter-area routes.

**intra-area** — Intra-area routes.

*distance* — Distance for different types of routes, ranging from 1 to 254. Its default value is 110.

### Command Mode

Router Configuration Mode

### Example

Configure the OSPFV3 routing administrative distance as 100:

```
Switch(config)#ipv6 router ospf  
Switch(config-router)#distance 100
```

## 40.9 timers throttle spf

### Description

The **timers throttle spf** command is used to configure the computing delay and interval of the SPF, thus preventing the consumption of the CPU and memory caused by frequent SPF computing. To restore to the default value, please use the **no timers throttle spf** command.

## Syntax

**timers throttle spf** *spf-delay spf-holdtime spf-max-holdtime*  
**no timers throttle spf**

## Parameter

*spf-delay*— The delay time of the SPF computing, ranging from 1 to 600000 milliseconds. The default value is 0 milliseconds.

*spf-holdtime* — The minimum interval between two SPF computings, ranging from 1 to 600000 milliseconds. The default value is 50 milliseconds

*spf-max-holdtime* — The Maximum interval between two SPF computings, ranging from 1 to 600000 milliseconds. The default value is 5000 milliseconds

## Command Mode

Router Configuration Mode

## Example

Configure the computing delay and interval of the SPF as 10 seconds:

```
Switch(config)#ipv6 router ospf
Switch(config-router)#timers throttle spf 10000 10000 50000
```

# 40.10 timers lsa arrival

## Description

The **timers lsa arrival** command is used to configure the time interval for OSPFv3 LSA reception. To restore to the default value, please use the **no timers lsa arrival** command.

## Syntax

**timers lsa arrival** *delay-time*  
**no timers lsa arrival**

## Parameter

*delay-time*— The time interval for OSPFv3 LSA reception, ranging from 1 to 600000 milliseconds. The default value is 1000 milliseconds.

## Command Mode

Router Configuration Mode

## Example

Configure the time interval for OSPFv3 LSA reception as 10 seconds:

```
Switch(config)#ipv6 router ospf
Switch(config-router)#timers lsa arrival 10000
```

## 40.11 area stub

### Description

The **area stub** command is used to define an area as a stub area. To restore the stub area to a normal one, please use the **no area stub** command. To restore the certain parameters to default values, please use the **no area stub** command with corresponding parameters.

### Syntax

```
area area-id stub [ no-summary ]
no area area-id stub [ no-summary ]
```

### Parameter

*area-id*. The area ID, in the format of an IP address in dotted decimal notation or decimal value ranging from 0 to 4294967295.

**no-summary** — Configure the stub area as a totally stub area, where the ABR advertises neither the destinations in other areas nor the external routes. The stub area is not a totally stub area by default.

### Command Mode

Router Configuration Mode

### Example

Configure the area 1 as a totally stub area:

```
Switch(config)#ipv6 router ospf
Switch(config-router)#area 1 stub no-summary
```

## 40.12 area nssa

### Description

The **area nssa** command is used to define an area as a NSSA area. To restore the NSSA area to a normal one, please use the **no area nssa** command without any optional parameters. To restore the certain parameters to default values, please use the **no area nssa** command with corresponding parameters.

### Syntax

```
area area-id nssa [ no-summary ]  
no area area-id nssa [ no-summary ]
```

### Parameter

*area-id*. The area ID, in the format of an IP address in dotted decimal notation or decimal value ranging from 0 to 4294967295.

**no-summary** — Select to not send summary LSAs into the NSSA.

### Command Mode

Router Configuration Mode

### Example

Configure the Area 1 as a totally NSSA area:

```
Switch(config)#router ospf 1  
Switch(config-router)# area 1 nssa no-summary
```

## 40.13 area range

### Description

The **area range** is to configure a summary route. To delete this route, please use the **no area range** command. By default no route is summarized.

This command is only used with the ABR to summarize the route information of a certain area. The ABR only sends one summarized route of the routes in the aggregated segment to the other areas. An area can be configured with multiple summary segments, which can be aggregated by OSPF.

If the **no area range** command is configured, the formally summarized routes will be redistributed.

## Syntax

```
area area-id range ipv6-address/mask-num [ advertise ] [ cost cost ]  
[ not-advertise ]
```

```
no area area-id range ip-address mask [ advertise ] [ cost cost ]  
[ not-advertise ]
```

## Parameter

*area-id*: The area ID, in the format of an IP address in dotted decimal notation or decimal value ranging from 0 to 4294967295.

*ipv6-address*—— The destination of the aggregated route.

*mask-num* —— The network mask for aggregated route, in the format of mask bits.

*cost*—— The cost of the aggregated route, ranging from 1 to 16777214. The default value is the maximum one of all the aggregated routes.

## Command Mode

Router Configuration Mode

## Example

Configure one aggregated route 2001::1/64 with the cost 10 in the Area 0:

```
Switch(config)# ipv6 router ospf  
Switch(config-router)# area 0 range 2001::1/64 cost 10
```

# 40.14 ipv6 ospf area

## Description

The **ipv6 ospf area** is used to assign the interface to different regions. By default, the interface does not belong to any area. Only the interface attached to a certain area can receive ospfv3 packets normally. To restore to the default value, please use the **no ipv6 ospf area** command.

## Syntax

```
ip ospf area area-id [ instance-id instance-id ]
```

```
no ip ospf area area-id [ instance-id instance-id ]
```



## Parameter

*area-id*. The area ID, in the format of an IP address in dotted decimal notation or decimal value ranging from 0 to 4294967295.

*instance-id* — The instance ID, ranging from 0 to 255. OSPFv3 supports running multiple instances on a single link, using the optional parameter *instance-id* as the instance identifier. The instance number only affects the reception of OSPFv3 messages. By default, this parameter value is 0. To restore the default value, use the `no ipv6 ospf area area-id instance-id` command.

## Command Mode

Interface Configuration Mode

## Example

Assign interface VLAN 2 to area 10:

```
Switch(config)#interface vlan 2
Switch(config-if)#ipv6 ospf area 10
```

# 40.15 ipv6 ospf cost

## Description

The **ipv6 ospf cost** is used to configure the interface cost. To restore to the default value, please use the **no ipv6 ospf cost** command.

## Syntax

**ipv6 ospf cost** *cost*

**no ipv6 ospf cost**

## Parameter

*cost* — The interface cost, ranging from 1 to 65535. The default value is calculated according to the bandwidth.

## Command Mode

Interface Configuration Mode

## Example

Configure the cost of interface VLAN 2 as 10:

```
Switch(config)#interface vlan 2
Switch(config-if)#ipv6 ospf cost 10
```

## 40.16 ipv6 ospf retransmit-interval

### Description

The **ipv6 ospf retransmit-interval** command is used to configure the interval to retransmit the LSA, DD and LSR packets on the specified interface. To restore to default value, please use the **no ipv6 ospf retransmit-interval** command.

### Syntax

```
ipv6 ospf retransmit-interval interval
no ipv6 ospf retransmit-interval
```

### Parameter

*interval*— The retransmit interval, ranging from 1 to 65535 seconds. The default value is 5 seconds.

### Command Mode

Interface Configuration Mode

### Example

Configure the retransmission interval of interface VLAN 2 as 10 seconds:

```
Switch(config)#interface vlan 2
Switch(config-if)#ipv6 ospf retransmit-interval 10
```

## 40.17 ipv6 ospf transmit-delay

### Description

The **ipv6 ospf transmit-delay** is used to configure the transmission delay of LSA on the specified interface. To restore to default value, please use the **no ipv6 ospf transmit-delay**.

## Syntax

**ipv6 ospf transmit-delay** *delay*

**no ipv6 ospf transmit-delay**

## Parameter

*delay*— The LSA transmission delay, ranging from 1 to 3600 seconds. The default value is 1 second.

## Command Mode

Interface Configuration Mode

## Example

Configure the LSA transmission delay of interface VLAN 2 as 2 seconds.

```
Switch(config)#interface vlan 2
Switch(config-if)#ipv6 ospf retransmit-delay 2
```

# 40.18 ipv6 ospf priority

## Description

The **ipv6 ospf priority** is used to configure the priority of the specified interface. To restore to the default value, please use the **no ipv6 ospf priority** command.

## Syntax

**ipv6 ospf priority** *pri*

**no ipv6 ospf priority**

## Parameter

*pri*— The priority of the interface, ranging from 0 to 255 and the default value is 1. Interface with the priority 0 cannot be elected as DR or BDR.

## Command Mode

Interface Configuration Mode

## Example

Configure the priority of the interface VLAN 2 as 1:

```
Switch(config)#interface vlan 2
```

```
Switch(config-if)#ipv6 ospf priority 1
```

## 40.19 ipv6 ospf hello-interval

### Description

The **ipv6 ospf hello-interval** is used to configure the hello intervals on the specified interface. To restore to the default value, please use the **no ipv6 ospf hello-interval** command.

### Syntax

```
ipv6 ospf hello-interval interval  
no ipv6 ospf hello-interval
```

### Parameter

*Interval* — The interval of the hello packets, ranging from 1 to 65535 seconds and the default value is 10 seconds.

### Command Mode

Interface Configuration Mode

### Example

Configure the interval of the hello packets sent on interface VLAN 2 as 20 seconds:

```
Switch(config)#interface vlan 2  
Switch(config-if)#ipv6 ospf hello-interval 20
```

## 40.20 ipv6 ospf dead-interval

### Description

The **ipv6 ospf dead-interval** command is used to set the number of seconds after the last device hello packet was seen before its neighbors declare the OSPFv3 router to be down. To restore to default value, please use the **no ipv6 ospf dead-interval** command.

### Syntax

```
ipv6 ospf dead-interval interval  
no ipv6 ospf dead-interval
```

## Parameter

*Interval* — The interval of the hello packets, ranging from 1 to 65535 seconds and the default value is 10 seconds.

## Command Mode

Interface Configuration Mode

## Example

Configure the neighbor's failure interval on interface VLAN 2 as 50 seconds:

```
Switch(config)#interface vlan 2
Switch(config-if)#ipv6 ospf dead-interval 50
```

# 40.21 ipv6 ospf network

## Description

The **ipv6 ospf network** command is used to configure the network type on the specified interface. To restore to default, please use the **no ipv6 ospf network** command.

## Syntax

```
ipv6 ospf network { broadcast | point-to-point }
no ipv6 ospf network
```

## Parameter

*broadcast* — The broadcast network type. It is the default value.

*point-to-point* — The point-to-point network type.

## Command Mode

Interface Configuration Mode

## Example

Configure the network type on interface VLAN 2 as broadcast:

```
Switch(config)#interface vlan 2
Switch(config-if)#ipv6 ospf network broadcast
```

## 40.22 ipv6 ospf mtu-ignore

### Description

The **ipv6 ospf mtu-ignore** command is used to ignore the MTU check in the DD exchanging process. This check is scheduled by default and the adjacency relationship will not establish if the MTUs are not matched. To restore to the default value, please use the **no ipv6 ospf mtu-ignore** command.

### Syntax

```
ipv6 ospf mtu-ignore  
no ipv6 ospf mtu-ignore
```

### Command Mode

Interface Configuration Mode

### Example

Configure interface VLAN 2 to ignore the MTU field check in the DD exchange process:

```
Switch(config)#interface vlan 2  
Switch(config-if)#ipv6 ospf mtu-ignore
```

## 40.23 ipv6 ospf passive

### Description

The **ipv6 ospf passive** command is used to prevent an interface from sending OSPFv3 packets. To restore to the default settings, please use **no ipv6 ospf passive** command. The interface is allowed to send OSPFv3 packets by default.

### Syntax

```
ipv6 ospf passive  
no ipv6 ospf passive
```

### Command Mode

Interface Configuration Mode

## Example

Prevent interface VLAN 2 from sending OSPFv3 packets:

```
Switch(config)#interface vlan 2
Switch(config-if)#ipv6 ospf passive
```

## 40.24 clear ipv6 ospf

### Description

The **clear ipv6 ospf** command is used to reset the OSPFv3 process, which will clear all the dynamic information. The **clear ipv6 ospf process** command will reset the OSPFv3 process. The **clear ipv6 ospf interface** command will reset the configuration of the interface in the OSPFv3 process.

### Syntax

```
clear ipv6 ospf { process | interface }
```

### Command Mode

Privileged EXEC Mode

### Example

Reset the OSPFv3 process:

```
Switch#clear ipv6 ospf process
Reset selected OSPFv3 processes? (Y/N):y
```

## 40.25 show ipv6 ospf

### Description

The **show ipv6 ospf** is used to display the global information of the OSPFv3 process.

### Syntax

```
show ipv6 ospf
```

### Command Mode

Privileged EXEC Mode and Any Configuration Mode

## Example

Display the global information of the OSPFv3 processes:

```
Switch#show ipv6 ospf
```

## 40.26 show ipv6 ospf database

### Description

The **show ip ospf database** command is used to display the LSDB.

### Syntax

```
show ipv6 ospf database
```

### Command Mode

Privileged EXEC Mode and Any Configuration Mode

### Example

Display the LSDB in OSPFv3 process:

```
Switch#show ipv6 ospf database
```

## 40.27 show ipv6 ospf interface

### Description

The **show ipv6 ospf interface** command is used to display the interface information.

### Syntax

```
show ipv6 ospf interface
```

### Command Mode

Privileged EXEC Mode and Any Configuration Mode

### Example

Display the information of the interfaces in the OSPFv3 process:

```
Switch#show ipv6 ospf interface
```



## 40.28 show ipv6 ospf neighbor

### Description

The **show ipv6 ospf neighbor** command is used to display information of the OSPFv3 neighbor.

### Syntax

```
show ipv6 ospf neighbor
```

### Command Mode

Privileged EXEC Mode and Any Configuration Mode

### Example

Display the neighbors' detailed information in OSPFv3 process:

```
Switch#show ipv6 ospf neighbor
```

## 40.29 show ipv6 ospf border-routers

### Description

The **show ipv6 ospf border-routers** is used to display the routing tables of the ABR/ASBR.

### Syntax

```
show ipv6 ospf border-routers
```

### Command Mode

Privileged EXEC Mode and Any Configuration Mode

### Example

Display the ABR/ASBR routing tables of the OSPFv3 proces:

```
Switch#show ipv6 ospf border-routers
```

## 40.30 show ipv6 ospf rib

### Description

The **show ipv6 ospf rib** command is used to display the OSPFv3 routing table.

### Syntax

```
show ipv6 ospf route
```

### Command Mode

Privileged EXEC Mode and Any Configuration Mode

### Example

Display the routing tables of OSPFv3:

```
Switch#show ipv6 ospf rib
```

# Chapter 41 IPv6 Address Configuration Commands

The IPv6 address configuration commands are provided in the Interface Configuration Mode, which includes the routed port, the port-channel interface and the VLAN interface. Enter the configuration mode of these Layer 3 interfaces and configure their IPv6 parameters.

## 41.1 ipv6 enable

### Description

This command is used to enable the IPv6 function on the specified Layer 3 interface. IPv6 function should be enabled before the IPv6 address configuration management. By default it is enabled on VLAN interface 1. IPv6 function can only be enabled on one Layer 3 interface at a time.

If the IPv6 function is disabled, the corresponding IPv6-based modules will be invalid, for example SSHv6, SSLv6, TFTPv6 and more. To disable the IPv6 function, please use **no ipv6 enable** command.

### Syntax

**ipv6 enable**  
**no ipv6 enable**

### Command Mode

Interface Configuration Mode

### Privilege Requirement

Only Admin, Operator and Power User level users have access to these commands.

### Example

Enable the IPv6 function on the VLAN interface 1:

```
Switch(config)# interface vlan 1
Switch(config-if)# ipv6 enable
```

## 41.2 ipv6 address autoconfig

### Description

This command is used to enable the automatic configuration of the ipv6 link-local address. The switch has only one ipv6 link-local address, which can be configured automatically or manually. The general ipv6 link-local address

has the prefix as fe80::/10. IPv6 routers cannot forward packets that have link-local source or destination addresses to other links. The auto-configured ipv6 link-local address is in EUI-64 format. To verify the uniqueness of the link-local address, the manually configured ipv6 link-local address will be deleted when the auto-configured ipv6 link-local address takes effect.

## Syntax

```
ipv6 address autoconfig
```

## Configuration Mode

Interface Configuration Mode

## Privilege Requirement

Only Admin, Operator and Power User level users have access to these commands.

## Example

Enable the automatic configuration of the ipv6 link-local address on VLAN interface 1:

```
Switch(config)# interface vlan 1
Switch(config-if)# ipv6 address autoconfig
```

# 41.3 ipv6 address link-local

## Description

The **ipv6 address link-local** command is used to configure the ipv6 link-local address manually on a specified interface. To delete the configured link-local address, please use **no ipv6 address link-local** command.

## Syntax

```
ipv6 address ipv6-addr link-local
no ipv6 address ipv6-addr link-local
```

## Parameter

*ipv6-addr* — The link-local address of the interface. It should be a standardized IPv6 address with the prefix fe80::/10, otherwise this command will be invalid.

## Configuration Mode

Interface Configuration Mode

## Privilege Requirement

Only Admin, Operator and Power User level users have access to these commands.

## Example

Configure the link-local address as fe80::1234 on the VLAN interface 1:

```
Switch(config)# interface vlan 1
Switch(config-if)# ipv6 address fe80::1234 link-local
```

# 41.4 ipv6 address dhcp

## Description

The **ipv6 address dhcp** command is used to enable the DHCPv6 Client function. When this function is enabled, the Layer 3 interface will try to obtain IP from DHCPv6 server. To delete the allocated IP from DHCPv6 server and disable the DHCPv6 Client function, please use **no ipv6 address dhcp** command.

## Syntax

**ipv6 address dhcp**

**no ipv6 address dhcp**

## Configuration Mode

Interface Configuration Mode

## Privilege Requirement

Only Admin, Operator and Power User level users have access to these commands.

## Example

Enable the DHCP Client function on VLAN interface 1:

```
Switch(config)# interface vlan 1
Switch(config-if)# ipv6 address dhcp
```

# 41.5 ipv6 address ra

## Description

This command is used to configure the interface's global IPv6 address according to the address prefix and other configuration parameters from its

received RA(Router Advertisement) message. To disable this function, please use **no ipv6 address ra** command.

## Syntax

**ipv6 address ra**

**no ipv6 address ra**

## Configuration Mode

Interface Configuration Mode

## Privilege Requirement

Only Admin, Operator and Power User level users have access to these commands.

## Example

Enable the automatic ipv6 address configuration function to obtain IPv6 address through the RA message on VLAN interface 1:

```
Switch(config)# interface vlan 1
Switch(config-if)# ipv6 address ra
```

# 41.6 ipv6 address eui-64

## Description

This command is used to manually configure a global IPv6 address with an extended unique identifier (EUI) in the low-order 64 bits on the interface. Specify only the network prefix. The last 64 bits are automatically computed from the switch MAC address. To remove a EUI-64 IPv6 address from the interface, please use the **no ipv6 address eui-64** command.

## Syntax

**ipv6 address *ipv6-addr* eui-64**

**no ipv6 address *ipv6-addr* eui-64**

## Parameter

*ipv6-addr* — Global IPv6 address with 64 bits network prefix, for example 3ffe::/64.

## Configuration Mode

Interface Configuration Mode

## Privilege Requirement

Only Admin, Operator and Power User level users have access to these commands.

## Example

Configure an EUI-64 global address on the interface with the network prefix 3ffe::/64:

```
Switch(config)# interface vlan 1
Switch(config-if)# ipv6 address 3ffe::/64 eui-64
```

# 41.7 ipv6 address

## Description

This command is used to manually configure a global IPv6 address on the interface. To remove a global IPv6 address from the interface, please use **no ipv6 address** command.

## Syntax

```
ipv6 address ipv6-addr
no ipv6 address ipv6-addr
```

## Parameter

*ipv6-addr* — Global IPv6 address with network prefix, for example 3ffe::1/64.

## Configuration Mode

Interface Configuration Mode

## Privilege Requirement

Only Admin, Operator and Power User level users have access to these commands.

## Example

Configure the global address 3001::1/64 on VLAN interface 1:

```
Switch(config)# interface vlan 1
Switch(config-if)# ipv6 address 3001::1/64
```

## 41.8 show ipv6 interface

### Description

This command is used to display the configured ipv6 information of the management interface, including ipv6 function status, link-local address and global address, ipv6 multicast groups etc.

### Syntax

```
show ipv6 interface
```

### Command Mode

Privileged EXEC Mode and Any Configuration Mode

### Privilege Requirement

None.

### Example

Display the ipv6 information of the management interface:

```
Switch(config)# show ipv6 interface
```



## Chapter 42 ARP Commands

Address Resolution Protocol (ARP) is used to resolve an IP address into an Ethernet MAC address. The switch maintains an ARP mapping table to record the IP-to-MAC mapping relations, which is used for forwarding packets. An ARP mapping table contains two types of ARP entries: dynamic and static. An ARP dynamic entry is automatically created and maintained by ARP. A static ARP entry is manually configured and maintained.

### 42.1 arp

#### Description

This **arp** command is used to add a static ARP entry. To delete the specified ARP entry, please use the **no arp** command.

#### Syntax

**arp** *ip mac type*

**no arp** *ip type*

#### Parameter

*ip*—— The IP address of the static ARP entry.

*mac*—— The MAC address of the static ARP entry.

*type*—— The ARP type. Configure it as "arpa".

#### Command Mode

Global Configuration Mode

#### Privilege Requirement

Only Admin, Operator and Power User level users have access to these commands.

#### Example

Create a static ARP entry with the IP as 192.168.0.1 and the MAC as 00:11:22:33:44:55:

```
Switch(config)# arp 192.168.0.1 00:11:22:33:44:55 arpa
```

## 42.2 clear arp-cache

### Description

This **clear arp-cache** command is used to clear all the dynamic ARP entries.

### Syntax

```
clear arp-cache
```

### Command Mode

Privileged EXEC Mode

### Privilege Requirement

Only Admin, Operator and Power User level users have access to these commands.

### Example

Clear all the dynamic ARP entries:

```
Switch(config)# clear arp-cache
```

## 42.3 arp dynamicrenew

### Description

This **arp dynamicrenew** command is used to automatically renew dynamic ARP entries. To disable the switch to automatically renew dynamic ARP entries, please use the **no arp dynamicrenew** command. By default, it is enabled.

### Syntax

```
arp dynamicrenew
```

```
no arp dynamicrenew
```

### Command Mode

Global Configuration Mode

### Privilege Requirement

Only Admin, Operator and Power User level users have access to these commands.

### Example

Enable the switch to automatically renew the dynamic ARP entries:

```
Switch(config)# arp dynamicrenew
```

## 42.4 arp timeout

### Description

This **arp timeout** command is used to configure the ARP aging time of the interface.

### Syntax

**arp timeout** *timeout*  
**no arp timeout**

### Parameter

*timeout* — Specify the aging time, ranging from 10 to 3000 seconds. The default value is 1200 seconds.

### Command Mode

Global Configuration Mode

### Privilege Requirement

Only Admin, Operator and Power User level users have access to these commands.

### Example

Configure the ARP aging time as 60 seconds:

```
Switch(config)# arp timeout 60
```

## 42.5 gratuitous-arp intf-status-up enable

### Description

This **gratuitous-arp intf-status-up enable** command is used to enable the Layer 3 interface to send a gratuitous ARP packet when the interface's status becomes up.

### Syntax

**gratuitous-arp intf-status-up enable**  
**no gratuitous-arp intf-status-up enable**

## Command Mode

Privileged EXEC Mode and Any Configuration Mode

## Privilege Requirement

None.

## Example

Enable the switch's Layer 3 interfaces to send gratuitous ARP packets when their status becomes up:

```
Switch(config)# gratuitous-arp intf-status-up enable
```

# 42.6 gratuitous-arp dup-ip-detected enable

## Description

This **gratuitous-arp dup-ip-detected enable** command is used to enable the Layer 3 interface to send a gratuitous ARP packet when receiving a gratuitous packets of which the IP address is the same as its own.

## Syntax

**gratuitous-arp dup-ip-detected enable**

**no gratuitous-arp dup-ip-detected enable**

## Command Mode

Privileged EXEC Mode and Any Configuration Mode

## Privilege Requirement

None.

## Example

Enable the switch's Layer 3 interface to send gratuitous ARP packets when receiving a gratuitous packets of which the IP address is the same as its own:

```
Switch(config)# gratuitous-arp dup-ip-detected enable
```

## 42.7 gratuitous-arp learning enable

### Description

This **gratuitous-arp learning enable** command is used to enable the Layer 3 interface to learn MAC addresses from the gratuitous ARP packets.

### Syntax

**gratuitous-arp learning enable**  
**no gratuitous-arp learning enable**

### Command Mode

Privileged EXEC Mode and Any Configuration Mode

### Privilege Requirement

None.

### Example

Enable the Layer 3 interface to learn MAC addresses from the gratuitous ARP packets:

```
Switch(config)# gratuitous-arp learning enable
```

## 42.8 gratuitous-arp send-interval

### Description

This **gratuitous-arp send-interval** command is used to configure the interval at which the interface periodically send the gratuitous ARP packets.

### Syntax

**gratuitous-arp send-interval** *interval*

### Parameter

*Interval* — Specify the interval at which the interface periodically send the gratuitous ARP packets. Value 0 means the interface will not send gratuitous ARP packets.

## Command Mode

Interface Configuration Mode (interface vlan / interface gigabitEthernet / interface range gigabitEthernet / interface port-channel / interface range port-channel)

## Privilege Requirement

None.

## Example

Specify the interface VLAN 1 to send gratuitous ARP packets every 1 second:

```
Switch(config)# interface vlan 1
Switch(config-if)# gratuitous-arp send-interval 1
```

# 42.9 ip proxy-arp

## Description

The **ip proxy-arp** command is used to enable Proxy ARP function on the specified VLAN interface or routed port. To disable Proxy ARP on this interface, please use **no ip proxy-arp** command.

## Syntax

```
ip proxy-arp
no ip proxy-arp
```

## Command Mode

Interface Configuration Mode (interface gigabitEthernet / interface range gigabitEthernet / interface port-channel / interface range port-channel)

## Privilege Requirement

None

## Example

Enable the Proxy ARP function on VLAN Interface 2:

```
Switch(config)# interface vlan 2
Switch(config-if)# ip proxy-arp
```

Enable the Proxy ARP function on routed port 1/0/2:

```
Switch(config)# interface gigabitEthernet 2
```

```
Switch(config-if)# no switchport
```

```
Switch(config-if)# ip proxy-arp
```

## 42.10 ip local-proxy-arp

### Description

The **ip local-proxy-arp** command is used to enable Local Proxy ARP function on the specified VLAN interface or routed port. To disable Local Proxy ARP function on this interface, please use **no ip local-proxy-arp** command.

### Syntax

```
ip local-proxy-arp
```

```
no ip local-proxy-arp
```

### Command Mode

Interface Configuration Mode (Interface vlan / interface gigabitEthernet / interface range gigabitEthernet / interface port-channel / interface range port-channel)

### Privilege Requirement

None

### Example

Enable the Proxy ARP function on VLAN Interface 2:

```
Switch(config)# interface vlan 2
```

```
Switch(config-if)# ip local-proxy-arp
```

Enable the Proxy ARP function on routed port 1/0/2:

```
Switch(config)# interface gigabitEthernet 2
```

```
Switch(config-if)# no switchport
```

```
Switch(config-if)# ip local-proxy-arp
```

## 42.11 show arp

### Description

This **show arp** command is used to display the active ARP entries. If no parameter is specified, all the active ARP entries will be displayed.

## Syntax

```
show arp [ ip ] [ mac ]
```

## Parameter

*ip*—— Specify the IP address of your desired ARP entry.

*mac*—— Specify the MAC address of your desired ARP entry.

## Command Mode

Privileged EXEC Mode and Any Configuration Mode

## Privilege Requirement

None.

## Example

Display the ARP entry with the IP as 192.168.0.2:

```
Switch(config)# show arp 192.168.0.2
```

# 42.12 show ip arp (interface)

## Description

This **show ip arp (interface)** command is used to display the active ARP entries associated with a specified Layer 3 interface.

## Syntax

```
show ip arp { gigabitEthernet port | port-channel port-channel-id | vlan id }
```

## Parameter

*port*—— Specify the number of the routed port.

*port-channel-id*—— Specify the ID of the port channel.

*id*—— Specify the VLAN interface ID.

## Command Mode

Privileged EXEC Mode and Any Configuration Mode

## Privilege Requirement

None.

## Example

Display the ARP entry associated with VLAN interface 2:



```
Switch(config)# show ip arp vlan 2
```

## 42.13 show ip arp summary

### Description

This **show ip arp summary** command is used to display the number of the active ARP entries.

### Syntax

```
show ip arp summary
```

### Command Mode

Privileged EXEC Mode and Any Configuration Mode

### Privilege Requirement

None.

### Example

Display the number of the ARP entries:

```
Switch(config)# show ip arp summary
```

## 42.14 show gratuitous-arp

### Description

This **show gratuitous arp** command is used to display the configuration of gratuitous ARP.

### Syntax

```
show gratuitous-arp
```

### Command Mode

Privileged EXEC Mode and Any Configuration Mode

### Privilege Requirement

None.

### Example

Display the configuration of gratuitous ARP:

```
Switch(config)# show gratuitous-arp
```

## 42.15 show ip proxy-arp

### Description

The **show ip proxy-arp** command is used to display the Proxy ARP status.

### Syntax

```
show ip proxy-arp
```

### Command Mode

Privileged EXEC Mode and Any Configuration Mode

### Privilege Requirement

None

### Example

Display the Proxy ARP status:

```
Switch(config)# show ip proxy-arp
```

## Chapter 43 VRRP Commands (Only for Certain Devices)

VRRP (Virtual Routing Redundancy Protocol) is a function on the switch that dynamically assigns responsibility for a virtual router to one of the VRRP routers on a LAN. The VRRP router that controls the IP address associated with a virtual router is called the Master and will forward packets sent to this IP address. This will allow any Virtual Router IP address on the LAN to be used as the default first hop router by end hosts.

### 43.1 ip vrrp vrid

#### Description

The **ip vrrp vrid** command is used to enable the VRRP-V2 protocol on the interface and specify the virtual router ID for it. To disable the protocol on the interface, please use the **no ip vrrp vrid** command.

#### Syntax

```
ip vrrp vrid vrid-index  
no ip vrrp vrid vrid-index
```

#### Parameter

*vrid-index* — Virtual router ID, ranging from 1 to 255.

#### Command Mode

Interface Configuration Mode

#### Privilege Requirement

Only Admin, Operator and Power User level users have access to these commands.

#### Example

Enable the VRRP-V2 protocol on VLAN 2 and specify the virtual router ID as 5:

```
Switch(config)#interface vlan 2  
Switch(config-if)#ip vrrp vrid 5
```

## 43.2 ipv6 vrrp vrid

### Description

The **ipv6 vrrp vrid** command is used to enable the VRRP-V3 protocol on the interface and specify the virtual router ID for it. To disable the protocol on the interface, please use the **no ipv6 vrrp vrid** command.

### Syntax

```
ipv6 vrrp vrid vrid-index  
no ipv6 vrrp vrid vrid-index
```

### Parameter

*vrid-index*—— Virtual router ID, ranging from 1 to 255.

### Command Mode

Interface Configuration Mode

### Privilege Requirement

Only Admin, Operator and Power User level users have access to these commands.

### Example

Enable the VRRP-V3 protocol on VLAN 2 and specify the virtual router ID as 5:

```
Switch(config)#interface vlan 2  
Switch(config-if)#ipv6 vrrp vrid 5
```

## 43.3 ip vrrp vrid authentication-mode

### Description

The **ip vrrp vrid authentication-mode** command is used to configure the authentication mode of the virtual router on the specified interface. To restore to the default authentication mode, please use the **no ip vrrp vrid authentication-mode** command.

### Syntax

```
ip vrrp vrid vrid-index authentication-mode {simple | md5} password  
no ip vrrp vrid vrid-index authentication-mode
```

## Parameter

*vrid-index*— Virtual router ID, ranging from 1 to 255.

**simple** | **md5**— Authentication mode, by default it is None and no authentication will be performed. "simple" refers to using a text password for authentication, and "md5" refers to using a text password to perform the authentication of MD5, which has a higher security than Simple mode.

*password*— Password, a string of 1 to 8 alphabets, numbers or symbols. Passwords are casesensitive, spaces allowed but leading spaces ignored, and cannot contain question marks. It is empty by default.

## Command Mode

Interface Configuration Mode

## Privilege Requirement

Only Admin, Operator and Power User level users have access to these commands.

## Example

Configure the md5 authentication mode on the VLAN 2, specify the password as 123 and the virtual router ID as 5:

```
Switch(config)#interface vlan 2
Switch(config-if)#ip vrrp vrid 5 authentication-mode md5 123
```

# 43.4 ip vrrp vrid description

## Description

The **ip vrrp vrid description** command is used to configure and modify the description for the virtual router. To delete the description, please use the **no ip vrrp vrid description** command.

## Syntax

```
ip vrrp vrid vrid-index description description
```

## Parameter

*vrid-index*— Virtual router ID, ranging from 1 to 255.

*description* — A string describing the virtual router, containing up to 256 characters, consisting only of numbers, English letters, and dashes.

## Command Mode

Interface Configuration Mode

## Privilege Requirement

Only Admin, Operator and Power User level users have access to these commands.

## Example

Configure the virtual router description as vr5 and the virtual router ID as 5 on the VLAN 2:

```
Switch(config)#interface vlan 2
Switch(config-if)#ip vrrp vrid 5 description vr5
```

# 43.5 ip vrrp vrid preempt-mode

## Description

The **ip vrrp vrid preempt-mode** command is used to configure the preemption mode and delay time of the specified virtual router on the interface. To set the specified virtual router on the interface to non-preempt mode, please use the **no ip vrrp vrid preempt-mode** command. By default, the virtual router is in preempt mode.

## Syntax

```
ip vrrp vrid vrid-index preempt-mode [ timer-delay delay-value ]
no ip vrrp vrid vrid-index preempt-mode
```

## Parameter

*vrid-index* — Virtual router ID, ranging from 1 to 255.

*delay-value* — When the current primary router is deemed unavailable, the backup router waits before switching to the primary router. The value ranges from 0 to 255 seconds, and the default is 0.

## Command Mode

Interface Configuration Mode

## Privilege Requirement

Only Admin, Operator and Power User level users have access to these commands.

## Example

Configure the virtual router preemption time to 12 seconds and the virtual router ID to 5 on VLAN 2:

```
Switch(config)#interface vlan 2
Switch(config-if)#ip vrrp vrid 5 preempt-mode timer-delay 12
```

## 43.6 ip vrrp vrid priority

### Description

The **ip vrrp vrid priority** command is used to configure the priority of the specified virtual router on the interface. To restore the default priority, please use the **no ip vrrp vrid priority** command.

### Syntax

```
ip vrrp vrid vrid-index priority priority
no ip vrrp vrid vrid-index priority
```

### Parameter

*vrid-index*—— Virtual router ID, ranging from 1 to 255.

*priority*—— Priority, value ranges from 1 to 254. The default priority is 100.

### Command Mode

Interface Configuration Mode

### Privilege Requirement

Only Admin, Operator and Power User level users have access to these commands.

## Example

Configure the virtual router priority to 1110 and the virtual router ID to 5 on VLAN 2:

```
Switch(config)#interface vlan 2
Switch(config-if)#ip vrrp vrid 5 priority 110
```

## 43.7 ip vrrp vrid timer-advertise

### Description

The **ip vrrp vrid timer-advertise** command is used to configure the frequency at which the specified virtual router sends advertisements on the interface. To restore the default advertisement interval, please use the **no ip vrrp vrid timer-advertise** command.

### Syntax

```
ip vrrp vrid vrid-indextimer-advertise adver-interval  
no ip vrrp vrid vrid-indextimer-advertise
```

### Parameter

*vrid-index* — Virtual router ID, ranging from 1 to 255.

*adver-interval* — Advertisement interval, for VRRP-V2, the value range is 1~255, the unit is seconds, the default is 1 second; for VRRP-V3, the value range is 100~4095, the unit is centiseconds, the default is 100 centiseconds.

### Command Mode

Interface Configuration Mode

### Privilege Requirement

Only Admin, Operator and Power User level users have access to these commands.

### Example

Configure the virtual router advertisement interval to 12 seconds and the virtual router ID to 5 on VLAN 2:

```
Switch(config)#interface vlan 2  
Switch(config-if)#ip vrrp vrid 5 timer-advertise 12
```

## 43.8 ip vrrp vrid track

### Description

The **ip vrrp vrid track** command is used to configure the specified virtual router on the interface to add a tracking interface. To delete the tracking interface, please use the **no ip vrrp vrid track** command.



## Syntax

**ip vrrp vrid** *vrid-index* **track interface** {{fastEthernet | gigabitEthernet | hundred-gigabitEthernet | ten-gigabitEthernet | twentyFive-gigabitEthernet | two-gigabitEthernet } *port* / **port-channel** *portchannel-id* / **vlan** *vlan-id*}  
[**reduce-priority** *priority*]

**no ip vrrp vrid** *vrid-index* **track interface** {{fastEthernet | gigabitEthernet | hundred-gigabitEthernet | ten-gigabitEthernet | twentyFive-gigabitEthernet | two-gigabitEthernet } *port* / **port-channel** *portchannel-id* / **vlan** *vlan-id*}

## Parameter

*vrid-index*—— Virtual router ID, ranging from 1 to 255.

fastEthernet | gigabitEthernet | hundred-gigabitEthernet | ten-gigabitEthernet | twentyFive-gigabitEthernet | two-gigabitEthernet —— Port type, which must be a layer 3 interface.

*port*—— Port number.

*portchannel-id*—— LAG group number.

*vlan-id* —— Decreasing priority of the tracked interface, ranging from 1 to 254, and the default is 10.

## Command Mode

Interface Configuration Mode

## Privilege Requirement

Only Admin, Operator and Power User level users have access to these commands.

## Example

Configure the virtual router to track VLAN 3 on the VLAN 2 with a decreasing priority of 20 and a virtual router ID of 5:

```
Switch(config)#interface vlan 2
Switch(config-if)#ip vrrp vrid 5 track interface vlan 3 reduce-priority 20
```

# 43.9 ip vrrp vrid version

## Description

The **ip vrrp vrid version** command is used to configure or switch the VRRP version of the specified virtual router on the interface. The default is VRRP-V2.

## Syntax

```
ip vrrp vrid vrid-index version vrrp-version
```

## Parameter

*vrid-index*—— Virtual router ID, ranging from 1 to 255.

*vrrp-version* —— VRRP protocol version, the value is 2 or 3. Due to the differences between VRRP-V2 and VRRP-V3, version switching is only allowed when authentication is not configured, ipv6 virtual address is not configured, and the default notification time is used.

## Command Mode

Interface Configuration Mode

## Privilege Requirement

Only Admin, Operator and Power User level users have access to these commands.

## Example

Switch the virtual router on the VALN 2 to VRRP-V3, and the virtual router ID to 5:

```
Switch(config)#interface vlan 2  
Switch(config-if)#ip vrrp vrid 5 version 3
```

# 43.10 ip vrrp vrid virtual-ip

## Description

The **ip vrrp vrid virtual-ip** command is used to add a primary virtual IPv4 address to a virtual router. Each virtual router has only one primary virtual IP that cannot be deleted. If the virtual router does not exist, a VRRP-V2 version of the virtual router will be automatically created.

## Syntax

```
ip vrrp vrid vrid-index virtual-ip virtual-ip
```

## Parameter

*vrid-index*—— Virtual router ID, ranging from 1 to 255.

*virtual-ip*—— The virtual IP address of the virtual router, which must be in the same network segment as the interface.

## Command Mode

Interface Configuration Mode

## Privilege Requirement

Only Admin, Operator and Power User level users have access to these commands.

## Example

Add virtual IP address 192.168.0.10 on VLAN 2 with the virtual router ID 5:

```
Switch(config)#interface vlan 2
Switch(config-if)#ip vrrp vrid 5 virtual-ip 192.168.0.10
```

# 43.11 ip vrrp vrid virtual-ip secondary

## Description

The **ip vrrp vrid virtual-ip secondary** command is used to add a secondary virtual IPv4 address to a virtual router. Each virtual router can be configured with up to 32 IP addresses. To delete the corresponding secondary virtual IP address, use the **no ip vrrp vrid virtual-ip secondary** command.

## Syntax

```
ip vrrp vrid vrid-index virtual-ip virtual-ip secondary
no ip vrrp vrid vrid-index virtual-ip virtual-ip secondary
```

## Parameter

*vrid-index* — Virtual router ID, ranging from 1 to 255.

*virtual-ip* — The virtual IP address of the virtual router, which must be in the same network segment as the interface.

## Command Mode

Interface Configuration Mode

## Privilege Requirement

Only Admin, Operator and Power User level users have access to these commands.

## Example

Add secondary virtual IP address 192.168.0.11 on VALN 2 with the virtual router ID 5:

```
Switch(config)#interface vlan 2
Switch(config-if)#ip vrrp vrid 5 virtual-ip 192.168.0.10 secondary
```

## 43.12 ipv6 vrrp vrid address link-local

### Description

The **ipv6 vrrp vrid address link-local** command is used to add a virtual ipv6 local link address to a virtual router. Each virtual router has only one virtual link-local address. If the virtual router does not exist, a VRRP-V3 version of the virtual router will be automatically created. To delete the virtual link-local address, use the **no ipv6 vrrp vrid address link-local** command.

### Syntax

```
ipv6 vrrp vrid vrid-index address virtual-linklocal/link-local
no ipv6 vrrp vrid vrid-index address virtual-linklocal/link-local
```

### Parameter

*vrid-index* — Virtual router ID, ranging from 1 to 255.

*virtual-linklocal* — The virtual link-local address of the virtual router. The address prefix should be the fe80::/10 standard ipv6 address.

### Command Mode

Interface Configuration Mode

### Privilege Requirement

Only Admin, Operator and Power User level users have access to these commands.

## Example

Add virtual ipv6 link-local address fe80::10 on VALN 2 with the virtual router ID 5:

```
Switch(config)#interface vlan 2
Switch(config-if)#ipv6 vrrp vrid 5 address fe80::10 link-local
```

## 43.13 ipv6 vrrp vrid address

### Description

The **ipv6 vrrp vrid address** command is used to add a virtual ipv6 address to a virtual router. Each virtual router can be configured with up to 32 ipv6 addresses. To delete the virtual address, use the **no ipv6 vrrp vrid address** command.

### Syntax

```
ipv6 vrrp vrid vrid-index address virtual-ipv6  
no ipv6 vrrp vrid vrid-index address virtual-ipv6
```

### Parameter

*vrid-index* — Virtual router ID, ranging from 1 to 255.

*virtual-ipv6* — The global ipv6 address of the virtual router, which must be in the same network segment as the interface ipv6 address.

### Command Mode

Interface Configuration Mode

### Privilege Requirement

Only Admin, Operator and Power User level users have access to these commands.

### Example

Add virtual ipv6 global address 3001::1 on VALN 2 with the virtual router ID 5:

```
Switch(config)#interface vlan 2  
Switch(config-if)#ipv6 vrrp vrid 5 address 3001::1
```

## 43.14 show ip vrrp

### Description

The **show ip vrrp** command is used to display basic configuration information of all virtual routers or a specified virtual router.

### Syntax

```
show ip vrrp [vrid vrid-index] [interface {{fastEthernet | gigabitEthernet |  
hundred-gigabitEthernet | ten-gigabitEthernet | twentyFive-gigabitEthernet |  
two-gigabitEthernet } port | port-channel portchannel-id | vlan vlan-id}]
```

## Parameter

*vrid-index*—— Virtual router ID, ranging from 1 to 255.

fastEthernet | gigabitEthernet | hundred-gigabitEthernet | ten-gigabitEthernet | twentyFive-gigabitEthernet | two-gigabitEthernet —— Port type, which must be a layer 3 interface.

*port*—— Port number.

*portchannel-id*—— LAG group number.

*vlan-id*—— VLAN value.

## Command Mode

Privileged EXEC Mode and Any Configuration Mode

## Privilege Requirement

None

## Example

Display the configuration information of the virtual router ID 5 on VLAN 2:

```
Switch(config)#show ip vrrp vrid 5 interface vlan 2
```

# 43.15 show ip vrrp statistics

## Description

The **show ip vrrp statistics** command is used to display statistics for all virtual routers or a specified virtual router.

## Syntax

```
show ip vrrp statistics [vrid vrid-index] [interface {{fastEthernet |  
gigabitEthernet | hundred-gigabitEthernet | ten-gigabitEthernet |  
twentyFive-gigabitEthernet | two-gigabitEthernet } port / port-channel  
portchannel-id / vlan vlan-id]
```

## Parameter

*vrid-index*—— Virtual router ID, ranging from 1 to 255.

fastEthernet | gigabitEthernet | hundred-gigabitEthernet | ten-gigabitEthernet | twentyFive-gigabitEthernet | two-gigabitEthernet —— Port type, which must be a layer 3 interface.

*port*—— Port number.

*portchannel-id*—— LAG group number.

*vlan-id*— VLAN value.

### Command Mode

Privileged EXEC Mode and Any Configuration Mode

### Privilege Requirement

None

### Example

Display statistics of the virtual router ID 5 on VLAN 2:

```
Switch(config)#show ip vrrp statistics vrid 5 interface vlan 2
```

## 43.16 clear ip vrrp statistics

### Description

The **clear ip vrrp statistics** command is used to clear the statistics of all virtual routers on the switch.

### Syntax

```
clear ip vrrp statistics
```

### Command Mode

Privileged EXEC Mode and Any Configuration Mode

### Privilege Requirement

None

### Example

Clear the statistics of all virtual routers on the switch:

```
Switch(config)#clear ip vrrp statistics
```

# Chapter 44 DHCP Server Commands

DHCP (Dynamic Host Configuration Protocol) is a network configuration protocol for hosts on TCP/IP networks, and it provides a framework for distributing configuration information to hosts. DHCP server assigns IP addresses from specified address pools on a switch or router to DHCP clients and manages them.

## 44.1 service dhcp server

### Description

The **service dhcp server** command is used to enable DHCP service globally. To disable DHCP server service, please use **no service dhcp server** command.

### Syntax

**service dhcp server**  
**no service dhcp server**

### Command Mode

Global Configuration Mode

### Privilege Requirement

Only Admin, Operator and Power User level users have access to these commands.

### Example

Enable DHCP server service globally:

```
Switch(config)# service dhcp server
```

## 44.2 ip dhcp server extend-option capwap-ac-ip

### Description

The **ip dhcp server extend-option capwap-ac-ip** command is used to specify the Option 138, which should be configured as the management IP address of an AC (Access Control) device. If the APs in the local network request this option, the server will inform the APs of the AC's IP address by



sending a packet containing this option. To delete the Option 138, please use **no ip dhcp server extend-option capwap-ac-ip** command.

### Syntax

```
ip dhcp server extend-option capwap-ac-ip ip-address  
no ip dhcp server extend-option capwap-ac-ip
```

### Parameter

*ip-address* — Specify the management IP address of an AC (Access Control) device.

### Command Mode

Global Configuration Mode

### Privilege Requirement

Only Admin, Operator and Power User level users have access to these commands.

### Example

Set the remote DHCP server's IP address as 192.168.3.1:

```
Switch(config)# ip dhcp server extend-option capwap-ac-ip 192.168.3.1
```

## 44.3 ip dhcp server extend-option vendor-class-id

### Description

The **ip dhcp server extend-option vendor-class-id** command is used to configure the class ID of the packets from DHCP server in a different network segment. To delete the class ID settings, please use **no ip dhcp server extend-option vendor-class-id** command.

### Syntax

```
ip dhcp server extend-option vendor-class-id class-id  
no ip dhcp server extend-option vendor-class-id
```

### Parameter

*class-id* — Specify the class ID of the DHCP packets from another network segment.

## Command Mode

Global Configuration Mode

## Privilege Requirement

Only Admin, Operator and Power User level users have access to these commands.

## Example

Set the class ID of the DHCP packets from another network segment as 34:

```
Switch(config)# ip dhcp server extend-option vendor-class-id 34
```

# 44.4 ip dhcp server excluded-address

## Description

The **ip dhcp server excluded-address** command is used to specify the reserved IP addresses which are forbidden to allocate, such as the gateway address, the network segment broadcast address, the server address etc. To delete the reserved IP addresses, please use **no ip dhcp server excluded-address** command.

## Syntax

```
ip dhcp server excluded-address start-ip-address end-ip-address  
no ip dhcp server excluded-address start-ip- address end-ip-address
```

## Parameter

*start-ip-address* — Specify the start IP address of the reserved IP pool.

*end-ip-address* — Specify the end IP address of the reserved IP pool. Only one IP address will be reserved if the end IP address and the start IP address are the same.

## Command Mode

Global Configuration Mode

## Privilege Requirement

Only Admin, Operator and Power User level users have access to these commands.

## Example

Set the reserved IP addresses from 192.168.1.1 to 192.168.1.9:

```
Switch(config)# ip dhcp server excluded-address 192.168.1.1 192.168.1.9
```

## 44.5 ip dhcp server pool

### Description

The **ip dhcp server pool** command is used to create the address pool of DHCP Server and enter the dhcp configuration mode. To delete the address pool, please use **no ip dhcp server pool** command.

### Syntax

```
ip dhcp server pool pool-name  
no ip dhcp server pool pool-name
```

### Parameter

*pool-name* — Specify the address pool name, ranging from 1 to 8 characters.

### Command Mode

Global Configuration Mode

### Privilege Requirement

Only Admin, Operator and Power User level users have access to these commands.

### Example

Create the address pool of name POOL1:

```
Switch(config)# ip dhcp server pool POOL1
```

## 44.6 ip dhcp server ping timeout

### Description

The **ip dhcp server ping timeout** command is used to specify the timeout of PING process. To resume the default value, please use **no ip dhcp server ping timeout** command.

### Syntax

```
ip dhcp server ping timeout value  
no ip dhcp server ping timeout
```

### Parameter

*value* — Specify the timeout value, ranging from 100 to 10000ms. The default value is 100ms.

## Command Mode

Global Configuration Mode

## Privilege Requirement

Only Admin, Operator and Power User level users have access to these commands.

## Example

Set the timeout of PING as 200ms:

```
Switch(config)# ip dhcp server ping timeout 200
```

# 44.7 ip dhcp server ping packets

## Description

The **ip dhcp server ping packets** command is used to specify the number of PING packets sent. If this value is set to 0, the PING process will be disabled. To resume the default value, please use **no ip dhcp server ping packets** command.

## Syntax

**ip dhcp server ping packets** *num*

**no ip dhcp server ping packets**

## Parameter

*num* — Specify the PING packets' number, ranging from 0 to 10. By default it's 1.

## Command Mode

Global Configuration Mode

## Privilege Requirement

Only Admin, Operator and Power User level users have access to these commands.

## Example

Specify the PING packets' number as 2:

```
Switch(config)# ip dhcp server ping packets 2
```

## 44.8 network

### Description

The **network** command is used to specify the address and subnet of the network pool.

### Syntax

**network** *network-address subnet-mask*

### Parameter

*network-address* — Specify the network address of the pool, with the format A.B.C.D. All the IP addresses in the same subnet are allocatable except the reserved addresses and specific addresses.

*subnet-mask* — Specify the subnet mask of the pool, with the format A.B.C.D.

### Command Mode

DHCP Configuration Mode

### Privilege Requirement

Only Admin, Operator and Power User level users have access to these commands.

### Example

Specify the address pool "product" as 192.168.1.0 255.255.255.0:

```
Switch(config)# ip dhcp server pool product
```

```
Switch(dhcp-config)# network 192.168.1.0 255.255.255.0
```

## 44.9 lease

### Description

The **lease** command is used to specify the lease time of the address pool.

### Syntax

**lease** *lease-time*

### Parameter

*lease-time* — Specify the lease time of the pool, ranging from 1 to 2880 minutes. The default value is 120 minutes.

## Command Mode

DHCP Configuration Mode

## Privilege Requirement

Only Admin, Operator and Power User level users have access to these commands.

## Example

Specify the lease time of address pool "product" as 10 minutes:

```
Switch(config)# ip dhcp server pool product
```

```
Switch(dhcp-config)# lease 10
```

# 44.10 address hardware-address

## Description

The **address hardware-address** command is used to reserve the static address bound with hardware address in the address pool. To delete the binding, please use **no address hardware-address**.

## Syntax

**address** *ip-address* **hardware-address** *hardware-address* **hardware-type**  
{ ethernet | ieee802 }

**no address** *ip-address*

## Parameter

*ip-address* — Specify the static binding IP address.

*hardware-address* — Specify the hardware address, in the format XX:XX:XX:XX:XX:XX.

ethernet | ieee802 — Specify the hardware type.

## Command Mode

DHCP Configuration Mode

## Privilege Requirement

Only Admin, Operator and Power User level users have access to these commands.

## Example

Reserve the IP address 192.168.0.10 in the address pool "product" for the device with the MAC address as 5e:4c:a6:31:24:01 and the hardware type as ethernet:

```
Switch(config)# ip dhcp server pool product
Switch(dhcp-config)# address 192.168.0.10 hardware-address
5e:4c:a6:31:24:01 hardware-type ethernet
```

## 44.11 address client-identifier

### Description

The **address client-identifier** command is used to specify the static address bound with client ID in the address pool. To delete the binding, please use **no address** command.

### Syntax

```
address ip-address client-identifier client-id[ascii]
no address ip-address
```

### Parameter

*ip-address*—— Specify the static binding IP address.  
*client-id*—— Specify the client ID, in the format of hex value.  
**ascii** —— The client ID is entered with ASCII characters.

### Command Mode

DHCP Configuration Mode

### Privilege Requirement

Only Admin, Operator and Power User level users have access to these commands.

### Example

Reserve the IP address 192.168.0.10 in the address pool “product” for the device with the client ID as abc in ASCII:

```
Switch(config)# ip dhcp pool product
Switch(dhcp-config)# address 192.168.0.10 client-identifier abc ascii
```

## 44.12 default-gateway

### Description

The **default-gateway** command is used to specify the default gateway of the address pool. To delete the configuration, please use **no default-gateway**.

## Syntax

**default-gateway** *gateway-list*  
**no default-gateway**

## Parameter

*gateway-list* — Specify the gateway list, with the format of A.B.C.D,E.F.G.H. At most 8 gateways can be configured, separated by comma.

## Command Mode

DHCP Configuration Mode

## Privilege Requirement

Only Admin, Operator and Power User level users have access to these commands.

## Example

Specify the address pool product's default gateways as 192.168.0.1 and 192.168.1.1:

```
Switch(config)# ip dhcp server pool product
Switch(dhcp-config)# default-gateway 192.168.0.1,192.168.1.1
```

# 44.13 dns-server

## Description

The **dns-server** command is used to specify the DNS server of the address pool. To delete this configuration, please use **no dns-server** command.

## Syntax

**dns-server** *dns-list*  
**no dns-server**

## Parameter

*dns-list* — Specify the DNS server list, with the format of A.B.C.D,E.F.G.H. At most 8 DNS servers can be configured, separated by comma.

## Command Mode

DHCP Configuration Mode

## Privilege Requirement

Only Admin, Operator and Power User level users have access to these commands.



## Example

Specify the address pool's DNS servers as 192.168.0.1 and 192.168.1.1:

```
Switch(config)# ip dhcp server pool product
Switch(dhcp-config)# dns-server 192.168.0.1,192.168.1.1
```

## 44.14 netbios-name-server

### Description

The **netbios-name-server** command is used to specify the Netbios server's IP address. To delete the Netbios servers, please use **no netbios-name-server** command.

### Syntax

```
netbios-name-server NBNS-list
no netbios-name-server
```

### Parameter

*NBNS-list* — Specify the Netbios server list, with the format of A.B.C.D,E.F.G.H. At most 8 Netbios servers can be configured, separated by comma.

### Command Mode

DHCP Configuration Mode

### Privilege Requirement

Only Admin, Operator and Power User level users have access to these commands.

## Example

Specify the address pool's Netbios servers as 192.168.0.1 and 192.168.1.1:

```
Switch(config)# ip dhcp server pool product
Switch(dhcp-config)# netbios-name-server 192.168.0.1,192.168.1.1
```

## 44.15 netbios-node-type

### Description

The **netbios-node-type** command is used to specify the Netbios server's node type. To delete the node type settings, please use **no netbios-node-type** command.

## Syntax

**netbios-node-type** *type*  
**no netbios-node-type**

## Parameter

*type*—— Specify the node type as b-node, h-node, m-node or p-node.

## Command Mode

DHCP Configuration Mode

## Privilege Requirement

Only Admin, Operator and Power User level users have access to these commands.

## Example

Specify the address pool's Netbios server type as b-node:

```
Switch(config)# ip dhcp server pool product
Switch(dhcp-config)# netbios-node-type b-node
```

# 44.16 next-server

## Description

The **next-server** command is used to specify the next DHCP server's address during the DHCP boot process. To delete the next server, please use **no next-server** command.

## Syntax

**next-server** *ip-address*  
**next-server**

## Parameter

*ip-address*—— Specify the IP address of the next server.

## Command Mode

DHCP Configuration Mode

## Privilege Requirement

Only Admin, Operator and Power User level users have access to these commands.

## Example

Specify the next server's IP address as 192.168.2.1:

```
Switch(config)# ip dhcp server pool product
Switch(dhcp-config)# next-server 192.168.2.1
```

## 44.17 domain-name

### Description

The **domain-name** command is used to specify the domain name for the DHCP client. To delete the domain name, please use **no domain-name** command.

### Syntax

```
domain-name domainname
no domain-name
```

### Parameter

*domainname* — Specify the domain name for the DHCP client.

### Command Mode

DHCP Configuration Mode

### Privilege Requirement

Only Admin, Operator and Power User level users have access to these commands.

### Example

Specify the DHCP client's domain name as edu:

```
Switch(config)# ip dhcp server pool product
Switch(dhcp-config)# domain-name edu
```

## 44.18 bootfile

### Description

The **bootfile** command is used to specify the name of the DHCP client's bootfile. To delete the bootfile, please use **no bootfile** command.

### Syntax

```
bootfile file-name
no bootfile
```

## Parameter

*file-name*—— Specify the name of the DHCP client's bootfile.

## Command Mode

DHCP Configuration Mode

## Privilege Requirement

Only Admin, Operator and Power User level users have access to these commands.

## Example

Specify the name of the DHCP client's bootfile as boot1:

```
Switch(config)# ip dhcp server pool product
Switch(dhcp-config)# bootfile boot1
```

# 44.19 option

## Description

The **option** command is used to specify an option for the DHCP client. To delete the option, please use **no option** command.

## Syntax

```
option code [HEX | IP | STRING] value
no option
```

## Parameter

*value*—— Option value, ranging from 1 to 254.

## Command Mode

DHCP Configuration Mode

## Privilege Requirement

Only Admin, Operator and Power User level users have access to these commands.

## Example

Specify the option for the DHCP client as IP 1:

```
Switch(config)# ip dhcp server pool product
Switch(dhcp-config)# option code 1
```

## 44.20 show ip dhcp server status

### Description

The **show ip dhcp server status** command is used to display the status of the DHCP service.

### Syntax

```
show ip dhcp server status
```

### Command Mode

Privileged EXEC Mode and Any Configuration Mode

### Privilege Requirement

None.

### Example

Display the status of DHCP service:

```
Switch(config)# show ip dhcp server status
```

## 44.21 show ip dhcp server statistics

### Description

The **show ip dhcp server statistics** command is used to display the DHCP packets received and sent by DHCP server.

### Syntax

```
show ip dhcp server statistics
```

### Command Mode

Privileged EXEC Mode and Any Configuration Mode

### Privilege Requirement

None.

### Example

Display the statistics of DHCP packets received and sent by the DHCP server:

```
Switch(config)# show ip dhcp server statistics
```

## 44.22 show ip dhcp server extend-option

### Description

The **show ip dhcp server extend-option** command is used to display the configuration of the remote DHCP servers.

### Syntax

```
show ip dhcp server extend-option
```

### Command Mode

Privileged EXEC Mode and Any Configuration Mode

### Privilege Requirement

None.

### Example

Display the configurations of the remote DHCP servers:

```
Switch(config)# show ip dhcp server extend-option
```

## 44.23 show ip dhcp server pool

### Description

The **show ip dhcp server pool** command is used to display the configuration of the address pool.

### Syntax

```
show ip dhcp server pool
```

### Command Mode

Privileged EXEC Mode and Any Configuration Mode

### Privilege Requirement

None.

### Example

Display the configured address pool:

```
Switch(config)# show ip dhcp server pool
```

## 44.24 show ip dhcp server excluded-address

### Description

The **show ip dhcp server excluded-address** command is used to display the configuration of reserved addresses.

### Syntax

```
show ip dhcp server excluded-address
```

### Command Mode

Privileged EXEC Mode and Any Configuration Mode

### Privilege Requirement

None.

### Example

Display the configured reserved addresses:

```
Switch(config)# show ip dhcp server excluded-address
```

## 44.25 show ip dhcp server manual-binding

### Description

The **show ip dhcp server manual-binding** command is used to display the configuration of static binding address.

### Syntax

```
show ip dhcp server manual-binding
```

### Command Mode

Privileged EXEC Mode and Any Configuration Mode

### Privilege Requirement

None.

### Example

Display the configured static binding address:

```
Switch(config)# show ip dhcp server manual-binding
```

## 44.26 show ip dhcp server binding

### Description

The **show ip dhcp server binding** command is used to display the binding entries.

### Syntax

```
show ip dhcp server binding [ ip ip-address ]
```

### Parameter

*ip-address* — Specify the binding IP address.

### Command Mode

Privileged EXEC Mode and Any Configuration Mode

### Privilege Requirement

None.

### Example

Display the address binding entries:

```
Switch(config)# show ip dhcp server binding
```

## 44.27 clear ip dhcp server statistics

### Description

The **clear ip dhcp server statistics** command is used to clear the statistics information of DHCP packets.

### Syntax

```
clear ip dhcp server statistics
```

### Command Mode

Privileged EXEC Mode and Any Configuration Mode

### Privilege Requirement

Only Admin, Operator and Power User level users have access to these commands.



## Example

Clear the packet statistics:

```
Switch(config)# clear ip dhcp server statistics
```

# 44.28 clear ip dhcp server binding

## Description

The **clear ip dhcp server binding** command is used to clear the binding information.

## Syntax

```
clear ip dhcp server binding [ ip-address ]
```

## Parameter

*ip-address* — Specify the binding IP address.

## Command Mode

Privileged EXEC Mode and Any Configuration Mode

## Privilege Requirement

Only Admin, Operator and Power User level users have access to these commands.

## Example

Clear all the binding addresses:

```
Switch(config)# clear ip dhcp server binding
```

# Chapter 45 DHCP Relay Commands

A DHCP Relay agent is a Layer 3 device that forwards DHCP packets between clients and servers. DHCP Relay forward requests and replies between clients and servers when they are not on the same physical subnet.

## 45.1 service dhcp relay

### Description

The **service dhcp relay** command is used to enable DHCP Relay function globally. To disable DHCP Relay function, please use **no service dhcp relay** command.

### Syntax

**service dhcp relay**  
**no service dhcp relay**

### Command Mode

Global Configuration Mode

### Privilege Requirement

Only Admin, Operator and Power User level users have access to these commands.

### Example

Enable DHCP Relay function globally:

```
Switch(config)# service dhcp relay
```

## 45.2 ip dhcp relay hops

### Description

The **ip dhcp relay hops** command is used to specify the maximum hops (DHCP Relay agent) that the DHCP packets can be relayed. To restore the default value, please use **no service dhcp relay hops** command.

### Syntax

**ip dhcp relay hops** *hops*  
**no ip dhcp relay hops**

## Parameter

*hops* —Specify the maximum hops (DHCP Relay agent) that the DHCP packets can be relayed. If a packet's hop count is more than the value you set here, the packet will be dropped. The valid value ranges from the 1 to 16, and the default value is 4.

## Command Mode

Global Configuration Mode

## Privilege Requirement

Only Admin, Operator and Power User level users have access to these commands.

## Example

Configure the maximum number of relay hops as 6:

```
Switch(config)# ip dhcp relay hops 6
```

# 45.3 ip dhcp relay time

## Description

The **ip dhcp relay time** command is used to specify the DHCP relay time threshold. DHCP relay time is the time elapsed since client began address acquisition or renewal process. When the elapsed time of the DHCP packet is greater than the value set here, the DHCP packet will be dropped by the switch. To restore the default value, please use **no service dhcp relay time** command.

## Syntax

**ip dhcp relay time** *time*

**no ip dhcp relay time**

## Parameter

*time* —Specify the DHCP relay time threshold. The valid value ranges from 1 to 65535. The default value is 0, which means the switch will not examine this field of the DHCP packets.

## Command Mode

Global Configuration Mode

## Privilege Requirement

Only Admin, Operator and Power User level users have access to these commands.

## Example

Configure the DHCP Relay time as 30 seconds:

```
Switch(config)# ip dhcp relay time 30
```

## 45.4 ip helper-address

### Description

The **ip helper-address** command is used to add DHCP Server address to the Layer 3 interface. To delete the server address, please use **no ip helper-address** command.

### Syntax

```
ip helper-address ip-address  
no ip helper-address [ ip-address ]
```

### Parameter

*ip-address* — DHCP Server address.

### Command Mode

Interface Configuration Mode

### Privilege Requirement

Only Admin, Operator and Power User level users have access to these commands.

### Example

Add DHCP Server address 192.168.2.1 to interface VLAN 1:

```
Switch(config)# interface vlan 1  
Switch(config-if)# ip helper-address 192.168.2.1
```

## 45.5 ip dhcp relay information option

### Description

The **ip dhcp relay information option** command is used to enable option 82 support in DHCP Relay. To disable this function, please use **no ip dhcp relay information option** command.

## Syntax

**ip dhcp relay information option**  
**no ip dhcp relay information option**

## Command Mode

Interface Configuration Mode (interface gigabitEthernet/interface range gigabitEthernet / interface port-channel / interface range port-channel)

## Privilege Requirement

Only Admin, Operator and Power User level users have access to these commands.

## Example

Enable option 82 support in DHCP Relay for port 2:

```
Switch(config)#interface gigabitEthernet 1/0/2
Switch(config-if)#ip dhcp relay information option
```

# 45.6 ip dhcp relay information strategy

## Description

The **ip dhcp relay information strategy** command is used to specify the operation for the Option 82 field of the DHCP request packets from the Host. To restore to the default option, please use **no ip dhcp relay information strategy** command.

## Syntax

**ip dhcp relay information strategy** { drop | keep | replace }  
**no ip dhcp relay information strategy**

## Parameter

drop | keep | replace —The operations for Option 82 field of the DHCP request packets from the Host. The default operation is keep.

drop: Discard the packet with the Option 82 field.

keep: Keep the Option 82 field in the packet.

replace: Replace the option 82 field with the system option defined by the switch.

## Command Mode

Interface Configuration Mode (interface gigabitEthernet / interface range gigabitEthernet / interface port-channel / interface range port-channel)

## Privilege Requirement

Only Admin, Operator and Power User level users have access to these commands.

## Example

Specify the option 82 strategy as replace to replace the Option 82 field with the local parameter on receiving the DHCP request packet for port 2:

```
Switch(config)#interface gigabitEthernet 1/0/2
Switch(config-if)# ip dhcp relay information strategy replace
```

# 45.7 ip dhcp relay information format

## Description

The **ip dhcp relay information format** command is used to select the format of option 82 sub-option value field. To restore to the default option, please use **no ip dhcp relay information format** command.

## Syntax

```
ip dhcp relay information format { normal | private }
no ip dhcp relay information format
```

## Parameter

normal | private — The format type of option 82 sub-option value field.

normal: Indicates that the format of sub-option value field is TLV (type-length-value).

private: Indicates that the format of sub-option value field is the value you configure for the related sub-option.

## Command Mode

Interface Configuration Mode (interface gigabitEthernet / interface range gigabitEthernet / interface port-channel / interface range port-channel)

## Privilege Requirement

Only Admin, Operator and Power User level users have access to these commands.

## Example

Select the format of option 82 sub-option value field as TLV (type-length-value) for port 2:

```
Switch(config)#interface gigabitEthernet 1/0/2
Switch(config-if)#ip dhcp relay information format normal
```

# 45.8 ip dhcp relay information circuit-id

## Description

The **ip dhcp relay information circuit-id** command is used to specify the custom circuit ID when option 82 customization is enabled. To clear the circuit ID, please use **no ip dhcp relay information circuit-id** command.

## Syntax

```
ip dhcp relay information circuit-id circuitID
no ip dhcp relay information circuit-id
```

## Parameter

*circuitID*—— Specify the circuit ID, ranging from 1 to 64 characters.

## Command Mode

Interface Configuration Mode (interface gigabitEthernet / interface range gigabitEthernet / interface port-channel / interface range port-channel)

## Privilege Requirement

Only Admin, Operator and Power User level users have access to these commands.

## Example

Specify the circuit ID as "TP-Link" for port 2:

```
Switch(config)#interface gigabitEthernet 1/0/2
Switch(config-if)# ip dhcp relay information circuit-id TP-Link
```

## 45.9 ip dhcp relay information remote-id

### Description

The **ip dhcp relay information remote-id** command is used to specify the custom remote ID when option 82 customization is enabled. To clear the remote ID, please use **no ip dhcp relay information remote-id** command.

### Syntax

```
ip dhcp relay information remote-id remoteID  
no ip dhcp relay information remote-id
```

### Parameter

*remoteID*—— Specify the remote ID, ranging from 1 to 64 characters.

### Command Mode

Interface Configuration Mode (interface gigabitEthernet / interface range gigabitEthernet / interface port-channel / interface range port-channel)

### Privilege Requirement

Only Admin, Operator and Power User level users have access to these commands.

### Example

Specify the remote ID as "TP-Link" for port 2:

```
Switch(config)#interface gigabitEthernet 1/0/2  
Switch(config-if)# ip dhcp relay information remote-id TP-Link
```

## 45.10 ip dhcp relay default-interface

### Description

The **ip dhcp relay default-interface** command is used to configure default relay agent interface. When the switch works at DHCP VLAN Relay mode and there is no IP interface in the VLAN, the switch uses the IP of default relay agent interface to fill in the relay agent IP address field of DHCP packets. To delete the default relay agent interface use **no ip dhcp relay default-interface**.



## Syntax

**ip dhcp relay default-interface**  
**no ip dhcp relay default-interface**

## Command mode

Interface Configuration Mode

## Privilege Requirement

Only Admin, Operator and Power User level users have access to these commands.

## Example

Configure interface VLAN 1 as the default relay agent interface:

```
Switch(config)# interface vlan 1
Switch(config-if)# ip dhcp relay default-interface
```

# 45.11 ip dhcp relay vlan

## Description

The **ip dhcp relay vlan** command is used to add DHCP server address to specified VLAN. If there is an IP interface in the VLAN and it has configured a DHCP server address at the interface level, then the configuration at the interface level has higher priority. In this case, the DHCP server configured on the VLAN will not be used to forward the DHCP packets. To delete the DHCP server address use **no ip dhcp relay vlan**.

## Syntax

**ip dhcp relay vlan** *vid***helper-address** *ip-address*  
**no ip dhcp relay vlan** *vid***helper-address** [*ip-address*]

## Parameter

*vid*—— VLAN ID.

*ip-address*—— DHCP Server address.

## Command mode

Global Configuration Mode

## Privilege Requirement

Only Admin, Operator and Power User level users have access to these commands.

## Example

Add DHCP server address 192.168.2.1 to VLAN 1:

```
Switch(config)# ip dhcp relay vlan 1 helper-address 192.168.2.1
```

# 45.12 show ip dhcp relay

## Description

The **show ip dhcp relay** command is used to display the global status and Option 82 configuration of DHCP Relay.

## Syntax

```
show ip dhcp relay
```

## Command Mode

Privileged EXEC Mode and Any Configuration Mode

## Privilege Requirement

None.

## Example

Display the configuration of DHCP Relay:

```
Switch(config)# show ip dhcp relay
```

# Chapter 46 DHCPV6 Relay Commands

A DHCPV6 Relay agent is a Layer 3 device that forwards DHCPV6 packets between clients and servers. DHCPV6 Relay forward requests and replies between clients and servers when they are not on the same physical subnet.

## 46.1 ipv6 dhcp relay

### Description

The **ipv6 dhcp relay** command is used to enable DHCPV6 Relay function globally. To disable DHCPV6 Relay function, please use **no ipv6 dhcp relay** command.

### Syntax

```
ipv6 dhcp relay  
no ipv6 dhcp relay
```

### Command Mode

Global Configuration Mode

### Privilege Requirement

Only Admin, Operator and Power User level users have access to these commands.

### Example

Enable DHCPV6 Relay function globally:

```
Switch(config)# ipv6 dhcp relay
```

## 46.2 ipv6 dhcp relay vlan 1 helper-address

### Description

The **ipv6 dhcp relay vlan 1 helper-address** command is used to add DHCPV6 Server address to the Layer 3 interface. To delete the server address, please use **no ipv6 dhcp relay vlan 1 helper-address** command.

### Syntax

```
ipv6 dhcp relay vlan 1 helper-address ip-address  
no ipv6 dhcp relay vlan 1 helper-address [ip-address]
```

## Parameter

*ipv6-address*—— DHCPV6 Server address.

## Command Mode

Interface Configuration Mode

## Privilege Requirement

Only Admin, Operator and Power User level users have access to these commands.

## Example

Add DHCPV6 Server address 2019:2020::21D:FFF:FE61:2005 to interface VLAN 1:

```
Switch(config)# ipv6 dhcp relay vlan 1 helper-address
2019:2020::21D:FFF:FE61:2005
```

# 46.3 ipv6 dhcp relay information option 18

## Description

The **ipv6 dhcp relay information option18** command is used to enable option 18 support of a specified port in DHCPV6 Relay. To disable this function, please use **no ipv6 dhcp relay information option18** command.

## Syntax

```
ipv6 dhcp relay information option18
no ipv6 dhcp relay information option18
```

## Command Mode

Interface Configuration Mode (interface gigabitEthernet / interface range gigabitEthernet / interface port-channel / interface range port-channel)

## Privilege Requirement

Only Admin, Operator and Power User level users have access to these commands.

## Example

Enable option18 support in DHCPV6 Relay for port 2:

```
Switch(config)#interface gigabitEthernet 1/0/2
```

## 46.1 Switch(config-if)# ipv6 dhcp relay information option37

### Description

The **ipv6 dhcp relay information option37** command is used to enable option37 support of a specified port in DHCPV6 Relay. To disable this function, please use **no ipv6 dhcp relay information option37** command.

### Syntax

```
ipv6 dhcp relay information option37
no ipv6 dhcp relay information option37
```

### Command Mode

Interface Configuration Mode (interface gigabitEthernet / interface range gigabitEthernet / interface port-channel / interface range port-channel)

### Privilege Requirement

Only Admin, Operator and Power User level users have access to these commands.

### Example

Enable option37 support in DHCPV6 Relay for port 2:

```
Switch(config)#interface gigabitEthernet 1/0/2
Switch(config-if)# ipv6 dhcp relay information option37
```

## 46.5 ipv6 dhcp relay information remote-id

### Description

The **ipv6 dhcp relay information remote-id** command is used to specify the custom remote ID when option37 customization is enabled. To clear the remote ID, please use **no ipv6 dhcp relay information remote-id** command.

### Syntax

```
ipv6 dhcp relay information remote-id remoteID
no ipv6 dhcp relay information remote-id
```

## Parameter

*remoteID*— Specify the remote ID, ranging from 1 to 64 characters.

## Command Mode

Interface Configuration Mode (interface gigabitEthernet / interface range gigabitEthernet / interface port-channel / interface range port-channel)

## Privilege Requirement

Only Admin, Operator and Power User level users have access to these commands.

## Example

Specify the remote ID as "tplink192.168.0.3" for port 2:

```
Switch(config)#interface gigabitEthernet 1/0/2
```

```
Switch(config-if)# ipv6 dhcp relay information remote-id tplink 192.168.0.
```

# 46.6 show ipv6 dhcp relay

## Description

The **show ipv6 dhcp relay** command is used to display the global status and Option 18\37 configuration of DHCPV6 Relay.

## Syntax

```
show ipv6 dhcp relay
```

## Command Mode

Privileged EXEC Mode and Any Configuration Mode

## Privilege Requirement

None.

## Example

Display the configuration of DHCPV6 Relay:

```
Switch(config)# show ipv6 dhcp relay
```

## 46.7 show ipv6 dhcp relay counters

### Description

The **show ipv6 dhcp relay counters** command is used to display the packet counter of the DHCPV6 relay.

### Syntax

```
show ipv6 dhcp relay counters
```

### Command Mode

Privileged EXEC Mode and Any Configuration Mode

### Privilege Requirement

None.

### Example

Display the packet counter of the DHCPV6 relay:

```
Switch# show ipv6 dhcp relay counters
```

# Chapter 47 DHCP L2 Relay Commands

## 47.1 ip dhcp l2relay

### Description

The **ip dhcp l2relay** command is used to enable DHCP L2 Relay function globally. To disable DHCP L2 Relay function, please use **no ip dhcp l2relay** command.

### Syntax

```
ip dhcp l2relay
no ip dhcp l2relay
```

### Command Mode

Global Configuration Mode

### Privilege Requirement

Only Admin, Operator and Power User level users have access to these commands.

### Example

Enable DHCP L2 Relay function globally:

```
Switch(config)# ip dhcp l2relay
```

## 47.2 ip dhcp l2relay vlan

### Description

The **ip dhcp l2relay vlan** command is used to enable DHCP L2 relay in the specified VLAN. To disable DHCP L2 Relay in the specific vlan, please use **no ip dhcp l2relay vlan** command.

### Syntax

```
ip dhcp l2relay vlan vlan-range
no ip dhcp l2relay vlan vlan-range
```

### Parameter

*vlan-range* — Specify the vlan to be enabled with DHCP L2 relay.

### Command Mode

Global Configuration Mode



## Privilege Requirement

Only Admin, Operator and Power User level users have access to these commands.

## Example

Enable DHCP L2 Relay for VLAN 2:

```
Switch(config)# ip dhcp l2relay vlan 2
```

# 47.3 ip dhcp l2relay information option

## Description

The **ip dhcp l2relay information option** command is used to enable option82 support in DHCP Relay. To disable this function, please use **no ip dhcp l2relay information option** command.

## Syntax

```
ip dhcp l2relay information option  
no ip dhcp l2relay information option
```

## Command Mode

Interface Configuration Mode (interface gigabitEthernet / interface range gigabitEthernet / interface port-channel / interface range port-channel)

## Privilege Requirement

Only Admin, Operator and Power User level users have access to these commands.

## Example

Enable option82 support in DHCP Relay for port 2:

```
Switch(config)#interface gigabitEthernet 1/0/2
```

```
Switch(config-if)# ip dhcp l2relay information option
```

## 47.4 ip dhcp l2relay information strategy

### Description

The **ip dhcp l2relay information strategy** command is used to specify the operation for the Option 82 field of the DHCP request packets from the Host. To restore to the default option, please use **no ip dhcp l2relay information strategy** command.

### Syntax

```
ip dhcp l2relay information strategy { drop | keep | replace }  
no ip dhcp l2relay information strategy
```

### Parameter

drop | keep | replace — The operations for Option 82 field of the DHCP request packets from the Host. The default operation is keep.

drop: Discard the packet with the Option 82 field.

keep: Keep the Option 82 field in the packet.

replace: Replace the option 82 field with the system option defined by the switch.

### Command Mode

Interface Configuration Mode (interface gigabitEthernet / interface range gigabitEthernet / interface port-channel / interface range port-channel)

### Privilege Requirement

Only Admin, Operator and Power User level users have access to these commands.

### Example

Specify the option 82 strategy as replace to replace the Option 82 field with the local parameter on receiving the DHCP request packet for port 2:

```
Switch(config)#interface gigabitEthernet 1/0/2  
Switch(config-if)# ip dhcp l2relay information strategy replace
```

## 47.5 ip dhcp l2relay information format

### Description

The **ip dhcp l2relay information format** command is used to select the format of option 82 sub-option value field. To restore to the default option, please use **no ip dhcp l2relay information format** command.

### Syntax

```
ip dhcp l2relay information format { normal | private }  
no ip dhcp l2relay information format
```

### Parameter

normal | private — The format type of option 82 sub-option value field.

normal: Indicates that the format of sub-option value field is TLV (type-length-value).

private: Indicates that the format of sub-option value field is the value you configure for the related sub-option.

### Command Mode

Interface Configuration Mode (interface gigabitEthernet / interface range gigabitEthernet / interface port-channel / interface range port-channel)

### Privilege Requirement

Only Admin, Operator and Power User level users have access to these commands.

### Example

Select the format of option 82 sub-option value field as TLV (type-length-value) for port 2:

```
Switch(config)#interface gigabitEthernet 1/0/2  
Switch(config-if)#ip dhcp l2relay information format normal
```

## 47.6 ip dhcp I2relay information circuit-id

### Description

The **ip dhcp I2relay information circuit-id** command is used to specify the custom circuit ID when option 82 customization is enabled. To clear the circuit ID, please use **no ip dhcp I2relay information circuit-id** command.

### Syntax

```
ip dhcp I2relay information circuit-id circuitID  
no ip dhcp I2relay information circuit-id
```

### Parameter

*circuitID*—— Specify the circuit ID, ranging from 1 to 64 characters.

### Command Mode

Interface Configuration Mode (interface gigabitEthernet / interface range gigabitEthernet / interface port-channel / interface range port-channel)

### Privilege Requirement

Only Admin, Operator and Power User level users have access to these commands.

### Example

Specify the circuit ID as "TP-Link" for port 2:

```
Switch(config)#interface gigabitEthernet 1/0/2  
Switch(config-if)# ip dhcp I2relay information circuit-id TP-Link
```

## 47.7 ip dhcp I2relay information remote-id

### Description

The **ip dhcp I2relay information remote-id** command is used to specify the custom remote ID when option 82 customization is enabled. To clear the remote ID, please use **no ip dhcp I2relay information remote-id** command.

### Syntax

```
ip dhcp I2relay information remote-id remoteID  
no ip dhcp I2relay information remote-id
```

## Parameter

*remoteID*— Specify the remote ID, ranging from 1 to 64 characters.

## Command Mode

Interface Configuration Mode (interface gigabitEthernet / interface range gigabitEthernet / interface port-channel / interface range port-channel)

## Privilege Requirement

Only Admin, Operator and Power User level users have access to these commands.

## Example

Specify the remote ID as "TP-Link" for port 2:

```
Switch(config)#interface gigabitEthernet 1/0/2
```

```
Switch(config-if)# ip dhcp I2relay information remote-id TP-Link
```

# 47.8 show ip dhcp I2relay

## Description

The **show ip dhcp I2relay** command is used to display the global status and Option 82 configuration of DHCP Relay.

## Syntax

```
show ip dhcp I2relay
```

## Command Mode

Privileged EXEC Mode and Any Configuration Mode

## Privilege Requirement

None.

## Example

Display the configuration of DHCP Relay:

```
Switch(config)# show ip dhcp I2relay
```

## 47.9 show ip dhcp l2relay interface

### Description

The **show ip dhcp l2relay interface** command is used to display the DHCP L2 Relay status for the ports.

### Syntax

```
show ip dhcp l2relay interface [ gigabitEthernet port | port-channel  
port-channel-id]
```

### Command Mode

Privileged EXEC Mode and Any Configuration Mode

### Privilege Requirement

None.

### Example

Display the DHCP L2 Relay configuration of port 1/0/2:

```
Switch(config)# show ip dhcp l2relay interface gigabitEthernet 1/0/2
```

# Chapter 48 DHCPV6 L2 Relay Commands

## 48.1 ipv6 dhcp l2relay

### Description

The **ipv6 dhcp l2relay** command is used to enable DHCPV6 L2 Relay function globally. To disable DHCPV6 L2 Relay function, please use **no ipv6 dhcp l2relay** command.

### Syntax

```
ipv6 dhcp l2relay  
no ipv6 dhcp l2relay
```

### Command Mode

Global Configuration Mode

### Privilege Requirement

Only Admin, Operator and Power User level users have access to these commands.

### Example

Enable DHCPV6 L2 Relay function globally:

```
Switch(config)# ipv6 dhcp l2relay
```

## 48.2 ipv6 dhcp l2relay vlan

### Description

The **ipv6 dhcp l2relay vlan** command is used to enable DHCPV6 L2 relay in the specified VLAN. To disable DHCPV6 L2 Relay in the specific vlan, please use **no ipv6 dhcp l2relay vlan** command.

### Syntax

```
ipv6 dhcp l2relay vlan vlan-id  
no ipv6 dhcp l2relay vlan vlan-id
```

### Parameter

*vlan-id*—— Specify the vlan to be enabled with DHCPV6 L2 relay.

### Command Mode

Global Configuration Mode

## Privilege Requirement

Only Admin, Operator and Power User level users have access to these commands.

## Example

Enable DHCP L2 Relay for VLAN 1:

```
Switch(config)# ipv6 dhcp l2relay vlan 1
```

# 48.3 ipv6 dhcp l2relay information option18

## Description

The **ipv6 dhcp l2relay information** command is used to enable option18 support of a specified port in DHCPV6 L2Relay. To disable this function, please use **no ipv6 dhcp l2relay information** command.

## Syntax

```
ipv6 dhcp l2relay information option18  
no ipv6 dhcp l2relay information option18
```

## Command Mode

Interface Configuration Mode (interface gigabitEthernet / interface range gigabitEthernet / interface port-channel / interface range port-channel)

## Privilege Requirement

Only Admin, Operator and Power User level users have access to these commands.

## Example

Enable option18 support in DHCPV6 L2Relay for port 2:

```
Switch(config)#interface gigabitEthernet 1/0/2  
Switch(config-if)# ipv6 dhcp l2relay information option18
```



## 48.4 ipv6 dhcp l2relay information option37

### Description

The **ipv6 dhcp l2relay information option37** command is used to enable option37 support of a specified port in DHCPV6 L2Relay. To disable this function, please use **no ipv6 dhcp l2relay information option37** command.

### Syntax

```
ipv6 dhcp l2relay information option37  
no ipv6 dhcp l2relay information option37
```

### Command Mode

Interface Configuration Mode (interface gigabitEthernet / interface range gigabitEthernet / interface port-channel / interface range port-channel)

### Privilege Requirement

Only Admin, Operator and Power User level users have access to these commands.

### Example

Enable option37 support in DHCPV6 L2Relay for port 2:

```
Switch(config)#interface gigabitEthernet 1/0/2  
Switch(config-if)# ipv6 dhcp l2relay information option37
```

## 48.5 ipv6 dhcp l2relay information remote-id

### Description

The **ipv6 dhcp l2relay information remote-id** command is used to specify the custom remote ID when option 37 customization is enabled. To clear the remote ID, please use **no ipv6 dhcp l2relay information remote-id** command.

### Syntax

```
ipv6 dhcp l2relay information remote-id remoteID  
no ipv6 dhcp l2relay information remote-id
```

## Parameter

*remoteID*— Specify the remote ID, ranging from 1 to 64 characters.

## Command Mode

Interface Configuration Mode (interface gigabitEthernet / interface range gigabitEthernet / interface port-channel / interface range port-channel)

## Privilege Requirement

Only Admin, Operator and Power User level users have access to these commands.

## Example

Specify the remote ID as "tplink192.168.0.3" for port 2:

```
Switch(config)#interface gigabitEthernet 1/0/2
Switch(config-if)# ipv6 dhcp l2relay information remote-id tplink
192.168.0.3
```

# 48.6 show ipv6 dhcp l2relay interface

## Description

The **show ipv6 dhcp l2relay** command is used to display the global status and Option 18\37 configuration of DHCPV6 L2Relay.

## Syntax

```
show ipv6 dhcp l2relay interface
```

## Command Mode

Privileged EXEC Mode and Any Configuration Mode

## Privilege Requirement

None.

## Example

Display the configuration of DHCPV6 L2Relay:

```
Switch(config)# show ipv6 dhcp l2relay interface
```

# Chapter 49 QoS Commands

QoS (Quality of Service) function is used to optimize the network performance. It provides you with network service experience of a better quality. The switch implements three priority modes based on port, on 802.1p and on DSCP.

## 49.1 qos trust mode

### Description

The **qos trust mode** command is used to configure the trust mode of CoS (Class of Service) function for the ports. The default trust mode is trust port priority.

### Syntax

```
qos trust mode { dot1p | dscp | untrust }
```

### Parameter

dot1p— Trust 802.1p mode. In this mode, data will be classified into different services based on the 802.1p priority.

dscp— Trust dscp mode. In this mode, data will be classified into different services based on the dscp priority.

untrust— Trust port mode. In this mode, data will be classified into different services based on the based on the port priority.

### Command Mode

Interface Configuration Mode (interface gigabitEthernet / interface range gigabitEthernet / interface port-channel / interface range port-channel)

### Privilege Requirement

Only Admin, Operator and Power User level users have access to these commands.

### Example

Set the trust mode of port 1/0/3 as dscp:

```
Switch(config)# interface gigabitEthernet 1/0/3
Switch(config-if)# qos trust mode dscp
```

## 49.2 qos port-priority

### Description

The **qos port-priority** command is used to configure the port to 802.1p priority mapping for the desired port. To return to the default configuration, please use **no qos port-priority** command. When Port Priority is enabled, the packets will be mapped to different priority queues based on the ingress ports.

### Syntax

```
qos port-priority { dot1p-priority }  
no qos port-priority
```

### Parameter

*dot1p-priority* — The 802.1p priority that the packets will be mapped to from the desired port. It ranges from 0 to 7, which represent 802.1p priority 0–7 respectively. By default, the priority is 0.

### Command Mode

Interface Configuration Mode (interface gigabitEthernet / interface range gigabitEthernet / interface port-channel / interface range port-channel)

### Privilege Requirement

Only Admin, Operator and Power User level users have access to these commands.

### Example

Configure the priority of port 5 as 3:

```
Switch(config)# interface gigabitEthernet 1/0/5  
Switch(config-if)# qos port-priority 3
```

## 49.3 qos cos-map

### Description

The **qos cos-map** command is used to configure 802.1p to queue mapping globally. To return to the default configuration, please use **no qos cos-map** command. When 802.1P Priority is enabled, the packets with 802.1Q tag are mapped to different priority levels based on 802.1P priority.

## Syntax

```
qos cos-map { dot1p-priority } { tc-queue }
```

```
no qos cos-map
```

## Parameter

*dot1p-priority* — The value of 802.1p priority. It ranges from 0 to 7, which represent 802.1p priority 0–7 respectively.

*tc-queue* — The number of TC queue that the 80.1p priority will be mapped to. It ranges from 0 to 7.

## Command Mode

Global Configuration Mode

## Privilege Requirement

Only Admin, Operator and Power User level users have access to these commands.

## Example

Map the 802.1p priority 5 to TC-2:

```
Switch (config)# qos cos-map 5 2
```

# 49.4 qos dot1p-remap

## Description

The **qos dot1p-remap** command is used to configure the 802.1p to 802.1p mappings. To return to the default configuration, please use **no qos dot1p-remap** command. When 802.1p remap is configured, the packets with the specific 802.1p priority will tagged with the desired new 802.1p priority.

## Syntax

```
qos dot1p-remap { dot1p-priority } { new-dot1p-priority }
```

```
no qos dot1p-remap
```

## Parameter

*dot1p-priority* — The original 802.1p priority. It ranges from 0 to 7, which represent 802.1p priority 0–7 respectively.

*new-dot1p-priority* — The new 802.1p priority. It ranges from 0 to 7.

## Command Mode

For some devices:

Global Configuration Mode

For other devices:

Interface Configuration Mode (interface gigabitEthernet / interface range gigabitEthernet / interface port-channel / interface range port-channel)

### Privilege Requirement

Only Admin, Operator and Power User level users have access to these commands.

### Example

For some devices:

Remap 802.1p priority 5 to 802.1p priority 6:

```
Switch(config)#qos dot1p-remap 5 6
```

For other devices:

Remap 802.1p priority 5 to 802.1p priority 6 for port 1/0/1:

```
Switch(config)# interface gigabitEthernet 1/0/1
```

```
Switch(config-if)#qos dot1p-remap 5 6
```

## 49.5 qos dscp-map

### Description

The **qos dscp-map** command is used to configure the DSCP to 802.1p mapping. To return to the default configuration, please use **no qos dscp-map** command. DSCP (DiffServ Code Point) is a new definition to IP ToS field given by IEEE. This field is used to divide IP datagram into 64 priorities. When DSCP Priority is enabled, IP datagram are mapped to different priority levels based on DSCP priority.

### Syntax

```
qos dscp-map { dscp-value-list } { dot1p-priority }
```

```
no qos dscp-map
```

### Parameter

*dscp-value-list* — The DSCP value list in the format of "1-3,5,7". The valid values are from 0 to 63.

*dot1p-priority* — The 802.1p priority to which the DSCP priority will be mapped. It ranges from 0 to 7, which represent 802.1p priority 0–7 respectively. By default, the priority is 0.

## Command Mode

For some devices:

Global Configuration Mode

For other devices:

Interface Configuration Mode (interface gigabitEthernet / interface range gigabitEthernet / interface port-channel / interface range port-channel)

## Privilege Requirement

Only Admin, Operator and Power User level users have access to these commands.

## Example

For some devices:

Map DSCP Priority 5 to 802.1p priority 2:

```
Switch(config)#qos dscp-map 5 2
```

For other devices:

Map DSCP Priority 5 to 802.1p priority 2 for port 1/0/1:

```
Switch(config)# interface gigabitEthernet 1/0/1
```

```
Switch(config-if)#qos dscp-map 5 2
```

# 49.6 qos dscp-remap

## Description

The **qos dscp-remap** command is used to configure the DSCP to DSCP mappings. To return to the default configuration, please use **no qos dscp-remap** command. When DSCP remap is configured, the packets with the specific DSCP priority will be changed to the desired new DSCP priority.

## Syntax

```
qos queue dscp-map { dscp-value-list } { dscp-remap-value }
```

```
no qos queue dscp-map
```

## Parameter

*Dscp-value-list*—The original DSCP value list in the format of "1-3,5,7". The valid values are from 0 to 63.

*Dscp-remap-value*— The new DSCP value, which ranges from 0 to 63.

## Command Mode

For some devices:

Global Configuration Mode

For other devices:

Interface Configuration Mode (interface gigabitEthernet / interface range gigabitEthernet / interface port-channel / interface range port-channel)

## Privilege Requirement

Only Admin, Operator and Power User level users have access to these commands.

## Example

For some devices:

Map DSCP values 10-12 to DSCP value 2:

```
Switch(config)# qos dscp-remap 10-12 2
```

For other devices:

Map DSCP values 10-12 to DSCP value 2 for port 1/0/2:

```
Switch(config)# interface gigabitEthernet 1/0/2
```

```
Switch(config-if)# qos dscp-remap 10-12 2
```

# 49.7 qos queue bandwidth



**Note:** This command is only available on certain devices

## Description

The **qos queue bandwidth** command is used to configure the minimum guaranteed bandwidth allocated to the specified queue. A value of 0 means there is no guaranteed minimum bandwidth in effect (best-effort service). The default value is 0. The sum of all bandwidth values for the queues must not exceed 100%. To return to the default configuration, please use **no qos bandwidth** command.

## Syntax

```
qos queue { tc-queue } bandwidth { rate }
```

```
no qos queue { tc-queue } bandwidth
```



## Parameter

*tc-queue* — The egress queue ID. It ranges from 0 to 7, which represents TC queue from TC0 to TC7 respectively.

*rate* — The minimum bandwidth percentage for queue, ranging from 1 to 100 in increments of 1. By default, it is 0.

## Command Mode

Interface Configuration Mode (interface gigabitEthernet / interface range gigabitEthernet / interface port-channel / interface range port-channel)

## Privilege Requirement

Only Admin, Operator and Power User level users have access to these commands.

## Example

Set the minimum bandwidth of TC5 as 10% for port 1/0/1:

```
Switch(config)# interface gigabitEthernet 1/0/1
```

```
Switch(config-if)# qos queue 5 bandwidth 10
```

# 49.8 qos queue mode

## Description

The **qos queue mode** command is used to configure the Scheduler Mode. When the network is congested, the program that many packets complete for resources must be solved, usually in the way of queue scheduling. The switch will control the forwarding sequence of the packets according to the priority queues and scheduling algorithms you set. On this switch, the priority levels are labeled as TC0, TC1, TC2 ... TC7.

## Syntax

```
qos queue { tc-queue } mode { sp | wrr } [ weight weight ]
```

## Parameter

*tc-queue* — The egress queue ID. It ranges from 0 to 7, which represents TC queue from TC0 to TC7 respectively.

sp — Strict-Priority Mode. In this mode, the queue with higher priority will occupy the whole bandwidth. Packets in the queue with lower priority are sent only when the queue with higher priority is empty.

*wrr* — Weight Round Robin Mode. In this mode, packets in all the queues are sent in order based on the weight value for each queue. If you select this mode, you need to specify the queue weight at the same time.

*weight* — Configure the weight value of the specified TC queue. When the scheduler mode is specified as WRR, the weight value ranges from 1 to 127. The 8 queues will take up the bandwidth according to their ratio.

### Command Mode

For some devices:

Global Configuration Mode

For other devices:

Interface Configuration Mode (interface gigabitEthernet / interface range gigabitEthernet / interface port-channel / interface range port-channel)

### Privilege Requirement

Only Admin, Operator and Power User level users have access to these commands.

### Example

For some devices:

Specify the Scheduler Mode of TC1 as WRR and set the queue weight as 10:

```
Switch(config)# qos queue 1 mode wrr weight 10
```

For other devices:

Specify the Scheduler Mode of TC1 as WRR and set the queue weight as 10 for port 1/0/1:

```
Switch(config)# interface gigabitEthernet 1/0/1
Switch(config-if)# qos queue 1 mode wrr weight 10
```

## 49.9 show qos cos-map

### Description

The **show qos cos-map** command is used to display the 802.1p priority to TC queue mappings.

### Syntax

```
show qos cos-map
```

## Command Mode

Privileged EXEC Mode and Any Configuration Mode

## Privilege Requirement

None.

## Example

Display the 802.1p to queue mappings:

```
Switch# show qos cos-map
```

# 49.10 show qos dot1p-remap interface



**Note:** This command is only available on certain devices.

## Description

The **show qos dot1p-remap interface** command is used to display the 802.1p priority to 802.1p priority mappings.

## Syntax

```
show qos dot1p-remap interface [fastEthernet port | gigabitEthernet port | ten-gigabitEthernet port | port-channel port-channel-id]
```

## Parameter

*port*— The port number.

*port-channel-id*— The ID of the port channel.

## Command Mode

Privileged EXEC Mode and Any Configuration Mode

## Privilege Requirement

None.

## Example

Display the IEEE 802.1P remap configuration of all the ports:

```
Switch# show qos dot1p-remap interface
```

# 49.11 show qos dot1p-remap



**Note:** This command is only available on certain devices.

## Description

The **show qos dot1p-remap interface** command is used to display the 802.1p priority to 802.1p priority mappings.

## Syntax

```
show qos dot1p-remap
```

## Command Mode

Privileged EXEC Mode and Any Configuration Mode

## Privilege Requirement

None.

## Example

Display the IEEE 802.1P remap configuration:

```
Switch# show qos dot1p-remap
```

# 49.12 show qos dscp-map interface



**Note:** This command is only available on certain devices.

## Description

The **show qos dscp-map interface** command is used to display the DSCP priority configuration of the ports.

## Syntax

```
show qos dscp-map interface [fastEthernet port | gigabitEthernet port |  
ten-gigabitEthernet port | port-channel port-channel-id]
```

## Parameter

*port*— The port number.

*port-channel-id*— The ID of the port channel.

## Command Mode

Privileged EXEC Mode and Any Configuration Mode

## Privilege Requirement

None.

## Example

Display the DSCP priority configuration of all the ports:

```
Switch# show qos dscp-map interface
```

## 49.13 show qos dscp-map



**Note:** This command is only available on certain devices.

### Description

The **show qos dscp-map** command is used to display the DSCP priority configuration.

### Syntax

```
show qos dscp-map
```

### Command Mode

Privileged EXEC Mode and Any Configuration Mode

### Privilege Requirement

None.

### Example

Display the DSCP priority configuration:

```
Switch# show qos dscp-map
```

## 49.14 show qos dscp-remap interface



**Note:** This command is only available on certain devices.

### Description

The **show qos dscp-remap interface** command is used to display the DSCP priority to DSCP priority mappings of the ports.

### Syntax

```
show qos dscp-remap interface [fastEthernet port | gigabitEthernet port |  
ten-gigabitEthernet port | port-channel port-channel-id]
```

### Parameter

*port* — The port number.

*port-channel-id*— The ID of the port channel.

### Command Mode

Privileged EXEC Mode and Any Configuration Mode

### Privilege Requirement

None.

### Example

Display the DSCP to DSCP mappings for all the ports:

```
Switch# show qos dscp-remap interface
```

## 49.15 show qos dscp-remap



**Note:** This command is only available on certain devices.

### Description

The **show qos dscp-remap** command is used to display the DSCP priority to DSCP priority mappings.

### Syntax

```
show qos dscp-remap
```

### Command Mode

Privileged EXEC Mode and Any Configuration Mode

### Privilege Requirement

None.

### Example

Display the DSCP to DSCP mappings:

```
Switch# show qos dscp-remap
```

## 49.16 show qos port-priority interface

### Description

The **show qos port-priority interface** command is used to display the port to 802.1p priority mappings for the ports.

## Syntax

```
show qos port-priority interface [fastEthernet port | gigabitEthernet port |  
ten-gigabitEthernet port | port-channel port-channel-id]
```

## Parameter

*port*—— The port number.

*port-channel-id*—— The ID of the port channel.

## Command Mode

Privileged EXEC Mode and Any Configuration Mode

## Privilege Requirement

None.

## Example

Display the port to 802.1p priority mappings for all the ports:

```
Switch# show qos port-priority interface
```

# 49.17 show qos trust interface

## Description

The **show qos trust interface** command is used to display the trust mode of the ports.

## Syntax

```
show qos trust interface [fastEthernet port | gigabitEthernet port |  
ten-gigabitEthernet port | port-channel port-channel-id]
```

## Parameter

*port*—— The port number.

*port-channel-id*—— The ID of the port channel.

## Command Mode

Privileged EXEC Mode and Any Configuration Mode

## Privilege Requirement

None.

## Example

Display the trust mode of all the ports:

```
Switch# show qos trust interface
```

## 49.18 show qos queue interface

### Description

The **show qos queue interface** command is used to display the scheduler settings of the ports.

### Syntax

```
show qos queue interface [fastEthernet port | gigabitEthernet port | ten-gigabitEthernet port | port-channel port-channel-id]
```

### Parameter

*port*—— The port number.

*port-channel-id*—— The ID of the port channel.

### Command Mode

Privileged EXEC Mode and Any Configuration Mode

### Privilege Requirement

None.

### Example

Display the scheduler settings of all the ports:

```
Switch# show qos queue interface
```



# Chapter 50 Bandwidth Control Commands

Bandwidth Control functions to control the traffic rate and traffic threshold on each port to ensure network performance. Rate limit functions to limit the ingress/egress traffic rate on each port. Storm Control function allows the switch to monitor broadcast packets, multicast packets and Unknown unicast frames in the network.

## 50.1 storm-control rate-mode

### Description

The **storm-control rate-mode** command is used to configure the storm control mode of the interface. To return to the default configuration, please use **no storm-control rate-mode** command.

### Syntax

```
storm-control rate-mode { kbps | ratio | pps }  
no storm-control rate-mode
```

### Parameter

kbps — Select the storm control mode of the interface as kbps. The switch will limit the maximum speed of the specific kinds of traffic in kilo-bits per second.

ratio — Select the storm control mode of the interface as ratio. The switch will limit the percentage of bandwidth utilization for specific kinds of traffic.

pps — The switch will limit the maximum number of packets per second for specific kinds of traffic.

**Note:** pps is only available on certain devices.

### Command Mode

Interface Configuration Mode (interface gigabitEthernet / interface range gigabitEthernet / interface port-channel / interface range port-channel)

### Privilege Requirement

Only Admin, Operator and Power User level users have access to these commands.

### User Guidelines

This command should be used along with the [storm-control](#) command to enable the storm control function and specify the detailed parameters.

## Example

Set the storm control mode as kbps on port 1/0/5:

```
Switch(config)# interface gigabitEthernet 1/0/5
Switch(config-if)# storm-control rate-mode kbps
```

## 50.2 storm-control

### Description

The **storm-control** command is used to enable the broadcast, multicast, or unknown unicast storm control function and to set threshold levels on an interface. To return to the default configuration, please use **no storm-control** command.

### Syntax

```
storm-control { broadcast | multicast | unicast } { rate }
no storm-control { broadcast | multicast | unicast }
```

### Parameter

**broadcast | multicast | unicast** — Select the mode of the storm control on the interface.

**rate** — Specify the bandwidth for receiving packets on the port. The specified type of packet traffic exceeding the bandwidth will be processed according to the configuration of **storm-control exceed** command. For kbps, the rate ranges from 1 to 1000000 kbps, and is rounded off to the nearest multiple of 64. For ratio, the rate ranges from 1 to 100 percent. For pps, the rate ranges from 1 to 1488000 packets per second.

### Command Mode

Interface Configuration Mode (interface gigabitEthernet / interface range gigabitEthernet / interface port-channel / interface range port-channel)

### Privilege Requirement

Only Admin, Operator and Power User level users have access to these commands.

### User Guidelines

Before you configure the storm-control type as kbps or ratio, please ensure that the port is not in pps mode.

## Example

Configure the broadcast storm control rate as 1024 kbps on port 1/0/5:

```
Switch(config)# interface gigabitEthernet 1/0/5
Switch(config-if)# storm-control rate-mode kbps
Switch(config-if)# storm-control broadcast 1024
```

## 50.3 storm-control exceed

### Description

The **storm-control exceed** command is used to configure the action that the switch will perform when the storm exceeds the defined limit on an interface.

### Syntax

```
storm-control exceed { drop | shutdown } [ revocer-time time ]
```

### Parameter

drop — Set the Action as Drop. The port will drop the subsequent packets when the traffic exceeds the limit.

shutdown — Set the Action as Shutdown. The port will be shutdown when the traffic exceeds the limit.

*time* — Specify the recover time for the port. It takes effect only when the action is set as shutdown. The valid values are from 0 to 3600 and the default value is 0. When the port is shutdown, it can recover to its normal state after the recover time passed. If the recover time is specified as 0, which means the port will not recover to its normal state automatically and you can recover the port manually using **storm-control recover** command.

### Command Mode

Interface Configuration Mode (interface gigabitEthernet / interface range gigabitEthernet / interface port-channel / interface range port-channel)

### Privilege Requirement

Only Admin, Operator and Power User level users have access to these commands.

### Example

Configure the action as drop on port 1/0/5:

```
Switch(config)# interface gigabitEthernet 1/0/5
Switch(config-if)# storm-control exceed drop
```

## 50.4 storm-control recover

### Description

The **storm-control recover** command is used to recover the port manually after the port is shutdown because of the storm. When the recover time is specified as 0, the port will not recover to its normal state automatically. In this condition, you need to use this command to recover the port manually.

### Syntax

```
storm-control recover
```

### Command Mode

Interface Configuration Mode (interface gigabitEthernet / interface range gigabitEthernet / interface port-channel / interface range port-channel)

### Privilege Requirement

Only Admin, Operator and Power User level users have access to these commands.

### Example

Recover port 1/0/5 manually:

```
Switch(config)# interface gigabitEthernet 1/0/5
Switch(config-if)# storm-control recover
```

## 50.5 bandwidth

### Description

The **bandwidth** command is used to configure the bandwidth limit for an Ethernet port. To disable the bandwidth limit, please use **no bandwidth** command.

### Syntax

```
bandwidth {[ ingress ingress-rate] [egress egress-rate]}
no bandwidth { all | ingress | egress }
```

### Parameter

*ingress-rate* — Specify the upper rate limit for receiving packets. The rate ranges from 1 to 1000000 kbps for the gigaport and 1 to 100000 kbps for the fast port, and is rounded off to the nearest multiple of 64.

*egress-rate* — Specify the upper rate limit for sending packets. The rate ranges from 1 to 1000000 kbps for the gigaport and 1 to 100000 kbps for the fast port, and is rounded off to the nearest multiple of 64.

### Command Mode

Interface Configuration Mode (interface gigabitEthernet / interface range gigabitEthernet / interface port-channel / interface range port-channel)

### Privilege Requirement

Only Admin, Operator and Power User level users have access to these commands.

### Example

Configure the ingress-rate as 5120Kbps and egress-rate as 1024Kbps for port 1/0/5:

```
Switch(config)# interface gigabitEthernet 1/0/5
Switch(config-if)# bandwidth ingress 5120 egress 1024
```

## 50.6 show storm-control

### Description

The **show storm-control** command is used to display the storm-control information of Ethernet ports.

### Syntax

```
show storm-control interface [ fastEthernet port | gigabitEthernet port-list
ten-gigabitEthernet port | port-channel port-channel-id-list ]
```

### Parameter

*port-list* — The list of Ethernet ports.

*port-channel-id-list* — The list of port channels.

### Command Mode

Privileged EXEC Mode and Any Configuration Mode

### Privilege Requirement

None.

### Example

Display the storm-control information of port 4, 5, 6, and 7:

```
Switch(config)# show storm-control interface gigabitEthernet 1/0/4-7
```

## 50.7 show bandwidth

### Description

The **show bandwidth** command is used to display the bandwidth-limit information of Ethernet ports.

### Syntax

```
show bandwidth interface [ fastEthernet port | gigabitEthernet port-list  
ten-gigabitEthernet port | port-channel port-channel-id-list ]
```

### Parameter

*port-list*——The list of Ethernet ports.

*port-channel-id-list*——The list of port channels.

### Command Mode

Privileged EXEC Mode and Any Configuration Mode

### Privilege Requirement

None.

### Example

Display the bandwidth-limit information of port 1/0/4:

```
Switch(config)# show bandwidth interface gigabitEthernet 1/0/4
```

# Chapter 51 Voice VLAN Commands

Voice VLANs are configured specially for voice data stream. By configuring Voice VLANs and adding the ports with voice devices attached to voice VLANs, you can perform QoS-related configuration for voice data, ensuring the transmission priority of voice data stream and voice quality.

## 51.1 voice vlan

### Description

The **voice vlan** command is used to enable Voice VLAN function. To disable Voice VLAN function, please use **no voice vlan** command.

### Syntax

```
voice vlan vlan-id  
no voice vlan
```

### Parameter

*vlan-id*—— Specify IEEE 802.1Q VLAN ID, ranging from 2 to 4094.

### Command Mode

Global Configuration Mode

### Privilege Requirement

Only Admin, Operator and Power User level users have access to these commands.

### Example

Enable the Voice VLAN function for VLAN 10:

```
Switch(config)# voice vlan 10
```

## 51.2 voice vlan (interface)

### Description

The **voice vlan** command is used to enable Voice VLAN function on the desired ports. To disable Voice VLAN function on ports, please use **no voice vlan** command.

## Syntax

**voice vlan**

**no voice vlan**

## Command Mode

Interface Configuration Mode (interface gigabitEthernet / interface range gigabitEthernet / interface port-channel / interface range port-channel)

## Privilege Requirement

Only Admin, Operator and Power User level users have access to these commands.

## Example

Enable the Voice VLAN function for port 1/0/1:

```
Switch(config)# interface gigabitEthernet 1/0/1
```

```
Switch(config-if)#voice vlan
```

# 51.3 voice vlan priority

## Description

The **voice vlan priority** command is used to configure the priority for the Voice VLAN. To restore to the default priority, please use **no voice vlan priority** command.

## Syntax

**voice vlan priority** *pri*

**no voice vlan priority**

## Parameter

*pri*—— Priority, ranging from 0 to 7, and the default value is 7.

## Command Mode

Global Configuration Mode

## Privilege Requirement

Only Admin, Operator and Power User level users have access to these commands.



## Example

Configure the priority of the Voice VLAN as 5:

```
Switch(config)# voice vlan priority 5
```

## 51.4 voice vlan oui

### Description

The **voice vlan oui** command is used to create Voice VLAN OUI. To delete the specified Voice VLAN OUI, please use **no voice vlan oui** command.

### Syntax

```
voice vlan oui oui-prefix oui-desc string
```

```
no voice vlan mac-address oui-prefix
```

### Parameter

*oui-prefix* — The OUI address of the voice device, in the format of XX:XX:XX.

*string* — Give a description to the OUI for identification which contains 16 characters at most.

### Command Mode

Global Configuration Mode

### Privilege Requirement

Only Admin, Operator and Power User level users have access to these commands.

### Example

Create a Voice VLAN OUI described as TP-Phone with the OUI address 00:11:11:11:11:11 and the mask address FF:FF:FF:00:00:00:

```
Switch(config)#voice vlan oui 00:11:11 oui-desc TP-Phone
```

## 51.5 show voice vlan

### Description

The **show voice vlan** command is used to display the global configuration information of Voice VLAN.

## Syntax

**show voice vlan**

## Command Mode

Privileged EXEC Mode and Any Configuration Mode

## Privilege Requirement

Only Admin, Operator and Power User level users have access to these commands.

## Example

Display the configuration information of Voice VLAN globally:

```
Switch(config)# show voice vlan
```

## 51.6 show voice vlan oui-table

### Description

The **show voice vlan oui** command is used to display the configuration information of Voice VLAN OUI.

### Syntax

**show voice vlan oui**

### Command Mode

Privileged EXEC Mode and Any Configuration Mode

### Privilege Requirement

Only Admin, Operator and Power User level users have access to these commands.

### Example

Display the configuration information of Voice VLAN OUI:

```
Switch(config)# show voice vlan oui-table
```

## 51.7 show voice vlan interface

### Description

The **show voice vlan interface** command is used to display the Voice VLAN configuration information of all ports.

## Syntax

**show voice vlan interface**

## Command Mode

Privileged EXEC Mode and Any Configuration Mode

## Privilege Requirement

Only Admin, Operator and Power User level users have access to these commands.

## Example

Display the Voice VLAN configuration information of all ports and port channels:

```
Switch(config)# show voice vlan interface
```

## Chapter 52 Auto VoIP Commands

The Auto VoIP feature is used to prioritize the transmission of voice traffic. Voice over Internet Protocol (VoIP) enables telephone calls over a data network, and the Auto VoIP feature helps provide a classification mechanism for voice packets. When Auto VoIP is configured on a port that receives both voice and data traffic, this feature can help ensure that the sound quality of an IP phone does not deteriorate when data traffic on the port is heavy.

### 52.1 auto-voip

#### Description

The **auto-voip** command is used to enable the Auto VoIP function globally. To disable the Auto VoIP function, use **no auto-voip** command.

#### Syntax

**auto-voip**  
**no auto-voip**

#### Command Mode

Global Configuration Mode

#### Example

Enable the Auto VoIP function globally:

```
Switch(config)# auto-voip
```

### 52.2 auto-voip (interface)

#### Description

The **auto-voip** command is used to specify the interface mode as VLAN ID for the ports. In this mode, the voice devices will send voice packets with desired VLAN tag.

#### Syntax

**auto-voip** *vlan-id*

#### Parameter

*vlan-id* —Specify the Auto VoIP VLAN ID. The valid values are from 2 to 4094.

## Command Mode

Interface Configuration Mode (interface gigabitEthernet / interface range gigabitEthernet / interface port-channel / interface range port-channel)

## Example

Set Auto VoIP VLAN 3 for port 3:

```
Switch(config)# interface gigabitEthernet 1/0/3
Switch(config-if)# auto-voip 3
```

# 52.3

## auto-voip dot1p

### Description

The **auto-voip dot1p** command is used to specify the interface mode as dot1p for the ports. In this mode, the voice devices will send voice packets with desired 802.1p priority.

### Syntax

```
auto-voip dot1p dot1p
```

### Parameter

*dot1p*—Set the 802.1p priority of Auto VoIP on specified ports. It ranges from 0 to 7.

## Command Mode

Interface Configuration Mode (interface gigabitEthernet / interface range gigabitEthernet / interface port-channel / interface range port-channel)

## Example

Set the 802.1p priority as 5 for the port:

```
Switch(config)# interface gigabitEthernet 1/0/3
Switch(config-if)# auto-voip dot1p 5
```

## 52.4

## auto-voip untagged

### Description

The **auto-voip untagged** command is used to specify the interface mode as untagged for the ports. In this mode, the voice devices will send untagged voice packets.

### Syntax

```
auto-voip untagged
```

### Command Mode

Interface Configuration Mode (interface gigabitEthernet / interface range gigabitEthernet / interface port-channel / interface range port-channel)

### Example

Set the interface mode as untagged for port 1/0/3:

```
Switch(config)# interface gigabitEthernet 1/0/3
Switch(config-if)# auto-voip untagged
```

## 52.5

## auto-voip none

### Description

The **auto-voip none** command is used to specify the interface mode as none for the ports. In this mode, the switch allows the voice devices to use its own configuration to send voice traffic.

### Syntax

```
auto-voip none
```

### Command Mode

Interface Configuration Mode (interface gigabitEthernet / interface range gigabitEthernet / interface port-channel / interface range port-channel)

### Example

Instruct voice devices that are connected to port 3 to send the packets according to its own configuration:

```
Switch(config)# interface gigabitEthernet 1/0/3
Switch(config-if)# auto-voip none
```

## 52.6

## no auto-voip (interface)

### Description

The **no auto-voip** command is used to specify the interface mode as disabled for the ports, which means the Auto VoIP function is disabled on the corresponding port.

### Syntax

```
no auto-voip
```

### Command Mode

Interface Configuration Mode (interface gigabitEthernet / interface range gigabitEthernet / interface port-channel / interface range port-channel)

### Example

Disable the Auto VoIP function on port 1/0/3:

```
Switch(config)# interface gigabitEthernet 1/0/3
Switch(config-if)# no auto-voip
```

## 52.7

## auto-voip dscp

### Description

The **auto-voip dscp** command is used to set the DSCP value of Auto VoIP on specified ports.

### Syntax

```
auto-voip dscp value
```

### Parameter

*value*—Set the DSCP value of Auto VoIP on specified ports. It ranges from 0 to 63. By default, it is 0.

### Command Mode

Interface Configuration Mode (interface gigabitEthernet / interface range gigabitEthernet / interface port-channel / interface range port-channel)

### Example

Set DSCP value of Auto VoIP on port 3 as 33:

```
Switch(config)# interface gigabitEthernet 1/0/3
Switch(config-if)# auto-voip dscp 33
```

## 52.8

## auto-voip data priority

### Description

The **auto-voip data priority** command is used to enable or disable the CoS Override Mode on specified ports.

### Syntax

```
auto-voip data priority { trust | untrust }
```

### Parameter

trust—In this mode, the switch will then put the voice packets in the corresponding TC queue according to the 802.1p priority of the packets.

untrust—In this mode, the switch will ignore the 802.1p priority in the voice packets and put the packets in TC-5 directly.

### Command Mode

Interface Configuration Mode (interface gigabitEthernet / interface range gigabitEthernet / interface port-channel / interface range port-channel)

### Example

Set the CoS Override Mode as trust for port 1/0/3:

```
Switch(config)# interface gigabitEthernet 1/0/3
Switch(config-if)# auto-voip data priority trust
```

## 52.9

## show auto-voip

### Description

The **show auto-voip** command is used to display the Auto VoIP configuration information.

### Syntax

```
show auto-voip [ interface ]
```



## Parameter

interface — Displays the Auto VoIP configuration information of ports. When no parameter is entered, displays the global Auto VoIP configuration information.

## Command Mode

Privileged EXEC Mode and any Configuration Mode

## Example

Displays the global Auto VoIP configuration information:

```
Switch (config)# show auto-voip
```

## Chapter 53 Access Control Commands

### 53.1 user access-control ip-based enable

#### Description

The **user access-control ip-based enable** command is used to configure the access control mode IP-based. To disable the access control feature, please use **no user access-control** command.

#### Syntax

```
user access-control ip-based enable  
no user access-control
```

#### Command Mode

Global Configuration Mode

#### Privilege Requirement

Only Admin and Operator level users have access to these commands.

#### Example

Configure the access control mode as IP-based:

```
Switch(config)# user access-control ip-based enable
```

### 53.2 user access-control ip-based

#### Description

The **user access-control ip-based** command is used to limit the IP-range of the users for login. Only the users within the IP-range you set here are allowed to login. You can add up to 30 IP-based entries. To cancel the user access limit, please use **no user access-control ip-based** command.

## Syntax

```
user access-control ip-based { ip-addr ip-mask } [ snmp ] [ telnet ] [ ssh ]  
[ http ] [ https ] [ ping ] [ all ]
```

```
no user access-control ip-based index id
```

## Parameter

*ip-addr* — The source IP address. Only the users within the IP-range you set here are allowed for login. 5 IP-based entries can be configured at most.

*ip-mask* — The subnet mask of the IP address.

[ snmp ] [ telnet ] [ ssh ] [ http ] [ https ] [ ping ] [ all ] — Specify the access interface. These interfaces are enabled by default.

*id* — Delete the specified IP-based entry.

## Command Mode

Global Configuration Mode

## Privilege Requirement

Only Admin and Operator level users have access to these commands.

## Example

Enable the access-control of the user whose IP address is 192.168.0.148:

```
Switch(config)# user access-control ip-based 192.168.0.148  
255.255.255.255
```

## 53.3 user access-control mac-based enable

### Description

The **user access-control mac-based enable** command is used to configure the access control mode MAC-based. To disable the access control feature, please use **no user access-control** command.

### Syntax

```
user access-control mac-based enable
```

```
no user access-control
```

## Command Mode

Global Configuration Mode

## Privilege Requirement

Only Admin and Operator level users have access to these commands.

## Example

Configure the access control mode as MAC-based:

```
Switch(config)# user access-control mac-based enable
```

# 53.4 user access-control mac-based

## Description

The **user access-control mac-based** command is used to limit the MAC address of the users for login. Only the user with this MAC address you set here is allowed to login. You can add up to 30 mac-based control entries. To delete the mac-based access control entry, please use **no user access-control mac-based** command.

## Syntax

```
user access-control mac-based { mac-addr } [ snmp ] [ telnet ] [ ssh ] [ http ]  
[ https ] [ ping ] [ all ]
```

```
no user access-control mac-based index id
```

## Parameter

*mac-addr* — The source MAC address. Only the user with this MAC address is allowed to login.

[ snmp ] [ telnet ] [ ssh ] [ http ] [ https ] [ ping ] [ all ] — Specify the access interface. These interfaces are enabled by default.

*id* — Specify the ID of the mac-based entry to be deleted.

## Command Mode

Global Configuration Mode

## Privilege Requirement

Only Admin and Operator level users have access to these commands.

## Example

Configure that only the user whose MAC address is 00:00:13:0A:00:01 is allowed to login:

```
Switch(config)# user access-control mac-based 00:00:13:0A:00:01
```

## 53.5 user access-control port-based enable

### Description

The **user access-control port-based enable** command is used to configure the access control mode Port-based. To disable the access control feature, please use **no user access-control** command.

### Syntax

```
user access-control port-based enable
```

```
no user access-control
```

### Command Mode

Global Configuration Mode

### Privilege Requirement

Only Admin and Operator level users have access to these commands.

## Example

Configure the access control mode as Port-based:

```
Switch(config)# user access-control port-based enable
```

## 53.6 user access-control port-based

### Description

The **user access-control port-based** command is used to limit the ports for login. Only the users connected to these ports you set here are allowed to login. You can add up to 30 port-based control entries. To delete the port-based access control entry, please use **no user access-control port-based** command.

## Syntax

```
user access-control port-based interface { gigabitEthernet port-list } [ snmp ]  
[ telnet ] [ ssh ] [ http ] [ https ] [ ping ] [ all ]  
no user access-control port-based index id
```

## Parameter

*port-list* — The list group of Ethernet ports, in the format of 1/0/1-4. You can appoint 5 ports at most.

[ snmp ] [ telnet ] [ ssh ] [ http ] [ https ] [ ping ] [ all ] — Specify the access interface. These interfaces are enabled by default.

*id* — Specify the ID of the port-based entry to be deleted.

## Command Mode

Global Configuration Mode

## Privilege Requirement

Only Admin and Operator level users have access to these commands.

## Example

Configure that only the users connected to ports 2-6 are allowed to login:

```
Switch(config)# user access-control port-based interface gigabitEthernet  
1/0/2-6
```

# 53.7 user access-control ipv6-based enable

## Description

The **user access-control ipv6-based enable** command is used to configure the access control mode IPV6-based. To disable the access control feature, please use **no user access-control** command.

## Syntax

```
user access-control ipv6-based enable  
no user access-control
```

## Command Mode

Global Configuration Mode

## Privilege Requirement

Only Admin and Operator level users have access to these commands.

## Example

Configure the access control mode as IPV6-based:

```
Switch(config)# user access-control ipv6-based enable
```

# 53.8 user access-control ipv6-based

## Description

The **user access-control ipv6-based** command is used to limit the IPV6-range of the users for login. Only the users within the IPV6-range you set here are allowed to login. You can add up to 30 IPV6-based entries. To cancel the user access limit, please use **no user access-control ipv6-based** command.

## Syntax

```
user access-control ipv6-based { ipv6-addr } [ snmp ] [ telnet ] [ ssh ] [ http ]  
[ https ] [ ping ] [ all ]
```

```
no user access-control ipv6-based index id
```

## Parameter

*ipv6-addr* — The source IP address. Only the users within the IPV6-range you set here are allowed for login.

[ snmp ] [ telnet ] [ ssh ] [ http ] [ https ] [ ping ] [ all ] — Specify the access interface. These interfaces are enabled by default.

*id* — Delete the specified IP-based entry that ranges from 1 to 30.

## Command Mode

Global Configuration Mode

## Privilege Requirement

Only Admin and Operator level users have access to these commands.

## Example

Enable the access-control of the user whose IP address is fe80::1234 :

```
Switch(config)# user access-control ipv6-based fe80::1234
```

# Chapter 54 HTTP and HTTPS Commands

With the help of HTTP (HyperText Transfer Protocol) or HTTPS (Hyper Text Transfer Protocol over Secure Socket Layer), you can manage the switch through a standard browser.

HTTP is the protocol to exchange or transfer hypertext.

SSL (Secure Sockets Layer), a security protocol, is to provide a secure connection for the application layer protocol (e.g. HTTP) based on TCP. Adopting asymmetrical encryption technology, SSL uses key pair to encrypt/decrypt information. A key pair refers to a public key (contained in the certificate) and its corresponding private key. By default the switch has a certificate (self-signed certificate) and a corresponding private key. The Certificate/Key Download function enables the user to replace the default key pair.

## 54.1 ip http server

### Description

The **ip http server** command is used to enable the HTTP server within the switch. To disable the HTTP function, please use **no ip http server** command. This function is enabled by default. The HTTP and HTTPS server function can be disabled at the same time.

### Syntax

**ip http server**  
**no ip http server**

### Command Mode

Global Configuration Mode

### Privilege Requirement

Only Admin and Operator level users have access to these commands.

### Example

Disable the HTTP function:

```
Switch(config)# no ip http server
```



## 54.2 ip http port

### Description

The **ip http port** command is used to configure the port number of the HTTP server within the switch. To set the number to the default value, please use **no ip http port** command.

### Syntax

```
ip http port port-num  
no ip http port
```

### Parameter

*port-num* — Enter the port number. This value ranges from 1 to 65535.

### Command Mode

Global Configuration Mode

### Privilege Requirement

Only Admin and Operator level users have access to these commands.

### Example

Set the port number of HTTP server as 1800:

```
Switch(config)# ip http port 1800
```

## 54.3 ip http max-users

### Description

The **ip http max-users** command is used to configure the maximum number of users that are allowed to connect to the HTTP server. To cancel this limitation, please use **no ip http max-users** command.

### Syntax

```
ip http max-users admin-num operator-num poweruser-num user-num  
no ip http max-users
```

### Parameter

*admin-num* — The maximum number of the users logging on to the HTTP server as Admin, ranging from 1 to 16. The total number of users should be no more than 16.

*operator-num* — The maximum number of the users logging on to the HTTP server as operator, ranging from 0 to 15. The total number of users should be no more than 16.

*poweruser-num* — The maximum number of the users logging on to the HTTP server as Power User, ranging from 0 to 15. The total number of users should be no more than 16.

*user-num* — The maximum number of the users logging on to the HTTP server as User, ranging from 0 to 15. The total number of users should be no more than 16.

## Command Mode

Global Configuration Mode

## Privilege Requirement

Only Admin and Operator level users have access to these commands.

## Example

Configure the maximum number of the Admin, Operator, Power User and User as 5, 1, 1, 1 for HTTP:

```
Switch(config)# ip http max-users 5 1 1 1
```

# 54.4 ip http session timeout

## Description

The **ip http session timeout** command is used to configure the connection timeout of the HTTP server. To restore to the default timeout time, please use **no ip http session timeout** command.

## Syntax

**ip http session timeout** *time*

**no ip http session timeout**

## Parameter

*time* —The timeout time, ranging from 5 to 30 in minutes. By default, the value is 10.

## Command Mode

Global Configuration Mode

## Privilege Requirement

Only Admin and Operator level users have access to these commands.

## Example

Configure the timeout time of the HTTP connection as 15 minutes:

```
Switch(config)# ip http session timeout 15
```

# 54.5 ip http secure-server

## Description

The **ip http secure-server** command is used to enable the HTTPS server within the switch. To disable the HTTPS function, please use **no ip http secure-server** command. This function is enabled by default. The HTTP and HTTPS server function can be disabled at the same time.

## Syntax

```
ip http secure-server  
no ip http secure-server
```

## Command Mode

Global Configuration Mode

## Privilege Requirement

Only Admin, Operator and Power User level users have access to these commands.

## Example

Disable the HTTP function:

```
Switch(config)# no ip http secure-server
```

# 54.6 ip http secure-port

## Description

The **ip http secure-port** command is used to configure the port number of the HTTPS server within the switch. To set the number to the default value, please use **no ip http secure-port** command.

## Syntax

```
ip http secure-port port-num
```

## **no ip http secure-port**

### **Parameter**

*port-num* — Enter the port number. This value ranges from 1 to 65535.

### **Command Mode**

Global Configuration Mode

### **Privilege Requirement**

Only Admin and Operator level users have access to these commands.

### **Example**

Set the port number of HTTPS server as 2800:

```
Switch(config)# ip http secure-port 2800
```

## **54.7 ip http secure-protocol**

### **Description**

The **ip http secure-protocol** command is used to configure the SSL protocol version. To restore to the default SSL version, please use **no ip http secure-protocol** command. By default, the switch supports all the protocol versions, including SSL 3.0, TLS 1.0, TLS 1.1 and TLS 1.2.

### **Syntax**

```
ip http secure-protocol { ssl3 | tls1 | tls11 | tls12 | all }
```

```
no ip http secure-protocol
```

### **Parameter**

ssl3 — Select SSL Version 3.0 as the protocol for HTTPS.

tls1 — Select TLS Version 1.0 as the protocol for HTTPS.

tls11 — Select TLS Version 1.1 as the protocol for HTTPS.

tls12 — Select TLS Version 1.2 as the protocol for HTTPS.

all — Enable all the above protocols for HTTPS. The HTTPS server and client will negotiate the protocol each time.

### **Command Mode**

Global Configuration Mode

## Privilege Requirement

Only Admin, Operator and Power User level users have access to these commands.

## Example

Configure the protocol of SSL connection as SSL 3.0:

```
Switch(config)# ip http secure-protocol ssl3
```

# 54.8 ip http secure-ciphersuite

## Description

The **ip http secure-ciphersuite** command is used to configure the cipherSuites over the SSL connection supported by the switch. To restore to the default ciphersuite types, please use **no ip http secure-ciphersuite** command.

## Syntax

```
ip http secure-ciphersuite { [ rc4-128-md5 ] [ rc4-128-sha ] [ des-cbc-sha ]  
[ 3des-ede-cbc-sha ] [ ecdhe-a128-g-s256 ] [ ecdhe-a256-g-s384 ] }
```

```
no ip http secure-ciphersuite
```

## Parameter

[ rc4-128-md5 ] [ rc4-128-sha ] [ des-cbc-sha ] [ 3des-ede-cbc-sha ] [ ecdhe-a128-g-s256 ] [ ecdhe-a256-g-s384 ] — Specify the encryption algorithm and the digest algorithm to use on an SSL connection. By default, the switch supports all these ciphersuites.

## Command Mode

Global Configuration Mode

## Privilege Requirement

Only Admin, Operator and Power User level users have access to these commands.

## Example

Configure the ciphersuite to be used for encryption over the SSL connection as 3des-ede-cbc-sha:

```
Switch(config)# ip http secure-ciphersuite 3des-ede-cbc-sha
```

## 54.9 ip http secure-max-users

### Description

The **ip http secure-max-users** command is used to configure the maximum number of users that are allowed to connect to the HTTPs server. To cancel this limitation, please use **no ip http secure-max-users** command.

### Syntax

```
ip http secure-max-users admin-num operator-num poweruser-num  
user-num
```

```
no ip secure-max-users
```

### Parameter

*admin-num* — The maximum number of the users logging on to the HTTPs server as Admin, ranging from 1 to 16. The total number of users should be less than 16.

*Operator-num* — The maximum number of the users logging on to the HTTPs server as operator, ranging from 0 to 15. The total number of users should be less than 16.

*poweruser-num* — The maximum number of the users logging on to the HTTP server as Power User, ranging from 0 to 15. The total number of users should be less than 16.

*user-num* — The maximum number of the users logging on to the HTTP server as User, ranging from 0 to 15. The total number of users should be less than 16.

### Command Mode

Global Configuration Mode

### Privilege Requirement

Only Admin, Operator and Power User level users have access to these commands.

### Example

Configure the maximum number of the Admin, Operator, Power User and User as 5, 1, 1, 1 for HTTPs:

```
Switch(config)# ip http secure-max-users 5 1 1 1
```

## 54.10 ip http secure-session timeout

### Description

The **ip http secure-session timeout** command is used to configure the connection timeout of the HTTPS server. To restore to the default timeout time, please use **no ip http secure-session timeout** command.

### Syntax

```
ip http secure-session timeout time  
no ip http secure-session timeout
```

### Parameter

*time* — The timeout time, ranging from 5 to 30 in minutes. By default, the value is 10.

### Command Mode

Global Configuration Mode

### Privilege Requirement

Only Admin, Operator and Power User level users have access to these commands.

### Example

Configure the timeout time of the HTTPs connection as 15 minutes:

```
Switch(config)# ip http secure-session timeout 15
```

## 54.11 ip http secure-server download certificate

### Description

The **ip http secure-server download certificate** command is used to download a certificate to the switch from TFTP server.

### Syntax

```
ip http secure-server download certificate ssl-cert ip-address ip-addr
```

## Parameter

*ssl-cert* — The name of the SSL certificate which is selected to download to the switch. The length of the name ranges from 1 to 25 characters. The Certificate must be BASE64 encoded.

*ip-addr* — The IP address of the TFTP server. Both IPv4 and IPv6 addresses are supported, for example 192.168.0.1 or fe80::1234.

## Command Mode

Global Configuration Mode

## Privilege Requirement

Only Admin, Operator and Power User level users have access to these commands.

## Example

Download an SSL Certificate named ssl-cert from TFTP server with the IP address of 192.168.0.146:

```
Switch(config)# ip http secure-server download certificate ssl-cert
ip-address 192.168.0.146
```

Download an SSL Certificate named ssl-cert from TFTP server with the IP address of fe80::1234

```
Switch(config)# ip http secure-server download certificate ssl-cert
ip-address fe80::1234
```

# 54.12 ip http secure-server download key

## Description

The **ip http secure-server download key** command is used to download an SSL key to the switch from TFTP server.

## Syntax

```
ip http secure-server download key ssl-key ip-address ip-addr
```



## Parameter

*ssl-key*— The name of the SSL key which is selected to download to the switch. The length of the name ranges from 1 to 25 characters. The Key must be BASE64 encoded.

*ip-addr*— The IP address of the TFTP server. Both IPv4 and IPv6 addresses are supported, for example 192.168.0.1 or fe80::1234.

## Command Mode

Global Configuration Mode

## Privilege Requirement

Only Admin, Operator and Power User level users have access to these commands.

## Example

Download an SSL key named ssl-key from TFTP server with the IP address of 192.168.0.146:

```
Switch(config)# ip http secure-server download key ssl-key ip-address  
192.168.0.146
```

Download an SSL key named ssl-key from TFTP server with the IP address of fe80::1234

```
Switch(config)# ip http secure-server download key ssl-key ip-address  
fe80::1234
```

# 54.13 show ip http configuration

## Description

The **show ip http configuration** command is used to display the configuration information of the HTTP server, including status, session timeout, access-control, max-user number and the idle-timeout, etc.

## Syntax

```
show ip http configuration
```

## Command Mode

Privileged EXEC Mode and Any Configuration Mode

## Privilege Requirement

None.

## Example

Display the configuration information of the HTTP server:

```
Switch(config)# show ip http configuration
```

# 54.14 show ip http secure-server

## Description

The **show ip http secure-server** command is used to display the global configuration of SSL.

## Syntax

```
show ip http secure-server
```

## Command Mode

Privileged EXEC Mode and Any Configuration Mode

## Privilege Requirement

None.

## Example

Display the global configuration of SSL:

```
Switch(config)# show ip http secure-server
```

# Chapter 55 SSH Commands

SSH (Security Shell) can provide the unsecured remote management with security and powerful authentication to ensure the security of the management information.

## 55.1 ip ssh server

### Description

The **ip ssh server** command is used to enable SSH function. To disable the SSH function, please use **no ip ssh server** command.

### Syntax

**ip ssh server**  
**no ip ssh server**

### Command Mode

Global Configuration Mode

### Privilege Requirement

Only Admin, Operator and Power User level users have access to these commands.

### Example

Enable the SSH function:

```
Switch(config)# ip ssh server
```

## 55.2 ip ssh port

### Description

The **ip ssh port** command is used to configure the port for SSH service. To set the value to the default, please use **no ip ssh port** command.

### Syntax

**ip ssh port** *port*  
**no ip ssh port**

## Parameter

*port* — Set the port number. It ranges from 1 to 65535. The default value is 22.

## Command Mode

Global Configuration Mode

## Privilege Requirement

Only Admin, Operator and Power User level users have access to these commands.

## Example

Configure the SSH port number as 22:

```
Switch(config)# ip ssh port 22
```

# 55.3 ip ssh algorithm

## Description

The **ip ssh algorithm** command is used to configure the algorithm in SSH function. To disable the specified algorithm, please use **no ip ssh algorithm** command.

## Syntax

```
ip ssh algorithm { AES-CBC | 3DES-CBC | AES-GCM | AES-CTR |  
HMAC-SHA1 | HMAC-SHA2 | HMAC-MD5 | UMAC }
```

```
no ip ssh algorithm
```

## Parameter

AES-CBC | 3DES-CBC | AES-GCM | AES-CTR | HMAC-SHA1 |  
HMAC-SHA2 | HMAC-MD5 | UMAC — Specify the SSH  
algorithm.

## Command Mode

Global Configuration Mode

## Privilege Requirement

Only Admin, Operator and Power User level users have access to these commands.

## Example

Specify the SSH algorithm as AES-CBC:

```
Switch(config)# ip ssh algorithm AES-CBC
```

## 55.4 ip ssh algorithm compatibility

### Description

The **ip ssh algorithm compatibility** command is used to configure enable compatibility configuration to allow SSH to use unsafe encryption algorithms.

### Syntax

```
ip ssh algorithm compatibility
```

### Command Mode

Privileged EXEC Mode and Any Configuration Mode

### Privilege Requirement

Only Admin, Operator and Power User level users have access to these commands.

### Example

Enable compatibility configuration to allow SSH to use unsafe encryption algorithms:

```
Switch#ip ssh algorithm compatibility
```

This command will synchronously enable unsafe algorithms such as AES-CBC, 3DES-CBC, HMAC-SHA1, HMAC-MD5, etc. (yes/no)

## 55.5 ip ssh timeout

### Description

The **ip ssh timeout** command is used to specify the idle-timeout time of SSH. To restore to the factory defaults, please use **ip ssh timeout** command.

### Syntax

```
ip ssh timeout value
```

```
no ip ssh timeout
```

### Parameter

*value* — The Idle-timeout time. During this period, the system will automatically release the connection if there is no operation from the client. It ranges from 1 to 120 in seconds. By default, this value is 120 seconds.

## Command Mode

Global Configuration Mode

## Privilege Requirement

Only Admin, Operator and Power User level users have access to these commands.

## Example

Specify the idle-timeout time of SSH as 30 seconds:

```
Switch(config)# ip ssh timeout 30
```

# 55.6 ip ssh max-client

## Description

The **ip ssh max-client** command is used to specify the maximum number of the connections to the SSH server. To return to the default configuration, please use **no ip ssh max-client** command.

## Syntax

```
ip ssh max-client num
```

```
no ip ssh max-client
```

## Parameter

*num* — The maximum number of the connections to the SSH server. It ranges from 1 to 5. By default, this value is 5.

## Command Mode

Global Configuration Mode

## Privilege Requirement

Only Admin, Operator and Power User level users have access to these commands.

## Example

Specify the maximum number of the connections to the SSH server as 3:

```
Switch(config)# ip ssh max-client 3
```

## 55.7 ip ssh download

### Description

The **ip ssh download** command is used to download the SSH key file from TFTP server.

### Syntax

```
ip ssh download { v1 | v2 } key-file ip-address ip-addr
```

### Parameter

*v1 | v2* — Select the type of SSH key to download, v1 represents SSH-1, v2 represents SSH-2.

*key-file* — The name of the key-file which is selected to download. The length of the name ranges from 1 to 25 characters. The key length of the downloaded file must be in the range of 512 to 3072 bits.

*ip-addr* — The IP address of the TFTP server. Both IPv4 and IPv6 addresses are supported, for example 192.168.0.1 or fe80::1234.

### Command Mode

Global Configuration Mode

### Privilege Requirement

Only Admin, Operator and Power User level users have access to these commands.

### Example

Download an SSH-1 type key file named ssh-key from TFTP server with the IP address 192.168.0.148:

```
Switch(config)# ip ssh download v1 ssh-key ip-address 192.168.0.148
```

Download an SSH-1 type key file named ssh-key from TFTP server with the IP address fe80::1234:

```
Switch(config)# ip ssh download v1 ssh-key ip-address fe80::1234
```

## 55.8 remove public-key

### Description

The **remove public-key** command is used to remove the SSH public key from the switch.

### Syntax

```
remove public-key { v1 | v2 }
```

### Parameter

v1 | v2 — Select the type of SSH public key, v1 represents SSH-1, v2 represents SSH-2.

### Command Mode

Privileged EXEC Mode

### Privilege Requirement

Only Admin level users have access to these commands.

### Example

Remove the SSH-1 type public key from the switch:

```
Switch# remove public-key v1
```

## 55.9 show ip ssh

### Description

The **show ip ssh** command is used to display the global configuration of SSH.

### Syntax

```
show ip ssh
```

### Command Mode

Privileged EXEC Mode and Any Configuration Mode

### Privilege Requirement

None.

### Example

Display the global configuration of SSH:

```
Switch(config)# show ip ssh
```



# Chapter 56 Telnet Commands

## 56.1 telnet

### Description

The **telnet** command is used to log in and manage other devices via telnet.

### Syntax

```
telnet ip-addr
```

### Parameter

*ip-addr*—The IP address of the device you want to log in.

### Command Mode

Privileged EXEC Mode

### Privilege Requirement

None.

### User Guidelines

Make sure the switch can access the device, and the device can be logged in via telnet.

### Example

Log in to a device with the IP address of 192.168.0.10:

```
Switch# telnet 192.168.0.10
```

## 56.2 telnet enable

### Description

The **telnet enable** command is used to enable the Telnet function. To disable the Telnet function, please use the **telnet disable** command. This function is enabled by default.

### Syntax

```
telnet enable
```

```
telnet disable
```

## Command Mode

Global Configuration Mode

## Privilege Requirement

Only Admin and Operator level users have access to these commands.

## Example

Disable the Telnet function:

```
Switch(config)# telnet disable
```

# 56.3 telnet port

## Description

The **telnet port** command is used to configure the telnet port number. To restore the setting, please use the **no telnet port** command.

## Syntax

```
telnet port port
```

```
no telnet port
```

## Parameter

*port*—The number of telnet port.

## Command Mode

Global Configuration Mode

## Privilege Requirement

Only Admin and Operator level users have access to these commands.

## Example

Configure the telnet port number as 566:

```
Switch(config)# telnet port 566
```

# 56.4 show telnet-status

## Description

The **show telnet-status** command is used to display the configuration information of the Telnet function.

## Syntax

**show telnet-status**

## Command Mode

Privileged EXEC Mode and Any Configuration Mode

## Privilege Requirement

None.

## Example

Display whether the Telnet function is enabled:

```
Switch(config)# show telnet-status
```

# Chapter 57 Serial Port Commands



**Note:** Serial Port commands are only available on certain devices.

## 57.1 serial\_port baud-rate

### Description

The **serial\_port baud-rate** command is used to configure the communication baud rate on the console port. To return to the default baud rate, please use **no serial\_port** command.

### Syntax

```
serial_port baud-rate { 9600 | 19200 | 38400 | 57600 | 115200 }  
no serial_port
```

### Parameter

9600 | 19200 | 38400 | 57600 | 115200 —Specify the communication baud rate on the console port. The default baul rate is 38400 bps.

### Command Mode

Global Configuration Mode

### Privilege Requirement

Only Admin and Operator level users have access to these commands.

### Example

Specify the communication baud rate on the console port to the default value:

```
Switch(config)# no serial_port
```

# Chapter 58 AAA Commands

AAA stands for authentication, authorization and accounting. This feature is used to authenticate users trying to log in to the switch or trying to access the administrative level privilege.

- **Applicable Access Application**

The authentication can be applied on the following access applications: Telnet, SSH and HTTP.

- **Authentication Method List**

A method list describes the authentication methods and their sequence to authenticate a user. The switch supports Login List for users to gain access to the switch, and Enable List for normal users to gain administrative privileges.

- **RADIUS/TACACS+ Server**

User can configure the RADIUS/TACACS+ servers for the connection between the switch and the server.

- **Server Group**

User can define the authentication server group with up to several servers running the same secure protocols, either RADIUS or TACACS+. Users can set these servers in a preferable order, which is called the server group list. When a user tries to access the switch, the switch will ask the first server in the server group list for authentication. If no response is received, the second server will be queried, and so on.

## 58.1 tacacs-server host

### Description

The **tacacs-server host** command is used to configure a new TACACS+ server. To delete the specified TACACS+ server, please use **no tacacs-server host** command.

### Syntax

```
tacacs-server host ip-address [ port port-id ] [ timeout time ] [ key { [ 0 ]  
string | 7 encryped-string } ]
```

```
no tacacs-server host ip-address
```

### Parameter

*ip-address*—— Specify the IP address of the TACACS+ server.

*port-id*—— Specify the server's port number for AAA. By default it is 49.

*time* — Specify the time in seconds the switch waits for the server's response before it times out. The time ranges from 1 to 9 seconds. The default is 5 seconds.

[ 0 ] *string* | 7 *encrypted-string* — 0 and 7 are the encryption type. 0 indicates that an unencrypted key will follow. 7 indicates that a symmetric encrypted key with a fixed length will follow. By default, the encryption type is 0. "*string*" is the shared key for the switch and the authentication servers to exchange messages. "*encrypted-string*" is a symmetric encrypted key with a fixed length, which you can copy from another switch's configuration file. The key or encrypted-key you configured here will be displayed in the encrypted form. Always configure the key as the last item of this command.

### Command Mode

Global Configuration Mode

### Privilege Requirement

Only Admin level users have access to these commands.

### User Guidelines

The TACACS+ servers you configured are added in the server group "tacacs" by default.

### Example

Configure a TACACS+ server with the IP address as 1.1.1.1, TCP port as 1500, timeout as 6 seconds, and the unencrypted key string as 12345.

```
Switch(config)# tacacs-server host 1.1.1.1 port 1500 timeout 6 key 12345
```

## 58.2 show tacacs-server

### Description

This **show tacacs-server** command is used to display the summary information of the TACACS+ servers.

### Syntax

```
show tacacs-server
```

### Command Mode

Privileged EXEC Mode and Any Configuration Mode

## Privilege Requirement

Only Admin level users have access to these commands.

## Example

Display the information of all the TACACS+ servers:

```
Switch(config)# show tacacs-server
```

# 58.3 radius-server host

## Description

The **radius-server host** command is used to configure a new RADIUS server. To delete the specified RADIUS server, please use **no radius-server host** command.

## Syntax

```
radius-server host ip-address [ auth-port port-id ] [ acct-port port-id ]  
[ timeout time ] [ retransmit number ] [ nas-id nas-id ] [ key { [ 0 ] string | 7  
encrypted-string } ]  
no radius-server host ip-address
```

## Parameter

*ip-address* — Specify the IP address of the RADIUS server.

**auth-port** *port-id* — Specify the UDP destination port for authentication requests. By default it is 1812.

**acct-port** *port-id* — Specify the UDP destination port for accounting requests. By default it is 1813.

*time* — Specify the time in seconds the switch waits for the server's response before it times out. The time ranges from 1 to 9 seconds. The default is 5 seconds.

*number* — Specify the number of times a RADIUS request is resent to a server if the server is not responding in time. By default it is 2 times.

*nas-id* — Specify the name of the NAS (Network Access Server) to be contained in RADIUS packets for identification. It ranges from 1 to 31 characters. The default value is the MAC address of the switch. Generally, the NAS indicates the switch itself.

[ 0 ] *string* | 7 *encrypted-string* — 0 and 7 are the encryption type. 0 indicates that an unencrypted key will follow. 7 indicates that a symmetric

encrypted key with a fixed length will follow. By default, the encryption type is 0. "*string*" is the shared key for the switch and the authentication servers to exchange messages. "*encrypted-string*" is a symmetric encrypted key with a fixed length, which you can copy from another switch's configuration file. The key or encrypted-key you configured here will be displayed in the encrypted form. Always configure the key as the last item of this command.

### Command Mode

Global Configuration Mode

### Privilege Requirement

Only Admin level users have access to these commands.

### User Guidelines

The RADIUS servers you configured are added in the server group "radius" by default.

### Example

Configure a RADIUS server with the IP address as 1.1.1.1, authentication port as 1200, timeout as 6 seconds, retransmit times as 3, and the unencrypted key string as 12345.

```
Switch(config)# radius-server host 1.1.1.1 auth-port 1200 timeout 6
retransmit 3 key 12345
```

## 58.4 show radius-server

### Description

This **show radius-server** command is used to display the summary information of the RADIUS servers.

### Syntax

```
show radius-server
```

### Command Mode

Privileged EXEC Mode and Any Configuration Mode

### Privilege Requirement

Only Admin level users have access to these commands.



## Example

Display the information of all the RADIUS servers:

```
Switch(config)# show radius-server
```

## 58.5 aaa group

### Description

This **aaa group** command is used to create AAA server groups to group existing TACACS+/RADIUS servers for authentication. This command puts the switch in the server group subconfiguration mode.

To delete the corresponding AAA group, please use the **no aaa group** command.

### Syntax

```
aaa group { radius | tacacs } group-name  
no aaa group { radius | tacacs } group-name
```

### Parameter

*radius | tacacs* — Specify the server group type as RADIUS or TACACS+.  
*group-name* — Specify the server group name.

### Command Mode

Global Configuration Mode

### Privilege Requirement

Only Admin level users have access to these commands.

## Example

Create a RADIUS server group with the name radius1:

```
Switch(config)# aaa group radius radius1
```

## 58.6 server

### Description

This **server** command is used to add the existing server in the defined server group. To remove the specified server from the server group, please use the **no server** command.

## Syntax

```
server ip-address  
no server ip-address
```

## Parameter

*ip-address*—— Specify the server's IP address.

## Command Mode

Server Group Configuration Mode

## Privilege Requirement

Only Admin level users have access to these commands.

## Example

Create the RADIUS server 1.1.1.1 to RADIUS server group "radius1":

```
Switch(config)# aaa group radius radius1  
Switch(aaa-group)# server 1.1.1.1
```

# 58.7 show aaa group

## Description

This **show aaa group** command is used to display the summary information of the AAA groups. All the servers in this group will be listed if you specify the group name.

## Syntax

```
show aaa group [ group-name ]
```

## Parameter

*group-name*—— Specify the server group name.

## Command Mode

Privileged EXEC Mode and Any Configuration Mode

## Privilege Requirement

Only Admin level users have access to these commands.

## Example

Display the information of all the server groups:

```
Switch(config)# show aaa group
```

## 58.8 aaa authentication login

### Description

This **aaa authentication login** command is used to configure a login authentication method list. A method list describes the authentication methods and their sequence to authenticate a user. To delete the specified authentication method list, please use the **no aaa authentication login** command.

### Syntax

```
aaa authentication login { method-list } { method1 } [ method2 ] [ method3 ]  
[ method4 ]
```

```
no authentication login method-list
```

### Parameter

*method-list* — Specify the method list name.

*method1, method2, method3, method4* — Specify the authentication methods in order. The next authentication method is tried only if the previous method does not respond, not if it fails.

The preset methods include radius, tacacs, local and none. "radius" means the RADIUS server group "radius"; "tacacs" means the RACACS+ server group "tacacs"; "local" means local username database are used; "none" means no authentication is used for login.

Users can also define new method with the [aaa group](#) command.

### Command Mode

Global Configuration Mode

### Privilege Requirement

Only Admin level users have access to these commands.

### User Guidelines

By default the login authentication method list is "default" with "local" as method1.

### Example

Configure a login authentication method list "list1" with the priority1 method as radius and priority2 method as local:

```
Switch(config)# aaa authentication login list1 radius local
```

## 58.9 aaa authentication enable

### Description

This **aaa authentication enable** command is used to configure a privilege authentication method list. A method list describes the authentication methods and their sequence to elevate a user's privilege. To delete the specified authentication method list, please use the **no aaa authentication enable** command.

### Syntax

```
aaa authentication enable { method-list } { method1 } [ method2 ] [ method3 ]  
[ method4 ]
```

```
no authentication enable method-list
```

### Parameter

*method-list* — Specify the method list name.

*method1, method2, method3, method4* — Specify the authentication methods in order. The next authentication method is tried only if the previous method does not respond, not if it fails.

The preset methods include radius, tacacs, local and none. "radius" means the RADIUS server group "radius"; "tacacs" means the RACACS+ server group "tacacs"; "local" means local username database are used; "none" means no authentication is used for privilege elevation.

Users can also define new method with the [aaa group](#) command.

### Command Mode

Global Configuration Mode

### Privilege Requirement

Only Admin level users have access to these commands.

### User Guidelines

By default the enable authentication method is "default" with "none" as method1.

### Example

Configure a privilege authentication method list "list2" with the priority1 method as radius and priority2 method as local:

```
Switch(config)# aaa authentication enable list2 radius local
```

## 58.10 aaa authentication dot1x default

### Description

This **aaa authentication dot1x default** command is used to configure an 802.1x authentication method list. A method list describes the authentication methods for users' login in 802.1x. To delete the default authentication method list, please use the **no aaa authentication dot1x default** command.

### Syntax

```
aaa authentication dot1x default { method }  
no aaa authentication dot1x default
```

### Parameter

*method* — Specify the method name. Only RADIUS server group is supported, and the default method is server group "radius".

### Command Mode

Global Configuration Mode

### Privilege Requirement

Only Admin level users have access to these commands.

### Example

Configure the default 802.1x authentication method as "radius1":

```
Switch(config)# aaa authentication dot1x default radius1
```

## 58.11 aaa accounting dot1x default

### Description

This **aaa accounting dot1x default** command is used to configure an 802.1x accounting method list. To delete the default accounting method list, please use the **no aaa accounting dot1x default** command.

### Syntax

```
aaa accounting dot1x default { method }
```

**no aaa accounting dot1x default**

### Parameter

*method* — Specify the method name. Only RADIUS server group is supported, and the default method is server group "radius".

### Command Mode

Global Configuration Mode

### Privilege Requirement

Only Admin level users have access to these commands.

### Example

Configure the default 802.1x accounting method as "radius1":

```
Switch(config)# aaa accounting dot1x default radius1
```

## 58.12 show aaa authentication

### Description

This **show aaa authentication** command is used to display the summary information of the authentication login, enable and dot1x method list.

### Syntax

```
show aaa authentication [ login | enable | dot1x ]
```

### Parameter

login | enable | dot1x — Specify the method list type.

### Command Mode

Privileged EXEC Mode and Any Configuration Mode

### Privilege Requirement

Only Admin level users have access to these commands.

### Example

Display the information of all the authentication method lists:

```
Switch(config)# show aaa authentication
```

## 58.13 show aaa accounting

### Description

This **show aaa accounting** command is used to display the summary information of the accounting method list.

### Syntax

```
show aaa accounting [ dot1x ]
```

### Parameter

dot1x — Specify the method list type.

### Command Mode

Privileged EXEC Mode and Any Configuration Mode

### Privilege Requirement

Only Admin level users have access to these commands.

### Example

Display the information of the default 802.1x accounting method list:

```
Switch(config)# show aaa accounting
```

## 58.14 line telnet

### Description

The **line telnet** command is used to enter the Line Configuration Mode to configure the telnet terminal line to which you want to apply the authentication list.

### Syntax

```
line telnet
```

### Command Mode

Global Configuration Mode

### Privilege Requirement

Only Admin level users have access to these commands.

## Example

Enter the telnet terminal line configuration mode:

```
Switch(config)#line telnet
```

## 58.15 login authentication (telnet)

### Description

The **login authentication** command is used to apply the login authentication method list to the telnet terminal line. To restore to the default authentication method list, please use the **no login authentication** command.

### Syntax

```
login authentication { method-list }
```

```
no login authentication
```

### Parameter

*method-list* — Specify the login method list on the telnet terminal line. It is "default" by default, which contains the method "local".

### Command Mode

Line Configuration Mode

### Privilege Requirement

Only Admin level users have access to these commands.

## Example

Configure the login authentication method list on the telnet terminal line as "list1":

```
Switch(config)#line telnet
```

```
Switch(config-line)# login authentication list1
```

## 58.16 line ssh

### Description

The **line ssh** command is used to enter the Line Configuration Mode to configure the ssh terminal line to which you want to apply the authentication list.



## Syntax

**line ssh**

## Command Mode

Global Configuration Mode

## Privilege Requirement

Only Admin level users have access to these commands.

## Example

Enter the ssh terminal line configuration mode:

```
Switch(config)#line ssh
```

# 58.17 login authentication (ssh)

## Description

The **login authentication** command is used to apply the login authentication method list to the ssh terminal line. To restore to the default authentication method list, please use the **no login authentication** command.

## Syntax

**login authentication** { *method-list* }

**no login authentication**

## Parameter

*method-list* — Specify the login method list on the ssh terminal line. It is "default" by default, which contains the method "local".

## Command Mode

Line Configuration Mode

## Privilege Requirement

Only Admin level users have access to these commands.


## Example

Configure the login authentication method list on the ssh terminal line as "list1":

```
Switch(config)# line ssh
```

```
Switch(config-line)# login authentication list1
```

## 58.18 line console

 **Note:** This command is only available on certain devices.

### Description

The **line console** command is used to enter the Line Configuration Mode to configure the console terminal line to which you want to apply the authentication list.

### Syntax

```
line console line-number
```

### Command Mode

Global Configuration Mode

### Privilege Requirement


Only Admin level users have access to these commands.

### Example

Enter the console 0 terminal line configuration mode:

```
Switch(config)#line console 0
```

## 58.19 login authentication (console)

 **Note:** This command is only available on certain devices.

### Description

The **login authentication** command is used to apply the login authentication method list to the console terminal line. To restore to the default authentication method list, please use the **no login authentication** command.

### Syntax

```
login authentication { method-list }
```

```
no login authentication
```

## Parameter

*method-list* — Specify the login method list on the console terminal line. It is "default" by default, which contains the method "local".

## Command Mode

Line Configuration Mode

## Privilege Requirement

Only Admin level users have access to these commands.

## Example

Configure the login authentication method list on the console 0 terminal line as "list1":

```
Switch(config)# line console 0
Switch(config-line)# login authentication list1
```

# 58.20 enable authentication (telnet)

## Description

The **enable authentication** command is used to apply the privilege authentication method list to the telnet terminal line. To restore to the default authentication method list, please use the **no enable authentication** command.

## Syntax

**enable authentication** { *method-list* }

**no enable authentication**

## Parameter

*method-list* — Specify the enable method list on the telnet terminal line. It is "default" by default, which contains the method "none".

## Command Mode

Line Configuration Mode

## Privilege Requirement

Only Admin level users have access to these commands.

## Example

Configure the enable authentication method list on the telnet terminal line as "list2":

```
Switch(config)#line telnet
Switch(config-line)# enable authentication list2
```

## 58.21 enable authentication (ssh)

### Description

The **enable authentication** command is used to apply the privilege authentication method list to the ssh terminal line. To restore to the default authentication method list, please use the **no enable authentication** command.

### Syntax

**enable authentication** { *method-list* }

**no enable authentication**

### Parameter

*method-list* — Specify the enable method list on the ssh terminal line. It is "default" by default, which contains the method "none".

### Command Mode

Line Configuration Mode

### Privilege Requirement

Only Admin level users have access to these commands.

## Example

Configure the enable authentication method list on the ssh terminal line as "list2":

```
Switch(config)# line ssh
Switch(config-line)# enable authentication list2
```

## 58.22 enable authentication (console)



**Note:** This command is only available on certain devices.

### Description

The **enable authentication** command is used to apply the privilege authentication method list to the console terminal line. To restore to the default authentication method list, please use the **no enable authentication** command.

### Syntax

**enable authentication** { *method-list* }

**no enable authentication**

### Parameter

*method-list* — Specify the enable method list on the console terminal line. It is "default" by default, which contains the method "none".

### Command Mode

Line Configuration Mode

### Privilege Requirement

Only Admin level users have access to these commands.

### Example

Configure the enable authentication method list on the console 0 terminal line as "list2":

```
Switch(config)# line console 0
Switch(config-line)# enable authentication list2
```

## 58.23 ip http login authentication

### Description

The **ip http login authentication** command is used to apply the login authentication method list to users accessing through HTTP. To restore to

the default authentication method list, please use the **no ip http login authentication** command.

### Syntax

```
ip http login authentication { method-list }  
no ip http login authentication
```

### Parameter

*method-list* — Specify the login method list on the HTTP access. It is "default" by default, which contains the method "local".

### Command Mode

Global Configuration Mode

### Privilege Requirement

Only Admin level users have access to these commands.

### Example

Configure the login authentication method list on the HTTP access as "list1":

```
Switch(config)# ip http login authentication list1
```

## 58.24 ip http enable authentication

### Description

The **ip http enable authentication** command is used to apply the privilege authentication method list to users accessing through HTTP. To restore to the default authentication method list, please use the **no ip http enable authentication** command.

### Syntax

```
ip http enable authentication { method-list }  
no ip http enable authentication
```

### Parameter

*method-list* — Specify the enable method list on the HTTP access. It is "default" by default, which contains the method "none".

## Command Mode

Line Configuration Mode

## Privilege Requirement

Only Admin level users have access to these commands.

## Example

Configure the enable authentication method list on the HTTP access as "list2":

```
Switch(config)# ip http enable authentication list2
```

# 58.25 show aaa global

## Description

This **show aaa global** command is used to display global status of AAA function and the login/enable method lists of different application modules: telnet, ssh and HTTP.

## Syntax

```
show aaa global
```

## Command Mode

Privileged EXEC Mode and Any Configuration Mode

## Privilege Requirement

Only Admin level users have access to these commands.

## Example

Display the AAA function's global status and each application's method list:

```
Switch(config)# show aaa global
```

# 58.26 enable admin password

## Description

The **enable admin password** command is used to set or change the Enable password for users to change the access level to admin. To remove the Enable password, please use **no enable admin** command. This command uses the symmetric encryption.

## Syntax

**enable admin password** {[ 0 ] *password* | 7 *encrypted-password*}

**no enable admin**

## Parameter

0 — Specify the encryption type. 0 indicates that an unencrypted password will follow. By default, the encryption type is 0.

*password* — Enable password, a string with 31 characters at most, which can contain only English letters (case-sensitive), digits and 17 kinds of special characters. The special characters are **!\$%()'\*,-./\_[]\_{}|**. By default, it is empty. By default, it is empty.

7 — Indicates a symmetric encrypted password with fixed length will follow.

*encrypted-password* — A symmetric encrypted password with fixed length, which you can copy from another switch's configuration file. After the encrypted password is configured, you should use the corresponding unencrypted password if you re-enter this mode.

## Command Mode

Global Configuration Mode

## Privilege Requirement

Only Admin level users have access to these commands.

## User Guidelines

If the password you configured here is unencrypted and the global encryption function is enabled in [service password-encryption](#), the password in the configuration file will be displayed in the symmetric encrypted form.

If both the **enable admin password** and **enable admin secret** are defined, only the latest configured password will take effect.

## Example

Set the Enable password as "abc123" and unencrypted for users to change the access level to admin:

```
Switch(config)#enable admin password 0 abc123
```



## 58.27 enable admin secret

### Description

The **enable admin secret** command is used to set or change the Enable password for users to change the access level to admin. To remove the Enable password, please use **no enable admin** command. This command uses the MD5 encryption.

### Syntax

```
enable admin secret {[ 0] password | 5 encrypted-password}
```

```
no enable admin
```

### Parameter

0 — Specify the encryption type. 0 indicates that an unencrypted password will follow. By default, the encryption type is 0.

*password* — Enable password, a string with 31 characters at most, which can contain only English letters (case-sensitive), digits and 17 kinds of special characters. The special characters are **!\$%'()\*,-./[]\_{}|**. By default, it is empty. By default, it is empty. The password in the configuration file will be displayed in the MD5 encrypted form.

5 — Indicates an MD5 encrypted password with fixed length will follow.

*encrypted-password* — An MD5 encrypted password with fixed length, which you can copy from another switch's configuration file. After the encrypted password is configured, you should use the corresponding unencrypted password if you re-enter this mode.

### Command Mode

Global Configuration Mode

### Privilege Requirement

Only Admin level users have access to these commands.

### User Guidelines

If both the **enable admin password** and **enable admin secret** are defined, only the latest configured password will take effect.

## Example

Set the Enable password as "abc123" and unencrypted for users to change the access level to admin. The password will be displayed in the encrypted form.

```
Switch(config)#enable admin secret 0 abc123
```

## 58.28 enable-admin

### Description

The **enable-admin** command is used to get the administrative privileges by a non-admin user.

### Syntax

```
enable-admin
```

### Command Mode

Privileged EXEC Mode

### Privilege Requirement

Only User, Power User and Operator level users have access to these commands.

### Example

Get the administrative privileges (the Enable password is "123456"):

```
Switch# enable-admin
```

```
Password: 123456
```

## Chapter 59 IEEE 802.1x Commands

IEEE 802.1x function is to provide an access control for LAN ports via the authentication. An 802.1x system include three entities: supplicant, authenticator and authentication server.

- Supplicant: the device that requests access to the LAN.
- Authentication server: performs the actual authentication of the supplicant. It validates the identity of the supplicant and notifies the authenticator whether or not the supplicant is authorized to access the LAN.
- Authenticator: controls the physical access to the network based on the authentication status of the supplicant. It is usually an 802.1x-supported network device, such as this TP-Link switch. It acts as an intermediary (proxy) between the supplicant and the authentication server, requesting identity information from the supplicant, verifying that information with the authentication server, and relaying a response to the supplicant.

This chapter handles with the authentication process between the supplicant and the switch. To realize the authentication and accounting function, you should also enable the AAA function and configure the RADIUS server. Go to [Chapter 42 AAA Commands](#) for more details.

### 59.1 dot1x system-auth-control

#### Description

The **dot1x system-auth-control** command is used to enable the IEEE 802.1x function globally. To disable the IEEE 802.1x function, please use **no dot1x system-auth-control** command.

#### Syntax

```
dot1x system-auth-control  
no dot1x system-auth-control
```

#### Command Mode

Global Configuration Mode

#### Privilege Requirement

Only Admin, Operator and Power User level users have access to these commands.

#### Example

Enable the IEEE 802.1x function:

```
Switch(config)#dot1x system-auth-control
```

## 59.2 dot1x handshake

### Description

The **dot1x handshake** command is used enable the handshake feature. The handshake feature is used to detect the connection status between the TP-Link 802.1x supplicant and the switch. Please disable the handshake feature if you are using a non-TP-Link 802.1x-compliant client software. This feature is enabled by default.

### Syntax

**dot1x handshake**

**no dot1x handshake**

### Command Mode

Global Configuration Mode

### Privilege Requirement

Only Admin, Operator and Power User level users have access to these commands.

### Example

Disable the 802.1x handshake function:

```
Switch(config)# no dot1x handshake
```

## 59.3 dot1x auth-protocol

### Description

The **dot1x auth-protocol** command is used to configure the authentication protocol of IEEE 802.1x and the default 802.1x authentication method is "eap". To restore to the default 802.1x authentication protocol, please use **no dot1x auth-protocol** command.

### Syntax

**dot1x auth-protocol** { pap | eap }

**no dot1x auth-protocol**

### Parameter

pap | eap —Authentication protocols.

pap: EAP termination mode. IEEE 802.1x authentication system uses extensible authentication protocol (EAP) to exchange information between the switch and the client. The EAP packets are terminated at the switch and repackaged in the Password Authentication Protocol (PAP) packets, and then transferred to the RADIUS server.

eap: EAP relay mode. IEEE 802.1x authentication system uses extensible authentication protocol (EAP) to exchange information between the switch and the client. The EAP protocol packets with authentication data are encapsulated in the advanced protocol (such as RADIUS) packets and transmitted to the authentication server.

## Command Mode

Global Configuration Mode

## Privilege Requirement

Only Admin, Operator and Power User level users have access to these commands.

## Example

Configure the Authentication protocol of IEEE 802.1x as "pap":

```
Switch(config)#dot1x auth-protocol pap
```

# 59.4 dot1x vlan-assignment

## Description

The **dot1x vlan-assignment** command is used to enable the VLAN assignment feature. To disable this feature, please use **no dot1x vlan-assignment** command.

802.1x VLAN assignment is a technology allowing the RADIUS server to send the VLAN assignment to the port when the port is authenticated.

If the assigned VLAN does not exist on the switch, the switch will create the related VLAN automatically, add the authenticated port to the VLAN and change the PVID based on the assigned VLAN.

If the assigned VLAN exists on the switch, the switch will directly add the authenticated port to the related VLAN and change the PVID instead of creating a new VLAN.

If no VLAN is supplied by the RADIUS server or if 802.1x authentication is disabled, the port will be in its original VLAN after successful authentication.

## Syntax

**dot1x vlan-assignment**  
**no dot1x vlan-assignment**

## Command Mode

Global Configuration Mode

## Privilege Requirement

Only Admin, Operator and Power User level users have access to these commands.

## Example

Enable the VLAN assignment feature:

```
Switch(config)#dot1x vlan-assignment
```

# 59.5 dot1x accounting

## Description

The **dot1x accounting** command is used to enable the IEEE 802.1x accounting function globally. To disable the IEEE 802.1x accounting function, please use **no dot1x accounting** command.

## Syntax

**dot1x accounting**  
**no dot1x accounting**

## Command Mode

Global Configuration Mode

## Privilege Requirement

Only Admin, Operator and Power User level users have access to these commands.

## Example

Enable the enable the IEEE 802.1x accounting function globally:

```
Switch(config)#dot1x accounting
```

## 59.6 dot1x mab

### Description

The **dot1x mab** command is used to enable the MAB feature on the port. To disable this feature, please use **no dot1x mab** command.

With MAB (MAC-Based Authentication Bypass) feature enabled, the switch automatically sends the authentication server a RADIUS access request frame with the client's MAC address as the username and password. It is also necessary to configure the RADIUS server with the client's information for authentication. You can enable this feature on IEEE 802.1x ports connected to devices without 802.1x capability. For example, most printers, IP phones and fax machines do not have 802.1x capability.

### Syntax

```
dot1x mab  
no dot1x mab
```

### Command Mode

Interface Configuration Mode

### Privilege Requirement

Only Admin, Operator and Power User level users have access to these commands.

### Example

Enable the MAB feature on the Gigabit Ethernet port 1/0/1:

```
Switch(config)#interface gigabitEthernet 1/0/1
```

```
Switch(config-if)#dot1x mab
```

## 59.7 dot1x guest-vlan

### Description

The **dot1x guest-vlan** command is used to configure the Guest VLAN function on the port. To disable the Guest VLAN function, please use **no dot1x guest-vlan** command.

## Syntax

```
dot1x guest-vlan vid
```

```
no dot1x guest-vlan
```

## Parameter

*vid* — The VLAN ID needed to enable the Guest VLAN function, ranging from 0 to 4094. 0 means that Guest VLAN is disabled. The supplicants in the Guest VLAN can access the specified network source.

## Command Mode

Interface Configuration Mode

## Privilege Requirement

Only Admin, Operator and Power User level users have access to these commands.

## Example

Enable the Guest VLAN function for VLAN 5 and set the VLAN ID as 20 on the Gigabit Ethernet port 1/0/1::

```
Switch(config)#interface gigabitEthernet 1/0/1
```

```
Switch(config-if)#dot1x guest-vlan 5
```

## 59.8 dot1x timeout quiet-period

### Description

The **dot1x timeout quiet-period** command is used to enable the quiet-period function on the port. To disable the function, please use **no dot1x timeout quiet-period** command.

### Syntax

```
dot1x timeout quiet-period [ time ]
```

```
no dot1x timeout quiet-period
```

### Parameter

*time* — The length of the quiet-period time. If one user's authentication fails, its subsequent IEEE 802.1x authentication requests will not be processed during the quiet-period time. It ranges from 1 to 999 seconds and the default value is 10 seconds.



## Command Mode

Interface Configuration Mode

## Privilege Requirement

Only Admin, Operator and Power User level users have access to these commands.

## Example

Enable the quiet-period function and set the quiet-period as 5 seconds on the Gigabit Ethernet port 1/0/1:

```
Switch(config)#interface gigabitEthernet 1/0/1
Switch(config-if)#dot1x quiet-period 5
```

# 59.9 dot1x timeout supp-timeout

## Description

The **dot1x timeout supp-timeout** command is used to configure the supplicant timeout on the port. To restore to the default, please use **no dot1x timeout supp-timeout** command.

## Syntax

```
dot1x timeout supp-timeout time
no dot1x timeout supp-timeout
```

## Parameter

*time* —The maximum time for the switch to wait for the response from supplicant before resending a request to the supplicant, ranging from 1 to 60 in second. By default, it is 30 seconds.

## Command Mode

Interface Configuration Mode

## Privilege Requirement

Only Admin, Operator and Power User level users have access to these commands.

## Example

Configure the supplicant timeout value as 5 seconds on the Gigabit Ethernet port 1/0/1:

```
Switch(config)#interface gigabitEthernet 1/0/1
Switch(config-if)#dot1x timeout supp-timeout 5
```

## 59.10 dot1x max-req

### Description

The **dot1x max-req** command is used to configure the maximum transfer times of the repeated authentication request when the server cannot be connected. To restore to the default value, please use **no dot1x max-req** command.

### Syntax

```
dot1x max-req times
no dot1x max-req
```

### Parameter

*times* — The maximum transfer times of the repeated authentication request, ranging from 1 to 9 in times. By default, the value is 3.

### Command Mode

Interface Configuration Mode

### Privilege Requirement

Only Admin, Operator and Power User level users have access to these commands.

### Example

Configure the maximum transfer times of the repeated authentication request as 5 on the Gigabit Ethernet port 1/0/1:

```
Switch(config)#interface gigabitEthernet 1/0/1
Switch(config-if)#dot1x max-req 5
```

## 59.11 dot1x

### Description

The **dot1x** command is used to enable the IEEE 802.1x function for a specified port. To disable the IEEE 802.1x function for a specified port, please use **no dot1x** command.

## Syntax

**dot1x**

**no dot1x**

## Command Mode

Interface Configuration Mode (interface gigabitEthernet / interface range gigabitEthernet )

## Privilege Requirement

Only Admin, Operator and Power User level users have access to these commands.

## Example

Enable the IEEE 802.1x function for the Gigabit Ethernet port 1:

```
Switch(config)#interface gigabitEthernet 1/0/1
```

```
Switch(config-if)#dot1x
```

# 59.12 dot1x port-control

## Description

The **dot1x port-control** command is used to configure the Control Mode of IEEE 802.1x for the specified port. By default, the control mode is "auto". To restore to the default configuration, please use **no dot1x port-control** command.

## Syntax

**dot1x port-control** {auto | authorized-force | unauthorized-force}

**no dot1x port-control**

## Parameter

auto | authorized-force | unauthorized-force — The Control Mode for the port.

auto: In this mode, the port will normally work only after passing the 802.1x Authentication.

authorized-force: In this mode, the port can work normally without passing the 802.1x Authentication.

unauthorized-force: In this mode, the port is forbidden working for its fixed unauthorized status.

## Command Mode

Interface Configuration Mode (interface gigabitEthernet / interface range gigabitEthernet)

## Privilege Requirement

Only Admin, Operator and Power User level users have access to these commands.

## Example

Configure the Control Mode for Gigabit Ethernet port 20 as "authorized-force":

```
Switch(config)#interface gigabitEthernet 1/0/20
Switch(config-if)#dot1x port-control authorized-force
```

# 59.13 dot1x port-method

## Description

The **dot1x port-method** command is used to configure the control type of IEEE 802.1x for the specified port. By default, the control type is "mac-based". To restore to the default configuration, please use **no dot1x port-method** command.

## Syntax

```
dot1x port-method { mac-based | port-based }
```

```
no dot1x port-method
```

## Parameter

mac-based | port-based —The control type for the port.

mac-based: Any client connected to the port should pass the 802.1x authentication for access.

port-based: All the clients connected to the port can access the network on the condition that any one of the clients has passed the 802.1x Authentication.

## Command Mode

Interface Configuration Mode (interface gigabitEthernet / interface range gigabitEthernet)

## Privilege Requirement

Only Admin, Operator and Power User level users have access to these commands.

## Example

Configure the Control Type for Gigabit Ethernet port 20 as "port-based":

```
Switch(config)#interface gigabitEthernet 1/0/20
Switch(config-if)#dot1x port-method port-based
```

# 59.14 dot1x auth-init

## Description

The **dot1x auth-init** command is used to initialize the specific client.

## Syntax

```
dot1x auth-init [ mac mac-address ]
```

## Parameter

*mac-address*: Enter the MAC address of the client that will be unauthorized.

## Command Mode

Interface Configuration Mode (interface gigabitEthernet / interface range gigabitEthernet)

## Privilege Requirement

None.

## Example

Initialize the client whose MAC address is a 00:02:58:4f:6c:23 on port 1:

```
Switch(Config)# interface gigabitEthernet 1/0/1
Switch(Config-if)#dot1x auth-init mac 00:02:58:4f:6c:23
```

# 59.15 dot1x auth-reauth

## Description

The **dot1x auth-reauth** command is used to reauthenticate the specific client.

## Syntax

```
dot1x auth-reauth [ mac mac-address]
```

## Parameter

*mac-address*: Enter the MAC address of the client that will be reauthenticated.

## Command Mode

Interface Configuration Mode (interface gigabitEthernet / interface range gigabitEthernet)

## Privilege Requirement

None.

## Example

Reauthenticate the client whose MAC address is a 00:02:58:4f:6c:23 on port 1:

```
Switch(Config)# interface gigabitEthernet 1/0/1
Switch(Config-if)#dot1x auth-reauth mac 00:02:58:4f:6c:23
```

# 59.16 show dot1x global

## Description

The **show dot1x global** command is used to display the global configuration of 801.X.

## Syntax

```
show dot1x global
```

## Command Mode

Privileged EXEC Mode and Any Configuration Mode

## Privilege Requirement

None.

## Example

Display the configuration of 801.X globally:

```
Switch(config)#show dot1x global
```

## 59.17 show dot1x interface

### Description

The **show dot1x interface** command is used to display all ports or the specified port's configuration information of 801.X.

### Syntax

```
show dot1x interface [ gigabitEthernet port]
```

### Parameter

*port*—— The Ethernet port number. If not specified, the information of all the ports will be displayed.

### Command Mode

Privileged EXEC Mode and Any Configuration Mode

### Privilege Requirement

None.

### Example

Display the configuration information of 801.X for Gigabit Ethernet port 20:

```
Switch(config)#show dot1x interface gigabitEthernet 1/0/20
```

Display the configuration information of 801.X for all Ethernet ports:

```
Switch(config)#show dot1x interface
```

## 59.18 show dot1x auth-state interface

### Description

The **show dot1x auth-state interface** command is used to display the authentication status of each port.

### Syntax

```
show dot1x auth-state interface [ fastEthernet port | gigabitEthernet port |  
ten-gigabitEthernet port]
```

### Parameter

*port*—— The Ethernet port number. If not specified, the information of all the ports will be displayed.

## Command Mode

Privileged EXEC Mode and Any Configuration Mode

## Privilege Requirement

None.

## Example

Display the authentication status of each port:

```
Switch(config)#show dot1x auth-state interface
```



# Chapter 60 Port Security Commands

You can limit the number of MAC addresses that can be learned on each port on this page, thus preventing the MAC address table from being exhausted by the attack packets.

## 60.1 mac address-table max-mac count

### Description

The **mac address-table max-mac-count** command is used to enable the port security feature of the port and configure the related parameters. To disable the feature and restore the parameters to defaults on the port, please use **no mac address-table max-mac-count** command.

### Syntax

```
mac address-table max-mac-count [ [ max-number num ]  
[ exceed-max-learned enable | disable ] [ mode { dynamic | static |  
permanent } ] [ status { forward | drop | disable } ] ]  
no mac address-table max-mac-count [ max-number | mode | status ]
```

### Command Mode

Interface Configuration Mode

### Privilege Requirement

Only Admin, Operator and Power User level users have access to these commands.

### Example

Set the maximum number of MAC addresses that can be learned on port 1/0/1 as 30, enable exceed-max-learned feature and configure the mode as permanent and the status as drop:

```
Switch (config)#interface gigabitEthernet 1/0/1  
Switch(config-if)#mac address-table max-mac-count max-number 30  
exceed-maxlearned enable mode permanent status drop
```

## 60.2 show mac address-table max-mac-count

### Description

The **show mac address-table max-mac-count** command is used to display the port security configuration on each port.

### Syntax

```
show mac address-table max-mac-count interface { fastEthernet port |  
gigabitEthernet port| ten-gigabitEthernet port}
```

### Command Mode

Privileged EXEC Mode and Any Configuration Mode

### Privilege Requirement

None.

### Example

Display the port security configuration on port 1/0/1

```
Switch# show mac address-table max-mac-count interface  
gigabitEthernet 1/0/1
```

# Chapter 61 Port Mirroring Commands

Port Mirroring allows the switch to send a copy of the traffic that passes through specified sources (ports, LAGs or the CPU) to a destination port. It does not affect the switching of network traffic on source ports, LAGs or the CPU. Usually, the monitoring port is connected to data diagnose device, which is used to analyze the monitored packets for monitoring and troubleshooting the network.

## 61.1 monitor session destination interface

### Description

The **monitor session destination interface** command is used to configure the monitoring port. Each monitor session has only one monitoring port. To change the monitoring port, please use the **monitor session destination interface** command by changing the port value. The **no monitor session** command is used to delete the corresponding monitoring port or monitor session.

### Syntax

```
monitor session session_num destination interface gigabitEthernet port  
no monitor session session_num destination interface gigabitEthernet  
port  
no monitor session session_num
```

### Parameter

*session\_num* — The monitor session number, can only be specified as 1.  
*port* — The monitoring port number.

### Command Mode

Global Configuration Mode

### Privilege Requirement

Only Admin, Operator and Power User level users have access to these commands.

### Example

Create monitor session 1 and configure port 1/0/1 as the monitoring port:

```
Switch(config)# monitor session 1 destination interface gigabitEthernet
1/0/1
```

Delete the monitoring port 1/0/2 from monitor session 1:

```
Switch(config)# no monitor session 1 destination interface
gigabitEthernet 1/0/2
```

Delete the monitor session 1:

```
Switch(config)# no monitor session 1
```

## 61.2 monitor session source

### Description

The **monitor session source** command is used to configure the monitored interface. To delete the corresponding monitored interface, please use **no monitor session source** command.

### Syntax

```
monitor session session_num source { cpu cpu_number | interface
gigabitEthernet port-list | interface port-channel port-channel-id } mode
no monitor session session_num source { cpu cpu_number | interface
gigabitEthernet port-list | interface port-channel port-channel-id } mode
```

### Parameter

*session\_num*—— The monitor session number. It can only be specified as 1.

*cpu\_number*—— The CPU number. It can only be specified as 1.

*port-list*—— List of the Ethernet port number. It is multi-optional.

*lag-list*—— List of LAG interfaces. It is multi-optional.

*mode* —— The monitor mode. There are three options: rx, tx and both. Rx (ingress monitoring mode), means the incoming packets received by the monitored interface will be copied to the monitoring port. Tx (egress monitoring mode), indicates the outgoing packets sent by the monitored interface will be copied to the monitoring port. Both (ingress and egress monitoring), presents the incoming packets received and the outgoing packets sent by the monitored interface will both be copied to the monitoring port.

### Command Mode

Global Configuration Mode

## Privilege Requirement

Only Admin, Operator and Power User level users have access to these commands.

## User Guidelines

1. The monitoring port is corresponding to current interface configuration mode.
2. Monitored ports number is not limited, but it can't be the monitoring port at the same time.
3. Whether the monitoring port and monitored ports are in the same VLAN or not is not demanded strictly.
4. The monitoring port and monitored ports cannot be link-aggregation member.

## Example

Create monitor session 1, then configure port 4, 5, 7 as monitored port and enable ingress monitoring:

```
Switch(config)# monitor session 1 source interface gigabitEthernet  
1/0/4-5,1/0/7 rx
```

Delete port 4 in monitor session 1 and its configuration:

```
Switch(config)# no monitor session 1 source interface gigabitEthernet  
1/0/4 rx
```

## 61.3 monitor session 1 destination remote vlan

### Description

The **monitor session 1 destination remote vlan** command is used to configure the RSPAN VLAN for remote port monitoring of egress packets. Please set the destination port before using this command. To disable this function, please use the **no monitor session 1 destination remote vlan** command.

### Syntax

```
monitor session 1 destination remote vlan vlanid
```

```
no monitor session 1 destination remote vlan vlanid
```

### Parameter

vlanid — Remote port monitoring export message VLAN. The value ranges from 2 to 4094 and is mutually exclusive with voice VLAN and internal VLAN.

### Command Mode

Global Configuration Mode

### Privilege Requirement

Only Admin, Operator and Power User level users have access to these commands.

### Example

Configure the RSPAN VLAN for remote port monitoring of egress packets:

```
Switch(config)#monitor session 1 destination remote vlan 4094
```

## 61.4 monitor session 1 source remote vlan

### Description

The **monitor session 1 source remote vlan** command is used to monitor the packets added to the RSPAN VLAN port. To disable this function, use the **no monitor session 1 source remote vlan** command.

### Syntax

```
monitor session 1 source remote vlan vlanid
```

```
no monitor session 1 source remote vlan vlanid
```

### Parameter

vlanid — Remote port monitoring export message VLAN. The value ranges from 2 to 4094 and is mutually exclusive with voice VLAN and internal VLAN.

### Command Mode

Global Configuration Mode

### Privilege Requirement

Only Admin, Operator and Power User level users have access to these commands.

### Example

Monitor the packets added to the RSPAN VLAN port:

```
Switch(config)#monitor session 1 source remote vlan 4094
```

## 61.5 show monitor session

### Description

The **show monitor session** command is used to display the configuration of port monitoring.

### Syntax

```
show monitor session [session_num]
```

### Parameter

*session\_num* — The monitor session number, can only be specified as 1. It is optional.

### Command Mode

Privileged EXEC Mode and Any Configuration Mode

### Privilege Requirement

None.

### Example

Display the monitoring configuration of monitor session 1:

```
Switch(config)# show monitor session 1
```

# Chapter 62 ACL Commands

ACL (Access Control List) is used to filter data packets by configuring a series of match conditions, operations and time ranges. It provides a flexible and secured access control policy and facilitates you to control the network security.

## 62.1 access-list create

### Description

The **access-list create** command is used to create an ACL.

### Syntax

**access-list create** *acl-id* [ **name** *acl-name* ]

**no access-list create** { *acl-id* }

### Parameter

*acl-id* — Enter an ACL ID. The IDs for MAC ACL are from 0 to 499. The IDs for IP ACL are from 500 to 999. The IDs for Combined ACL are from 1000 to 1499. The IDs for IPv6 ACL are from 1500 to 1999. The IDs for Packet Content ACL are from 2000 to 2499.

**Note:** Packet Content ACL is only available on certain devices.

*acl-name* — Enter a name to identify the ACL.

### Command Mode

Global Configuration Mode

### Privilege Requirement

Only Admin, Operator and Power User level users have access to these commands.

### Example

Create an IP ACL whose ID is 523:

```
Switch(config)# access-list create 523
```

## 62.2 access-list packet-content profile



**Note:** This command is only available on certain devices.



## Description

The **access-list packet-content profile** command is used to specify the offset of each chunk. There are four chunks to be configured. They must be configured before you configure the chunk value&mask.

## Syntax

```
access-list packet-content profile chunk-offset0 offset0 chunk-offset1  
offset1 chunk-offset2 offset2 chunk-offset3 offset3
```

## Parameter

*offset0 -offset3*: Specify the offset of each chunk. The value ranges from 0 to 31. When the offset is set as 31, it matches the first 127,128, 1, 2 bytes of the packet; when the offset is set as 0, it matches the 3, 4, 5, 6 bytes, and so on, for the rest of the offset value.

## Command Mode

Global Configuration Mode

## Privilege Requirement

Only Admin, Operator and Power User level users have access to these commands.

## Example

Configure a packet content profile with offset 0,1,2,3:

```
Switch(config)# access-list packet-content profile chunk-offset0 0  
chunk-offset1 1 chunk-offset2 2 chunk-offset3 3
```

## 62.3 access-list resequence

### Description

The **access-list resequence** command is used to resequence the rules by providing a Start Rule ID and Step value.

### Syntax

```
access-list resequence acl-id-or-name start start-rule-id step  
rule-id-step-value
```

### Parameter

*acl-id-or-name*—— The ACL ID or name.

*start-rule-id*—— The start rule ID.

*rule-id-step-value*—— The step value.

## Command Mode

Global Configuration Mode

## Privilege Requirement

Only Admin, Operator and Power User level users have access to these commands.

## Example

Resequence the rules of ACL 12 with the start ID as 1 and step value as 5:

```
Switch(config)# access-list resequence 12 start 1 step 5
```

# 62.4 access-list mac

## Description

The **access-list mac** command is used to create MAC ACL. To delete the MAC ACL, please use **no access-list mac**.

## Syntax

```
access-list mac acl-id-or-name rule { auto | rule-id } { deny | permit } logging  
{enable | disable} [smac source-mac smask source-mac-mask ] [dmac  
destination-mac dmask destination-mac-mask ] [type ether-type] [pri  
dot1p-priority] [vid vlan-id] [tseg time-range-name]
```

```
no access-list mac acl-id-or-name rule rule-id
```

## Parameter

*acl-id-or-name* — Enter the ID or name of the ACL that you want to add a rule for.

auto — The rule ID will be assigned automatically and the interval between rule IDs is 5.

*rule-id* — Assign an ID to the rule.

deny | permit — Specify the action to be taken with the packets that match the rule. By default, it is set to permit. The packets will be discarded if "deny" is selected and forwarded if "permit" is selected.

enable | disable — Enable or disable Logging function for the ACL rule. If "enable" is selected, the times that the rule is matched will be logged every 5 minutes. With ACL Counter trap enabled, a related trap will be generated if the matching times changes.

*source-mac* — Enter the source MAC address. The format is FF:FF:FF:FF:FF:FF.

*source-mac-mask* — Enter the mask of the source MAC address. This is required if a source MAC address is entered. The format is FF:FF:FF:FF:FF:FF.

*destination-mac* — Enter the destination MAC address. The format is FF:FF:FF:FF:FF:FF.

*destination-mac-mask* — Enter the mask of the destination MAC address. This is required if a destination MAC address is entered. The format is FF:FF:FF:FF:FF:FF.

*ether-type* — Specify an Ethernet-type with 4 hexadecimal numbers.

*dot1p-priority*. The user priority ranges from 0 to 7. The default is No Limit.

*vlan-id* — The VLAN ID ranges from 1 to 4094.

*time-range-name* — The name of the time-range. The default is No Limit.

## Command Mode

Global Configuration Mode

## Privilege Requirement

Only Admin, Operator and Power User level users have access to these commands.

## Example

Create MAC ACL 50 and configure Rule 5 to permit packets with source MAC address 00:34:a2:d4:34:b5:

```
Switch (config)#access-list create 50
Switch (config-mac-acl)#access-list mac 50 rule 5 permit logging disable
smac 00:34:a2:d4:34:b5 smask ff:ff:ff:ff:ff:ff
```

# 62.5 access-list ip

## Description

The **access-list ip** command is used to add IP ACL rule. To delete the corresponding rule, please use **no access-list ip** command. IP ACLs analyze and process data packets based on a series of match conditions, which can be the source IP addresses and destination IP addresses carried in the packets.

## Syntax

```
access-list ip acl-id-or-name rule {auto | rule-id} {deny | permit} logging
{enable | disable} [sip sip-address sip-mask sip-address-mask] [dip
dip-address dip-mask dip-address-mask] [dscp dscp-value] [tos tos-value]
```

**[pre *pre-value*] [frag enable | disable] [protocol *protocol*][s-port *s-port-number*] [s-port-mask *s-port-mask*] [d-port *d-port-number*] [d-port-mask *d-port-mask*] [tcpflag *tcpflag*]] [tseg *time-range-name*]**  
**no access-list ip *acl-id-or-name* rule *rule-id***

## Parameter

*acl-id-or-name* — Enter the ID or name of the ACL that you want to add a rule for.

auto — The rule ID will be assigned automatically and the interval between rule IDs is 5.

*rule-id* — Assign an ID to the rule.

deny | permit — Specify the action to be taken with the packets that match the rule. By default, it is set to permit. The packets will be discarded if "deny" is selected and forwarded if "permit" is selected.

**logging {enable | disable}** — Enable or disable Logging function for the ACL rule. If "enable " is selected, the times that the rule is matched will be logged every 5 minutes. With ACL Counter trap enabled, a related trap will be generated if the matching times changes.

*src-address* — Enter the source IP address.

*src-address-mask* — Enter the mask of the source IP address. This is required if a source IP address is entered.

*dst-address* — Enter the destination IP address.

*dst-address-mask* — Enter the mask of the destination IP address. This is required if a destination IP address is entered.

*dscp-value* — Specify the DSCP value between 0 and 63.

*tos-value* — Specify an IP ToS value to be matched between 0 and 15.

*pre-value* — Specify an IP Precedence value to be matched between 0 and 7.

**frag {enable | disable}** — Enable or disable matching of fragmented packets. The default is disable. When enabled, the rule will apply to all fragmented packets and always permit to forward the last fragment of a packet.

**Note:** **frag {enable | disable}** is only available on certain devices.

*protocol* — Specify a protocol type.

*s-port-number* — Specify the source port number.

*s-port-mask* — Specify the source port mask with 4 hexadecimal numbers.

*d-port-number* — Specify the destination port number.

*d-port-mask* — Specify the destination port mask with 4 hexadecimal numbers.

*tcpflag* — For TCP protocol, specify the flag value using either binary numbers or \* (for example, 01\*010\*). The default is \*, which indicates that the flag will not be matched. The flags are URG (Urgent flag), ACK (acknowledge flag), PSH(push flag), RST(reset flag),SYN(synchronize flag), and FIN(finish flag).

*time-range-name* — The name of the time-range. The default is No Limit.

## Command Mode

Global Configuration Mode

## Privilege Requirement

Only Admin, Operator and Power User level users have access to these commands.

## Example

Create IP ACL 600, and configure Rule 1 to permit packets with source IP address 192.168.1.100:

```
Switch (config)#access-list create 600
Switch (config)#access-list ip 600 rule 1 permit logging disable sip
192.168.1.100 sip-mask 255.255.255.255
```

# 62.6 access-list combined

## Description

The **access-list combined** command is used to add Combined ACL rule. To delete the corresponding rule, please use **no access-list extended** command.

## Syntax

```
access-list combined acl-id-or-name rule {auto | rule-id} {deny | permit}
logging {enable | disable} [smac source-mac-address smask
source-mac-mask] [dmac dest-mac-address dmask dest-mac-mask] [vid
vlan-id] [type ether-type] [pri priority] [sip source-ip-address sip-mask
source-ip-mask] [dip destination-ip-address dip-mask destination-ip-mask]
[dscp dscp-value] [tos tos-value] [pre pre-value] [protocol protocol] [s-port
s-port-number s-port-mask s-port-mask] [d-port d-port-number
d-port-mask d-port-mask] [tcpflag tcpflag] [tseg time-range-name]
no access-list combined acl-id-or-name rule rule-id
```

## Parameter

*acl-id-or-name* — Enter the ID or name of the ACL that you want to add a rule for.

*auto* — The rule ID will be assigned automatically and the interval between rule IDs is 5.

*rule-id* — Assign an ID to the rule.

*deny | permit* — Specify the action to be taken with the packets that match the rule. By default, it is set to permit. The packets will be discarded if "deny" is selected and forwarded if "permit" is selected.

**logging** {*enable | disable*} — Enable or disable Logging function for the ACL rule. If "enable " is selected, the times that the rule is matched will be logged every 5 minutes. With ACL Counter trap enabled, a related trap will be generated if the matching times changes.

*source-mac-address* — Enter the source MAC address.

*source-mac-mask* — Enter the source MAC address mask.

*dest-mac-address* — Enter the destination MAC address.

*dest-mac-mask* — Enter the destination MAC address mask. This is required if a destination MAC address is entered.

*vlan-id*: The VLAN ID ranges from 1 to 4094.

*ether-type* — Specify the Ethernet-type with 4 hexadecimal numbers.

*priority* — The user priority ranges from 0 to 7. The default is No Limit.

*source-ip*: Enter the source IP address.

*source-ip-mask* — Enter the mask of the source IP address. It is required if source IP address is entered.

*destination-ip* — This is required if a source IP address is entered.

*destination-ip-mask* — Enter the destination IP address mask. This is required if a destination IP address is entered.

*dscp-value* — Specify the DSCP value between 0 and 63.

*tos-value* — Specify an IP ToS value to be matched between 0 and 15.

*pre-value* — Specify an IP Precedence value to be matched between 0 and 7.

*protocol* — Specify a protocol type.

*s-port-number* — Specify the source port number.

*s-port-mask* — Specify the source port mask with 4 hexadecimal numbers.

*d-port-number* — Specify the destination port number.

*d-port-mask* — Specify the destination port mask with 4 hexadecimal numbers.

*tcpflag* — For TCP protocol, specify the flag value using either binary numbers or \* (for example, 01\*010\*). The default is \*, which indicates that the flag will not be matched. The flags are URG (Urgent flag), ACK (acknowledge flag), PSH(push flag), RST(reset flag),SYN(synchronize flag), and FIN(finish flag).

*time-range-name* — The name of the time-range. The default is No Limit.

## Command Mode

Global Configuration Mode

## Privilege Requirement

Only Admin, Operator and Power User level users have access to these commands.

## Example

Create Combined ACL 1100 and configure Rule 1 to deny packets with source IP address 192.168.3.100 in VLAN 2:

```
Switch(config)# access-list create 1100
Switch(config)# access-list combined 1100 logging disable rule 1 permit
vid 2 sip 192.168.3.100 sip-mask 255.255.255.255
```

# 62.7 access-list ipv6

## Description

The **access-list ipv6** command is used to add IPv6 ACL rule. To delete the corresponding rule, please use **no access-list ipv6** command. IPv6 ACLs analyze and process data packets based on a series of match conditions, which can be the source IP addresses and destination IP addresses carried in the packets, the DSCP and flow-label value, etc.

## Syntax

```
access-list ipv6 acl-id-or-name rule {auto | rule-id} {deny | permit} logging
{enable | disable} [class class-value] [flow-label flow-label-value] [sip
source-ip-address sip-mask source-ip-mask] [dip destination-ip-address
dip-mask destination-ip-mask] [s-port source-port-number] [d-port
destination-port-number] [tseg time-range-name]
no access-list ipv6 acl-id-or-name rule rule-id
```

## Parameter

*acl-id-or-name* — Enter the ID or name of the ACL that you want to add a rule for.

*auto* — The rule ID will be assigned automatically and the interval between rule IDs is 5.

*rule-id* — Assign an ID to the rule.

*deny | permit* — Specify the action to be taken with the packets that match the rule. By default, it is set to permit. The packets will be discarded if "deny" is selected and forwarded if "permit" is selected.

**logging** {enable | disable} — Enable or disable Logging function for the ACL rule. If "enable " is selected, the times that the rule is matched will be logged every 5 minutes. With ACL Counter trap enabled, a related trap will be generated if the matching times changes.

*class-value* — Specify a class value to be matched. It ranges from 0 to 63.

*flow-label-value* — Specify a Flow Label value to be matched.

*source-ip-address* — Enter the source IP address. Enter the destination IPv6 address to be matched. All types of IPv6 address will be checked. You may enter a complete 128-bit IPv6 address but only the first 64 bits will be valid.

*source-ip-mask* — Enter the source IP address mask. The mask is required if the source IPv6 address is entered. Enter the mask in complete format (for example, ffff:ffff:0000:ffff). The mask specifies which bits in the source IPv6 address to match the rule.

*destination-ip-address* — Enter the destination IPv6 address to be matched. All types of IPv6 address will be checked. You may enter a complete 128-bit IPv6 addresses but only the first 64 bits will be valid.

*destination-ip-mask*: Enter the source IP address mask. The mask is required if the source IPv6 address is entered. Enter the mask in complete format (for example, ffff:ffff:0000:ffff). The mask specifies which bits in the source IPv6 address to match the rule.

*source-port-number* — Enter the TCP/UDP source port if TCP/UDP protocol is selected.

*destination-port-number* — Enter the TCP/UDP destination port if TCP/UDP protocol is selected.

*time-range-name* — The name of the time-range. The default is No Limit.



## Command Mode

Global Configuration Mode

## Privilege Requirement

Only Admin, Operator and Power User level users have access to these commands.

## User Guidelines

Before binding an IPv6 ACL to a VLAN or interface, you should configure the SDM template as "enterpriseV6" and save your configurations.

## Example

Create IPv6 ACL 1600 and configure Rule 1 to deny packets with source IPv6 address CDCD:910A:2222:5498:8475:1111:3900:2020:

```
Switch(config)# access-list create 1600
Switch(config)# access-list ipv6 1600 rule 1 deny logging disable sip
CDCD:910A:2222:5498:8475:1111:3900:2020 sip-mask ffff:ffff:ffff:ffff
```

# 62.8 access-list packet-content config



**Note:** This command is only available on certain devices.

## Description

The **access-list packet-content config** command is used to add Packet Content ACL rule. To delete the corresponding rule, please use **no access-list packet-content config** command. Packet content ACLs analyze and process data packets based on 4 chunk match conditions, each chunk can specify a user-defined 4-byte segment carried in the packet's first 128 bytes.

## Syntax

```
access-list packet-content config acl-id-or-name rule {auto / rule-id} {deny | permit} logging {enable | disable} [chunk0 value mask0 mask] [chunk1 value mask1 mask] [chunk2 value mask2 mask] [chunk3 value mask3 mask] [tseg time-segment]
```

```
no access-list packet-content config acl-id-or-name rule rule-id
```

## Parameter

*acl-id-or-name* — Enter the ID or name of the ACL that you want to add a rule for.

*auto* — The rule ID will be assigned automatically and the interval between rule IDs is 5.

*rule-id* — Assign an ID to the rule.

*deny | permit* — Specify the action to be taken with the packets that match the rule. Deny means to discard; permit means to forward. By default, it is set to permit.

**logging** {enable | disable} — Enable or disable Logging function for the ACL rule. If "enable" is selected, the times that the rule is matched will be logged every 5 minutes. With ACL Counter trap enabled, a related trap will be generated if the matching times changes.

*value* — Specify the chunk value, ranging from 0-ffffff.

*mask* — Specify the chunk mask, ranging from 0-ffffff. Chunk mask here must be written completely in 4-byte hex mode, like '0000ffff'.

*time-segment* — The name of the time-range. The default is No Limit.

## Command Mode

Global Configuration Mode

## Privilege Requirement

Only Admin, Operator and Power User level users have access to these commands.

## Example

Create a packet-content ACL rule with all 4 chunks configured, the rule id is 1 and the default action is permit:

```
SwitchSwitch(config)# access-list packet-content config rule 1 permit
logging disable chunk0 45ea mask0 0000ffff chunk1 1111ffff mask1 ffffffff
chunk2 ee34 mask2 ffff0000 chunk3 7878 mask3 000ffae3
```

# 62.9 access-list action

## Description

The **access-list action** command is used to specify a rule to be configured with policies and enter Action Configuration mode. To delete the corresponding policies, please use **no access-list action** command.

## Syntax

**access-list action** *acl-id-or-name* **rule** *rule-id*

**no access-list action** *acl-id-or-name* **rule** *rule-id*

## Parameter

*acl-id-or-name*—— Enter the ID or name of the ACL.

*rule-id*—— Enter the ID of the ACL rule.

## Command Mode

Global Configuration Mode

## Privilege Requirement

Only Admin, Operator and Power User level users have access to these commands.

## Example

Specify the rule 1 of ACL 200 to be configured with policies:

```
Switch(config)# access-list action 200 rule 1
```

# 62.10 redirect

## Description

The **redirect interface** command is used to define the policy to redirect the matched packets to the desired port. To disable this policy, please use **no redirect interface** command.

## Syntax

**redirect interface** { **fastEthernet** *port* | **gigabitEthernet** *port* | **ten-gigabitEthernet** *port* }

**no redirect interface** { **fastEthernet** *port* | **gigabitEthernet** *port* | **ten-gigabitEthernet** *port* }

## Parameter

*port* —— The destination port to which the packets will be redirected. The default is All.

## Command Mode

Action Configuration Mode

## Privilege Requirement

Only Admin, Operator and Power User level users have access to these commands.

## Example

Define the policy to redirect the matched packets to port 1/0/1 for rule 1 of ACL 6:

```
Switch(config)# access-list action 6 rule 1
Switch(config-action)# redirect interface gigabitEthernet 1/0/1
```

## 62.11 s-condition

### Description

The **s-condition** command is used to limit the rate of the matched packets. To restore the settings to the defaults, please use **no s-condition**.

### Syntax

```
s-condition rate rate burst burst-size osd { none | discard | remark dscp dscp }
```

```
no s-condition
```

### Parameter

*rate* — Specify a rate, ranging from 0 to 1000000kbps.

*burst-size* — Specify the number of bytes allowed in one second ranging from 1 to 128.

**osd** — Select either "none" or "discard" as the action to be taken for the packets whose rate is beyond the specified rate. The default is None. When "remark dscp" is selected, you also need to specify the DSCP value for the matched packets. The DSCP value ranges from 0 to 63.

**Note:** Remark DSCP is only available on certain devices.

### Command Mode

Action Configuration Mode

### Privilege Requirement

Only Admin, Operator and Power User level users have access to these commands.

### Example

Configure a policy for rule 1 of ACL 6: limit the transmission rate of the matched packets as 1000 Kbps and if the number of bytes per second is beyond 100, the packets will be discarded by the switch:

```
Switch(config)#access-list action 6 rule 1
Switch(config-action)# s-condition rate 1000 burst 100 osd discard
```

## 62.12 s-mirror

### Description

The **s-mirror** command is used to define the policy to mirror the matched packets to the desired port. To disable this policy, please use **no s-mirror** command.

### Syntax

```
s-mirror interface { fastEthernet port | gigabitEthernet port |  
ten-gigabitEthernet port }
```

### Parameter

*port*—— The destination port to which the packets will be mirrored.

### Command Mode

Action Configuration Mode

### Privilege Requirement

Only Admin, Operator and Power User level users have access to these commands.

### Example

Configure a policy for rule 1 of ACL 6: specify the mirror port as Gigabit Ethernet port 1/0/2 for the data packets matching this rule:

```
Switch(config)#access-list action 6 rule 1  
Switch(config-action)#s-mirror interface gigabitEthernet 1/0/2
```

## 62.13 qos-remark

### Description

The **qos-remark** command is used to configure QoS Remark function of policy action. To restore the settings to the default, please use **no qos-remark**.

### Syntax

```
qos-remark [ dscp dscp ] [ priority pri ] [ dot1p dot1p-pri ]  
no qos-remark
```

### Parameter

*dscp* —— DSCP of QoS Remark. Specify the DSCP region for the data packets matching the corresponding ACL. DSCP ranges from 0 to 63. By default, it is not limited.

*pri* — Local Priority of QoS Remark. Specify the local priority for the data packets matching the corresponding ACL. Local Priority ranges from 0 to 7.

*dot1p-pri* — 802.1P priority of QoS Remark. This remark configuration will change the data packet's 802.1P priority field to the dot1p-pri you set. 802.1P priority ranges from 0 to 7.



**Note:** The DSCP and dot1p cannot be configured at the same time.

## Command Mode

Action Configuration Mode

## Privilege Requirement

Only Admin, Operator and Power User level users have access to these commands.

## Example

Configure a policy for rule 1 of ACL 6: specify the DSCP region as 30 and local priority 2 for the packets matching this rule:

```
Switch(config)#access-list action 6 rule 1
```

```
Switch(config-action)# qos-remark dscp 30 priority 2
```

# 62.14 access bind

## Description

The **access-list policy name** command is used to add Policy. To delete the corresponding Policy, please use **no access-list policy name** command. A Policy is used to control the data packets those match the corresponding ACL rules.

## Syntax

```
access-list bind acl-id-or-name interface { [ vlan vlan-list ] | [ fastEthernet port-list ] | [ gigabitEthernet port-list ] | [ ten-gigabitEthernet port-list ] }
```

```
no access-list bind acl-id-or-name interface { [ vlan vlan-list ] | [ fastEthernet port-list ] | [ gigabitEthernet port-list ] | [ ten-gigabitEthernet port-list ] }
```

## Parameter

*acl-id-or-name* — Enter the ID or name of the ACL that you want to add a rule for.

*vlan-list* — Specify the ID or the ID list of the VLAN(s) that you want to bind the ACL to. The valid values are from 1 to 4094, for example, 2-3,5.

*port-list* — Specify the number or the list of the Ethernet port that you want to bind the ACL to.

### Command Mode

Global Configuration Mode

### Privilege Requirement

Only Admin, Operator and Power User level users have access to these commands.

### Example

Bind ACL 1 to port 3 and VLAN 4:

```
Switch(config)#access-list bind 1 interface vlan 4 gigabitEthernet 1/0/3
```

## 62.15 show access-list

### Description

The **show access-list** command is used to display configuration of ACL.

### Syntax

```
show access-list acl-id-or-name
```

### Parameter

*acl-id-or-name* — The ID or name of the ACL selected to display the configuration.

### Command Mode

Privileged EXEC Mode and Any Configuration Mode

### Privilege Requirement

None.

### Example

Display the configuration of the MAC ACL whose ID is 20:

```
Switch(config)# show access-list 20
```

## 62.16 show access-list bind

### Description

The **show access-list bind** command is used to display the configuration of ACL binding.

## Syntax

```
show access-list bind
```

## Command Mode

Privileged EXEC Mode and Any Configuration Mode

## Privilege Requirement

None.

## Example

Display the configuration of Policy bind:

```
Switch(config)# show access-list bind
```

# 62.17 show access-list status

## Description

The **show access-list status** command is used to display usage status of ACL entry resource.

## Syntax

```
show access-list status
```

## Command Mode

Privileged EXEC Mode and Any Configuration Mode

## Privilege Requirement

None.

## Example

Display the usage status of ACL entry resource:

```
Switch(config)# show access-list status
```

# 62.18 show access-list counter

## Description

The **show access-list counter** command is used to display the packet counter of a specified ACL.

## Syntax

```
show access-list acl-id-or-name counter
```

## Parameter

*acl-id-or-name* — The ID or name of the ACL to display.



## Command Mode

Privileged EXEC Mode and Any Configuration Mode

## Privilege Requirement

None.

## Example

Display the packet counter of ACL 100:

```
Switch(config)# show access-list 100 counter
```

# 62.19 clear access-list

## Description

The **clear access-list** command is used to clear the counter of matched packets of a specified ACL or rule.

## Syntax

```
clear access-list acl-id-or-name [rule rule-id]
```

## Parameter

*acl-id-or-name*— The ID or name of the ACL.

*rule-id*— The ID of the rule.

## Command Mode

Privileged EXEC Mode and Any Configuration Mode

## Privilege Requirement

None.

## Example

Clear the packet counter of ACL 100:

```
Switch(config)# clear access-list 100
```

## Chapter 63 IPv4 IMPB Commands

You can bind the IP address, MAC address, VLAN and the connected Port number of the Host together, which can be the condition for the ARP Inspection and IP verify source to filter the packets.

### 63.1 ip source binding

#### Description

The **ip source binding** command is used to bind the IP address, MAC address, VLAN ID and the Port number together manually. You can manually bind the IP address, MAC address, VLAN ID and the Port number together in the condition that you have got the related information of the Hosts in the LAN. To delete the IP-MAC-VID-PORT entry from the binding table, please use **no ip source binding index** command.

#### Syntax

```
ip source binding hostname ip-addr mac-addr vlan vlan-id interface  
{ fastEthernet port | gigabitEthernet port | ten-gigabitEthernet port |  
port-channel port-channel-id } { none | arp-detection | ip-verify-source |  
both }  
no ip source binding index ip-addr
```

#### Parameter

*hostname*——The Host Name, which contains 20 characters at most.

*ip-addr*—— The IP address of the Host.

*mac-addr*—— The MAC address of the Host.

*vlan-id*——The VLAN ID needed to be bound, ranging from 1 to 4094.

*port*—— The number of port connected to the Host.

none | arp-detection | ip-verify-source | both ——The protect type for the entry. "arp-detection" indicates ARP detection; "ip-verify-source" indicates IP source filter; "none" indicates applying none; "both" indicates applying both.

*ip-addr*—— The IP address of the entry to be deleted.

#### Command Mode

Global Configuration Mode

## Privilege Requirement

Only Admin, Operator and Power User level users have access to these commands.

## Example

Bind an ACL entry with the IP 192.168.0.1, MAC 00:00:00:00:00:01, VLAN ID 2 and the Port number 5 manually. And then enable the entry for the ARP detection:

```
Switch(config)#ip source binding host1 192.168.0.1 00:00:00:00:00:01 vlan  
2 interface gigabitEthernet 1/0/5 arp-detection
```

Delete the IP-MAC-VID-PORT entry with the index 5:

```
Switch(config)#no ip source binding index 5
```

## 63.2 ip dhcp snooping

### Description

The **ip dhcp snooping** command is used to enable DHCP Snooping function globally. To disable DHCP Snooping function globally, please use **no ip dhcp snooping** command. DHCP Snooping functions to monitor the process of the Host obtaining the IP address from DHCP server, and record the IP address, MAC address, VLAN and the connected Port number of the Host for automatic binding.

### Syntax

**ip dhcp snooping**

**no ip dhcp snooping**

### Command Mode

Global Configuration Mode

### Privilege Requirement

Only Admin, Operator and Power User level users have access to these commands.

### Example

Enable the DHCP Snooping function globally:

```
Switch(config)#ip dhcp snooping
```

## 63.3 ip dhcp snooping vlan

### Description

The **ip dhcp snooping vlan** command is used to enable DHCP Snooping function on a specified VLAN. To disable DHCP Snooping function on this VLAN, please use **no ip dhcp snooping vlan** command.

### Syntax

```
ip dhcp snooping vlan vlan-range  
no ip dhcp snooping vlan vlan-range
```

### Parameter

*vlan-range* — Specify the VLANs to enable the DHCP snooping function, in the format of 1-3, 5.

### Command Mode

Global Configuration Mode

### Privilege Requirement

Only Admin, Operator and Power User level users have access to these commands.

### Example

Enable the DHCP Snooping function on VLAN 1,4,6-7:

```
Switch(config)#ip dhcp snooping vlan 1,4,6-7
```

## 63.4 ip dhcp snooping max-entries

### Description

The **ip dhcp snooping max-entries** command is used to configure the maximum number of entries that can be learned on a port via DHCP Snooping. To restore to the default setting, please use **no ip dhcp snooping max-entries** command.

### Syntax

```
ip dhcp snooping max-entries value  
no ip dhcp snooping max-entries
```

## Syntax

*value* — Enter the value of maximum number of entries that can be learned on the port via DHCP Snooping.

## Command Mode

Interface Configuration Mode (interface gigabitEthernet / interface range gigabitEthernet / interface port-channel / interface range port-channel)

## Privilege Requirement

Only Admin, Operator and Power User level users have access to these commands.

## Example

Configure the maximum number of entries that can be learned on port 1 as 100:

```
Switch(config)#interface gigabitEthernet 1/0/1
Switch(config-if)#ip dhcp snooping max-entries 100
```

# 63.5 ip dhcp snooping trust

## Description

The **ip dhcp snooping trust** command is used to configure the trust status of a specified interface, and only DHCP Server connected to a trusted port can assign packets to clients. To delete the status, please use **no ip dhcp snooping trust** command.

## Syntax

```
ip dhcp snooping trust
no ip dhcp snooping trust
```

## Command Mode

Interface Configuration Mode (interface gigabitEthernet / interface range gigabitEthernet / interface port-channel / interface range port-channel)

## Privilege Requirement

Only Admin, Operator and Power User level users have access to these commands.

## Example

Enable DHCP Snooping trust function for port 1/0/3:

```
Switch(config)#interface gigabitEthernet 1/0/3
Switch(config-if)#ip dhcp snooping trust
```

## 63.6 show ip source binding

### Description

The **show ip source binding** command is used to display the IP-MAC-VID-PORT binding table.

### Syntax

```
show ip source binding
```

### Command Mode

Privileged EXEC Mode and Any Configuration Mode

### Privilege Requirement

None.

### Example

Display the IP-MAC-VID-PORT binding table:

```
Switch(config)#show ip source binding
```

## 63.7 show ip dhcp snooping

### Description

The **show ip dhcp snooping** command is used to display the running status of DHCP Snooping.

### Syntax

```
show ip dhcp snooping
```

### Command Mode

Privileged EXEC Mode and Any Configuration Mode

### Privilege Requirement

None.

## Example

Display the running status of DHCP Snooping:

```
Switch#show ip dhcp snooping
```

## 63.8 show ip dhcp snooping interface

### Description

The **show ip dhcp snooping interface** command is used to display the DHCP Snooping configuration of a desired Gigabit Ethernet port/port channel or of all Ethernet ports/port channels.

### Syntax

```
show ip dhcp snooping interface [ gigabitEthernet port | port-channel  
port-channel-id]
```

### Parameters

*port*— The Ethernet port number.

*port-channel-id*— The ID of the port channel.

### Command Mode

Privileged EXEC Mode and Any Configuration Mode

### Privilege Requirement

None.

### Example

Display the DHCP Snooping configuration of all Ethernet ports and port channels:

```
Switch#show ip dhcp snooping interface
```

Display the DHCP Snooping configuration of Gigabit Ethernet port 1/0/5:

```
Switch#show ip dhcp snooping interface gigabitEthernet 1/0/5
```

# Chapter 64 IPv6 IMPB Commands

You can bind the IPv6 address, MAC address, VLAN and the connected Port number of the Host together, which can be the condition for the ARP Inspection and IP verify source to filter the packets.

## 64.1 ipv6 source binding

### Description

The **ipv6 source binding** command is used to bind the IPv6 address, MAC address, VLAN ID and the Port number together manually. You can manually bind the IPv6 address, MAC address, VLAN ID and the Port number together in the condition that you have got the related information of the Hosts in the LAN. To delete the IPv6-MAC-VID-PORT entry from the binding table, please use **no ipv6 source binding index** command.

### Syntax

```
ipv6 source binding hostname ipv6-addr mac-addr vlan vlan-id interface  
{ fastEthernet port | gigabitEthernet port | ten-gigabitEthernet port |  
port-channel port-channel-id } { none | nd-detection | ipv6-verify-source |  
both }  
no ipv6 source binding index ipv6-addr
```

### Parameter

*hostname*——The Host Name, which contains 20 characters at most.

*ipv6-addr*—— The IP address of the Host.

*mac-addr*—— The MAC address of the Host.

*vlan-id*——The VLAN ID needed to be bound, ranging from 1 to 4094.

*port*—— The number of port connected to the Host.

none | nd-detection | ipv6-verify-source | both ——The protect type for the entry. "nd-detection" indicates ND detection; "ipv6-verify-source" indicates IPv6 source filter; "none" indicates applying none; "both" indicates applying both.

*ipv6-addr*—— The IPv6 address of the entry to be deleted.

### Command Mode

Global Configuration Mode



## Privilege Requirement

Only Admin, Operator and Power User level users have access to these commands.

## Example

The following example shows how to bind an entry with the hostname host1, IPv6 address 2001:0:9d38:90d5::34, MAC address AA-BB-CC-DD-EE-FF, VLAN ID 10, port number 1/0/5, and enable this entry for ND Detection.

```
Switch(config)# ipv6 source binding host1 2001:0:9d38:90d5::34
aa:bb:cc:dd:ee:ff vlan 10 interface gigabitEthernet 1/0/5 nd-detection
```

## 64.2 ipv6 dhcp snooping

### Description

The **ipv6 dhcp snooping** command is used to enable DHCPv6 Snooping function globally. To disable DHCPv6 Snooping function globally, please use **no ipv6 dhcp snooping** command. DHCPv6 Snooping functions to monitor the process of the Host obtaining the IP address from DHCPv6 server, and record the IPv6 address, MAC address, VLAN and the connected Port number of the Host for automatic binding.

### Syntax

```
ipv6 dhcp snooping
no ipv6 dhcp snooping
```

### Command Mode

Global Configuration Mode

### Privilege Requirement

Only Admin, Operator and Power User level users have access to these commands.

### Example

Enable the DHCPv6 Snooping function globally:

```
Switch(config)#ipv6 dhcp snooping
```

## 64.3 ipv6 dhcp snooping vlan

### Description

The **ipv6 dhcp snooping vlan** command is used to enable DHCP Snooping function on a specified VLAN. To disable DHCP Snooping function on this VLAN, please use **no ipv6 dhcp snooping vlan** command.

### Syntax

```
ipv6 dhcp snooping vlan vlan-range  
no ipv6 dhcp snooping vlan vlan-range
```

### Parameter

*vlan-range* — Specify the VLANs to enable the DHCP snooping function, in the format of 1-3, 5.

### Command Mode

Global Configuration Mode

### Privilege Requirement

Only Admin, Operator and Power User level users have access to these commands.

### Example

Enable the DHCPv6 Snooping function on VLAN 1,4,6-7:

```
Switch(config)#ipv6 dhcp snooping vlan 1,4,6-7
```

## 64.4 ipv6 dhcp snooping max-entries

### Description

The **ipv6 dhcp snooping max-entries** command is used to configure the maximum number of entries that can be learned on a port via DHCPv6 Snooping. To restore to the default setting, please use **no ipv6 dhcp snooping max-entries** command.

### Syntax

```
ipv6 dhcp snooping max-entries value  
no ipv6 dhcp snooping max-entries
```

## Syntax

*value*: Enter the value of maximum number of entries that can be learned on the port via DHCPv6 Snooping.

## Command Mode

Interface Configuration Mode (interface gigabitEthernet / interface range gigabitEthernet / interface port-channel / interface range port-channel)

## Privilege Requirement

Only Admin, Operator and Power User level users have access to these commands.

## Example

Configure the maximum number of entries that can be learned on port 1 as 100:

```
Switch(config)#interface gigabitEthernet 1/0/1
Switch(config-if)#ipv6 dhcp snooping max-entries 100
```

# 64.5 ipv6 nd snooping

## Description

The **ipv6 nd snooping** command is used to enable ND snooping function globally. To disable ND Snooping function globally, please use **no ipv6 nd snooping** command. ND Snooping functions to monitor the process of the duplication address detection, and record the IPv6 address, MAC address, VLAN and the connected Port number of the Host for automatic binding.

## Syntax

```
ipv6 nd snooping
no ipv6 nd snooping
```

## Command Mode

Global Configuration Mode

## Privilege Requirement

Only Admin, Operator and Power User level users have access to these commands.

## Example

Enable the ND snooping function globally:

```
T160G-28TS(config)#ipv6 nd snooping
```

## 64.6 ipv6 nd snooping vlan

### Description

The **ipv6 nd snooping vlan** command is used to enable ND snooping function on a specified VLAN. To disable ND Snooping function on this VLAN, please use **no ipv6 nd snooping vlan** command.

### Syntax

```
ipv6 nd snooping vlan vlan-range
```

```
no ipv6 nd snooping vlan vlan-range
```

### Parameter

*vlan-range* — Specify the VLANs to enable the ND snooping function, in the format of 1-3, 5.

### Command Mode

Global Configuration Mode

### Privilege Requirement

Only Admin, Operator and Power User level users have access to these commands.

## Example

Enable the ND snooping function on VLAN 1,4,6-7:

```
Switch(config)#ipv6 nd snooping vlan 1,4,6-7
```

## 64.7 ipv6 nd snooping max-entries

### Description

The **ipv6 nd snooping max-entries** command is used to specify the maximum number of binding entries that are allow to be bound to a port. To return the default, please use **no ipv6 nd snooping max-entries** command.

## Syntax

```
ipv6 nd snooping max-entries value  
no ipv6 nd snooping max-entries
```

## Parameter

*value* — Specify the maximum number of ND snooping entries on this interface.

## Command Mode

Interface Configuration Mode (interface gigabitEthernet / interface range gigabitEthernet / interface port-channel / interface range port-channel)

## Privilege Requirement

Only Admin, Operator and Power User level users have access to these commands.

## Example

Configure the maximum number of binding entries from ND Snooping of Gigabit Ethernet port 1/0/2 is 100:

```
Switch(config)#interface gigabitEthernet 1/0/2  
Switch(config-if)#ipv6 nd snooping max-entries 100
```

# 64.8 show ipv6 source binding

## Description

The **show ipv6 source binding** command is used to display the IPv6-MAC-VID- PORT binding table.

## Syntax

```
show ipv6 source binding
```

## Command Mode

Privileged EXEC Mode and Any Configuration Mode

## Privilege Requirement

None.

## Example

Display the IPv6-MAC-VID-PORT binding table:

```
Switch(config)#show ipv6 source binding
```

## 64.9 show ipv6 dhcp snooping

### Description

The **show ipv6 dhcp snooping** command is used to display the running status of DHCPv6 Snooping.

### Syntax

```
show ipv6 dhcp snooping
```

### Command Mode

Privileged EXEC Mode and Any Configuration Mode

### Privilege Requirement

None.

### Example

Display the running status of DHCPv6 Snooping:

```
Switch#show ipv6 dhcp snooping
```

## 64.10 show ipv6 dhcp snooping interface

### Description

The **show ipv6 dhcp snooping interface** command is used to display the DHCPv6 Snooping configuration of a desired Gigabit Ethernet port/port channel or of all Ethernet ports/port channels.

### Syntax

```
show ipv6 dhcp snooping interface [ gigabitEthernet port | port-channel  
port-channel-id]
```

### Parameters

*port*— The Ethernet port number.

*port-channel-id*— The ID of the port channel.

## Command Mode

Privileged EXEC Mode and Any Configuration Mode

## Privilege Requirement

None.

## Example

Display the DHCPv6 Snooping configuration of all Ethernet ports and port channels:

```
Switch#show ipv6 dhcp snooping interface
```

Display the DHCPv6 Snooping configuration of Gigabit Ethernet port 1/0/5:

```
Switch#show ipv6 dhcp snooping interface gigabitEthernet 1/0/5
```

## 64.11

## show ipv6 nd snooping

### Description

The **show ipv6 nd snooping** command is used to display the running status of ND Snooping.

### Syntax

```
show ipv6 nd snooping
```

### Command Mode

Privileged EXEC Mode and Any Configuration Mode

### Privilege Requirement

None.

### Example

Display the running status of ND Snooping:

```
Switch#show ipv6 nd snooping
```

## 64.12 show ipv6 nd snooping interface



**Note:** This command is only available on certain devices.

## Description

The **show ipv6 nd snooping interface** command is used to display the ND Snooping configuration of a desired Gigabit Ethernet port/port channel or of all Ethernet ports/port channels.

## Syntax

```
show ipv6 nd snooping interface [ gigabitEthernet port | port-channel port-channel-id ]
```

## Parameters

*port*— The Ethernet port number.

*port-channel-id*— The ID of the port channel.

## Command Mode

Privileged EXEC Mode and Any Configuration Mode

## Privilege Requirement

None.

## Example

Display the ND Snooping configuration of all Ethernet ports and port channels:

```
Switch#show ipv6 nd snooping interface
```

Display the ND Snooping configuration of Gigabit Ethernet port 1/0/5:

```
Switch#show ipv6 nd snooping interface gigabitEthernet 1/0/5
```



# Chapter 65 IP Verify Source Commands

IP Verify Source is to filter the IP packets based on the IP-MAC Binding entries. Only the packets matched to the IP-MAC Binding rules can be processed, which can enhance the bandwidth utility.

## 65.1 ip verify source

### Description

The **ip verify source** command is used to configure the IP Verify Source mode for a specified port. To disable the IP Verify Source function, please use **no ip verify source** command.

### Syntax

```
ip verify source { sip+mac | sip }  
no ip verify source
```

### Parameter

sip+mac — Security type. "sip+mac" indicates that only the packets with its source IP address, source MAC address and port number matched to the IP-MAC binding rules can be processed.

sip — Security type. "sip" indicates that only the packets with its source IP address and port number matched to the IP-MAC binding rules can be processed.

**Note:** sip is only available on certain devices.

### Command Mode

Interface Configuration Mode (interface gigabitEthernet / interface range gigabitEthernet)

### Privilege Requirement

Only Admin, Operator and Power User level users have access to these commands.

### Example

Enable the IP Verify Source function for Gigabit Ethernet ports 5-10. Configure that only the packets with its source IP address, source MAC

address and port number matched to the IP-MAC binding rules can be processed:

```
Switch(config)#interface range gigabitEthernet 1/0/5-10
Switch(config-if-range)#ip verify source sip+mac
```

## 65.2 ip verify source logging

### Description

The **ip verify source logging** command is used to enable the log feature. With this feature enabled, the switch will generate a log when illegal packets are received. To disable the log feature, please use **no ip verify source logging** command.

### Syntax

```
ip verify source logging
no ip verify source logging
```

### Command Mode

Global Configuration Mode

### Privilege Requirement

Only Admin, Operator and Power User level users have access to these commands.

### Example

Enable the log feature to make the switch generate logs when receiving illegal packets:

```
Switch(config)#ip verify source logging
```

## 65.3 show ip verify source

### Description

The **show ip verify source** command is used to display the IP Verify Source configuration information.

### Syntax

```
show ip verify source
```

## Command Mode

Privileged EXEC Mode and Any Configuration Mode

## Privilege Requirement

None.

## Example

Display the IP Verify Source configuration information:

```
Switch(config)#show ip verify source
```

# 65.4 show ip verify source interface

## Description

The **show ip verify source interface** command is used to display the IP verify source configuration of a desired Gigabit Ethernet port.

## Syntax

```
show ip verify source interface [fastEthernet port | gigabitEthernet port |  
ten-gigabitEthernet port | port-channel port-channel-id]
```

## Parameters

*port*— The Ethernet port number.

*port-channel-id*— The ID of the port channel.

## Command Mode

Privileged EXEC Mode and Any Configuration Mode

## Privilege Requirement

None.

## Example

Display the IP verify source configuration of Gigabit Ethernet port 1/0/5:

```
Switch#show ip verify source interface gigabitEthernet 1/0/5
```

# Chapter 66 IPv6 Verify Source Commands

IPv6 Verify Source is to filter the IPv6 packets based on the IPv6-MAC Binding entries. Only the packets matched to the IPv6-MAC Binding rules can be processed, which can enhance the bandwidth utility.

Before configuring IPv6 Verify Source feature, you should configure the SDM template as "enterpriseV6" and save your configurations.

## 66.1 ipv6 verify source

### Description

The **ipv6 verify source** command is used to configure the IPv6 Verify Source mode for a specified port. To disable the IPv6 Verify Source function, please use **no ipv6 verify source** command.

### Syntax

**ipv6 verify source** { sipv6+mac | sipv6 }

**no ipv6 verify source**

### Parameter

sipv6+mac — Security type. "sipv6+mac" indicates that only the packets with its source IPv6 address, source MAC address and port number matched to the IPv6-MAC binding rules can be processed.

sipv6 — Security type. "sipv6" indicates that only the packets with its source IPv6 address and port number matched to the IPv6-MAC binding rules can be processed.

### Command Mode

Interface Configuration Mode (interface gigabitEthernet / interface range gigabitEthernet )

### Privilege Requirement

Only Admin, Operator and Power User level users have access to these commands.

### Example

Enable the IPv6 Verify Source function for Gigabit Ethernet ports 5-10. Configure that only the packets with its source IPv6 address, source MAC

address and port number matched to the IPv6-MAC binding rules can be processed:

```
Switch(config)#interface range gigabitEthernet 1/0/5-10
Switch(config-if-range)#ipv6 verify source sipv6+mac
```

## 66.2 show ipv6 verify source

### Description

The **show ipv6 verify source** command is used to display the IPv6 Verify Source configuration information.

### Syntax

```
show ipv6 verify source
```

### Command Mode

Privileged EXEC Mode and Any Configuration Mode

### Privilege Requirement

None.

### Example

Display the IPv6 Verify Source configuration information:

```
Switch(config)#show ipv6 verify source
```

## 66.3 show ipv6 verify source interface

### Description

The **show ipv6 verify source interface** command is used to display the IPv6 verify source configuration of a desired Gigabit Ethernet port.

### Syntax

```
show ipv6 verify source interface gigabitEthernet port
```

### Parameters

*port*— The Ethernet port number.

## Command Mode

Privileged EXEC Mode and Any Configuration Mode

## Privilege Requirement

None.

## Example

Display the IPv6 verify source configuration of Gigabit Ethernet port 1/0/5:

```
Switch#show ipv6 verify source interface gigabitEthernet 1/0/5
```

# Chapter 67 DHCPv4 Filter Commands

DHCPv4 Filter function allows the user to not only to restrict all DHCP Server packets but also to receive any specified DHCP server packet by any specified DHCP client, it is useful when one or more DHCP servers are present on the network and both provide DHCP services to different distinct groups of clients.

## 67.1 ip dhcp filter

### Description

The **ip dhcp filter** command is used to enable DHCP Filter function globally. To disable DHCP Filter function globally, please use **no ip dhcp filter** command.

### Syntax

**ip dhcp filter**  
**no ip dhcp filter**

### Command Mode

Global Configuration Mode

### Privilege Requirement

Only Admin, Operator and Power User level users have access to these commands.

### Example

Enable the DHCP Filter function globally:

```
Switch(config)#ip dhcp filter
```

## 67.2 ip dhcp filter (interface)

### Description

The **ip dhcp filter (interface)** command is used to enable DHCP Filter function on a specified port. To disable DHCP Filter function on this port, please use **no ip dhcp filter (interface)** command.

## Syntax

**ip dhcp filter**  
**no ip dhcp filter**

## Command Mode

Interface Configuration Mode (interface gigabitEthernet / interface range gigabitEthernet / interface port-channel / interface range port-channel)

## Privilege Requirement

Only Admin, Operator and Power User level users have access to these commands.

## Example

Enable the DHCP Filter on port 1/0/1

```
Switch(config)#interface gigabitEthernet 1/0/1
Switch(Config-if)#ip dhcp filter
```

## 67.3 ip dhcp filter mac-verify

### Description

The **ip dhcp filter mac-verify** command is used to enable the MAC Verify feature. To disable the MAC Verify feature, please use **no ip dhcp filter mac-verify** command. There are two fields of the DHCP packet containing the MAC address of the Host. The MAC Verify feature is to compare the two fields and discard the packet if the two fields are different.

### Syntax

**ip dhcp filter mac-verify**  
**no ip dhcp filter mac-verify**

### Command Mode

Interface Configuration Mode (interface gigabitEthernet / interface range gigabitEthernet / interface port-channel / interface range port-channel)

### Privilege Requirement

Only Admin, Operator and Power User level users have access to these commands.



## Example

Enable the MAC Verify feature for the Gigabit Ethernet port 10/2:

```
Switch(config)#interface gigabitEthernet 1/0/2
Switch(config-if)#ip dhcp filter mac-verify
```

## 67.4 ip dhcp filter limit rate

### Description

The **ip dhcp filter limit rate** command is used to enable the Flow Control feature for the DHCP packets. The excessive DHCP packets will be discarded. To restore to the default configuration, please use **no ip dhcp filter limit rate** command.

### Syntax

```
ip dhcp filter limit rate value
no ip dhcp filter limit rate
```

### Parameter

*value* — The value of Flow Control. The options are 5/10/15/20/25/30 (packet/second). The default value is 0, which stands for "disable".

### Command Mode

Interface Configuration Mode (interface gigabitEthernet / interface range gigabitEthernet / interface port-channel / interface range port-channel)

### Privilege Requirement

Only Admin, Operator and Power User level users have access to these commands.

## Example

Set the Flow Control of GigabitEthernet port 2 as 20 pps:

```
Switch(config)#interface gigabitEthernet 1/0/2
Switch(config-if)#ip dhcp filter limit rate 20
```

## 67.5 ip dhcp filter decline rate

### Description

The **ip dhcp filter decline rate** command is used to enable the Decline Protect feature and configure the rate limit on DHCP Decline packets. The excessive DHCP Decline packets will be discarded. To disable the Decline Protect feature, please use **no ip dhcp filter decline rate** command.

### Syntax

**ip dhcp filter decline rate** *value*

**no ip dhcp filter decline rate**

### Parameter

*value* — Specify the rate limit of DHCP Decline packets, and the optional values are 0, 5, 10, 15, 20, 25 and 30 (units:packet/second). Its default value is 0, which stands for "disable".

### Command Mode

Interface Configuration Mode (interface gigabitEthernet / interface range gigabitEthernet / interface port-channel / interface range port-channel)

### Privilege Requirement

Only Admin, Operator and Power User level users have access to these commands.

### Example

Configure the rate limit of DHCP Decline packets as 20 packets per second on Gigabit Ethernet port 1/0/2:

```
Switch(config)#interface gigabitEthernet 1/0/2
Switch(config-if)#ip dhcp filter decline rate 20
```

## 67.6 ip dhcp filter server permit-entry

### Description

The **ip dhcp filter server permit-entry** command is used to add entry for the legal DHCP server. To restore to the default option, please use **no ip dhcp snooping information strategy** command.

### Syntax

```
ip dhcp filter server permit-entry server-ip ipAddr client-mac macAddr  
interface { fastEthernet port | gigabitEthernet port | ten-gigabitEthernet  
port | interface port-channel port-channel-id}
```

```
no ip dhcp filter server permit-entry server-ip ipAddr client-mac macAddr  
interface { fastEthernet port | gigabitEthernet port | ten-gigabitEthernet  
port | interface port-channel port-channel-id}
```

### Parameter

*ipAddr*—— Specify the IP address of the legal DHCPv4 server.

*macAddr* —— Specify the MAC address of the DHCP Client. The value "all" means all client mac addresses.

*port-list / port-channel-id* —— Specify the port that the legal DHCPv4 server is connected to.

### Command Mode

Global Configuration Mode

### Privilege Requirement

Only Admin, Operator and Power User level users have access to these commands.

### Example

Create an entry for the legal DHCPv4 server whose IP address is 192.168.0.100 and connected port number is 1/0/1 without client MAC address restricted:

```
Switch(config)#ip dhcp filter server permit-entry server-ip 192.168.0.100  
client-mac all interface gigabitEthernet 1/0/1
```

## 67.7 show ip dhcp filter

### Description

The **show ip dhcp filter** command is used to display the configuration of DHCP Filter.

### Syntax

```
show ip dhcp filter
```

### Command Mode

Privileged EXEC Mode and Any Configuration Mode

### Privilege Requirement

None.

### Example

Display the DHCP Filter configuration:

```
Switch#show ip dhcp filter
```

## 67.8 show ip dhcp filter interface

### Description

The **show ip dhcp filter interface** command is used to display the configuration of DHCP Filter on ports.

### Syntax

```
show ip dhcp filter interface [fastEthernet port | gigabitEthernet port |  
ten-gigabitEthernet port | port-channel port-channel-id]
```

### Command Mode

Privileged EXEC Mode and Any Configuration Mode

### Privilege Requirement

None.

### Example

Display the DHCP Filter configuration on port 1/0/3:

```
Switch#show ip dhcp filter interface gigabitEthernet 1/0/3
```

## 67.9 show ip dhcp filter server permit-entry

### Description

The **show ip dhcp filter server permit-entry** command is used to display the legal server configuration.

### Syntax

```
show ip dhcp filter server permit-entry
```

### Command Mode

Privileged EXEC Mode and Any Configuration Mode

### Privilege Requirement

None.

### Example

Display the legal DHCP server configuration:

```
Switch#show ip dhcp filter server permit-entry
```

# Chapter 68 DHCPv6 Filter Commands

DHCPv6 Filter function allows the user to not only to restrict all DHCPv6 Server packets but also to receive any specified DHCPv6 server packet by any specified DHCPv6 client, it is useful when one or more DHCPv6 servers are present on the network and both provide DHCPv6 services to different distinct groups of clients.

## 68.1 ipv6 dhcp filter

### Description

The **ipv6 dhcp filter** command is used to enable DHCP Filter function globally. To disable DHCPv6 Filter function globally, please use **no ipv6 dhcp filter** command.

### Syntax

**ipv6 dhcp filter**  
**no ipv6 dhcp filter**

### Command Mode

Global Configuration Mode

### Privilege Requirement

Only Admin, Operator and Power User level users have access to these commands.

### Example

Enable the DHCPv6 Filter function globally:

```
Switch(config)#ipv6 dhcp filter
```

## 68.2 ipv6 dhcp filter (interface)

### Description

The **ipv6 dhcp filter (interface)** command is used to enable DHCPv6 Filter function on a specified port. To disable DHCPv6v Filter function on this port, please use **no ipv6 dhcp filter (interface)** command.

## Syntax

**ipv6 dhcp filter**  
**no ipv6 dhcp filter**

## Command Mode

Interface Configuration Mode (interface gigabitEthernet / interface range gigabitEthernet / interface port-channel / interface range port-channel)

## Privilege Requirement

Only Admin, Operator and Power User level users have access to these commands.

## Example

Enable the DHCPv6 Filter on port 1/0/1

```
Switch(config)#interface gigabitEthernet 1/0/1
Switch(Config-if)#ipv6 dhcp filter
```

## 68.3 ipv6 dhcp filter limit rate

### Description

The **ipv6 dhcp filter limit rate** command is used to enable the Flow Control feature for the DHCPv6 packets. The excessive DHCPv6 packets will be discarded. To restore to the default configuration, please use **no ipv6 dhcp filter limit rate** command.

### Syntax

**ipv6 dhcp filter limit rate** *value*  
**no ipv6 dhcp filter limit rate**

### Parameter

*value* — The value of Flow Control. The options are 5/10/15/20/25/30 (packet/second). The default value is 0, which stands for "disable".

### Command Mode

Interface Configuration Mode (interface gigabitEthernet / interface range gigabitEthernet / interface port-channel / interface range port-channel)

## Privilege Requirement

Only Admin, Operator and Power User level users have access to these commands.

## Example

Set the Flow Control of GigabitEthernet port 2 as 20 pps:

```
Switch(config)#interface gigabitEthernet 1/0/2
```

```
Switch(config-if)#ipv6 dhcp filter limit rate 20
```

# 68.4 ipv6 dhcp filter decline rate

## Description

The **ipv6 dhcp filter decline rate** command is used to enable the Decline Protect feature and configure the rate limit on DHCP Decline packets. The excessive DHCPv6 Decline packets will be discarded. To disable the Decline Protect feature, please use **no ipv6 dhcp filter decline rate** command.

## Syntax

**ipv6 dhcp filter decline rate** *value*

**no ipv6 dhcp filter decline rate**

## Parameter

*value* — Specify the rate limit of DHCPv6 Decline packets, and the optional values are 0, 5, 10, 15, 20, 25 and 30 (units:packet/second). Its default value is 0, which stands for "disable".

## Command Mode

Interface Configuration Mode (interface gigabitEthernet / interface range gigabitEthernet / interface port-channel / interface range port-channel)

## Privilege Requirement

Only Admin, Operator and Power User level users have access to these commands.



## Example

Configure the rate limit of DHCPv6 Decline packets as 20 packets per second on Gigabit Ethernet port 1/0/2:

```
Switch(config)#interface gigabitEthernet 1/0/2
Switch(config-if)#ipv6 dhcp filter decline 20
```

## 68.5 ipv6 dhcp filter server permit-entry

### Description

The **ipv6 dhcp filter server permit-entry** command is used to add entry for the legal DHCPv6 server. To restore to the default option, please use **no ipv6 dhcp snooping information strategy** command.

### Syntax

```
ipv6 dhcp filter server permit-entry server-ip ipAddr interface
{ fastEthernet port | gigabitEthernet port | ten-gigabitEthernet port |
interface port-channel port-channel-id}
no ipv6 dhcp filter server permit-entry server-ip ipAddr interface
{ fastEthernet port | gigabitEthernet port | ten-gigabitEthernet port |
interface port-channel port-channel-id}
```

### Parameter

*ipAddr*—— Specify the IPv6 address of the legal DHCPv6 server.

*port-list* / *port-channel-id*—— Specify the port that the legal DHCPv6 server is connected to.

### Command Mode

Global Configuration Mode

### Privilege Requirement

Only Admin, Operator and Power User level users have access to these commands.

### Example

Create an entry for the legal DHCPv6 server whose IP address is 192.168.0.100 and connected port number is 1/0/1:

```
Switch(config)#ipv6 dhcp filter server permit-entry server-ip 2003::1
interface gigabitEthernet 1/0/1
```

## 68.6 show ipv6 dhcp filter

### Description

The **show ipv6 dhcp filter** command is used to display the configuration of DHCPv6 Filter.

### Syntax

```
show ipv6 dhcp filter
```

### Command Mode

Privileged EXEC Mode and Any Configuration Mode

### Privilege Requirement

None.

### Example

Display the DHCPv6 Filter configuration:

```
Switch#show ipv6 dhcp filter
```

## 68.7 show ipv6 dhcp filter interface

### Description

The **show ipv6 dhcp filter interface** command is used to display the configuration of DHCPv6 Filter on ports.

### Syntax

```
show ipv6 dhcp filter interface [fastEthernet port | gigabitEthernet port |
ten-gigabitEthernet port | port-channel port-channel-id]
```

### Command Mode

Privileged EXEC Mode and Any Configuration Mode

### Privilege Requirement

None.

## Example

Display the DHCPv6 Filter configuration on port 1/0/3:

```
Switch#show ipv6 dhcp filter interface gigabitEthernet 1/0/3
```

## 68.8 show ip dhcp filter server permit-entry

### Description

The **show ipv6 dhcp filter server permit-entry** command is used to display the legal server configuration.

### Syntax

```
show ipv6 dhcp filter server permit-entry
```

### Command Mode

Privileged EXEC Mode and Any Configuration Mode

### Privilege Requirement

None.

## Example

Display the legal DHCPv6 server configuration:

```
Switch#show ipv6 dhcp filter server permit-entry
```

# Chapter 69 DoS Defend Commands

DoS (Denial of Service) Attack is to occupy the network bandwidth maliciously by the network attackers or the evil programs sending a lot of service requests to the Host. With the DoS Defend enabled, the switch can analyze the specific field of the received packets and provide the defend measures to ensure the normal working of the local network.

## 69.1 ip dos-prevent

### Description

The **ip dos-prevent** command is used to enable the DoS defend function globally. To disable the DoS defend function, please use **no ip dos-prevent** command.

### Syntax

**ip dos-prevent**  
**no ip dos-prevent**

### Command Mode

Global Configuration Mode

### Privilege Requirement

Only Admin, Operator and Power User level users have access to these commands.

### Example

Enable the DoS defend function globally:

```
Switch(config)#ip dos-prevent
```

## 69.2 ip dos-prevent type

### Description

The **ip dos-prevent type** command is used to select the DoS Defend Type. To disable the corresponding Defend Type, please use **no ip dos-prevent type** command.

## Syntax

```
ip dos-prevent type { land | scan-synfin | xma-scan | null-scan |  
port-less-1024 | blat | ping-flood | syn-flood | win-nuke | ping-of-death |  
smurf }
```

```
no ip dos-prevent type { land | scan-synfin | xma-scan | null-scan |  
port-less-1024 | blat | ping-flood | syn-flood | win-nuke | ping-of-death |  
smurf }
```

## Parameter

**land** —The attacker sends a specific fake SYN (synchronous) packet to the destination host. Because both of the source IP address and the destination IP address of the SYN packet are set to be the IP address of the host, the host will be trapped in an endless circle of building the initial connection.

**scan-synfin** —The attacker sends the packet with its SYN field and the FIN field set to 1. The SYN field is used to request initial connection whereas the FIN field is used to request disconnection. Therefore, the packet of this type is illegal.

**xma-scan** —The attacker sends the illegal packet with its TCP index, FIN, URG and PSH field set to 1.

**null-scan** —The attacker sends the illegal packet with its TCP index and all the control fields set to 0. During the TCP connection and data transmission, the packets with all control fields set to 0 are considered illegal.

**port-less-1024** —The attacker sends the illegal packet with its TCP SYN field set to 1 and source port smaller than 1024.

**blat** —The attacker sends the illegal packet with the same source port and destination port on Layer 4 and with its URG field set to 1. Similar to the Land Attack, the system performance of the attacked host is reduced because the Host circularly attempts to build a connection with the attacker.

**ping-flood** —The attacker floods the destination system with Ping packets, creating a broadcast storm that makes it impossible for the system to respond to legal communication.

**syn-flood** —The attacker uses a fake IP address to send TCP request packets to the server. Upon receiving the request packets, the server responds with SYN-ACK packets. Since the IP address is fake, no response will be returned. The server will keep on sending SYN-ACK packets. If the attacker sends overflowing fake request packets, the network resource will be occupied maliciously and the requests of the legal clients will be denied.

**win-nuke** —Because the Operation System with bugs cannot correctly process the URG (Urgent Pointer) of TCP packets, the attacker sends this

type of packets to the TCP port 139 (NetBIOS) of the host with the Operation System bugs, which will cause the host with a blue screen.

ping-of-death — Ping of Death attack means that the attacker sends abnormal ping packets larger than 65535 bytes to cause system crash on the target computer.

**Note:** ping-of-death is only available on certain devices.

smurf — Smurf attack is a distributed denial-of-service attack in which large numbers of Internet Control Message Protocol (ICMP) packets with the intended victim's spoofed source IP are broadcast to a computer network using an IP broadcast address. Most devices on a network will, by default, respond to this by sending a reply to the source IP address. If the number of machines on the network that receive and respond to these packets is very large, the victim's computer will be flooded with traffic.

**Note:** smurf is only available on certain devices.

## Command Mode

Global Configuration Mode

## Privilege Requirement

Only Admin, Operator and Power User level users have access to these commands.

## Example

Enable the DoS Defend Type named Land attack:

```
Switch(config)#ip dos-prevent type land
```

# 69.3 show ip dos-prevent

## Description

The **show ip dos-prevent** command is used to display the DoS information of the detected DoS attack, including enable/disable status, the DoS Defend Type, the count of the attack, etc.

## Syntax

```
show ip dos-prevent
```

## Command Mode

Privileged EXEC Mode and Any Configuration Mode

## Privilege Requirement

None.

## Example

Display the DoS information of the detected DoS attack globally:

```
Switch(config)#show ip dos-prevent
```

# Chapter 70 sFlow Commands (Only for Certain Devices)



**Note:** sFlow commands are only available on certain devices.

sFlow (Sampled Flow) is a technology for accurately monitoring network traffic at high speeds. The sFlow monitoring system consists of a sFlow agent (embedded in a switch or router or in a standalone probe) and a central sFlow collector. The sFlow agent is a virtual entity using sampling technology to capture traffic statistics from the device it is monitoring. The sFlow collector can be a host receiving sFlow datagrams from the sFlow agent.

The sFlow feature is implemented as follows: the sFlow sampler take samples of traffic statistics and send sFlow datagrams to the sFlow agent for processing. The sFlow agent will forward sFlow datagrams to the sFlow collector for analysis. The analytic results can be displayed on the sFlow collector.

## 70.1 sflow address

### Description

The **sflow address** command is used to configure the sFlow agent's IP address. To delete the configured address, please use **no sflow address** command.

### Syntax

**sflow address** { *ipv4-addr* }

**no sflow address** { *ipv4-addr* }

### Parameter

*ipv4-addr* —The IP address of the sFlow agent. The type of the IP address should be IPv4. For example, you can set the switch's management IP as the IP address of the sFlow agent.

### Command Mode

Global Configuration Mode

### Privilege Requirement

Only Admin and Operator level users have access to these commands.

### Example

Configure the sFlow agent with the IP address as 192.168.0.1:

```
Switch(config)#sflow address 192.168.0.1
```



## 70.2 sflow enable

### Description

The **sflow enable** command is used to enable sFlow function. To disable the sFlow function, please use **no sflow enable** command.

### Syntax

**sflow enable**

**no sflow enable**

### Command Mode

Global Configuration Mode

### Privilege Requirement

Only Admin and Operator level users have access to these commands.

### User Guidelines

A valid agent address should be assigned to the sFlow agent embedded in the switch before you enable the sFlow function.

### Example

Enable sFlow function globally:

```
Switch(config)#sflow enable
```

## 70.3 sflow collector collector-ID

### Description

The **sflow collector collector-ID** command is used to configure the parameters about the sFlow collector.

### Syntax

```
sflow collector collector-ID value{[descript descript][[ip ip][[port port][[maxData maxData][[timeout timeout]}
```

### Parameter

*value* — The ID of the sFlow collector you desire to configure. The value ranges from 1 to 4.

*descript* — Give a Description to the sFlow collector, which contains 16 characters at most.

*ip* — The IP address of the sFlow collector. The type of the IP address should be IPv4, for example 192.168.0.100.

*port* —The number of the udp port which is selected for the sFlow collector.

*maxData* —Specify the maximum number of data bytes that can be sent in a single sample datagram. The value ranges from 300 to 1400 and the default value is 300 bytes.

*timeout* —Specify the aging time of the sFlow collector, ranging from 0 to 2000000 seconds. When the timeout is set to 0, it means the life cycle of the collector is infinite.

## Command Mode

Global Configuration Mode

## Privilege Requirement

Only Admin and Operator level users have access to these commands.

## Example

Specify the ip of the sFlow collector 1 as 192.168.0.100, the port as 3000:

```
Switch(config)# sflow collector collector-ID 1 ip 192.168.0.100
Switch(config)# sflow collector collector-ID 1 port 3000
```

# 70.4 sflow sampler

## Description

The **sflow sampler** command is used to configure the parameters about the sFlow sampler.

## Syntax

```
sflow sampler {[ collector-ID value] | [ingRate ingress-rate] [egRate egress-rate] | [maxHeader maxHeader] }
```

## Parameter

*value* — The ID of the sFlow collector which the sFlow sampler will send sFlow datagrams to. The value ranges from 0 to 4. When the value is zero, it means no collector is selected.

*ingress-rate* —Specify the ingress sampling frequency of the sFlow sampler. When a sample is taken, the value indicates how many packets to skip before the next sample is taken. The value ranges from 1024 to 65535 and the default value is 0 which means no packets will be sampled.

*egress-rate* —Specify the egress sampling frequency of the sFlow sampler. When a sample is taken, the value indicates how many packets to skip before

the next sample is taken. The value ranges from 1024 to 65535 and the default value is 0 which means no packets will be sampled.

*maxHeader*—Specify the maximum number of bytes that should be copied from a sampled packet. The value ranges from 18 to 256 and the default value is 128 bytes.

### Command Mode

Interface Configuration Mode (interface gigabitEthernet / interface range gigabitEthernet)

### Privilege Requirement

Only Admin and Operator level users have access to these commands.

### Example

Configure Gigabit Ethernet port 1 as the sFlow sampler: specify the Collector-ID as 1, the ingress rate as 1024:

```
Switch(config)#interface gigabitEthernet 1/0/1
```

```
Switch(config-if)#sflow sampler collector-ID 1
```

For L2/L2+ switches:

```
Switch(config-if)#sflow sampler ingRate 1024
```

For L3 switches:

```
Switch(config)#sflow sampler ingRate 1024
```

## 70.5 show sflow global

### Description

The **show sflow global** command is used to display the global configuration of sFlow.

### Syntax

```
show sflow global
```

### Command Mode

Privileged EXEC Mode and Any Configuration Mode

### Privilege Requirement

None.

### Example

Display the global configuration of sFlow:

```
Switch#show sflow global
```

## 70.6 show sflow collector

### Description

The **show sflow collector** command is used to display the global configuration of the sFlow collector.

### Syntax

```
show sflow collector
```

### Command Mode

Privileged EXEC Mode and Any Configuration Mode

### Privilege Requirement

None.

### Example

Display the global configuration of the sFlow collector:

```
Switch#show sflow collector
```

## 70.7 show sflow sampler

### Description

The **show sflow sampler** command is used to display the global configuration of the sFlow sampler.

### Syntax

```
show sflow sampler
```

### Command Mode

Privileged EXEC Mode and Any Configuration Mode

### Privilege Requirement

None.

### Example

Display the global configuration of the sFlow sampler:

```
Switch#show sflow sampler
```

# Chapter 71 Ethernet OAM Commands (Only for Certain Devices)



**Note:** Ethernet OAM commands are only available on certain devices.

Ethernet OAM (standing for Operation, Administration, and Maintenance) is Layer 2 protocol that is used for monitoring and troubleshooting Ethernet networks. It can report the network status to network administrators through the OAMPDUs exchanged between two OAM entities. The operation of OAM on an Ethernet interface does not adversely affect data traffic as OAM is a slow protocol with very limited bandwidth potential.

## 71.1 ethernet-oam

### Description

The **ethernet-oam** command is used to enable the Ethernet OAM function for the desired port. To disable the Ethernet OAM function, please use **no ethernet-oam** command.

### Syntax

**ethernet-oam**

**no ethernet-oam**

### Command Mode

Interface Configuration Mode (interface gigabitEthernet / interface range gigabitEthernet)

### Privilege Requirement

Only Admin and Operator level users have access to these commands.

### Example

Enable the Ethernet OAM function for Gigabit Ethernet port 1/0/2:

```
Switch(config)# interface gigabitEthernet 1/0/2
```

```
Switch(config-if)#ethernet-oam
```

## 71.2 ethernet-oam mode

### Description

The **ethernet-oam mode** command is used to configure the OAM mode for the desired port. To return to the default configurations, please use **no ethernet-oam mode** command. The default mode is active.

### Syntax

```
ethernet-oam mode { passive | active }  
no ethernet-oam mode
```

### Parameter

passive — Specify the OAM mode as passive.  
active — Specify the OAM mode as active.

### Command Mode

Interface Configuration Mode (interface gigabitEthernet / interface range gigabitEthernet)

### Privilege Requirement

Only Admin and Operator level users have access to these commands.

### Example

Configure Ethernet OAM client to operate in passive mode for Gigabit Ethernet port 2:

```
Switch(config)# interface gigabitEthernet 1/0/2  
Switch(config-if)#ethernet-oam mode passive
```

## 71.3 ethernet-oam link-monitor symbol-period

### Description

The **ethernet-oam link-monitor symbol-period** command is used to configure the parameters about one of the link events, error symbol period event. To return to the default configurations, please use **no ethernet-oam link-monitor symbol-period** command.

## Syntax

```
ethernet-oam link-monitor symbol-period { threshold threshold | window window | notify { disable | enable } }
```

```
no ethernet-oam link-monitor symbol-period { threshold | window | notify }
```

## Parameter

*threshold* — Configure the error threshold for generating error symbol-period event. The range is from 1 to 4294967295 and the default value is 1.

*window* — Configure the error symbol-period event detection interval. The range is from 10 to 600, in terms of 100 ms intervals. The default value is 10.

notify — Enable/Disable the event notification. By default, it is enabled.

threshold | window | notify — The parameter that you want to return to the default configuration.

## Command Mode

Interface Configuration Mode (interface gigabitEthernet / interface range gigabitEthernet)

## Privilege Requirement

Only Admin and Operator level users have access to these commands.

## Example

For error symbol-period event, configure the error threshold as 5 and the event detection interval as 3 seconds on Gigabit Ethernet port 1/0/2:

```
Switch(config)# interface gigabitEthernet 1/0/2
Switch(config-if)# ethernet-oam link-monitor symbol-period threshold 5
window 30
```

# 71.4 ethernet-oam link-monitor frame

## Description

The **ethernet-oam link-monitor frame** command is used to configure the parameters about one of the link events, error frame event. To return to the

default configurations, please use **no ethernet-oam link-monitor frame** command.

## Syntax

```
ethernet-oam link-monitor frame { [threshold threshold] [window window] [notify { disable | enable } ] }
```

```
no ethernet-oam link-monitor frame { threshold | window | notify }
```

## Parameter

*threshold* — Configure the error threshold for generating error frame event. The range is from 1 to 4294967295 and the default value is 1.

*window* — Configure the error symbol-period event detection interval. The range is from 10 to 600, in terms of 100 ms intervals. The default value is 10.

notify — Enable/Disable the event notification. By default, it is enabled.

threshold | window | notify — The parameter that you want to return to the default configuration.

## Command Mode

Interface Configuration Mode (interface gigabitEthernet / interface range gigabitEthernet)

## Privilege Requirement

Only Admin and Operator level users have access to these commands.

## Example

For error frame event, configure the error threshold as 6 and the event detection interval as 9 seconds on Gigabit Ethernet port 1/0/3:

```
Switch(config)# interface gigabitEthernet 1/0/3
Switch(config-if)# ethernet-oam link-monitor frame threshold 6 window
90
```

# 71.5 ethernet-oam link-monitor frame-period

## Description

The **ethernet-oam link-monitor frame-period** command is used to configure the parameters about one of the link events, error frame period



event. To return to the default configurations, please use **no ethernet-oam link-monitor frame-period** command.

## Syntax

```
ethernet-oam link-monitor frame-period { [threshold threshold] [window window] [notify { disable | enable } ] }
```

```
no ethernet-oam link-monitor frame-period { threshold | window | notify }
```

## Parameter

*threshold* — Configure the error threshold for generating error frame period event. The range is from 1 to 4294967295 and the default value is 1.

*window* — Configure the error frame period event detection interval. The range is from 148810 to 89286000. The default value is 148810 for Fast Ethernet port and 1488100 for Gigabit Ethernet port.

notify — Enable/Disable the event notification. By default, it is enabled.

threshold | window | notify — The parameter that you want to return to the default configuration.

## Command Mode

Interface Configuration Mode (interface gigabitEthernet / interface range gigabitEthernet)

## Privilege Requirement

Only Admin and Operator level users have access to these commands.

## Example

For error frame period event, configure the error threshold as 6 and the event detection interval as 150000 frames on Gigabit Ethernet port 1/0/4:

```
Switch(config)# interface gigabitEthernet 1/0/4  
Switch(config-if)# ethernet-oam link-monitor frame-period threshold 6  
window 150000
```

## 71.6 ethernet-oam link-monitor frame-seconds

### Description

The **ethernet-oam link-monitor frame-seconds** command is used to configure the parameters about one of the link events, error frame seconds event. To return to the default configurations, please use **no ethernet-oam link-monitor frame-seconds** command.

### Syntax

```
ethernet-oam link-monitor frame-seconds { [threshold threshold ]  
[ window window] [notify { disable | enable }]}  
no ethernet-oam link-monitor frame-seconds { threshold | window | notify }
```

### Parameter

*threshold* — Configure the error threshold for generating error frame seconds event. The range is from 1 to 900 and the default value is 1.

*window* — Configure the error frame seconds event detection interval. The range is from 100 to 9000, in terms of 100 ms intervals. The default value is 600.

notify — Enable/Disable the event notification. By default, it is enabled.

threshold | window | notify — The parameter that you want to return to the default configuration.

### Command Mode

Interface Configuration Mode (interface gigabitEthernet / interface range gigabitEthernet)

### Privilege Requirement

Only Admin and Operator level users have access to these commands.

### Example

For error frame seconds event, configure the error threshold as 8 and the event detection interval as 30 seconds on Gigabit Ethernet port 5:

```
Switch(config)# interface gigabitEthernet 1/0/5  
Switch(config-if)# ethernet-oam link-monitor frame-seconds threshold 8  
window 300
```

## 71.7 ethernet-oam remote-failure

### Description

The ethernet-oam remote-failure command is used to configure whether to notify the link faults or not. The link faults include dying gasp and critical event. To return to the default configurations, please use **no ethernet-oam remote-failure** command.

### Syntax

```
ethernet-oam remote-failure { dying-gasp | critical-event } notify { disable | enable }
```

```
no ethernet-oam remote-failure { dying-gasp | critical-event } notify
```

### Parameter

dying-gasp — Dying Gasp link event. Dying gasp means an unrecoverable fault, such as power failure, occurs.

critical-event — Critical Event. Critical-event means unspecified critical event occurs.

notify — Enable/Disable the event notification. By default, it is enabled.

### Command Mode

Interface Configuration Mode (interface gigabitEthernet / interface range gigabitEthernet)

### Privilege Requirement

Only Admin and Operator level users have access to these commands.

### Example

Disable the Dying Gasp link event notification on Gigabit Ethernet port 1/0/7:

```
Switch(config)# interface gigabitEthernet 1/0/7  
Switch(config-if)# ethernet-oam remote-failure dying-gasp notify disable
```

# 71.8 ethernet-oam remote-loopback received-remote- loopback

## Description

The **ethernet-oam remote-loopback received-remote-loopback** command is used to configure the client to process or to ignore the received remote loopback request. To return to the default configurations, please use **no ethernet-oam remote-loopback received-remote-loopback** command.

## Syntax

```
ethernet-oam remote-loopback received-remote-loopback { process | ignore }  
no ethernet-oam remote-loopback received-remote-loopback
```

## Parameter

process — Process the received remote loopback request.

ignore — Ignore the received remote loopback request.

## Command Mode

Interface Configuration Mode (interface gigabitEthernet / interface range gigabitEthernet)

## Privilege Requirement

Only Admin and Operator level users have access to these commands.

## Example

Configure the client to process the received remote loopback request on Gigabit Ethernet port 1:

```
Switch(config)# interface gigabitEthernet 1/0/1  
Switch(config-if)# ethernet-oam remote-loopback received  
-remote-loopback process
```

## 71.9 ethernet-oam remote-loopback

### Description

The **ethernet-oam remote-loopback** command is used to request the remote peer to start or stop the Ethernet OAM remote loopback mode.

### Syntax

```
ethernet-oam remote-loopback { start | stop }
```

### Parameter

start — Request the remote peer to start the Ethernet OAM remote loopback mode.

stop — Request the remote peer to stop the Ethernet OAM remote loopback mode.

### Command Mode

Interface Configuration Mode (interface gigabitEthernet / interface range gigabitEthernet)

### Privilege Requirement

Only Admin and Operator level users have access to these commands.

### Example

Request the remote peer to start the Ethernet OAM remote loopback mode on Gigabit Ethernet port 1/0/3:

```
Switch(config)# interface gigabitEthernet 1/0/3  
Switch(config-if)# ethernet-oam remote-loopback start
```

## 71.10 clear ethernet-oam statistics

### Description

The **clear ethernet-oam statistics** command is used to clear Ethernet OAM statistics.

## Syntax

**clear ethernet-oam statistics [ interface gigabitEthernet *port*]**

## Parameter

*port* — The Gigabit Ethernet port number. By default, the Ethernet OAM statistics of all ports are cleared.

## Command Mode

Global Configuration Mode

## Privilege Requirement

Only Admin and Operator level users have access to these commands.

## Example

Clear Ethernet OAM statistics of Gigabit Ethernet port 1/0/3:

```
Switch(config)# clear ethernet-oam statistics interface gigabit Ethernet  
1/0/3
```

# 71.11 clear ethernet-oam event-log

## Description

The **clear ethernet-oam event-log** command is used to clear the Ethernet OAM event log.

## Syntax

**clear ethernet-oam event-log [ interface gigabitEthernet *port*]**

## Parameter

*port* —The Gigabit Ethernet port number. By default, the Ethernet OAM event logs of all ports are cleared.

## Command Mode

Global Configuration Mode

## Privilege Requirement

Only Admin and Operator level users have access to these commands.

## Example

Clear Ethernet OAM event log of Gigabit Ethernet port 1/0/3:

```
Switch(config)# clear ethernet-oam event-log interface gigabitEthernet
1/0/3
```

# 71.12 show ethernet-oam configuration

## Description

The **show ethernet-oam configuration** command is used to display Ethernet OAM configuration information.

## Syntax

```
show ethernet-oam configuration [ interface gigabitEthernet port]
```

## Parameter

*port* — The Gigabit Ethernet port number. By default, the Ethernet OAM configuration information of all ports is displayed.

## Command Mode

Privileged EXEC Mode and Any Configuration Mode

## Privilege Requirement

Only Admin and Operator level users have access to these commands.

## Example

Display Ethernet OAM configuration information of Gigabit Ethernet port 1/0/2:

```
Switch(config)# show ethernet-oam configuration interface
gigabitEthernet 1/0/2
```

## 71.13 show ethernet-oam event-log

### Description

The **show ethernet-oam event-log** command is used to display the Ethernet OAM event log.

### Syntax

```
show ethernet-oam event-log [ interface gigabitEthernet port]
```

### Parameter

*port* — The Gigabit Ethernet port number. By default, the Ethernet OAM event logs of all ports are displayed.

### Command Mode

Privileged EXEC Mode and Any Configuration Mode

### Privilege Requirement

Only Admin and Operator level users have access to these commands.

### Example

Display Ethernet OAM event log of Gigabit Ethernet port 1/0/2:

```
Switch(config)# show ethernet-oam event-log interface gigabitEthernet  
1/0/2
```

## 71.14 show ethernet-oam statistics

### Description

The **show ethernet-oam statistics** command is used to display the Ethernet OAM statistics.

### Syntax

```
show ethernet-oam statistics [ interface gigabitEthernet port]
```



## Parameter

*port* — The Gigabit Ethernet port number. By default, the Ethernet OAM statistics of all ports are displayed.

## Command Mode

Privileged EXEC Mode and Any Configuration Mode

## Privilege Requirement

Only Admin and Operator level users have access to these commands.

## Example

Display Ethernet OAM statistics of Gigabit Ethernet port 1/0/2:

```
Switch(config)# show ethernet-oam statistics interface gigabitEthernet
1/0/2
```

# 71.15 show ethernet-oam status

## Description

The **show ethernet-oam status** command is used to display the Ethernet OAM status of both the local and the remote client.

## Syntax

```
show ethernet-oam status [ interface gigabitEthernet port ]
```

## Parameter

*port* — The Gigabit Ethernet port number. By default, the Ethernet OAM status of all ports is displayed.

## Command Mode

Privileged EXEC Mode and Any Configuration Mode

## Privilege Requirement

Only Admin and Operator level users have access to these commands.

## Example

Display Ethernet OAM status of Gigabit Ethernet port 1/0/2:

```
Switch(config)# show ethernet-oam status interface gigabitEthernet 1/0/2
```

# Chapter 72 DLDP Commands (Only for Certain Devices)

DLDP (Device Link Detection Protocol) is used to monitor the link state of fiber-optic or twisted-pair Ethernet cables. When a unidirectional link is detected, the corresponding port will be shut down automatically or manually (depending on the shut mode configured).

## 72.1 dldp (global)

### Description

The **dldp** command is used to enable the DLDP function globally. To disable it, please use **no dldp** command.

### Syntax

**dldp**  
**no dldp**

### Command Mode

Global Configuration Mode

### Privilege Requirement

Only Admin and Operator level users have access to these commands.

### Example

Enable the DLDP function globally:

```
Switch(config)# dldp
```

## 72.2 dldp interval

### Description

The **dldp interval** command is used to define the interval of sending advertisement packets on ports that are in the advertisement state.

### Syntax

**dldp interval** *interval-time*

## Parameter

*interval-time* — The interval of sending advertisement packets. It ranges from 1 to 30 seconds. By default, it is 5 seconds.

## Command Mode

Global Configuration Mode

## Privilege Requirement

Only Admin and Operator level users have access to these commands.

## Example

Specify the interval of sending advertisement packets as 10 seconds:

```
Switch(config)# dldp interval 10
```

# 72.3 dldp shut-mode

## Description

The **dldp shut-mode** command is used to configure the shutdown mode when a unidirectional link is detected.

## Syntax

```
dldp shut-mode { auto /manual }
```

## Parameter

**auto** — The switch automatically shuts down ports when a unidirectional link is detected. By default, the shut-mode is auto.

**manual** — The switch displays an alert when a unidirectional link is detected. The operation to shut down the unidirectional link ports is accomplished by the users.

## Command Mode

Global Configuration Mode

## Privilege Requirement

Only Admin and Operator level users have access to these commands.

## Example

Configure the shut-mode as manual:

```
Switch(config)# dldp shut-mode manual
```

## 72.4 dldp reset (global)



**Note:** This command is only available on certain devices

### Description

The **dldp reset** command is used to reset all the unidirectional links and restart the link detect process.

### Syntax

```
dldp reset
```

### Command Mode

Global Configuration Mode

### Privilege Requirement

Only Admin and Operator level users have access to these commands.

### Example

Reset the DLDP function globally:

```
Switch(config)# dldp reset
```

## 72.5 dldp(interface)

### Description

The **dldp** command is used to enable the DLDP function of the specified port. To disable it, please use **no dldp** command.

### Syntax

```
dldp  
no dldp
```

### Command Mode

Interface Configuration Mode (interface gigabitEthernet / interface range gigabitEthernet)

### Privilege Requirement

Only Admin and Operator level users have access to these commands.

## Example

Enable the DLDP function of ports 1/0/2-4:

```
Switch (config)# interface range gigabitEthernet 1/0/2-4
Switch (config-if-range)# dldp
```

## 72.6 dldp reset (interface)



**Note:** This command is only available on certain devices

### Description

The **dldp reset** command is used to reset the specified port and restart the link detect process.

### Syntax

```
dldp reset
```

### Command Mode

Interface Configuration Mode (interface gigabitEthernet / interface range gigabitEthernet)

### Privilege Requirement

Only Admin and Operator level users have access to these commands.

### Example

Reset the DLDP function of ports 2-4:

```
Switch (config)# interface range gigabitEthernet 1/0/2-4
Switch (config-if-range)# dldp reset
```

## 72.7 show dldp

### Description

The **show dldp** command is used to display the global configuration of DLDP function such as DLDP global state, DLDP interval and shut mode.

### Syntax

```
show dldp
```

## Command Mode

Privileged EXEC Mode and Any Configuration Mode

## Privilege Requirement

None.

## Example

Display the global configuration of DLDAP function:

```
Switch# show dldap
```

# 72.8 show dldap interface

## Description

The **show dldap interface** command is used to display the configuration and state of all ports. By default, the configuration and state of all the ports will be displayed.

## Syntax

```
show dldap interface
```

## Command Mode

Privileged EXEC Mode and Any Configuration Mode

## Privilege Requirement

None.

## Example

Display the configuration and state of all ports:

```
Switch# show dldap interface
```

# Chapter 73 SNMP Commands

SNMP (Simple Network Management Protocol) functions are used to manage the network devices for a smooth communication, which can facilitate the network administrators to monitor the network nodes and implement the proper operation.

## 73.1 snmp-server

### Description

The **snmp-server** command is used to enable the SNMP function. By default, it is disabled (For L3 switches, it is enabled by default). To return to the default configuration, please use **no snmp-server** command.

### Syntax

**snmp-server**  
**no snmp-server**

### Command Mode

Global Configuration Mode

### Privilege Requirement

Only Admin level users have access to these commands.

### Example

Enable the SNMP function:

```
Switch(config)# snmp-server
```

## 73.2 snmp-server view

### Description

The **snmp-server view** command is used to add View. To delete the corresponding View, please use **no snmp-server view** command. The OID (Object Identifier) of the SNMP packets is used to describe the managed objects of the switch, and the MIB (Management Information Base) is the set of the OIDs. The SNMP View is created for the SNMP management station to manage MIB objects.

### Syntax

**snmp-server view** *name mib-oid* { include | exclude }  
**no snmp-server view** *name mib-oid*

## Parameter

*name* — The entry name of View, ranging from 1 to 16 characters. Each View includes several entries with the same name.

*mib-oid* — MIB Object ID. It is the Object Identifier (OID) for the entry of View, ranging from 1 to 61 characters.

include | exclude — View Type, with include and exclude options. They represent the view entry can/cannot be managed by the SNMP management station individually.

## Command Mode

Global Configuration Mode

## Privilege Requirement

Only Admin level users have access to these commands.

## Example

Add a View named view1, configuring the OID as 1.3.6.1.6.3.20, and this OID can be managed by the SNMP management station:

```
Switch(config)# snmp-server view view1 1.3.6.1.6.3.20 include
```

# 73.3 snmp-server group

## Description

The **snmp-server group** command is used to manage and configure the SNMP group. To delete the corresponding SNMP group, please use **no snmp-server group** command. SNMP v3 provides the VACM (View-based Access Control Model) and USM (User-Based Security Model) mechanisms for authentication. The users in the SNMP Group can manage the device via the Read View, Write View and Notify View. And the authentication mode and the privacy mode guarantee the high security for the communication between the management station and the managed device.

## Syntax

```
snmp-server group name [ smode v3 ] [ slev { noAuthNoPriv | authNoPriv | authPriv } ] [ read read-view ] [ write write-view ] [ notify notify-view ]
```

```
no snmp-server group name smode v3 slev { noAuthNoPriv | authNoPriv | authPriv }
```

## Parameter

*name* — The SNMP Group name, ranging from 1 to 16 characters. The Group Name, Security Model and Security Level compose the identifier of the



SNMP Group. These three items of the Users in one group should be the same.

**v3** — The security mode for the group, v3 indicates SNMPv3, the most secure level.

**slev** — The Security Level of SNMP v3 Group. There are three options, including noAuthNoPriv (No authentication algorithm but a user name match is applied to check packets, and no privacy algorithm is applied to encrypt them), authNoPriv (An authentication algorithm is applied to check packets, but no privacy algorithm is applied to encrypt them) and authPriv (An authentication algorithm and a privacy algorithm are applied to check and encrypt packets). By default, the Security Level is noAuthNoPriv. There is no need to configure this in SNMP v1 Mode and SNMP v2c Mode.

**read-view** — Select the View to be the Read View. The management access is restricted to read-only, and changes cannot be made to the assigned SNMP View.

**write-view** — Select the View to be the Write View. The management access is writing only and changes can be made to the assigned SNMP View. The View defined both as the Read View and the Write View can be read and modified.

**notify-view** — Select the View to be the Notify View. The management station can receive notification messages of the assigned SNMP view generated by the switch's SNMP agent.

## Command Mode

Global Configuration Mode

## Privilege Requirement

Only Admin level users have access to these commands.

## Example

Add a group, and configure the name as group 1, the Security Model as SNMP v3, the security level as authNoPriv, the management access to the assigned View viewDefault as read-write, besides the notification messages sent by View viewDefault can be received by Management station:

```
Switch(config)# snmp-server group group1 smode v3 slev authNoPriv read
viewDefault write viewDefault notify viewDefault
```

Delete group 1:

```
Switch(config)# no snmp-server group group1 smode v3 slev authNoPriv
```

## 73.4 snmp-server user

### Description

The **snmp-server user** command is used to add User. To delete the corresponding User, please use **no snmp-server user** command. The User in an SNMP Group can manage the switch via the management station software. The User and its Group have the same security level and access right.

### Syntax

#### For L2/L2+ switches:

```
snmp-server user name { local | remote } group-name [ smode v3 ] [ slev noAuthNoPriv ] [ cmode none ] [ cpwd confirm-pwd ] [ emode none ] [ epwd encrypt-pwd ]
```

```
snmp-server user name { local | remote } group-name [ smode v3 ] slev authNoPriv cmode { MD5 | SHA } cpwd confirm-pwd [ emode none ] [ epwd encrypt-pwd ]
```

```
snmp-server user name { local | remote } group-name [ smode v3 ] slev authPriv cmode { MD5 | SHA } cpwd confirm-pwd emode DES epwd encrypt-pwd
```

```
no snmp-server user name
```

#### For L3 switches:

```
snmp-server user name { local | remote } group-name [ smode v3 ] [ slev noAuthNoPriv ]
```

```
snmp-server user name { local | remote } group-name [ smode v3 ] slev authNoPriv cmode { MD5 | SHA } cpwd confirm-pwd
```

```
snmp-server user name { local | remote } group-name [ smode v3 ] slev authPriv cmode { MD5 | SHA } cpwd confirm-pwd emode DES epwd encrypt-pwd
```

```
no snmp-server user name
```

### Parameter

*name*—— User Name, ranging from 1 to 16 characters.

local | remote —— User Type, with local and remote options. Local indicates that the user is connected to a local SNMP engine, while remote means that the user is connected to a remote SNMP engine. As the remote engine ID and user password are used to compute the authentication and privacy digests, before configuring a remote user, you need to set the remote engine ID first.

*group-name* — The Group Name of the User. The User is classified to the corresponding Group according to its Group Name, Security Model and Security Level.

*v3* — The security mode for the user. *v3* indicates SNMPv3, the most secure model.

*slev* — The Security Level of SNMP v3 User. There are three options, including *noAuthNoPriv* (No authentication algorithm but a user name match is applied to check packets, and no privacy algorithm is applied to encrypt them), *authNoPriv* (An authentication algorithm is applied to check packets, but no privacy algorithm is applied to encrypt them) and *authPriv* (An authentication algorithm and a privacy algorithm are applied to check and encrypt packets). The security level from lowest to highest is: *noAuthNoPriv*, *authNoPriv*, *authPriv*, and the default is *noAuthNoPriv*. The security level of the user should not be lower than the group it belongs to.

*cmode* — The Authentication Mode of the SNMP v3 User, with *none*, *MD5* and *SHA* options. *None* indicates no authentication method is used, *MD5* indicates the port authentication is performed via HMAC-MD5 algorithm and *SHA* indicates the port authentication is performed via SHA (Secure Hash Algorithm). *SHA* authentication mode has a higher security than *MD5* mode. By default, the Authentication Mode is “*none*”.

*confirm-pwd* — Authentication Password, ranging from 1 to 16 characters. The question marks and spaces are not allowed. This password in the configuration file will be displayed in the symmetric encrypted form.

*emode* — The Privacy Mode of the SNMP v3 User, with *none* and *DES* options. *None* indicates no privacy method is used, and *DES* indicates DES encryption method is used. By default, the Privacy Mode is “*none*”.

*encrypt-pwd* — Privacy Password, ranging from 1 to 16 characters. The question marks and spaces are not allowed. This password in the configuration file will be displayed in the symmetric encrypted form.

## **Command Mode**

Global Configuration Mode

## **Privilege Requirement**

Only Admin level users have access to these commands.

## **Example**

Add Local User *admin* to Group *group2*, and configure the Security Model of the user as *v3*, the Security Level of the group as *authPriv*, the Authentication

Mode of the user as MD5, the Authentication Password as 11111, the Privacy Mode as DES, and the Privacy Password as 22222:

```
Switch(config)# snmp-server user admin local group2 smode v3 slev  
authPriv cmode MD5 cpwd 11111 emode DES epwd 22222
```

## 73.5 snmp-server community

### Description

The **snmp-server community** command is used to add Community. To delete the corresponding Community, please use **no snmp-server community** command. SNMP v1 and SNMP v2c adopt community name authentication. The community name can limit access to the SNMP agent from SNMP network management station, functioning as a password.

### Syntax

```
snmp-server community name { read-only | read-write } mib-view
```

```
no snmp-server community name
```

### Parameter

*name*—— Community Name, ranging from 1 to 16 characters.

read-only | read-write —— The access rights of the community, with read-only and read-write options.

*mib-view*—— The MIB View for the community to access.

### Command Mode

Global Configuration Mode

### Privilege Requirement

Only Admin level users have access to these commands.

### Example

Add community public, and the community has read-write management right to View viewDefault:

```
Switch(config)# snmp-server community public read-write viewDefault
```

## 73.6 snmp-server host

### Description

The **snmp-server host** command is used to add Notification. To delete the corresponding Notification, please use **no snmp-server host** command.

## Syntax

```
snmp-server host ip udp-port user-name [ smode { v1 | v2c | v3 } ] [ slev  
{ noAuthNoPriv | authNoPriv | authPriv } ] [ type { trap | inform } ] [ retries retries ]  
[ timeout timeout ]
```

```
no snmp-server host ip user-name
```

## Parameter

*ip* — The IP Address of the management Host. Both IPv4 and IPv6 addresses are supported, for example 192.168.0.100 or fe80::1234.

*udp-port* — UDP port, which is used to send notifications. The UDP port functions with the IP address for the notification sending. It ranges from 1 to 65535.

*user-name* — The User name of the management station.

*smode* — The Security Model of the management station, with v1, v2c and v3 options. By default, the option is v1.

*slev* — The Security Level of SNMP v3 User. There are three options, including noAuthNoPriv (No authentication algorithm but a user name match is applied to check packets, and no privacy algorithm is applied to encrypt them), authNoPriv (An authentication algorithm is applied to check packets, but no privacy algorithm is applied to encrypt them) and authPriv (An authentication algorithm and a privacy algorithm are applied to check and encrypt packets). By default, the Security Level is noAuthNoPriv.

*type* — The type of the notifications, with trap and inform options. Trap indicates traps are sent, while inform indicates informs are sent. The inform type has a higher security than the trap type and resend and timeout need to be configured if you select this option. You can only select the trap type in Security Model v1. By default, the type of the notifications is "trap".

*retries* — The amount of times the switch retries an inform request, ranging from 1 to 255. The switch will resend the inform request if it doesn't get the response from the management station during the Timeout interval, and it will terminate resending the inform request if the resending times reach the specified Retry times.

*timeout* — The maximum time for the switch to wait for the response from the management station before resending a request, ranging from 1 to 3600 in seconds.

## Command Mode

Global Configuration Mode

## Privilege Requirement

Only Admin level users have access to these commands.

## Example

Add a Notification entry, and configure the IP address of the management Host as 192.168.0.146, the UDP port as 162, the User name of the management station as admin, the Security Model of the management station as v2c, the type of the notifications as inform, the maximum time for the switch to wait as 1000 seconds, and the retries time as 100:

### For L2/L2+ switches:

```
Switch(config)#snmp-server host 192.168.0.146 162 admin smode v2c  
type inform retries 100 timeout 1000
```

### For L3 switches:

```
Switch(config)#snmp-server host 192.168.0.146 162 admin smode v2c  
slev noAuthNoPriv type inform retries 100 timeout 1000
```

```
Switch(config)#snmp-server host fe80::1234 162 admin smode v2c slev  
noAuthNoPriv type inform retries 100 timeout 1000
```

Add a Notification entry, and configure the IP Address of the management Host as fe80::1234, the UDP port as 162, the User name of the management station as admin, the Security Model of the management station as v2c, the type of the notifications as inform, the maximum time for the switch to wait as 1000 seconds, and the retries time as 100:

```
Switch(config)# snmp-server host fe80::1234 162 admin smode v2c type  
inform retries 100 timeout 1000
```

## 73.7 snmp-server engineID

### Description

The **snmp-server engineID** command is used to configure the local and remote engineID of the switch. To restore to the default setting, please use **no snmp-server engineID** command.

### Syntax

```
snmp-server engineID { [ local local-engineID] [ remote remote-engineID] }  
no snmp-server engineID
```

## Parameter

*local-engineID*— Local Engine ID for local clients. The Engine ID is a unique alphanumeric string used to identify the SNMP engine on the switch. Its length ranges from 10 to 64 hexadecimal characters, which must be even number meanwhile.

*remote-engineID* — Remote Engine ID for the switch. The Engine ID is a unique alphanumeric string used to identify the SNMP engine on the remote device which receives informs from the switch. Its length ranges from 10 to 64 hexadecimal characters, which must be even number meanwhile. The **snmp-server engineID** will be disabled if the **local** and **remote** are both not configured.

## Command Mode

Global Configuration Mode

## Privilege Requirement

Only Admin level users have access to these commands.

## Example

Specify the local engineID as 1234567890, and the remote engineID as abcdef123456:

```
Switch(config)# snmp-server engineID local 1234567890
```

```
Switch(config)# snmp-server engineID remote abcdef123456
```

# 73.8 snmp-server traps snmp

## Description

The **snmp-server traps snmp** command is used to enable SNMP standard traps which include four types: linkup, linkdown, warmstart and coldstart. The command without parameter enables all SNMP standard traps. All SNMP standard traps are enabled by default. To disable the sending of SNMP standard traps, please use **no snmp-server traps snmp** command.

## Syntax

```
snmp-server traps snmp [ linkup | linkdown | warmstart | coldstart |  
auth-failure ]
```

```
no snmp-server traps snmp [ linkup | linkdown | warmstart | coldstart |  
auth-failure ]
```

## Parameter

linkup — Indicates a port status changes from linkdown to linkup, and can be triggered when you connect a device to a port.

linkdown — Indicates a port status changes from linkup to linkdown, and can be triggered when you disconnect a device to a port.

warmstart — Indicates the SNMP feature on the switch is reinitialized with the physical configuration unchanged. The trap can be triggered if you disable and then enable SNMP after the SNMP is completely configured and enabled.

coldstart — Indicates an SNMP initialization caused by the reinitialization of the switch system. The trap can be triggered when you reboot the switch.

auth-failure — Triggered when a received SNMP request fails the authentication.

## Command Mode

Global Configuration Mode

## Privilege Requirement

Only Admin level users have access to these commands.

## Example

Enable SNMP standard linkup trap for the switch:

```
Switch(config)# snmp-server traps snmp linkup
```

# 73.9 snmp-server traps

## Description

The **snmp-server traps** command is used to enable SNMP extended traps. To disable the sending of SNMP extended traps, please use **no snmp-server traps** command. All SNMP extended traps are disabled by default.

## Syntax

```
snmp-server traps { rate-limit | cpu | flash | lldp remtableschange | lldp topologychange | loopback-detection | storm-control | spanning-tree | memory }
```

```
no snmp-server traps { rate-limit | cpu | flash | lldp remtableschange | lldp topologychange | loopback-detection | storm-control | spanning-tree | memory }
```



## Parameter

rate-limit —Monitors whether the bandwidth has reached the limit you have set. The trap can be triggered when the Rate Limit feature is enabled and packets are sent to the port with a rate higher than what you have set.

cpu —Monitors the load status of the switch CPU. The trap can be triggered when the utilization rate of the CPU has exceeded the limit that you have set. The limit of CPU utilization rate for the switch is 80% by default.

flash —Triggered when flash is modified during operations such as backup, reset, firmware upgrade, configuration import, and so on.

Ildp remtableschange —An Ildp RemTablesChange notification is sent when the value of Ildp StatsRemTableLastChangeTime changes. It can be utilized by an NMS host to trigger LLDP remote systems table maintenance polls.

Ildp topologychange —A notification generated by the local device to sense the change in the topology that indicates a new remote device attached to a local port, or a remote device disconnected or moved from one port to another.

loopback-detection —The feature is used to detect loopbacks. And the trap is disabled by default. The system will generate the trap when a loopback is detected or cleared.

storm-control —The feature is used to monitor network storms. And the trap is disabled by default. The system will generate the trap when the rate of broadcast or multicast reaches the limit of storm control.

spanning-tree —The feature is used to monitor the spanning tree status. And the trap is disabled by default. The system will generate the trap in the following situations: a port changes from non-forwarding state to forwarding state or the other way round; a port receives a packet with TC flag or a TCN packet.

memory —The feature is used to monitor the memory. And the trap is disabled by default. The system will generate the trap when the memory utilization exceeds 80%.

## Command Mode

Global Configuration Mode

## Privilege Requirement

Only Admin level users have access to these commands.

## Example

Enable SNMP extended rate-limit trap for the switch:

```
Switch(config)# snmp-server traps rate-limit
```

# 73.10 snmp-server traps ddm



**Note:** This command is only available on certain devices.

## Description

The **snmp-server traps ddm** command is used to enable the corresponding DDM traps. DDM function is used to monitor the status of the SFP modules inserted into the SFP ports on the switch. The command without parameter enables all SNMP DDM traps. To disable the sending of SNMP DDM traps, use **no snmp-server traps ddm** command. All DDM traps are disabled by default.

## Syntax

```
snmp-server traps ddm [ temperature | voltage | bias_current | tx_power | rx_power ]
```

```
no snmp-server traps ddm [ temperature | voltage | bias_current | tx_power | rx_power ]
```

## Parameter

**temperature** — Monitors the temperature of SFP modules inserted into the SFP ports on the switch. The trap can be triggered when the temperature of any SFP module has reached the warning or alarm threshold.

**voltage** — Monitors the voltage of SFP modules inserted into the SFP ports on the switch. The trap can be triggered when the voltage of any SFP module has reached the warning or alarm threshold.

**bias\_current** — Monitors the bias current of SFP modules inserted into the SFP ports on the switch. The trap can be triggered when the bias current of any SFP module has reached the warning or alarm threshold.

**tx\_power** — Monitors the TX Power of SFP modules inserted into the SFP ports on the switch. The trap can be triggered when the TX Power of any SFP module has reached the warning or alarm threshold.

**rx\_power** — Monitors the RX Power of SFP modules inserted into the SFP ports on the switch. The trap can be triggered when the RX Power of any SFP module has reached the warning or alarm threshold.

## User guidelines

The **snmp-server traps ddm** command without any parameter is used to enable all the types of DDM traps. And the **no snmp-server traps ddm** command without any parameter is used to disable all the types of DDM traps.

For more instructions about the alarm threshold or warning threshold, refer to [Chapter 11 DDM Commands](#).

## Command Mode

Global Configuration Mode

## Example

Enable all the SNMP DDM traps for the switch:

```
Switch(config)# snmp-server traps ddm
```

# 73.11 snmp-server traps vlan

## Description

The **snmp-server traps vlan** command is used to enable the corresponding VLAN traps. The command without parameter enables all SNMP VLAN traps. To disable this function, please use **no snmp-server traps vlan** command. All VLAN traps are disabled by default.

## Syntax

```
snmp-server traps vlan [ create | delete ]
```

```
no snmp-server traps vlan [create | delete ]
```

## Parameter

create ——Triggered when certain VLANs are created successfully.

delete ——Triggered when certain VLANs are deleted successfully.

## Command Mode

Global Configuration Mode

## Privilege Requirement

Only Admin level users have access to these commands.

## Example

Enable all SNMP extended VLAN-related traps for the switch:

```
Switch(config)# snmp-server traps vlan
```

Enable VLAN-created trap only for the switch:

```
Switch(config)# snmp-server traps vlan create
```

## 73.12 snmp-server traps security

### Description

The **snmp-server traps security** command is used to enable the corresponding security traps. To disable this feature, please use **no snmp-server traps security** command. All security traps are disabled by default.

### Syntax

```
snmp-server traps security { dhcp-filter | ip-mac-binding }
```

```
no snmp-server traps security { dhcp-filter | ip-mac-binding }
```

### Parameter

dhcp-filter — Triggered when the DHCPv4 Filter feature is enabled and the switch receives DHCP packets from an illegal DHCP server.

ip-mac-binding — Triggered when the ARP Inspection feature is enabled and the switch receives an illegal ARP packet, or the IPv4 Source Guard feature is enabled and the switch receives an illegal IP packet.

### Command Mode

Global Configuration Mode

### Privilege Requirement

Only Admin level users have access to these commands.

### Example

Enable the DHCP filter trap for the switch:

```
Switch(config)# snmp-server traps security dhcp-filter
```

## 73.13 snmp-server traps security dhcp6-filter

### Description

The **snmp-server traps security dhcp6-filter** command is used to enable the IPv6 DHCP Filter illegal message snmp trap and log function. To disable this function, please use **no snmp-server traps security dhcp6-filter** command. All security traps are disabled by default.

### Syntax

```
snmp-server traps security dhcp6-filter
```

**no snmp-server traps security dhcp6-filter**

### Command Mode

Global Configuration Mode

### Privilege Requirement

Only Admin level users have access to these commands.

### Example

Enable the IPv6 DHCP Filter illegal message snmp trap and log function:

```
Switch(config)# snmp-server traps security dhcp6-filter
```

## 73.14 snmp-server traps acl

### Description

The **snmp-server traps acl** command is used to enable the ACL trap. To disable this feature, please use **no snmp-server traps acl** command. It is disabled by default.

The trap monitors matched ACL information, including the matched ACL ID, rule ID and the number of the matched packets. With both this trap and the Logging feature in ACL rule settings enabled, the switch will check the matched ACL information every five minutes and send SNMP traps if there is any updated information.

### Syntax

**snmp-server traps acl**

**no snmp-server traps acl**

### Command Mode

Global Configuration Mode

### Privilege Requirement

Only Admin level users have access to these commands.

### Example

Enable the ACL trap for the switch:

```
Switch(config)# snmp-server traps acl
```

## 73.15 snmp-server traps ip

### Description

The **snmp-server traps ip** command is used to enable IP traps. To disable this feature, please use **no snmp-server traps ip** command. All IP traps are

disabled by default.

### Syntax

**snmp-server traps ip** { change | duplicate }

**no snmp-server traps ip** { change | duplicate }

### Parameter

change — Enable SNMP IP change traps. The trap monitors the IP changed of each interface. The trap can be triggered when the IP address of any interface is changed.

duplicate — Enable SNMP IP duplicate traps. The trap can be triggered when the switch detects an IP conflict event.

### Command Mode

Global Configuration Mode

### Privilege Requirement

Only Admin level users have access to these commands.

### Example

Enable the IP-Change trap for the switch:

```
Switch(config)# snmp-server traps ip change
```

## 73.16 snmp-server traps power

(Only for Certain Devices)



**Note:** This command is only available on certain devices

### Description

The **snmp-server traps power** command is used to enable PoE traps. The command without parameter enables all PoE traps. To disable this feature, please use **no snmp-server traps power** command. All PoE traps are disabled by default.

### Syntax

**snmp-server traps power** [over-max-pwr-budget | port-pwr-change | port-pwr-deny | port-pwr-over-30w | port-pwr-overload | port-short-circuit | thermal-shutdown ]

**no snmp-server traps power** [over-max-pwr-budget | port-pwr-change | port-pwr-deny | port-pwr-over-30w | port-pwr-overload | port-short-circuit | thermal-shutdown ]

## Parameter

**over-max-pwr-budget** —Triggered when the total power required by the connected PDs exceeds the maximum power the PoE switch can supply.

**port-pwr-change** —Triggered when the total power required by the connected PDs exceeds the maximum power the PoE switch can supply.

**port-pwr-deny** —Triggered when the switch powers off PDs on low-priority PoE ports. When the total power required by the connected PDs exceeds the system power limit, the switch will power off PDs on low-priority PoE ports to ensure stable running of the other PDs.

**port-pwr-over-30w** —Triggered when the power required by the connected PD exceeds 30 watts.

**port-pwr-overload** —Triggered when the power required by the connected PD exceeds the maximum power the port can supply.

**port-short-circuit** —Triggered when a short circuit is detected on a port.

**thermal-shutdown** —Triggered when the PSE chip overheats. The switch will stop supplying power in this case.

## Command Mode

Global Configuration Mode

## Privilege Requirement

Only Admin level users have access to these commands.

## Example

Enable all PoE traps for the switch:

```
Switch(config)# snmp-server traps power
```

# 73.17 snmp-server traps

## link-status

### Description

The **snmp-server traps link-status** command is used to enable SNMP link status trap for the specified port. To disable the sending of SNMP link status trap, please use **no snmp-server traps link-status** command. By default, it is enabled.

### Syntax

**snmp-server traps link-status**

**no snmp-server traps link-status**

## Command Mode

Interface Configuration Mode (interface gigabitEthernet / interface range gigabitEthernet)

## Privilege Requirement

Only Admin level users have access to these commands.

## Example

Enable SNMP link status trap for port 3:

```
Switch(config)# interface gigabitEthernet 1/0/3
Switch(config-if)# snmp-server traps link-status
```

# 73.18 rmon history

## Description

The **rmon history** command is used to configure the history sample entry. To return to the default configuration, please use **no rmon history** command. RMON (Remote Monitoring), basing on SNMP architecture, functions to monitor the network. History Group is one of the commonly used RMON Groups. After a history group is configured, the switch collects network statistics information periodically, based on which the management station can monitor network effectively.

## Syntax

```
rmon history index interface gigabitEthernet port [ interval interval ]
[ owner owner-name ] [ buckets number ]
no rmon history index
```

## Parameter

*index* — The index number of the entry, ranging from 1 to 12, in the format of 1-3,5.

*port* — The Ethernet port number.

*interval* — The interval to take samplings from the port, ranging from 10 to 3600 in seconds. By default, it is 1800.

*owner-name* — The owner of the history sample entry, ranging from 1 to 16 characters. By default, it is "monitor".

*number* — The maximum number of buckets desired for the RMON history group of statistics, ranging from 1 to 130. The default is 50 buckets.



## Command Mode

Global Configuration Mode

## Privilege Requirement

Only Admin level users have access to these commands.

## Example

Configure the sample port as Gi1/0/2 and the sample interval as 100 seconds for the entry 1-3:

```
Switch(config)# rmon history 1-3 interface gigabitEthernet 1/0/2 interval
100 owner owner1
```

# 73.19 rmon event

## Description

The **rmon event** command is used to configure the entries of SNMP-RMON Event. To return to the default configuration, please use **no rmon event** command. Event Group, as one of the commonly used RMON Groups, is used to define RMON events. Alarms occur when an event is detected.

## Syntax

```
rmon event index [user user-name] [description descript] [type { none |
log | notify | log-notify }] [owner owner-name]
```

```
no rmon event index
```

## Parameter

*index* — The index number of the event entry, ranging from 1 to 12. You can only select one entry for each command.

*user-name* — The name of the User to which the event belongs, ranging from 1 to 16 characters. By default, it is "public".

*descript* — The description of the event, ranging from 1 to 16 characters. By default, it is empty.

*type* — The event type, with none, log, notify and both options. None indicates no processing, log indicates logging the event, notify indicates sending trap messages to the management station, and both indicates logging the event and sending trap messages to the management station.

*owner-name* — The owner of the event entry, ranging from 1 to 16 characters. By default, it is "monitor".

## Command Mode

Global Configuration Mode

## Privilege Requirement

Only Admin level users have access to these commands.

## Example

Configure the user name of entry 1, 2, 3 and 4 as user1, the description of the event as description1, the type of event as log and the owner of the event as owner1:

```
Switch(config)# rmon event 1-4 user user1 description description1 type  
log owner owner1
```

# 73.20 rmon alarm

## Description

The **rmon alarm** command is used to configure SNMP-RMON Alarm Management. To return to the default configuration, please use **no rmon alarm** command. Alarm Group is one of the commonly used RMON Groups. RMON alarm management allows monitoring the specific alarm variables. When the value of a monitored variable exceeds the threshold, an alarm event is generated, which triggers the switch to act in the set way.

## Syntax

```
rmon alarm index { stats-index sindex } [ alarm-variable { revbyte | revpkt |  
bpkt | mpkt | crc-lign | undersize | oversize | jabber | collision | 64 | 65-127 |  
128-511 | 512-1023 | 1024-10240 } ] [ s-type { absolute | delta } ]  
[ rising-threshold r-hold ] [ rising-event-index r-event ] [ falling-threshold  
f-hold ] [ falling-event-index f-event ] [ a-type { rise | fall | all } ] [ owner  
owner-name ] [ interval interval ]
```

```
no rmon alarm index
```

## Parameter

*index* — The index number of the Alarm Management entry, ranging from 1 to 12, in the format of 1-3,5.

*sindex* — Specify the statistics index.

alarm-variable — The alarm variable. By default, the option is revbyte.

s-type — Sample Type, which is the sampling method for the selected variable and comparing the value against the thresholds. There are two options, absolute and delta. Absolute indicates comparing the values directly

with the thresholds at the end of the sampling interval. Delta indicates subtracting the last sampled value from the current value, and then comparing the difference in the values with the threshold. By default, the Sample Type is absolute.

*r-hold* — The rising counter value that triggers the Rising Threshold alarm, ranging from 1 to 2147483647. By default, it is 100.

*r-event* — Rise Event, which is the index of the corresponding event which will be triggered if the sampled value is larger than the Rising Threshold. It ranges from 1 to 12.

*f-hold* — The falling counter value that triggers the Falling Threshold alarm, ranging from 1 to 2147483647. By default, it is 100.

*f-event* — Fall Event, which is the index of the corresponding event which will be triggered if the sampled value is lower than the Falling Threshold. It ranges from 1 to 12.

*a-type* — Alarm Type, with rise, fall and all options. Rise indicates that the alarm event will be triggered when the sampled value exceeds the Rising Threshold, fall indicates that the alarm event will be triggered when the sampled value is under the Falling Threshold, and all indicates that the alarm event will be triggered either the sampled value exceeds the Rising Threshold or is under the Falling Threshold. By default, the Alarm Type is all.

*owner-name* — The owner of the entry, ranging from 1 to 16 characters. By default, it is monitor.

*interval* — The alarm interval time, ranging from 10 to 3600 in seconds. By default, it is 1800.

## Command Mode

Global Configuration Mode

## Privilege Requirement

Only Admin level users have access to these commands.

## Example

Configure rmon alarm entries 1-3 binding with statistics entry 2, the owners as owner1 and the alarm intervals as 100 seconds:

```
Switch(config)#rmon alarm 1-3 stats-index 2 owner owner1 interval 100
```

## 73.21 rmon statistics

### Description

The **rmon statistics** command is used to configure the entries of SNMP-RMON statistics. To delete the corresponding entry, please use **no rmon statistics** command. The maximum supported entries are 1000.

### Syntax

```
rmon statistics index interface gigabitEthernet port [ owner owner-name ]  
[ status { underCreation | valid } ]
```

```
no rmon statistics index
```

### Parameter

*index* — The index number of the statistics entry, ranging from 1 to 65535, in the format of 1-3,5.

*port* — The statistics port number, in the format of 1/0/1.

*owner-name* — The creator of the event entry, ranging from 1 to 16 characters. By default, it is "monitor".

*status* — The status of the statistics entry, either "underCreation" or "valid". "underCreation" means this entry won't take effect until it is modified to "valid"; "valid" means this entry takes effect immediately after it is created.

### Command Mode

Global Configuration Mode

### Privilege Requirement

Only Admin level users have access to these commands.

### Example

Configure the statistics entries 1-3 with the statistics port as 1/0/1, owner as owner1 and status as valid:

```
Switch(config)#rmon statistics 1-3 interface gigabitEthernet 1/0/1 owner  
owner1 status valid
```

## 73.22 show snmp-server

### Description

The **show snmp-server** command is used to display SNMP configuration globally.

## Syntax

```
show snmp-server
```

## Command Mode

Privileged EXEC Mode and Any Configuration Mode

## Privilege Requirement

Only Admin level users have access to these commands.

## Example

Display SNMP configuration globally:

```
Switch# show snmp-server
```

# 73.23 show snmp-server view

## Description

The **show snmp-server view** command is used to display the View table.

## Syntax

```
show snmp-server view
```

## Command Mode

Privileged EXEC Mode and Any Configuration Mode

## Privilege Requirement

Only Admin level users have access to these commands.

## Example

Display the View table:

```
Switch# show snmp-server view
```

# 73.24 show snmp-server group

## Description

The **show snmp-server group** command is used to display the Group table.

## Syntax

```
show snmp-server group
```

## Command Mode

Privileged EXEC Mode and Any Configuration Mode

## Privilege Requirement

Only Admin level users have access to these commands.

## Example

Display the Group table:

```
Switch# show snmp-server group
```

## 73.25 show snmp-server user

### Description

The **show snmp-server user** command is used to display the User table.

### Syntax

```
show snmp-server user
```

### Command Mode

Privileged EXEC Mode and Any Configuration Mode

### Privilege Requirement

Only Admin level users have access to these commands.

## Example

Display the User table:

```
Switch# show snmp-server user
```

## 73.26 show snmp-server community

### Description

The **show snmp-server community** command is used to display the Community table.

### Syntax

```
show snmp-server community
```

### Command Mode

Privileged EXEC Mode and Any Configuration Mode

### Privilege Requirement

Only Admin level users have access to these commands.

## Example

Display the Community table:

```
Switch# show snmp-server community
```

## 73.27 show snmp-server host

### Description

The **show snmp-server host** command is used to display the Host table.

### Syntax

```
show snmp-server host
```

### Command Mode

Privileged EXEC Mode and Any Configuration Mode

### Privilege Requirement

Only Admin level users have access to these commands.

### Example

Display the Host table:

```
Switch# show snmp-server host
```

## 73.28 show snmp-server engineID

### Description

The **show snmp-server engineID** command is used to display the engineID of the SNMP.

### Syntax

```
show snmp-server engineID
```

### Command Mode

Privileged EXEC Mode and Any Configuration Mode

### Privilege Requirement

Only Admin level users have access to these commands.

### Example

Display the engineID:

```
Switch# show snmp-server engineID
```

## 73.29 show rmon history

### Description

The **show rmon history** command is used to display the configuration of the history sample entry.

## Syntax

**show rmon history** [ *index* ]

## Parameter

*index* — The index number of the entry selected to display the configuration, ranging from 1 to 12, in the format of 1-3, 5. You can select more than one entry for each command. By default, the configuration of all history sample entries is displayed.

## Command Mode

Privileged EXEC Mode and Any Configuration Mode

## Privilege Requirement

Only Admin level users have access to these commands.

## Example

Display the configuration of all history sample entries:

```
Switch# show rmon history
```

# 73.30 show rmon event

## Description

The **show rmon event** command is used to display the configuration of SNMP-RMON Event.

## Syntax

**show rmon event** [ *index* ]

## Parameter

*index* — The index number of the entry selected to display the configuration, ranging from 1 to 12, in the format of 1-3, 5. You can select more than one entry for each command. By default, the configuration of all SNMP-RMON enabled entries is displayed.

## Command Mode

Privileged EXEC Mode and Any Configuration Mode

## Privilege Requirement

Only Admin level users have access to these commands.

## Example

Display the Event configuration of entry1-4:

```
Switch# show rmon event 1-4
```



## 73.31 show rmon alarm

### Description

The **show rmon alarm** command is used to display the configuration of the Alarm Management entry.

### Syntax

```
show rmon alarm [ index ]
```

### Parameter

*index* — The index number of the entry selected to display the configuration, ranging from 1 to 12, in the format of 1-3, 5. You can select more than one entry for each command. By default, the configuration of all Alarm Management entries is displayed.

### Command Mode

Privileged EXEC Mode and Any Configuration Mode

### Privilege Requirement

Only Admin level users have access to these commands.

### Example

Display the configuration of the Alarm Management entry 1-2:

```
Switch# show rmon alarm 1-2
```

## 73.32 show rmon statistics

### Description

The **show rmon statistics** command is used to display the configuration of the specified statistics entry.

### Syntax

```
show rmon statistics [ index ]
```

### Parameter

*index* — The index number of the statistics entry selected to display the configuration, ranging from 1 to 65535. By default, the configuration of all statistics entries is displayed.

### Command Mode

Privileged EXEC Mode and Any Configuration Mode

### Privilege Requirement

Only Admin level users have access to these commands.

## Example

Display the configuration of the statistics entry 1:

```
Switch#show rmon statistics 1
```

# Chapter 74 PoE Commands (Only for Certain Devices)



**Note:** PoE commands are only available on certain devices.

PoE (Power over Ethernet) technology describes a system to transmit electrical power along with data to remote devices over standard twisted-pair cable in an Ethernet network. It is especially useful for supplying power to IP telephones, wireless LAN access points, cameras and so on.

## 74.1 power inline consumption (global)

### Description

The **power inline consumption** command is used to configure the max power the PoE switch can supply globally.

### Syntax

**power inline consumption** *power-limit*

### Parameter

*power-limit*—The max power the PoE switch can supply.

### Command Mode

Global Configuration Mode

### Privilege Requirement

None.

### Example

Configure the max power the PoE switch can supply as 160 W:

```
Switch(config)# power inline consumption 160
```

## 74.2 power profile

### Description

The **power profile** command is used to create a PoE profile for the switch. To delete the configured PoE profile configuration, please use **no power profile**

command. PoE Profile is a short cut for the configuration of the PoE port. In a PoE profile, the PoE status, PoE priority and power limit are configured. You can specify a PoE profile for each PoE port individually.

## Syntax

```
power profile name [supply {enable | disable} [priority {low | middle | high} [consumption { power-limit | auto | class1 | class2 | class3 | class4 } ] ] ] ]
```

```
no power profile name
```

## Parameter

*name* — The PoE profile name, ranging from 1 to 16 characters. If the name being assigned contains spaces then put it inside double quotes.

**supply** — The PoE status of the port in the profile. By default, the PoE status is "enable".

**priority** — The PoE priority of the port in the profile. The priority levels include "high", "middle" and "low" in descending order. When the supply power exceeds the system power limit, the PD linked to the port with lower priority will be disconnected. By default, the PoE priority is "low".

**consumption** — The max power the port in the profile can supply, with five options: "power-limit", "auto", "class1", "class2", "class3" and "class4". "Power-limit" indicates you can manually enter a value ranging from 1 to 300. The value is in the unit of 0.1 watt. For instance, if you want to configure the max power as 5w, you should enter 50. "Auto" indicates the value is assigned automatically by the PoE switch. "Class1" represents 4w. "Class2" represents 7w. "Class3" represents 15.4w. "Class4" represents 30w.

## Command Mode

Global Configuration Mode

## Privilege Requirement

None.

## Example

Create a PoE profile named "IP Camera" whose PoE status is "enable", PoE priority is "low" and the power limit is "5w":

```
Switch(config)# power profile "IP Camera" supply enable priority low  
consumption 50
```

## 74.3 power inline consumption (interface)

### Description

The **power inline consumption** command is used to configure the power limit the corresponding port can supply.

### Syntax

```
power inline consumption { power-limit | auto | class1 | class2 | class3 | class4 }
```

### Parameter

*power-limit* — The max power the port in the profile can supply, with five options: "power-limit", "auto", "class1", "class2", "class3" and "class4". "Power-limit" indicates you can manually enter a value ranging from 1 to 300. The value is in the unit of 0.1 watt. For instance, if you want to configure the max power as 5w, you should enter 50. "Auto" indicates the value is assigned automatically by the PoE switch. "Class1" represents 4w. "Class2" represents 7w. "Class3" represents 15.4w. "Class4" represents 30w.

### Command Mode

Interface Configuration Mode (interface gigabitEthernet / interface range gigabitEthernet)

### Privilege Requirement

None.

### Example

Configure the power limit as "5w" for port 2:

```
Switch(config)# interface gigabitEthernet 1/0/2
Switch(config-if)# power inline consumption 50
```

## 74.4 power inline consumption (unit)

### Description

The **power inline unit consumption** command is used to specify the maximum power a stack unit can supply.

## Syntax

**power inline unit** {*unit id*} **consumption** {power-limit}

## Parameter

*unit id* — Stack unit ID, ranging from 1-4

power-limit — Specify the maximum power the PoE switch can supply, which depends on actual power usage.

## Command Mode

Global Configuration Mode

## Privilege Requirement

Only Admin, Operator and Power User level users have access to these commands.

## Example

Specify the maximum power unit 1 can supply to 402W:

```
Switch(config)#power inline unit 1 consumption 402
```

# 74.5 power inline priority

## Description

The **power inline priority** command is used to configure the PoE priority for the corresponding port

## Syntax

**power inline priority** { low | middle | high }

## Parameter

priority — The PoE priority of the port. The priority levels include "high", "middle" and "low" in descending order. When the supply power exceeds the system power limit, the PD linked to the port with lower priority will be disconnected. By default, the priority level is "low".

## Command Mode

Interface Configuration Mode (interface gigabitEthernet / interface range gigabitEthernet)

## Privilege Requirement

None.

## Example

Configure the PoE priority as "low" for port 2:

```
Switch(config)# interface gigabitEthernet 1/0/2
Switch(config-if)# power inline priority low
```

## 74.6 power inline supply

### Description

The **power inline supply** command is used to configure the PoE status of the corresponding port.

### Syntax

```
power inline supply { enable | disable }
```

### Parameter

enable | disable — The PoE status of the port. By default, the PoE status is "enable".

### Command Mode

Interface Configuration Mode (interface gigabitEthernet / interface range gigabitEthernet)

### Privilege Requirement

None.

### Example

Enable the PoE feature for port 2:

```
Switch(config)# interface gigabitEthernet 1/0/2
Switch(config-if)# power inline supply enable
```

## 74.7 power inline profile

### Description

The **power inline profile** command is used to bind a PoE profile to the corresponding port. To cancel the bind relation, please use **no power inline profile** command.

### Syntax

```
power inline profile name
no power inline profile
```

### Parameter

*name* — The name of the PoE profile to be bound to the port. If the name

being assigned contains spaces then put it inside double quotes.

### Command Mode

Interface Configuration Mode (interface gigabitEthernet / interface range gigabitEthernet)

### Privilege Requirement

None.

### Example

Bind the PoE profile named "IP Camera" to port 2:

```
Switch(config)# interface gigabitEthernet 1/0/2
Switch(config-if)# power inline profile "IP Camera"
```

## 74.8 power inline time-range

### Description

The **power inline time-range** command is used to bind a PoE time-range to the corresponding port. To cancel the bind relation, please use **no power inline time-range** command.

### Syntax

**power inline time-range** *name*

**no power inline time-range**

### Parameter

*name*—— The name of the PoE time-range to be bound to the port.

### Command Mode

Interface Configuration Mode

### Privilege Requirement

None.

### Example

Bind the PoE time-range named "tRange2" to port 2:

```
Switch(config)# interface gigabitEthernet 1/0/2
Switch(config-if)# power inline time-range tRange2
```



## 74.9 show power inline

### Description

The **show power inline** command is used to display the global PoE information of the system.

### Syntax

```
show power inline
```

### Command Mode

Privileged EXEC Mode and Any Configuration Mode

### Privilege Requirement

None.

### Example

Display the PoE information of the system:

```
Switch# show power inline
```

## 74.10 show power inline configuration interface

### Description

The **show power inline configuration interface** command is used to display the PoE configuration of the certain port.

### Syntax

```
show power inline configuration interface [ fastEthernet port |  
gigabitEthernet port | ten-gigabitEthernet port ]
```

### Parameter

*port*— The Ethernet port number.

### Command Mode

Privileged EXEC Mode and Any Configuration Mode

### Privilege Requirement

None.

### Example

Display the PoE configuration of all ports:

```
Switch# show power inline configuration interface
```

## 74.11 show power inline information interface

### Description

The **show power inline information** command is used to display the PoE information of the certain port.

### Syntax

```
show power inline information interface [ fastEthernet port | gigabitEthernet port | ten-gigabitEthernet port ]
```

### Parameter

*port*— The Ethernet port number.

### Command Mode

Privileged EXEC Mode and Any Configuration Mode

### Privilege Requirement

None.

### Example

Display the PoE information of all ports:

```
Switch# show power inline information interface
```

## 74.12 show power profile

### Description

The **show power profile** command is used to display the defined PoE profile.

### Syntax

```
show power profile
```

### Command Mode

Privileged EXEC Mode and Any Configuration Mode

### Privilege Requirement

None.

### Example

Display the defined PoE profile:

```
Switch# show power profile
```

## 74.13 power recovery stsus enable

### Description

The **power recovery stsus enable** command is used to enable the power auto recovery function globally. To disable this function, please use **power recovery stsus disable** command

### Syntax

```
power recovery stsus enable  
power recovery stsus disable
```

### Command Mode

Global Configuration Mode

### Privilege Requirement

Only Admin, Operator and Power User level users have access to these commands.

### Example

Enable the power auto recovery function globally:

```
Switch(config)# power recovery stsus enable
```

## 74.14 power recovery status

### Description

The **power recovery stsus** command is used to configure the power recovery status and parameters of a specified port..

### Syntax

```
power recovery stsus {disable|enable} ip ipv4_addr startup startup delay  
interval ping interval retry failure threshold break break time
```

### Parameter

*ipv4\_addr*—— Ipv4 address, in string format, for example, 192.168.0.1.

*startup delay*—— Feature startup delay(S), ranging from 30 to 600.

*ping interval*—— Ping package interval(S), ranging from 10 to 120.

*failure threshold*—— Number of ping failures, ranging from 1 to 10.

*break time* —— Break time after detecting abnormal POE status(S), ranging from 3 to 120.

## Command Mode

Interface Configuration Mode (interface gigabitEthernet / interface range gigabitEthernet)

## Privilege Requirement

Only Admin, Operator and Power User level users have access to these commands.

## Example

Enable the power recovery status of port 2 and configure relevant parameters:

```
Switch(config)# interface gigabitEthernet 1/0/2
Switch(config-if)# power recovery status enable ip 192.168.0.1 startup 60
interval 60 retry 5 break 60
```

# 74.15 show power recovery

## Description

The **show power recovery** command is used to display all POE auto recovery configurations.

## Syntax

```
show power recovery
```

## Command Mode

Privileged EXEC Mode and Any Configuration Mode

## Privilege Requirement

Only Admin, Operator and Power User level users have access to these commands.

## Example

Display all POE auto recovery configurations:

```
Switch(config)#show power recovery
```

## 74.16 show power recovery interface

### Description

The **show power recovery interface** command is used to display power auto recovery configurations of the selected port.

### Syntax

```
show power recovery interface [fastEthernet | gigabitEthernet | two-gigabitEthernet | ten-gigabitEthernet] port list
```

### Parameter

*interface*—— Port type.

*port list*—— Port number list.

### Command Mode

Privileged EXEC Mode and Any Configuration Mode

### Privilege Requirement

Only Admin, Operator and Power User level users have access to these commands.

### Example

Display power auto recovery configurations of:

```
Switch(config)#show power recovery
```

# Chapter 75 ARP Inspection Commands

ARP (Address Resolution Protocol) Detect function is to protect the switch from the ARP cheating, such as the Network Gateway Spoofing and Man-In-The-Middle Attack, etc.

## 75.1 ip arp inspection

### Description

The **ip arp inspection** command is used to enable the ARP Detection function globally. To disable the ARP Detection function, please use **no ip arp detection** command.

### Syntax

**ip arp inspection**  
**no ip arp inspection**

### Command Mode

Global Configuration Mode

### Privilege Requirement

Only Admin, Operator and Power User level users have access to these commands.

### Example

Enable the ARP Detection function globally:

```
Switch(config)#ip arp inspection
```

## 75.2 ip arp inspection validate

### Description

The **ip arp inspection validate** command is used to enable the switch to check whether the received ARP packet is illegal. To disable the feature please use **no ip arp detection validate** command.

### Syntax

**ip arp inspection validate { src-mac | dst-mac | ip }**  
**no ip arp inspection validate { src-mac | dst-mac | ip }**

## Syntax

`src-mac` — Enable the switch to check whether the source MAC address and the sender MAC address are the same when receiving an ARP packet. If not, the ARP packet will be discarded.

`dst-mac` — Enable the switch to check whether the sender IP address of all ARP packets and the target IP address of ARP reply packets are legal. The illegal packets will be discarded.

`ip` — Enable or disable the switch to check whether the sender IP address of all ARP packets and the target IP address of ARP reply packets are legal. The illegal packets will be discarded.

## Command Mode

Global Configuration Mode

## Privilege Requirement

Only Admin, Operator and Power User level users have access to these commands.

## Example

Enable the switch to check whether the source MAC address and the sender MAC address are the same when receiving an ARP packet

```
Switch(config)#ip arp inspection validate src-mac
```

# 75.3 ip arp inspection vlan

## Description

The `ip arp inspection vlan` command is used to enable the ARP Detection function on VLANs. To disable the ARP Detection function on VLANs, please use `no ip arp detection vlan` command.

## Syntax

```
ip arp inspection vlan vlan-list
```

```
no ip arp inspection vlan vlan-list
```

## Syntax

*vlan-list* — Enter the VLAN ID. The format is 1,5-9.

## Command Mode

Global Configuration Mode

## Privilege Requirement

Only Admin, Operator and Power User level users have access to these commands.

## Example

Enable the ARP Detection function on VLAN 2:

```
Switch(config)#ip arp inspection vlan 2
```

# 75.4 ip arp inspection vlan logging

## Description

The **ip arp inspection vlan logging** command is used to enable the Log function on the specific VLAN. To disable the Log function on the VLAN, please use **no ip arp detection vlan logging** command.

## Syntax

**ip arp inspection vlan** *vlan-list* **logging**

**no ip arp inspection vlan** *vlan-list* **logging**

## Syntax

*vlan-list* — Enter the VLAN ID. The format is 1,5-9.

**logging** — Enable the Log feature to make the switch generate a log when an ARP packet is discarded.

## Command Mode

Global Configuration Mode

## Privilege Requirement

Only Admin, Operator and Power User level users have access to these commands.

## Example

Enable the log feature on VLAN 2:

```
Switch(config)#ip arp inspection vlan 2 logging
```



## 75.5 ip arp inspection trust

### Description

The **ip arp inspection trust** command is used to configure the port for which the ARP Detect function is unnecessary as the Trusted Port. To clear the Trusted Port list, please use **no ip arp detection trust** command .The specific ports, such as up-linked port and routing port and LAG port, should be set as Trusted Port. To ensure the normal communication of the switch, please configure the ARP Trusted Port before enabling the ARP Detect function.

### Syntax

**ip arp inspection trust**

**no ip arp inspection trust**

### Command Mode

Interface Configuration Mode (interface gigabitEthernet / interface range gigabitEthernet)

### Privilege Requirement

Only Admin, Operator and Power User level users have access to these commands.

### Example

Configure the Gigabit Ethernet ports 1/0/2-5 as the Trusted Port:

```
Switch(config)#interface range gigabitEthernet 1/0/2-5
Switch(config-if-range)#ip arp inspection trust
```

## 75.6 ip arp inspection limit-rate

### Description

The **ip arp inspection limit-rate** command is used to configure the ARP speed of a specified port. To restore to the default speed, please use **no ip arp inspection limit-rate** command.

### Syntax

**ip arp inspection limit-rate** *value*

**no ip arp inspection limit-rate**

## Parameter

*value* —The value to specify the maximum amount of the received ARP packets per second, ranging from 1 to 300 in pps(packet/second). By default, the value is 100.

## Command Mode

Interface Configuration Mode (interface gigabitEthernet / interface range gigabitEthernet)

## Privilege Requirement

Only Admin, Operator and Power User level users have access to these commands.

## Example

Configure the maximum amount of the received ARP packets per second as 50 pps for Gigabit Ethernet port 5:

```
Switch(config)#interface gigabitEthernet 1/0/5
Switch(config-if)#ip arp inspection limit-rate 50
```

# 75.7 ip arp inspection burst-interval

## Description

The **ip arp inspection burst-interval** command is used to configure the burst interval of a specified port. To restore to the default speed, please use **no ip arp inspection burst-interval** command.

## Syntax

```
ip arp inspection burst-interval value
no ip arp inspection burst-interval
```

## Parameter

*value* — Specify a time range. If the speed of received ARP packets in this time range reaches the limit for this time range, the port will be shut down. The valid values are from 1 to 15 seconds, and the default value is 1 second.

## Command Mode

Interface Configuration Mode (interface gigabitEthernet / interface range gigabitEthernet)

## Privilege Requirement

Only Admin, Operator and Power User level users have access to these commands.

## Example

Configure the burst interval as 2 seconds for Gigabit Ethernet port 5:

```
Switch(config)#interface gigabitEthernet 1/0/5
Switch(config-if)#ip arp inspection burst-interval 2
```

# 75.8 ip arp inspection recover

## Description

The **ip arp inspection recover** command is used to restore a port to the ARP transmit status from the ARP filter status.

## Syntax

```
ip arp inspection recover
```

## Command Mode

Interface Configuration Mode (interface gigabitEthernet / interface range gigabitEthernet)

## Privilege Requirement

Only Admin, Operator and Power User level users have access to these commands.

## Example

Restore Gigabit Ethernet port 1/0/5 to the ARP transmit status:

```
Switch(config)#interface gigabitEthernet 1/0/5
Switch(config-if)#ip arp inspection recover
```

## 75.9 ip arp inspection exceed

### Description

The **ip arp inspection exceed** command is used to configure the overspeed action. To delete this action, please use **no ip arp inspection exceed** command.

### Syntax

```
ip arp inspection exceed [drop | shutdown] recover-time  
no ip arp inspection exceed
```

### Parameter

*drop*—— Drop messages when speeding.  
*shutdown*—— Shut ports down when speeding.  
*recover-time*—— Configure self-recovery time.

### Command Mode

Interface Configuration Mode (interface gigabitEthernet / interface range gigabitEthernet)

### Privilege Requirement

Only Admin, Operator and Power User level users have access to these commands.

### Example

Configure the overspeed action as dropping messages when speeding and self-recovery time as 2 seconds for Gigabit Ethernet port 5:

```
Switch(config)#interface gigabitEthernet 1/0/5  
Switch(config-if)#ip arp inspection exceed drop 2
```

## 75.10 show ip arp inspection

### Description

The **show ip arp inspection** command is used to display the ARP detection global configuration including the enable/disable status and the Trusted Port list.

## Syntax

```
show ip arp inspection
```

## Command Mode

Privileged EXEC Mode and Any Configuration Mode

## Privilege Requirement

None.

## Example

Display the ARP detection configuration globally:

```
Switch(config)#show ip arp inspection
```

# 75.11 show ip arp inspection interface

## Description

The **show ip arp inspection interface** command is used to display the interface configuration of ARP detection.

## Syntax

```
show ip arp inspection interface [ gigabitEthernet port ]
```

## Parameter

*port*—The Ethernet port number.

## Command Mode

Privileged EXEC Mode and Any Configuration Mode

## Privilege Requirement

None.

## Example

Display the configuration of Gigabit Ethernet port 1/0/1:

```
Switch(config)#show ip arp inspection interface gigabitEthernet 1/0/1
```

Display the configuration of all Ethernet ports:

```
Switch(config)#show ip arp inspection interface
```

## 75.12 show ip arp inspection vlan

### Description

The **show ip arp inspection vlan** command is used to display the VLAN configuration of ARP detection.

### Syntax

```
show ip arp inspection vlan
```

### Command Mode

Privileged EXEC Mode and Any Configuration Mode

### Privilege Requirement

None.

### Example

Display the ARP Inspection configuration of VLAN:

```
Switch(config)#show ip arp inspection vlan
```

## 75.13 show ip arp inspection statistics

### Description

The **show ip arp inspection statistics** command is used to display the number of the illegal ARP packets received.

### Syntax

```
show ip arp inspection statistics
```

### Command Mode

Privileged EXEC Mode and Any Configuration Mode

### Privilege Requirement

None.

### Example

Display the number of the illegal ARP packets received:

```
Switch(config)#show ip arp inspection statistics
```

## 75.14 clear ip arp inspection statistics

### Description

The **clear ip arp inspection statistics** command is used to clear the statistic of the illegal ARP packets received.

### Syntax

**clear ip arp inspection statistics**

### Command Mode

Privileged EXEC Mode and Any Configuration Mode

### Privilege Requirement

Only Admin, Operator and Power User level users have access to these commands.

### Example

Clear the statistic of the illegal ARP packets received:

```
Switch(config)#clear ip arp inspection statistics
```

# Chapter 76 ND Detection Commands

The ND Detection feature allows the switch to detect the ND packets based on the binding entries in the IPv6-MAC Binding Table and filter out the illegal ND packets. Before configuring ND Detection, complete IPv6-MAC Binding configuration. For details, refer to IPv6-MAC Binding Configurations.

## 76.1 ipv6 nd detection

### Description

The **ipv6 nd detection** command is used to enable the ND Detection function globally. To disable the ND Detection function, please use **no ipv6 nd detection** command.

### Syntax

```
ipv6 nd detection
no ipv6 nd detection
```

### Command Mode

Global Configuration Mode

### Example

Enable the ND Detection function globally:

```
Switch(config)#ipv6 nd detection
```

## 76.2 ipv6 nd detection vlan

### Description

The **ipv6 nd detection vlan** command is used to enable ND Detection function on a specified VLAN. To disable ND Detection function on this VLAN, please use **no ipv6 nd detection vlan** command.

### Syntax

```
ipv6 nd detection vlan vlan-range
no ipv6 nd detection vlan vlan-range
```



## Parameter

*vlan-range*——Enter the vlan range in the format of 1-3, 5.

## Command Mode

Global Configuration Mode

## Example

Enable the ND Detection function on VLAN 1,4,6-7:

```
Switch(config)#ipv6 nd detection vlan 1,4,6-7
```

# 76.3 ipv6 nd detection vlan logging

## Description

The **ipv6 nd detection vlan logging** command is used to enable Log function on a specified VLAN. To disable Log function on this VLAN, please use **no ipv6 nd detection vlan logging** command.

## Syntax

**ipv6 nd detection vlan** *vlan-range* **logging**

**no ipv6 nd detection vlan** *vlan-range* **logging**

## Parameter

*vlan-range*——Enter the vlan range in the format of 1-3, 5.

## Command Mode

Global Configuration Mode

## Example

Enable the Log function on VLAN 1,4,6-7:

```
Switch(config)#ipv6 nd detection vlan 1,4,6-7 logging
```

# 76.4 ipv6 nd detection trust

## Description

The **ipv6 nd detection trust** command is used to configure the port for which the ND Detection function is unnecessary as the Trusted Port. To clear the

Trusted Port list, please use **no ipv6 nd detection trust** command .The specific port, such as up-linked port, routing port and LAG port, should be set as Trusted Port. To ensure the normal communication of the switch, please configure the ND Detection Trusted Port before enabling the ND Detection function.

## Syntax

**ipv6 nd detection trust**

**no ipv6 nd detection trust**

## Command Mode

Interface Configuration Mode (interface gigabitEthernet / interface range gigabitEthernet/ interface port-channel / interface range port-channel)

## Example

Configure the Gigabit Ethernet ports 1/0/2-5 as the Trusted Port:

```
Switch(config)#interface range gigabitEthernet 1/0/2-5
```

```
Switch(config-if-range)#ipv6 nd detection trust
```

# 76.5 show ipv6 nd detection

## Description

The **show ipv6 nd detection** command is used to display the ND detection global configuration including the enable/disable status.

## Syntax

**show ipv6 nd detection**

## Command Mode

Privileged EXEC Mode and Any Configuration Mode

## Example

Display the ND Detection configuration globally:

```
Switch(config)#show ipv6 nd detection
```

## 76.6 show ipv6 nd detection interface

### Description

The **show ipv6 nd detection interface** command is used to display the interface configuration of ND Detection.

### Syntax

```
show ipv6 nd detection interface [ fastEthernet port | gigabitEthernet port | ten-gigabitEthernet port | port-channel port-channel-id ]
```

### Parameter

*port*—The Ethernet port number.

*port-channel-id*— The ID of the port channel.

### Command Mode

Privileged EXEC Mode and Any Configuration Mode

### Example

Display the configuration of Gigabit Ethernet port 1/0/1:

```
Switch(config)#show ipv6 nd detection interface gigabitEthernet 1/0/1
```

Display the configuration of all Ethernet ports:

```
Switch(config)#show ipv6 nd detection interface
```

## 76.7 show ipv6 nd detection statistics



**Note:** This command is only available on certain devices.

### Description

The **show ipv6 nd detection statistics** command is used to display the ND statistics of each VLAN, including the number of forwarded and dropped ND packets.

## Syntax

**show ipv6 nd detection statistics**

## Command Mode

Privileged EXEC Mode and Any Configuration Mode

## Example

Display the ipv6 ND Detection statistics of each VLAN.

```
Switch(config)#show ipv6 nd detection statistics
```

# 76.8 show ipv6 nd detection vlan

## Description

The **show ipv6 nd detection vlan** command is used to display the VLAN configuration of ND Detection.

## Syntax

**show ipv6 nd detection vlan**

## Command Mode

Privileged EXEC Mode and Any Configuration Mode

## Example

Display the ipv6 ND Detection configuration of VLAN.

```
Switch(config)#show ipv6 nd detection vlan
```

## Chapter 77 System Log Commands

The log information will record the settings and operation of the switch respectively for you to monitor operation status and diagnose malfunction.

### 77.1 logging buffer

#### Description

The **logging buffer** command is used to store the system log messages to an internal buffer. To disable the log buffer function, please use the **no logging buffer** command. Local Log is the system log information saved in the switch. It has two output channels, that is, it can be saved to two different positions, log buffer and log flash memory. The log buffer indicates the RAM for saving system log and the information in the log buffer can be got by [show logging buffer](#) command. It will be lost when the switch is restarted.

#### Syntax

**logging buffer**

**no logging buffer**

#### Command Mode

Global Configuration Mode

#### Privilege Requirement

Only Admin and Operator level users have access to these commands.

#### Example

Enable the system log buffer:

```
Switch(config)#logging buffer
```

### 77.2 logging buffer level

#### Description

The **logging buffer level** command is used to configure the severity level and the status of the configuration input to the log buffer. To return to the default configuration, please use **no logging buffer level** command.

## Syntax

**logging buffer level** *level*

**no logging buffer level**

## Parameter

*level*— Severity level of the log information output to each channel. There are 8 severity levels marked with values 0-7. The smaller value has the higher priority. Only the log with the same or smaller severity level value will be output. By default, it is 6 indicating that the log information with level 0-6 will be saved in the log buffer.

## Command Mode

Global Configuration Mode

## Privilege Requirement

Only Admin and Operator level users have access to these commands.

## Example

Set the severity level as 5:

```
Switch(config)#logging buffer level 5
```

# 77.3 logging file flash

## Description

The **logging file flash** command is used to store the log messages in a file in the flash on the switch. To disable the log file flash function, please use **no logging file flash** command. This function is disabled by default. The log file flash indicates the flash sector for saving system log. The information in the log file of the flash will not be lost after the switch is restarted and can be got by the [show logging flash](#) command.

## Syntax

**logging file flash**

**no logging file flash**

## Command Mode

Global Configuration Mode

## Privilege Requirement

Only Admin and Operator level users have access to these commands.

## Example

Enable the log file flash function:

```
Switch(config)#logging file flash
```

# 77.4 logging file flash frequency

## Description

The **logging file flash frequency** command is used to specify the frequency to synchronize the system log file in the log buffer to the flash. To resume the default synchronizing frequency, please use the **no logging file flash frequency** command.

## Syntax

```
logging file flash frequency { periodic periodic | immediate }
```

```
no logging file flash frequency
```

## Parameter

*periodic* — The frequency to synchronize the system log file in the log buffer to the flash, ranging from 1 to 48 hours. By default, the synchronization process takes place every 24 hours.

**immediate** — The system log file in the buffer will be synchronized to the flash immediately. This option will reduce the life of the flash and is not recommended.

## Command Mode

Global Configuration Mode

## Privilege Requirement

Only Admin and Operator level users have access to these commands.

## Example

Specify the log file synchronization frequency as 10 hours:

```
Switch(config)#logging file flash frequency periodic 10
```

## 77.5 logging file flash level

### Description

The **logging file flash level** command is used to specify the system log message severity level. Messages with a severity level equal to or higher than this value will be stored to the flash. To restore to the default level, please use **no logging file flash level** command.

### Syntax

**logging file flash level** *level*

**no logging file flash level**

### Parameter

*level* — Severity level of the log message. There are 8 severity levels marked with values 0–7. The smaller value has the higher priority. Only the log with the same or smaller severity level value will be saved to the flash. By default, it is 3 indicating that the log message marked with 0–3 will be saved in the log flash.

### Command Mode

Global Configuration Mode

### Privilege Requirement

Only Admin and Operator level users have access to these commands.

### Example

Save the log messages with their severities equal or higher than 7 to the flash :

```
Switch(config)#logging file flash level 7
```

## 77.6 logging host index

### Description

The **logging host index** command is used to configure the Log Host. To clear the configuration of the specified Log Host, please use **no logging host index** command. Log Host is to receive the system log from other devices. You can remotely monitor the settings and operation status of other devices through the log host.



## Syntax

**logging host index** *idx host-ip level*

**no logging host index** *idx*

## Parameter

*idx*—— The index of the log host. The switch supports 4 log hosts at most.

*host-ip*—— The IP for the log host.

*level*—— The severity level of the log information sent to each log host. There are 8 severity levels marked with values 0-7. The smaller value has the higher priority. Only the log with the same or smaller severity level value will be sent to the corresponding log host. By default, it is 6 indicating that the log information marked with 0-6 will be sent to the log host.

## Command Mode

Global Configuration Mode

## Privilege Requirement

Only Admin and Operator level users have access to these commands.

## Example

Enable log host 2 and set its IP address as 192.168.0.148, the level 5:

```
Switch(config)# logging host index 2 192.168.0.148 5
```

# 77.7 logging console

## Description

The **logging console** command is used to send the system logs to the console port. To disable logging to the console, please use **no logging console** command. This function is enabled by default.

## Syntax

**logging console**

**no logging console**

## Command Mode

Global Configuration Mode

## Privilege Requirement

Only Admin and Operator level users have access to these commands.

## Example

Enable logging to the console port:

```
Switch(config)# logging console
```

# 77.8 logging console level

## Description

The **logging console level** command is used to limit messages logged to the console port. System logs no higher than the set threshold level will be displayed on the console port. To restore the threshold level to default value, please use **no logging console level** command.

## Syntax

**logging console level** *level*

**no logging console level**

## Parameter

*level* — Severity level of the log information output to the console port. There are 8 severity levels marked with values 0–7. The smaller value has the higher priority. Only the log with the same or smaller severity level value will be output to the terminal devices. By default, it is 5 indicating that all the log information between level 0–5 will be output to the terminal devices.

## Command Mode

Global Configuration Mode

## Privilege Requirement

Only Admin and Operator level users have access to these commands.

## Example

Output the log information with severity levels between 0–7 to the console port:

```
Switch(config)# logging console level 7
```

## 77.9 logging monitor

### Description

The **logging monitor** command is used to display the system logs on the terminal devices. To disable logging to the terminal, please use **no logging monitor** command. This function is enabled by default.

### Syntax

**logging monitor**  
**no logging monitor**

### Command Mode

Global Configuration Mode

### Privilege Requirement

Only Admin and Operator level users have access to these commands.

### Example

Disable logging to the terminal devices:

```
Switch(config)# no logging monitor
```

## 77.10 logging monitor level

### Description

The **logging monitor level** command is used to limit messages logged to the terminal devices. System logs no higher than the set threshold level will be displayed on the terminal devices. To restore the threshold level to default value, please use **no logging monitor level** command.

### Syntax

**logging monitor level** *level*  
**no logging monitor level**

### Parameter

*level*— Severity level of the log information output to the terminal devices. There are 8 severity levels marked with values 0–7. The smaller value has the higher priority. Only the log with the same or smaller severity level value will

be output to the terminal devices. By default, it is 5 indicating that all the log information between level 0–5 will be output to the terminal devices.

### Command Mode

Global Configuration Mode

### Privilege Requirement

Only Admin and Operator level users have access to these commands.

### Example

Output the log information with severity levels between 0–7 to the terminal devices:

```
Switch(config)# logging monitor level 7
```

## 77.11 clear logging

### Description

The **clear logging** command is used to clear the information in the log buffer and log file.

### Syntax

```
clear logging [ buffer | flash ]
```

### Parameter

buffer | flash —The output channels: buffer and flash. Clear the information of the two channels, by default.

### Command Mode

Global Configuration Mode

### Privilege Requirement

Only Admin and Operator level users have access to these commands.

### Example

Clear the information in the log file:

```
Switch(config)# clear logging buffer
```

## 77.12 show logging local-config

### Description

The **show logging local-config** command is used to display the configuration of the Local Log output to the console, the terminal, the log buffer and the log file.

### Syntax

```
show logging local-config
```

### Command Mode

Privileged EXEC Mode and Any Configuration Mode

### Privilege Requirement

None.

### Example

Display the configuration of the Local Log:

```
Switch(config)# show logging local-config
```

## 77.13 show logging loghost

### Description

The **show logging loghost** command is used to display the configuration of the log host.

### Syntax

```
show logging loghost [ index ]
```

### Parameter

*index* —The index of the log host whose configuration will be displayed, ranging from 1 to 4. Display the configuration of all the log hosts by default.

### Command Mode

Privileged EXEC Mode and Any Configuration Mode

### Privilege Requirement

None.

## Example

Display the configuration of the log host 2:

```
Switch(config)# show logging loghost 2
```

## 77.14 show logging buffer

### Description

The **show logging buffer** command is used to display the log information in the log buffer according to the severity level.

### Syntax

```
show logging buffer [ level level]
```

### Parameter

*level* — Severity level. There are 8 severity levels marked with values 0–7. The information of levels with priority not lower than the select level will display. Display all the log information in the log buffer by default.

### Command Mode

Privileged EXEC Mode and Any Configuration Mode

### Privilege Requirement

None.

### Example

Display the log information from level 0 to level 5 in the log buffer:

```
Switch(config)# show logging buffer level 5
```

## 77.15 show logging flash

### Description

The **show logging flash** command is used to display the log information in the log file according to the severity level.

### Syntax

```
show logging flash [ level level]
```

## Parameter

*level* — Severity level. There are 8 severity levels marked with values 0–7. The information of levels with priority not lower than the select level will display. Display all the log information in the log file by default.

## Command Mode

Privileged EXEC Mode and Any Configuration Mode

## Privilege Requirement

None.

## Example

Display the log information with the level marked 0-3 in the log file:

```
Switch(config)# show logging flash level 3
```