


Ex9IP



Isolator
 Hlavní vypínač
 Vypínač
 Rozłącznik izolacyjny
 Interrupitor
 Hauptlastschalter
 Interrupteur
 Выключатель нагрузки
 Закljučваем в позиции OFF
 Шалтер(товаров прекљсвач)
 Rastavljač

NOARK

1

Ex9IP

Mounting instructions
 Montážní návod
 Montážne inštrukcie
 Instrukcja montażu
 Istruzioni di assemblare
 Montageanleitung
 Instructions de montage
 Инструкция по монтажу
 Monteringsanvisning
 Istruzioni di montaggio
 Instrucciones de montaje
 Összeszerelési útmutató

Asennusohjeita
 Montage-instructies
 Instruções de montagem
 Navodila za montažo
 Οδηγίες Εγκατάστασης
 Инструкции за инсталиране
 Monteringsvejledningen
 Montažu upute
 Surinkimo instrukcijos
 Instalēšanas instrukcijas
 Скупштина упутство
 Paigaldusjuhendid


2

Ex9IP

Caution: Installation by electricians only
 Varování: Montáž pouze osobou s elektrotech. kvalifikací
 Varovanie: Montáž iba osobou s elektrotech. kvalifikáciou
 Uwaga: Montaż tylko przez uprawnionych instalatorów
 Atenție: Instalare numai de către electricieni
 Vorsicht: Montagenur durch Elektrofachkräfte
 Attention: Montage uniquement par un électricien
 Осторожно: Монтаж только электрика


3

Ex9IP




4

Ex9IP



5


Ex9IP








6

Ex9IP


	1-35mm ²
	2-3.5Nm



7



Green
Zelená
Zielony
Verde
Grün
Vert
Зеленый



Red
Červená
Czerwony
Roşu
Rot
Rouge
Красный

NOARK



Printed with environment-friendly paper

Copyright Noark. All Rights Reserved

www.noark-electric.eu